

Installation Instructions

Procon

MS-FRT-TCB

CM-FRT-TCB

MS-FRT-TCB-TEMP

Product Overview

The MS-FRT-TCB / MS-FRT-TCB-TEMP and CM-FRT-TCB units supersede the FRT02 and 03 products for use with 'A' Control and City-Multi equipment respectively.

Common features of the units are as follows:

- Relay indication of unit running (c/o contacts)
- Relay indication of unit in fault (c/o contacts)
- Pulsed On/Off operation.
- Remote On/Off operation using 3-wire loom. (CN32)
- Semi-Remote On/Off using 3-wire loom (as TCB1)

Additional features on the MS-FRT-TCB-TEMP :

- External Operational Settings for PLC control
 - Setpoint (0-10v DC = 19°C to 28°C)
 - Mode, Fan Vane, Louver (By Switches)

The units have terminals equivalent to the **TB1**, **TB2** etc terminals of the FRT02 / FRT03 units – see Appendix A.

Interconnections:

Two wiring looms are provided with the equipment. Loom C is always supplied. Loom A or Loom B is supplied depending on the unit type

MS-FRT-TCB , MS-FRT-TCB-TEMP

- A) A seven wire loom with seven bare ends at one end and two connectors (9-pin and 4-Pin) at the other.

CM-FRT-TCB

- B) A five wire loom with five bare ends at one end and a 5-Pin connector at the other.

All Units

- C) A three wire loom with three bare ends at one end and a 3-Pin connector at the other.

Wiring connections must be made before the unit is mounted.

Disconnect all supplies to the air conditioner unit before installation.




Fig 1 : Terminal Numbers

MS-FRT-TCB , MS-FRT-TCB-TEMP

Connect the bare ends of loom A to the following pins on the MS-FRT-TCB :

MS-FRT-TCB Pin	(Air-con connector)
1	CN90-5
2	CN90-4
3	CN90-6
4	CN90-3
5	CN90-9
6	CN41-1
7	CN41-2

CM-FRT-TCB

Connect the bare ends of loom B to the following pins on the CM-FRT-TCB :

CM-FRT-TCB Pin	(Air-con connector)
3	CN51-5
4	CN51-4
5	CN51-3
6	CN51-1
7	CN51-2

1) Run /Fault Monitoring

Terminals 11,12 & 13 provide indication of the Running status.
(13 = common, 11 = n/o, 12 = n/c)

Terminals 14,15 & 16 provide indication of the Fault status.
(16 = common, 14 = n/o, 15 = n/c)

Maximum switching capacity for terminals 11 to 16 is 40 V d.c. at 50mA.

2) Remote On/Off

Terminals 17 & 18 are a volt free input which mimics the operation of the on/off push button on the wall controller. Successive contact closures will toggle the unit on and off.

Using the 3-wire loom (CN32)

Connecting the 3-wire loom (SAP 141637) between CN32 and terminals 10(orange), 9(red) and 8(brown) will activate remote On/Off. With no connections to terminals 19 to 24 the unit will then be forced to the OFF state.

Two ON modes are possible as follows:

a) By joining terminals 19 & 20 and joining terminals 21 & 22 the unit will be forced to the ON state.

b) By connecting 12v DC to terminals 23(+ve) & 24(-ve) the unit will turn ON but the remote will be released after approx 3 seconds allowing further on/off control via the wall controller.

In this mode, as an alternative to the wall controller the pulsed On/Off feature of CN41 may be used by pulsing a connection across Terminals 17 & 18.

3) Periodic Setpoint Adjustment (MS-FRT-TCB-TEMP only)

The setpoint of the 'A' control unit may be set using a DC voltage (eg. from a PLC).

To enable this feature it is necessary to apply a DC voltage of 8 -24v to terminals 26(-ve) and 27(+ve). The MS-FRT-TCB-TEMP will recognise this voltage and illuminate LED4.

The required setpoint is now set by applying a DC voltage to terminals 26(-ve) and 25(+ve). The voltage / setpoint relationship is as follows:

Voltage	Setpoint	
<0.75	19	Between the ranges either value may be sent e.g. 2.0 volts may give 20 or 21 degrees
1.25-1.75	20	
2.25-2.75	21	The general recommendation would be to use 0.5, 1.5, 2.5... etc...7.5, 8.5, 9.5 volts
-- through --		
8.25-8.75	27	
9.25-10	28	

Together with the setpoint the MS-FRT-TCB-TEMP also sends other parameters (mode, fan speed etc). These parameters may be set on bit switches which are accessible through a gap adjacent to terminal 1. The functions of these switches are shown in appendix B

When enabled, the parameter message is sent every 5 minutes or on setpoint change but only when the unit is ON and not in fault. LED3 will perform a brief double 'blip' to indicate that the message has been received.

Calibration

The calibration of the external setpoint is set at the factory. If it is necessary to re-calibrate the unit follow the details in appendix C

LED indications on the unit – LED1 is the top LED, LED4 the bottom one.

LED1 : illuminated when the unit is running (or in fault)

LED2 : illuminated when the unit is in fault

LED3 : (MS-FRT-TCB, MS-FRT-TCB-TEMP only)
indication of the fault signal line.

LED4 : (MS-FRT-TCB-TEMP only)
provides an indication that setpoint transmission is enabled.
(this LED is also used in the setpoint calibration sequence)

Appendix A FRT0x terminal equivalences

TB1	Terminals 11,12,13
TB2	Terminals 14,15,16
TB3	Terminals 17,18
TB4	Terminals 19,20
TB5	Terminals 21,22

Appendix B Bit Switch Settings (MS-FRT-TCB-TEMP only)

Switches are accessible through the lower side of the unit.
SW1 is towards the front.

Mode	Fan	Cool	Heat	Auto	
SW1	OFF	ON	OFF	ON	
SW2	OFF	OFF	ON	ON	
Fan Speed	Low	Mid 2	Mid 1	High	
SW3	OFF	ON	OFF	ON	
SW4	OFF	OFF	ON	ON	
Vane	100%	80%	60%	Horiz	Swing
SW5	OFF	ON	OFF	ON	OFF
SW6	OFF	OFF	ON	ON	OFF
SW7	OFF	OFF	OFF	OFF	ON

Appendix C Calibration (MS-FRT-TCB-TEMP only)

To calibrate the external setpoint – if required.

Remove CN90 and fit the link adjacent to the LEDs (under front cover).

Apply an external setpoint voltage of 5.0V

Replace CN90

LED4 will flash 3 times and should then become steady.

Unit is calibrated – remove CN90 and the link – replace CN90.

If the unit continues to flash then calibration has not been achieved. Check the setpoint voltage to ensure that it is 5.0V.

