
Run / Standby Panel

PANEL_RS1

FOR INSTALLERS

INSTALLATION MANUAL

Version 1.03


For safe and correct use, please read this installation manual thoroughly before installing the PANEL_RS1.

mitsubishi
MITSUBISHI ELECTRIC


1

[Fig. 1]

A



B




- A 2 x PAC-SA89TA
- B 2 x PAC-SF40RM

2

[Fig. 2]


- A Input / output terminal
- B Time clock
- C Relays
- D Control fuses
- E Transformer
- F 240VAC terminal



3


[Fig. 3]

- A Thermostat
- B Lamp status
- C Remote controllers
- D Door lock
- E Air conditioning On/Off switch
- F Buzzer switch




4

[Fig. 4]



[Fig. 5]



Contents

1. Safety precautions	8
2. Overview	9
3. Panel size and weight	10
4. Selecting an installation site	11
5. Installation	12
5.1. System diagram 1 – Connected to Mr Slim units	12
5.2. System diagram 2 – Connected to City Multi PFD units	13
6. Electrical wiring	14
6.1. Precautions on electrical wiring	14
6.2. Types of control cables	14
6.3. Connecting wiring	14
6.3.1. Power supply wiring	14
6.3.2. Connecting PAC-SA89TA	14
6.3.3. Connecting PAC-SF40RM (for Mr Slim)	14
6.3.4. Connecting optional PAR-21MAA	14
7. Applicable Air Conditioning models	15
8. Important notes	16
9. Additional information	17
9.1. AKO-14123 thermostat	17
9.1.1. Overview	17
9.1.2. Set temperature	17
9.1.3. Technical Details	17
9.2. Inlec transformer	18
9.2.1. Overview	18
9.3. SCL SMT-10 Multifunction time relay	19
9.4. Mitsubishi Electric PAR-21MAA remote controller	21
9.4.1. Overview	21
9.4.2. Lock the buttons	22
9.4.3. Error codes	23

1. Safety precautions

- | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none">➤ Before installing the unit, make sure you read all the "Safety precautions"➤ The "Safety precautions" provide very important points regarding safety. Make sure you follow them |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Symbols used in the text

Warning:

Describes precautions that should be observed to prevent danger of injury or death to the user.

Caution:

Describes precautions that should be observed to prevent damage to the unit.

- | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p> Warning:
Carefully read the labels affixed to the main unit</p> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|

Warning:

- **Ask the dealer or an authorised technician to install the unit**
 - Improper installation by the user may result in water leakage, electric shock, or fire
- **Use the specified cables for wiring. Make the connections securely so that any outside forces acting on the cables are not applied to the terminals**
 - Inadequate connection and fastening may generate heat and cause a fire
- **Never repair the unit. If the controller must be repaired, consult the dealer**
 - If the unit is repaired improperly, electric shock, or fire may result
- **When handling this product, always wear protective equipment. EG: Gloves, full arm protection and safety glasses**
 - Improper handling may result in injury
- **Have all electric work done by a licensed electrician according to "Electric Facility Engineering Standard", "Interior Wire Regulations" and the instructions given in this manual and always use a special circuit**
 - If the power source capacity is inadequate or electric work is performed improperly, electric shock and fire may result
- **Keep the electric parts away from any water - washing water etc...**
 - Contact may result in electric shock, fire or smoke
- **Do not reconstruct or change the settings of the protection devices**
 - If the protection device is shorted or operated forcibly, or parts other than those specified by Mitsubishi Electric are used, fire or explosion may result
- **To dispose of this product, consult your dealer**

Caution:

- **Ground the unit**
 - Do not connect the ground wire to gas or water pipes, lightning rods, or telephone ground lines. Improper grounding may result in electric shock
- **Install the power cable so that tension is not applied to the cable**
 - Tension may cause the cable to break and generate heat which may, in turn, cause fire
- **Install a leak circuit breaker, as required**
 - If a leak circuit breaker is not installed, electric shock may result
- **Use power line cables of sufficient current carrying capacity and rating**
 - Cables that are too small may leak, generate heat, and cause a fire
- **Use only a circuit breaker and fuse of the specified capacity**
 - A fuse or circuit breaker of a larger capacity or a steel or copper wire may result in a general unit failure or fire
- **Be careful that the installation base is not damaged**
 - If the damage is left uncorrected, the unit may fall and cause personal injury or property damage
- **Be very careful regarding product transportation**
 - Two people should be used to carry products of 20kg or more
 - Some products use PP bands for packaging. Do not use any PP bands for a means of transportation
- **Safely dispose of the packing materials**
 - Packing materials, such as nails and other metal or wooden parts, may cause stabs or other injuries
 - Tear apart and throw away plastic packaging bags so that children will not play with them - If children play with a plastic bag which has not been torn apart, they face the risk of suffocation

2. Overview

The run/standby panel is used to automatically change over two Air Conditioning indoor units.

The panel will be fed with a 240VAC power supply.

The panel is fitted with a selectable day time switch with battery back-up and latching relay to permit one indoor unit to run for instance 7 days, after this the panel will automatically change over to the next indoor unit for 7 days etc.

The panel is designed that if one indoor unit goes to fault while running it would automatically bring in the backup indoor unit.

The high temperature thermostat option will allow the two indoor units to run together if a high temperature exists. A high temperature warning lamp will indicate.

The sounder & mute option will allow any fault condition received by the control panel (i.e. unit fault, or high temperature) to initiate a sounder on the panel door. A mute button is fitted to silence the sounder.

Volt free terminals are fitted to allow fault signals to be transmitted to any external monitoring system.

The panel is supplied with accessories to interface with the Air Conditioning indoor unit:

- 3 wire adaptor to control the On/Off
- PAC-SF40RM to monitor Run and Faults with Mr Slim indoor units

Figure 1 shows the accessories supplied with the panel.

Figure 2 shows the inside of the panel.

Figure 3 shows the front panel.

Figure 4 shows the wiring diagram of the panel.

3. Panel size and weight

The panel details are:

- Height 600mm
- Width 400mm
- Depth 210mm
- Weight 21Kg


4. Selecting an installation site

- Avoid locations in direct sunlight
- Avoid locations exposed to steam or oil vapour
- Avoid locations where combustible gas may leak, settle or be generated
- Avoid installation near machines emitting high-frequency waves
- Avoid places where acidic solutions are frequently handled
- Avoid places where sulphur-based or other sprays are frequently used
- Avoid areas of high humidity (when cooling operation is required)
- Install inside the building
- Install near the indoor units monitored and controlled

5. Installation


5.1. System diagram 1 – Connected to Mr Slim units

Two Mr Slim indoor units can be connected to the PANEL_RS1 via two PAC-SF40RM and two PAC-SA89TA.



5.2. System diagram 2 – Connected to City Multi PFD units

Two City Multi PFD indoor units can be connected to the PANEL_RS1 via two PAC-SA89TA. The PAC-SF40RM interfaces are not required.



Please note that DIP SWITCH SW1-9 and SW1-10 must be switched **OFF** to activate level input with CN32 instead of pulse input.

6. Electrical wiring

6.1. Precautions on electrical wiring

⚠ Warning:

Electrical work should be done by qualified electrical engineers / electrician in accordance with "Engineering Standards for Electrical Installation" and supplied installation manuals. Dedicated circuits should also be used. If the power circuit lacks capacity or has an installation failure, it may cause a risk of electric shock or fire.

- Be sure to take power from the special branch circuit
- Be sure to install an earth leakage breaker to the power
- Install the unit to prevent any of the control circuit cables (MNET transmission cables) coming into direct contact with the power cable outside the unit
- Ensure that there is no slack on all wire connections
- Never connect the power cable to leads for the transmission cables. This will damage the transmission cable
- Select control cables from the conditions given in "Type of control cables" section

6.2. Types of control cables

Wiring transmission cables

- Cable diameter: More than 1.25 mm² screened cable

6.3. Connecting wiring

6.3.1. Power supply wiring

Power supply cords of appliances shall not be lighter than design 245 IEC 57 or 227 IEC 57.

⚠ Caution:

Do not use anything other than the correct capacity breaker and fuse. Using fuse, wire or copper wire with too large capacity may cause a risk of malfunction or fire.

6.3.2. Connecting PAC-SA89TA

Connect the PAC-SA89TA to the CN32 terminal on the indoor unit. The other end of the wire must be connected to the panel (18, 19 and 20 for system 1 and 26, 27 and 28 for system 2).

6.3.3. Connecting PAC-SF40RM (for Mr Slim)

Connect the PAC-SF40RM to the CN90 and CN41 terminals on the Mr Slim indoor unit. The TB1 and TB2 terminals must be connected to the panel (15, 16 and 17 for system 1 and 23, 24 and 25 for system 2).

6.3.4. Connecting optional PAR-21MAA

Connect the optional PAR-21MAA to the MA remote controller terminal on the indoor unit. The other end of the wire must be connected to the panel (21 and 22 for system 1 and 29 and 30 for system 2). A CN22 connector is required for each wall mounted indoor unit.

7. Applicable Air Conditioning models

Below is a list of Air Conditioning models that can be connected to this panel:

- Mr Slim product range
- PFD City Multi VRF product range

Please note that:

- **A CN22 connector is required for each wall mounted indoor unit**
- The PAC-SF40RM is not required for the PFD units

8. Important notes

Please note that:

- **If the internal fuse fails on the panel all systems stop**
- **If the internal fuse fails on the panel the volt free contacts for remote alarm does not operate**
- **If the panel is switched off all indoor units stop**
- **If the panel is switched off the volt free contacts for remote alarm does not operate**
- **When the panel is first energised all indoor units start together**
- **If the power of the indoor unit is switched off, the panel will not automatically change over**

9. Additional information

9.1. AKO-14123 thermostat


9.1.1. Overview



9.1.2. Set temperature

The factory SET POINT default value is 0 °C.

- Press **2** key for at least 5 seconds to DISPLAY SET POINT. It displays the CURRENT SET POINT value and LED "2" start flashing.
 - Press **0** or **3** keys for CHANGE SET POINT to the required value.
 - Press **0** + **3** keys simultaneously to ACCEPT THE NEW SET POINT. The display returns to the CURRENT TEMPERATURE display status and the LED "2" stop flashing.
- When **PA** appears in display, PASSWORD programmed in L5 parameter should be enter for accede to the CURRENT SET POINT.
- Press **0** + **3** keys simultaneously. **0** will be displayed to ENTER PASSWORD.
 - Press **0** or **3** keys to CHANGE NUMBER and DISPLAY PASSWORD.
 - Press **0** + **3** keys simultaneously to ACCEPT PASSWORD. The CURRENT SET POINT value will be displayed and possible to be modified.



9.1.3. Technical Details

Temperature range: (-59°F to 99°F) -50 °C to 99 °C
 Resolution, Set Point and differential: 1 °C
 Input for NTC probe: AKO-149XX
 Thermometric accuracy: ± 1 °C
 Probe tolerance at 25 °C: ± 0,4 °C
 Maximum input power: 3 VA
 Working ambient temperature: 5 °C to 50 °C
 Storage ambient temperature: -30 °C to 70 °C
 Control device classification: Independent mounting, with characteristic of automatic operation action Type 1.B, to be used in clean situation, logical medium (software) class A.
 Double insulation between the power supply, the secondary circuit and the relay output.

9.2. Inlec transformer


9.2.1. Overview

control panel transformers

- Conforms to EN60742, IEC742, IEC61558
- Double wound with earth screen between windings
- Frequency range 50/60 Hz
- Terminal block connection
- Good access to fixing flanges
- Continuous duty
- Full varnish impregnation for silent running



voltages		VA rating part no.	A	B	C	D	E	% reg	inrush VA for 10% drop	weight kg	
Primary	0 - 220 - 230 - 240	U CL50	76	70	86	53	47	9	105	1.1	
	0 - 380 - 400 - 415	N CL75	76	76	86	53	53	8.8	160	1.5	
Secondary	0 - 12	J CL100	84	78	95	60	68	6.7	250	2.2	
	0 - 24	B CL150	96	76	102	68	63	6.7	375	3.2	
	0 - 48	E CL200	96	86	102	68	73	5.8	550	4.0	
	0 - 110	F CL250	96	101	102	68	88	5.3	720	5.0	
	0 - 230	U CL300	120	88	122	80	71	5.3	870	6.0	
			CL500	120	120	122	80	103	4.1	1700	7.5
			CL750	150	135	140	105	70	5.2	2200	10.0
			CL1000	150	161	140	105	96	3.3	4000	13.0
			CL1500	150	188	140	105	123	3.2	6200	16.0
			CL2000	175	150	165	153	125	3.3	8060	18.0
		CL2500	175	178	165	153	158	2.6	12100	20.0	



9.3. SCL SMT-10 Multifunction time relay



- ▶ STM-10, STM-10-230, STM-103, STM-103-230: Universal supply voltage AC/DC 12 - 240 V or AC 230 V
- ▶ STM-10T: Universal supply voltage AC 12 - 240 V
- ▶ 10 functions:
 - 5 time functions controlled by supply voltage
 - 4 time functions controlled by control input
 - 1 function of memory (latching) relay
- ▶ Time scale 0.1 s - 10 days divided into 10 ranges
- ▶ Output contact:
 - STM-10, STM-10-230: 1x changeover 16 A
 - STM-103, STM-103-230: 3x changeover 8 A
 - STM-10T: 1x static output 0.7 A (60A/>10ms) switches potential A1
- ▶ Output indication: multifunction red LED, flashing at certain states
- ▶ 1-MODULE, DIN rail mounting

Technical parameters


	STM-10, STM-10-230	STM-103, STM-103-230	STM-10T
Number of functions:	10		
Supply terminals:	A1 - A2		
Supply voltage:	AC/DC 12 - 240 V (AC 50 - 60 Hz)	AC/DC 12 - 240 V (AC 50 - 60 Hz)	AC 12 - 240 V (50 - 60 Hz)
Consumption:	AC 0.7 - 3 VA / DC 0.5 - 1.7 W	AC 0.7 - 3 VA / DC 0.5 - 1.7 W	AC max. 0.35 VA
Supply voltage:	AC 230 V / 50 - 60 Hz	AC 230 V / 50 - 60 Hz	×
Consumption:	AC max. 12 VA / 1.3 W	AC max. 12 VA / 1.9 W	×
Supply voltage tolerance:	-15 %; +10 %		
Supply indication:	green LED		
Time ranges:	0.1 s - 10 days		
Time setting:	rotary switch		
Time deviation:	5 % - mechanical setting		
Repeat accuracy:	0.2 % - set value stability		
Temperature coefficient:	0.01 % / °C, at = 20 °C		
Output			
Changeover contacts:	1, (AgNi)	3, (AgNi)	1 static output (triac)
Rated current:	16 A / AC1	8 A / AC1	0.7 A
Breaking capacity:	4000 VA / AC1, 384 W / DC	2000 VA / AC1, 192 W / DC	×
Inrush current:	30 A / <3 s	10 A / <3 s	60 A / <10 ms
Switching voltage:	250 V AC1 / 24 V DC	250 V AC1 / 24 V DC	×
Min. breaking capacity DC:	500 mW	500 mW	×
Voltage drop on switch:	×	×	max. 0.9 V at I max.
Load on B1 terminal:	×	×	Yes / I max. 0.7 A
Output indication:	multifunction red LED		
Mechanical life:	3x10 ⁷	3x10 ⁷	>10 ⁸
Electrical life (AC1):	0.7x10 ⁵	0.7x10 ⁵	>10 ⁸
Controlling			
Power on control input:	AC 0.025 - 0.2 VA / DC 0.1 - 0.7 W (UNI), AC 0.53 VA (AC 230 V), AC 0.025 - 0.2 VA (AC 12 - 240 V)		
Load between S-A2:	YES (UNI, AC 230 V, AC 12 - 240 V)		
Glow-tubes:	NO (UNI), YES (AC 230 V), NO (AC 12 - 240 V)		
Control terminals:	A1-S		
Impulse length:	min. 25 ms / max. unlimited		
Reset time:	max. 150 ms	max. 150 ms	max. 250 ms
Other information			
Operating temperature:	-20 .. +55 °C		
Storage temperature:	-30 .. +70 °C		
Electrical strength:	4 kV (supply - output)	4 kV (supply - output)	×
Operating position:	any		
Mounting/DIN rail:	DIN rail EN 60715		
Protection degree:	IP 40		
Overvoltage category:	III.		
Pollution degree:	2		
Max. cable size:	max. 2.5 mm ² / with cavern 1.5 mm ²		
Dimensions:	90 x 17.6 x 64 mm, see page 41-43		
Weight:	UNI - 69 g, 230 - 59 g	UNI - 89 g, 230 - 88 g	52 g
Standards:	EN 61812-1, EN 61010-1		

Functions


Delay ON,
after energisation




On pulse,
after energisation




Cyclic, pause first after
energisation




Cyclic, pulse first after
energisation



Delay off (Trailing edge,
signal start)




On pulse, (Leading edge,
signal start)



Off pulse (Trailing edge,
signal start delay on and off)




Delay on and off
(signal start)



Latching on/off relay
(Signal start)




Delay on fixed pulse




Connection


STM-10
STM-10-230



STM-103
STM-103-230




STM-10T




Load with control input possible.
Load between S-A2 possible to connect in parallel way,
without disturbing of proper operation of the relay.

Time ranges




Description




9.4. Mitsubishi Electric PAR-21MAA remote controller

9.4.1. Overview

1. Display Section



2. Operation Section



9.4.2. Lock the buttons


The following settings can be made.

- ① no1 : All buttons except for the [ON/OFF] button are locked.
- ② no2 : All buttons are locked.
- ③ OFF (default): No buttons are locked.

* To activate this operation lock function on the normal screen, hold down the **ON/OFF** button for two seconds while holding down the **FILTER** button.

How to Lock the Buttons

■ Display example




(1) While pressing the **MODE** button, press the **ON/OFF** button for two seconds to activate the remote controller's function selection mode.

(2) Press the **MODE** button to select **FUNCTION SELECTION** on the screen (at **A**).




(3) Press the **MENU** button until "LOCKING FUNCTION" appears on the screen (at **A**).



* Displays the mode that is set in "Temperature Range Limit Setting".

(4) Press the **ON/OFF** button until the desired lock mode appears on the screen (at **D**).



(5) While pressing the **MODE** button, press the **ON/OFF** button for two seconds to return to normal mode. Setting is now complete.

Completing steps (1) to (5) allows use of the operation lock function.
To enable the lock function, carry out the following steps.

Enabling the Lock Function

(6) While pressing the **FILTER** (↵) button, press the **① ON/OFF** button for two seconds to enable the operation lock function. **FUNCTION** appears on the screen (at **E**).

* If a locked button is pressed while the operation lock function is in use, **FUNCTION** will flash on the screen (at **E**).

■ Display example when operation lock function is in use



How to Unlock the Buttons

(7) While pressing the **FILTER** (↵) button, press the **① ON/OFF** button for two seconds. **FUNCTION** disappears from the screen (at **E**).

■ Display example when the operation lock function is not in use



9.4.3. Error codes

Control Error Codes (E)

Displayed on remote controller	Outdoor control board		Error details	Non INV	Power INV	Location of error	Location of inspection	
	LED1 "Green"	LED2 "Red"						
E0	Flashes 2 times	Flashes 3 times	Remote controller transmission error	●	●	Remote controller	① If two remote controllers are used, check whether they are set as the main and sub controllers. ② Check if the specified 2-core cable is used.	
E3			Remote controller transmission error	●	●			
E4			Remote controller transmission error	●	●			
E5		Flashes 2 times	Flashes 2 times	Remote controller transmission error	●	●	Indoor	Check if the cables connecting the indoor and outdoor units are connected firmly and correctly. ② Check if 3-core VVF-type power cable is used. (In the case of superimposed power supply system)
E6				Indoor/outdoor unit transmission error	●	●		
E7				Indoor/outdoor unit transmission error	●	●		
E8				Indoor/outdoor unit transmission error	●	●		
E9				Indoor/outdoor unit transmission error	●	●		
Ea				Mis-wiring of indoor/outdoor units	●	●		
Eb		Flash 1 time	Flash 1 time	Mis-wiring of indoor/outdoor units (Incorrect connection, disconnection)	●	●	Outdoor	③ Check if indoor/outdoor unit connecting cables are exposed to rain. ④ Check if indoor/outdoor unit connecting cables are extended using extension cable. ⑤ Check if fuse on outdoor control board is blown. ⑥ Check if connectors are connected firmly.
Ec				"Startup" time over	●	●		
Ee				Combination error	●	●		
Ef		Flashes 4 times	Flashes 4 times	Undefined error (No corresponding M-NET error code)	●	●	Indoor Outdoor	① Check M-NET remote controller and central control system for abnormality. ① Check for disconnected connectors between indoor control board and M-NET board.
Ed				Transmission error between M-NET adapters	●	●		
E1		—	—	Remote controller control board error	●	●	Remote controller	① Replace the remote controller
E2	—	—						

A-Control Error Codes (F/P)

Displayed on remote controller	Outdoor control board		Error details	Non INV	Power INV	Location of error	Location of inspection	
	LED1 "Green"	LED2 "Red"						
F1	Flash 1 time	Flash 1 time	Reverse phase detected / power and indoor-outdoor incorrect connection	—	—	Outdoor	① Power cable and indoor-outdoor cable are misconnected. ② Reverse phase → Replace R-phase with T-phase (outdoor power terminals). ③ Check if all three phases show the same power voltage.	
F2			Detection of loss of power line phase (when no T-phase)	—	—		① Loose connection of T-phase on outdoor unit power terminal block ② Check if all three phases show the same power voltage.	
F3			Flashes 2 times	Connector (63L) open	●		●	① Outdoor control board connector (63L) disconnected ② Low-pressure switch (63L) disconnected
F5				Connector (63H) open	●		●	① Outdoor control board connector (63H) disconnected ② High-pressure switch (63H) disconnected
F9				2 or more connectors open	●		●	① Check outdoor control board connector for disconnection and looseness.
F7			Flashes 3 times	Reverse-phase detecting circuit (board) error	—		—	Replace outdoor control board.
F8				Input circuit (board) error	●		●	
Fb			Flashes 2 times	Flashes 4 times	Indoor control board error		●	●
P1	Flashes 1 time	Flash 1 time	Intake air sensor error	●	●	① Indoor control board connector (CN20) disconnected		
P2			Pipe (fluid pipe) sensor error	●	●	② Indoor control board connector (CN21) disconnected		
P4			Drain sensor error	●	●	③ Indoor control board connector (CN31) disconnected		
P5			Flashes 2 times	Drain overflow protection activated, water leakage	●	●	① Check if drain pipe is tilted or clogged. ② Check if drain pan and drain sensor are dirty. ③ Indoor control board CNP connector disconnected	
P6	Flashes 4 times	Flashes 3 times	Anti-freeze protection (during cool mode) Overheat protection (during heat mode)	●	●	① Dirty filter ② Gas leakage/insufficient gas ③ Check if air is blown from outdoor unit. → Check fan connector.		
P8			Flashes 4 times	Abnormal pipe (fluid) temperature	●	●	① If two or more units are used, check indoor-outdoor connecting cable and pipe for incorrect connection. ② Gas leakage/insufficient gas	
P9	—	—	Pipe (two-phase pipe) sensor error	●	●	② Indoor control board connector (CN29) disconnected		

A-Control Error Codes (U)

Displayed on remote controller	Outdoor control board		Error details	Non INV	Power INV	Location of error	Location of inspection
	LED1 "Green"	LED2 "Red"					
U2	Flash 1 time	Flash 1 time	Abnormal discharge temperature / 49C activated (inner thermostat) Insufficient refrigerant	—	●	Outdoor	① Check filter for dirt → Clean if dirty. ② Gas leakage/insufficient gas ③ Check for indoor/outdoor short cycle.
U7			Abnormality of low discharge super heat	—	●		① Check if discharging thermistor is disconnected. ② Check electronic expansion valve for breakdown. ③ Check CNLEV connector on outdoor control board.
U1	Flashes 2 times	Flashes 2 times	63H activated due to abnormally high pressure	●	●	Outdoor	① Check if ball valve is open. ② Check for indoor/outdoor short cycle.
UE			63H activated due to abnormally high pressure	●	●		① Check if ball valve is open. ② Check for indoor/outdoor short cycle. ③ Check if there is too much gas.
UL			63L activated due to abnormally low pressure	●	—		① Check if ball valve is open. ② Gas leakage/insufficient gas
Ud			Flashes 3 times	Overheat protection (overloaded operation protection / fan error)	●		—
U6	Flashes 3 times	Flashes 3 times	Shutoff due to overcurrent in compressor (overload)	●	●	Outdoor	① Check if 12 hours or more have passed since crank-case heater was turned ON. (Replace outdoor control board.)
UC			Power module error	—	●		① Check if ball valve is open.
UF			Compressor self-protection function activated	—	●		① Check if ball valve is open. ② Check if power capacity is sufficient.
UP	Flashes 4 times	Flashes 4 times	Compressor overcurrent (lock)	●	●	Outdoor	① Check if ball valve is open. ② Check if power capacity is sufficient.
UH			Shutoff due to overcurrent in compressor	●	●		① Check if ball valve is open. ② Check if power capacity is sufficient.
U3	Flashes 5 times	Flashes 5 times	Current sensor error	●	●	Outdoor	① If outdoor control board has been replaced: Check wiring and board design.
U4			Discharging thermistor (TH4) open/short-circuit	●	●		① Outdoor control board connector (TH4) disconnected
U4			Pipe thermistor (TH3) open/short-circuit	●	●		① Outdoor control board connector (TH3/TH32) disconnected
U4			2-phase pipe thermistor (TH6) open/short-circuit	—	●		① Outdoor control board connector (TH6) disconnected
U4			Outside air temperature thermistor (TH7) open/short-circuit	—	●		① Outdoor control board connector (TH7) disconnected
U5	Flashes 6 times	Flashes 6 times	Heat sink thermistor (TH8) open/short-circuit	—	●	Outdoor	① Outdoor control board connector (TH8) disconnected
U5			Abnormal heat sink temperature	—	●		① Check if there are obstructions in intake/discharge ports of outdoor unit.
U6	Flashes 7 times	Flashes 7 times	Abnormal voltage	—	●	Outdoor	① Check power line for open phase. ② Check if power voltage is high enough.

This product is designed and intended for use in the residential, commercial and light-industrial environment.

The product at hand is based on the following EU regulations:

- Low Voltage Directive 73/23/EEC
- Electromagnetic Compatibility Directive 89/336/EEC

Please be sure to put the contact address/telephone number on this manual before handing it to the customer.

mitsubishi electric uk

MITSUBISHI ELECTRIC UK, TRAVELLERS LANE, HATFIELD HERTFORDSHIRE, AL10 8XB