

# SERVICE MANUAL

**R410A**

[Model Name]

**EHSC-MEC**  
**EHSC-VM2C**  
**EHSC-VM2EC**  
**EHSC-VM6C**  
**EHSC-VM6EC**  
**EHSC-YM9C**  
**EHSC-YM9EC**  
**EHSC-TM9C**  
**EHSD-MC**  
**EHSD-MEC**  
**EHSD-VM2C**  
**EHSD-YM9C**

**ERSC-MEC**  
**ERSC-VM2C**  
**ERSD-VM2C**  
**EHPX-VM2C**  
**EHPX-VM6C**  
**EHPX-YM9C**

Revision:

- Added EHSC-MECR3.UK, EHSC-VM2CR3.UK, EHSC-VM2ECR3.UK, EHSC-VM6CR3.UK, EHSC-VM6ECR3.UK, EHSC-YM9CR3.UK, EHSC-YM9ECR3.UK, EHSC-TM9CR3.UK, EHSD-MCR3.UK, EHSD-MECR3.UK, EHSD-VM2CR3.UK, EHSD-YM9CR3.UK, ERSC-MECR3.UK, ERSC-VM2CR3.UK, ERSD-VM2CR3.UK, EHPX-VM2CR3.UK, EHPX-VM6CR3.UK and EHPX-YM9CR3.UK in REVISED EDITION-D.
- Some descriptions have been modified.


OCH571 REVISED EDITION-C is void.

Notes:


- This manual describes service data of Hydrobox only.

[Service Ref.]

Refer to page 2.



HYDROBOX


 MAIN REMOTE  
CONTROLLER

## CONTENTS

1. REFERENCE MANUAL .....	3
2. SAFETY PRECAUTION .....	4
3. SPECIFICATIONS .....	7
4. PART NAMES AND FUNCTIONS .....	10
5. OUTLINES AND DIMENSIONS .....	12
6. WIRING DIAGRAM .....	14
7. FIELD WIRING .....	30
8. WATER SYSTEM DIAGRAM .....	32
9. CONTROLS .....	35
10. TROUBLESHOOTING .....	55
11. DISASSEMBLY PROCEDURE .....	72
12. SUPPLEMENTARY INFORMATION .....	93
13. SERVICE AND MAINTENANCE .....	94

**PARTS CATALOG (OCB571)**

**[Service Ref.]**

**EHSC-MEC.UK  
EHSC-VM2C.UK  
EHSC-VM2EC.UK  
EHSC-VM6C.UK  
EHSC-VM6EC.UK  
EHSC-YM9C.UK  
EHSC-YM9EC.UK  
EHSC-TM9C.UK  
EHSD-MC.UK  
EHSD-MEC.UK  
EHSD-VM2C.UK  
EHSD-YM9C.UK  
ERSC-MEC.UK  
ERSC-VM2C.UK  
ERSD-VM2C.UK  
EHPX-VM2C.UK  
EHPX-VM6C.UK  
EHPX-YM9C.UK**

**EHSC-MECCR1.UK  
EHSC-VM2CR1.UK  
EHSC-VM2ECR1.UK  
EHSC-VM6CR1.UK  
EHSC-VM6ECR1.UK  
EHSC-YM9CR1.UK  
EHSC-YM9ECR1.UK  
EHSC-TM9CR1.UK  
EHSD-MCR1.UK  
EHSD-MECCR1.UK  
EHSD-VM2CR1.UK  
EHSD-YM9CR1.UK  
ERSC-MECCR1.UK  
ERSC-VM2CR1.UK  
ERSD-VM2CR1.UK  
EHPX-VM2CR1.UK  
EHPX-VM6CR1.UK  
EHPX-YM9CR1.UK**

**EHSC-MECCR2.UK  
EHSC-VM2CR2.UK  
EHSC-VM2ECR2.UK  
EHSC-VM6CR2.UK  
EHSC-VM6ECR2.UK  
EHSC-YM9CR2.UK  
EHSC-YM9ECR2.UK  
EHSC-TM9CR2.UK  
EHSD-MCR2.UK  
EHSD-MECCR2.UK  
EHSD-VM2CR2.UK  
EHSD-YM9CR2.UK  
ERSC-MECCR2.UK  
ERSC-VM2CR2.UK  
ERSD-VM2CR2.UK  
EHPX-VM2CR2.UK  
EHPX-VM6CR2.UK  
EHPX-YM9CR2.UK**

**EHSC-MECCR3.UK  
EHSC-VM2CR3.UK  
EHSC-VM2ECR3.UK  
EHSC-VM6CR3.UK  
EHSC-VM6ECR3.UK  
EHSC-YM9CR3.UK  
EHSC-YM9ECR3.UK  
EHSC-TM9CR3.UK  
EHSD-MCR3.UK  
EHSD-MECCR3.UK  
EHSD-VM2CR3.UK  
EHSD-YM9CR3.UK  
ERSC-MECCR3.UK  
ERSC-VM2CR3.UK  
ERSD-VM2CR3.UK  
EHPX-VM2CR3.UK  
EHPX-VM6CR3.UK  
EHPX-YM9CR3.UK**

## OUTDOOR UNIT'S SERVICE MANUAL

Service Ref.	Service Manual No.
PUHZ-W50/85VHA(-BS) PUHZ-W50/85VHAR1(-BS) PUHZ-W50VHAR2(-BS) PUHZ-W50VHAR3(-BS)	OCH439
PUHZ-W50VHA2(-BS) PUHZ-W50VHA2R1(-BS)	OCH605
PUHZ-W85VHA2(-BS).UK PUHZ-W85VHA2R1(-BS).UK PUHZ-W85VHA2R3(-BS).UK PUHZ-W85VHA2R4(-BS).UK PUHZ-W85VHA2R5(-BS).UK	OCH465
PUHZ-W112VHA(-BS) PUHZ-W112VHAR1(-BS)	OCH562
PUHZ-HW112/140YHA(-BS) PUHZ-HW112/140YHA2(-BS) PUHZ-HW112/140YHA2R1(-BS) PUHZ-HW112/140YHA2R3(-BS) PUHZ-HW112/140YHA2R4(-BS) PUHZ-HW112/140YHA2R5(-BS) PUHZ-HW140VHA(-BS) PUHZ-HW140VHA2(-BS) PUHZ-HW140VHA2R1(-BS) PUHZ-HW140VHA2R2(-BS) PUHZ-HW140VHA2R3(-BS) PUHZ-HW140VHA2R4(-BS) PUHZ-HW140VHA2R5(-BS)	OCH439
PUHZ-SW40/50VHA(-BS) PUHZ-SW40/50VHAR1(-BS) PUHZ-SW50VKA(-BS)	OCH525
PUHZ-SW75/100/120VHA(-BS).UK PUHZ-SW75/100/120VHAR3(-BS).UK PUHZ-SW75/100/120VHAR4(-BS).UK PUHZ-SW100/120YHA(-BS).UK PUHZ-SW100/120YHAR1(-BS).UK PUHZ-SW100/120YHAR3(-BS).UK PUHZ-SW100/120YHAR4(-BS).UK	OCH533
PUHZ-SHW80/112VHA PUHZ-SHW80/112VHAR2(-BS).UK PUHZ-SHW80/112VHAR3(-BS).UK PUHZ-SHW80/112VHAR4(-BS).UK PUHZ-SHW112/140YHA(R1) PUHZ-SHW112/140YHAR2(-BS).UK PUHZ-SHW112/140YHAR3(-BS).UK PUHZ-SHW112/140YHAR4(-BS).UK	OCH526
PUHZ-FRP71VHA	OCH544
SUHZ-SW45VA(H).TH SUHZ-SW45VA(H)R1.TH SUHZ-SW45VA(H)R2.TH	OCH557

Please read the following safety precautions carefully.

**⚠ WARNING:**  
Precautions that must be observed to prevent injuries or death.

**⚠ CAUTION:**  
Precautions that must be observed to prevent damage to unit.

**This installation manual along with the user manual should be left with the product after installation for future reference.**  
**Mitsubishi Electric is not responsible for the failure of locally-supplied parts.**

- Be sure to perform periodical maintenance.
- Be sure to follow your local regulations.
- Be sure to follow the instructions provided in this manual.

### ⚠ WARNING

#### Mechanical

The hydrobox and outdoor units must not be installed, disassembled, relocated, altered or repaired by the user. Ask an authorised installer or technician. If the unit is installed improperly or modified after installation by the user, water leakage, electric shock or fire may result.

The outdoor unit should be securely fixed to a hard level surface capable of bearing its weight.

The hydrobox should be positioned on a hard vertical surface capable of supporting its filled weight to prevent excessive sound or vibration.

Do not position furniture or electrical appliances below the outdoor unit or hydrobox.

The discharge pipework from the emergency/safety devices of the hydrobox should be installed according to local law.

Only use accessories and replacement parts authorised by Mitsubishi Electric. Ask a qualified technician to fit the parts.

#### Electrical

All electrical work should be performed by a qualified technician according to local regulations and the instructions given in this manual.

The units must be powered by a dedicated power supply and the correct voltage and circuit breakers must be used.

Wiring should be in accordance with national wiring regulations. Connections must be made securely and without tension on the terminals.

Earth unit correctly.

#### General

Keep children and pets away from both the hydrobox and outdoor units.

Do not use the hot water produced by the heat pump directly for drinking or cooking. This could cause illness to the user.

Do not stand on the units.

Do not touch switches with wet hands.

Annual maintenance checks on both the hydrobox and the outdoor unit should be conducted by a qualified person.

Do not place containers with liquids on top of the hydrobox. If they leak or spill onto the hydrobox damage to the unit and/or fire could occur.

Do not place any heavy items on top of the hydrobox.

When installing, relocating, or servicing the hydrobox, use only the specified refrigerant (R410A) to charge the refrigerant lines. Do not mix it with any other refrigerant and do not allow air to remain in the lines. If air is mixed with the refrigerant, then it can be the cause of abnormal high pressure in the refrigerant line, and may result in an explosion and other hazards.

The use of any refrigerant other than that specified for the system will cause mechanical failure or system malfunction or unit breakdown. In the worst case, this could lead to a serious impediment to securing product safety.

In heating mode, to avoid the heat emitters being damaged by excessively hot water, set the target flow temperature to a minimum of 2°C below the maximum allowable temperature of all the heat emitters. For Zone2, set the target flow temperature to a minimum of 5°C below the maximum allowable flow temperature of all the heat emitters in Zone2 circuit.

Do not install the unit where combustible gases may leak, be produced, flow, or accumulate. If combustible gas accumulates around the unit, fire or explosion may result.

### ⚠ CAUTION

Use clean water that meets local quality standards on the primary circuit.

The outdoor unit should be installed in an area with sufficient airflow according to the diagrams in the outdoor unit installation manual.

The hydrobox should be located inside to minimise heat loss.

Water pipe-runs on the primary circuit between outdoor and indoor unit should be kept to a minimum to reduce heat loss.

Ensure condensate from outdoor unit is piped away from the base to avoid puddles of water.

Remove as much air as possible from water circuit.

Refrigerant leakage may cause suffocation. Provide ventilation in accordance with EN378-1.

Be sure to wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite.

Never put batteries in your mouth for any reason to avoid accidental ingestion.

Battery ingestion may cause choking and/or poisoning.


Install the unit on a rigid structure to prevent excessive sound or vibration during operation.

If power to the hydrobox is to be turned off (or system switched off) for a long time, the water should be drained.

Preventative measures should be taken against water hammer, such as installing a Water Hammer Arrestor on the primary water circuit, as directed by the manufacturer.

In order to prevent condensation on emitters, adjust flow temperature appropriately and also set the lower limit of the flow temperature on site.

As for the handling of refrigerant, refer to the outdoor unit installation manual.



**⚠ WARNING (SPLIT MODELS ONLY \*1)**

Do not discharge refrigerant into the atmosphere if refrigerant leaks during installation, ventilate the room.

Use appropriate tools for high pressure refrigerant.

When pumping down refrigerant, stop the compressor before disconnecting the refrigerant pipes.

During installation securely fasten the refrigerant pipes before starting the compressor.

Check that refrigerant gas does not leak after the completion of installation.

Use R410A refrigerant only. Do not allow air to enter the lines. Failure to observe these instructions will cause mechanical failure, system failure or, in the worst case, serious breach of product safety.

**⚠ CAUTION (SPLIT MODELS ONLY \*1)**

<Using R410A refrigerant heat pumps>

Use C1220 copper phosphorus, for copper and copper alloy seamless pipes, to connect the refrigerant pipes. Make sure the insides of the pipes are clean and do not contain any harmful contaminants such as sulfuric compounds, oxidants, debris, or dust. Use pipes with the specified thickness. Note the following if reusing existing pipes that carried R22 refrigerant.

- Replace the existing flare nuts and flare the flared sections again.
- Do not use thin pipes.

Store the pipes to be used during installation indoors and keep both ends of the pipes sealed until just before brazing. (Leave elbow joints, etc. in their packaging.) If dust, debris, or moisture enters the refrigerant lines, oil deterioration or compressor breakdown may result.

Use ester oil, ether oil, alkylbenzene oil (small amount) as the refrigeration oil applied to the flared sections. If mineral oil is mixed in the refrigeration oil, oil deterioration may result.

Do not use refrigerant other than R410A refrigerant. If another refrigerant is used, the chlorine will cause the oil to deteriorate.

Use the following tools specifically designed for use with R410A refrigerant. The following tools are necessary to use R410A refrigerant. Contact your nearest dealer for any questions.

Tools (for R410A)	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adapter
Torque wrench	Electronic refrigerant charging scale

Be sure to use the correct tools. If dust, debris, or moisture enters the refrigerant lines, refrigeration oil deterioration may result.

Do not use a charging cylinder, a cylindrical measuring container, when charging R410A refrigerant gas. If the refrigerant gas is transferred to a charging cylinder, the composition of the refrigerant will change and system efficiency will be reduced.

\*1 Split model = EHSC/D or ERSC/D series  
Packaged model = EHPX series


## [1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) If moisture or foreign matter might have entered the refrigerant piping during service, ensure to remove them.

## [2] Additional refrigerant charge

### When charging directly from refrigerant cylinder

- (1) Check that cylinder for R410A on the market is syphon type.
- (2) Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



## [3] Service tools

Use the service tools below as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications
1	Gauge manifold	· Only for R410A
		· Use the existing fitting specifications. (UNF1/2)
		· Use high-tension side pressure of 5.3 MPa·G or over.
2	Charge hose	· Only for R410A
		· Use pressure performance of 5.09 MPa·G or over.
3	Electronic scale	—
4	Gas leak detector	· Use the detector for R134a, R407C or R410A
5	Adaptor for reverse flow check	· Attach on vacuum pump.
6	Refrigerant charge base	—
7	Refrigerant cylinder	· Only for R410A      · Top of cylinder (Pink)
		· Cylinder with syphon
8	Refrigerant recovery equipment	—



Model name (Service Ref.)	EHSD-MECCR1.UK	EHSD-MECCR2.UK	EHSD-MCR1.UK	EHSD-MCR2.UK	EHSD-VM2CR1.UK	EHSD-VM2CR2.UK	EHSD-VM9CR1.UK	EHSD-VM9CR2.UK	EHSD-VM6CR1.UK	EHSD-VM6CR2.UK	EHSD-VM8CR1.UK	EHSD-VM8CR2.UK	EHSD-VM9CR1.UK	EHSD-VM9CR2.UK	ERSC-MECCR1.UK	ERSC-MECCR2.UK	ERSC-VM2CR1.UK	ERSC-VM2CR2.UK	ERSC-VM9CR1.UK	ERSC-VM9CR2.UK	ERSC-VM6CR1.UK	ERSC-VM6CR2.UK	EHPX-VM2CR1.UK	EHPX-VM2CR2.UK	EHPX-VM9CR1.UK	EHPX-VM9CR2.UK		
Overall unit dimensions	800 x 530 x 360 mm (Height x Width x Depth)																											
Weight (empty)	38 kg	43 kg	44 kg	45 kg	42 kg	48 kg	43 kg	44 kg	49 kg	44 kg	49 kg	44 kg	49 kg	44 kg	43 kg	45 kg	49 kg	44 kg	49 kg	44 kg	49 kg	43 kg	45 kg	37 kg	38 kg	38 kg	38 kg	
Weight (full)	44 kg	49 kg	50 kg	51 kg	49 kg	55 kg	50 kg	51 kg	56 kg	51 kg	56 kg	51 kg	56 kg	51 kg	50 kg	51 kg	56 kg	51 kg	56 kg	51 kg	56 kg	50 kg	51 kg	42 kg	43 kg	43 kg	43 kg	
Water volume of heating circuit in the unit	5.2 kg	5.2 kg	5.2 kg	5.2 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.4 kg	5.5 kg	6.4 kg	6.4 kg	6.4 kg	6.4 kg	6.4 kg	6.4 kg	4.5 kg	4.5 kg	4.5 kg	4.5 kg	4.5 kg	
Plate heat exchanger (MWA2)	—	—	—	—	✓	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
Plate heat exchanger (MWA1)	✓	✓	✓	✓	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
Cooling mode	NOT available																											
Unvented expansion vessel (Primary heating)	—	10 L	—	—	10 L	—	10 L	—	10 L	—	10 L	—	10 L	—	—	10 L	—	10 L	—	10 L	—	—	10 L	—	10 L	—	10 L	
Charge pressure	—	1 bar	—	—	1 bar	—	1 bar	—	1 bar	—	1 bar	—	1 bar	—	—	1 bar	—	1 bar	—	1 bar	—	—	1 bar	—	1 bar	—	1 bar	
Control thermostat	1–80°C																											
Pressure relief valve (Red)	0.3 MPa (3bar)																											
Flow sensor	Min flow 5.0 L/min																											
Manual reset thermostat	90°C																											
Thermal Cut-out (for dry run prevention)	121°C																											
Primary circuit circulating Pump	Grundfos UPM2 15–70 130																											
Water	28 mm compression (primary circuit)																											
Refrigerant (R410A)	Liquid 6.35 mm Gas 12.7 mm																											
Flow temperature	25–60°C																											
Room temperature	10–30°C																											
Room temperature	—																											
Cooling	—																											
Heating	5–25°C																											
Ambient *1	0–35°C (≤ 80%RH)																											
Guaranteed operating range	See outdoor unit spec table.																											
Outdoor temperature	—																											
Cooling	—																											
Power supply (Phase, voltage, frequency)	~N, 230 V, 50 Hz																											
Breaker (when powered from independent source)	10A																											
Control board	—																											
Power supply (Phase, voltage, frequency)	—	—	~N, 230 V, 50 Hz	3–, 400 V, 50 Hz	—	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	3–, 400 V, 50 Hz	3–, 230 V, 50 Hz	3–, 230 V, 50 Hz	3–, 230 V, 50 Hz	3–, 230 V, 50 Hz	~N, 230 V, 50 Hz	—	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	3–, 400 V, 50 Hz	
Booster heater	—	—	2 kW	3kW+ 6 kW	—	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW
Capacity	—	—	2 kW	3kW+ 6 kW	—	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW
Current	—	—	9 A	13 A	—	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A
Breaker	—	—	16 A	16 A	—	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A
Sound pressure level	28 dB(A)																											
Sound power level	40 dB(A)																											

<Table 3-2>

**Optional extras**

- Wireless Remote Controller PAR-WT50R-E
- Wireless Receiver PAR-WRS1R-E
- Remote Sensor PAC-SE41TS-E
- Tank thermostat (THW5) (5 m) PAC-TH011TK-E
- Tank thermostat (THW5) (30 m) PAC-TH011TKL-E
- Thermostat PAC-TH011-E
- High temperature thermostat PAC-TH011HT-E
- ecodan Wi-Fi Interface PAC-WF010-E
- 2-zone kit PAC-TZ01-E
- \*1 The environment must be frost-free.
- \*2 Cooling mode is not available in low outdoor temperature. If you use our system in cooling mode at the low ambient temperature (10°C or below), there are some risks of plate heat exchanger breaking by frozen water.




Model name (Service Ref.)	EHSD-MEGR3.UK	EHSD-MCR3.UK	EHSD-VM2CR3.UK	EHSD-VM9CR3.UK	EHSD-MEGR3.UK	EHSD-VM2CR3.UK	EHSD-VM6CR3.UK	EHSD-VM6EGR3.UK	EHSD-VM9EGR3.UK	EHSD-VM9CR3.UK	EHSD-VM2CR3.UK	EHSD-VM2CR3.UK	ERSC-MEGR3.UK	ERSC-VM2CR3.UK	ERSC-VM2CR3.UK	ERSC-VM9CR3.UK	EHPX-VM2CR3.UK	EHPX-VM6CR3.UK	EHPX-VM9CR3.UK	
Overall unit dimensions	800 × 530 × 360 mm (Height × Width × Depth)																			
Weight (empty)	38 kg	43 kg	44 kg	45 kg	42 kg	48 kg	43 kg	49 kg	44 kg	49 kg	44 kg	49 kg	43 kg	45 kg	49 kg	49 kg	37 kg	38 kg	38 kg	
Weight (full)	44 kg	49 kg	50 kg	51 kg	49 kg	55 kg	50 kg	56 kg	51 kg	56 kg	51 kg	56 kg	50 kg	51 kg	56 kg	56 kg	42 kg	43 kg	43 kg	
Water volume of heating circuit in the unit	5.2 kg	5.2 kg	5.2 kg	5.2 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	6.1 kg	4.5 kg	4.5 kg	4.5 kg	
Plate heat exchanger (MWA2)	—	—	—	—	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	—	—	—	
Plate heat exchanger (MWA1)	✓	✓	✓	✓	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
Cooling mode	NOT available																			
Unvented expansion vessel (Primary heating)	—	10 L	10 L	10 L	—	10 L	—	10 L	—	10 L	—	10 L	—	10 L	—	10 L	10 L	10 L	10 L	
Charge pressure	—	1 bar	1 bar	1 bar	—	1 bar	—	1 bar	—	1 bar	—	1 bar	—	1 bar	—	1 bar	1 bar	1 bar	1 bar	
Control thermostat	1–80°C																			
Pressure relief valve (Red)	0.3 MPa (3bar)																			
Pressure relief valve (Black)	—	0.5 MPa (5bar)	—	—	—	0.5 MPa (5bar)	—	—	—	—	—	—	0.5 MPa (5bar)	—	—	—	0.5 MPa (5bar)	—	—	
Safety device	Min flow 5.0 L/min																			
Flow sensor	90°C																			
Manual reset thermostat	121°C																			
Thermal Cut-out (for dry run prevention)	—	90°C	—	—	—	—	—	—	—	—	—	—	—	—	—	—	90°C	—	—	
Primary circuit circulating Pump	Grundfos UPM2 15–70 130																			
Water	28 mm compression (primary circuit)																			
Refrigerant (R410A)	—	6.35 mm	—	—	—	—	—	—	—	—	—	—	—	—	—	—	6.35 mm	9.52 mm	—	
Gas	—	12.7 mm	—	—	—	—	—	—	—	—	—	—	—	—	—	—	12.7 mm	15.88 mm	—	
Heating	25–60°C																			
Cooling	10–30 °C																			
Room temperature	—																			
Cooling	5–25°C																			
Ambient*1	0–35°C (≤ 80%RH)																			
Guaranteed operating range	See outdoor unit spec table.																			
Outdoor temperature	—																			
Cooling	See outdoor unit spec table (minimum 10°C)*2																			
Control board	—																			
Power supply (Phase, voltage, frequency)	~N, 230 V, 50 Hz																			
Breaker (when powered from independent source)	10A																			
Power supply (Phase, voltage, frequency)	—	—	~N, 230 V, 50 Hz	3~, 400 V, 50 Hz	—	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	3~, 400 V, 50 Hz	3~, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	~N, 230 V, 50 Hz	3~, 400 V, 50 Hz
Capacity	—	—	2 kW	3kW+ 6 kW	—	2 kW	2 kW	2 kW	3kW+ 6 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	2 kW	3kW+ 6 kW
Current	—	—	9 A	13 A	—	9 A	9 A	9 A	13 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	9 A	13 A
Breaker	—	—	16 A	16 A	—	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	16 A	26 A
Electrical data	28 dB(A)																			
Sound pressure level	40 dB(A)																			

<Table 3-3>


**Optional extras**

- Wireless Remote Controller PAR-WT50R-E
  - Wireless Receiver PAR-WRS1R-E
  - Remote Sensor PAC-SE41TS-E
  - Tank thermostat (THW5) (5 m) PAC-TH011TK-E
  - Tank thermostat (THW5) (30 m) PAC-TH011TKL-E
  - Thermistor PAC-TH011-E
  - High temperature thermostat PAC-TH011HT-E
  - ecodan Wi-Fi Interface PAC-WF010-E
  - 2-zone kit PAC-TZ01-E
- \*1 The environment must be frost-free.  
 \*2 Cooling mode is not available in low outdoor temperature.  
 If you use our system in cooling mode at the low ambient temperature (10°C or below), there are some risks of plate heat exchanger breaking by frozen water.

## &lt;E\*S\*-\*M\*\*C(R1)&gt; (Split model system)




&lt;Figure 4-1&gt;



&lt;Figure 4-2&gt;

## &lt;EHPX-\*M\*C(R1)&gt; (Packaged model system)




&lt;Figure 4-3&gt;


No.	Part name	EHS*-MEC(R1)	EHS*-*M*C(R1)	EHSC-*M*EC(R1)	ERS*-VM2C(R1)	ERSC-MEC(R1)	EHPX-*M*C(R1)
1	Control and electrical box	✓	✓	✓	✓	✓	✓
2	Main remote controller	✓	✓	✓	✓	✓	✓
3	Plate heat exchanger (Refrigerant - Water)	✓	✓	✓	✓	✓	-
4	Water circulation pump 1	✓	✓	✓	✓	✓	✓
5	Pump valve	✓	✓	✓	✓	✓	✓
6	Drain cock (Primary circuit)	✓	✓	✓	✓	✓	✓
7	Booster heater 1,2	-	✓	✓	✓	-	✓
8	Flow sensor	✓	✓	✓	✓	✓	✓
9	Manometer	✓	✓	✓	✓	✓	✓
10	Pressure relief valve (3bar)	✓	✓	✓	✓	✓	✓
11	Automatic air vent	✓	✓	✓	✓	✓	✓
12	Expansion vessel	-	✓	-	✓	-	✓
13	Strainer valve	✓	✓	✓	✓	✓	✓
14	Drain pan	-	-	-	✓	✓	-

&lt;Table 4-1&gt;

<E\*S\*-\*M\*\*C R2/R3> (Split model system)




<Figure 4-4>



<Figure 4-5>

<EHPX-\*M\*C R2/R3> (Packaged model system)





<Figure 4-6>


No.	Part name	EHS*-MEC R2/R3	EHS*-*M*CR2	EHS*-*M*CR3	EHSC-*M*EC R2/R3	ERS*-VM2CR2	ERS*-VM2CR3	ERSC-MEC R2/R3	EHPX-*M*CR2	EHPX-*M*CR3
1	Control and electrical box	✓	✓	✓	✓	✓	✓	✓	✓	✓
2	Main remote controller	✓	✓	✓	✓	✓	✓	✓	✓	✓
3	Plate heat exchanger (Refrigerant - Water)	✓	✓	✓	✓	✓	✓	✓	-	-
4	Water circulation pump 1	✓	✓	✓	✓	✓	✓	✓	✓	✓
5	Pump valve	✓	✓	✓	✓	✓	✓	✓	✓	✓
6	Drain cock (Primary circuit)	✓	✓	✓	✓	✓	✓	✓	✓	✓
7	Booster heater 1,2	-	✓	✓	✓	✓	✓	-	✓	✓
8	Flow sensor	✓	✓	✓	✓	✓	✓	✓	✓	✓
9	Manometer	✓	✓	✓	✓	✓	✓	✓	✓	✓
10	Pressure relief valve (3bar)	✓	✓	✓	✓	✓	✓	✓	✓	✓
11	Automatic air vent	✓	✓	✓	✓	✓	✓	✓	✓	✓
12	Expansion vessel	-	✓	✓	-	✓	✓	-	✓	✓
13	Strainer valve	✓	✓	✓	✓	✓	✓	✓	✓	✓
14	Drain pan	-	-	-	-	✓	✓	✓	-	-
15	Pressure relief valve (5bar)	-	-	✓	-	-	✓	-	-	✓

<Table 4-2>


5-1. Technical Drawings




<EHS\*> (Split model system)



<ERS\*> (Split model system for heating and cooling)



<EHPX> (Packaged model system)



Letter	Pipe description	Connection size/type
A	Space heating/Indirect DHW tank (primary) return connection	28 mm/Compression (E*SD-* and EHPX-*) G1 nut (ERS*-* )
B	Space heating/Indirect DHW tank (primary) flow connection	28 mm/Compression (EHS*-* and EHPX-*) G1 nut (ERS*-* )
C	Refrigerant (Liquid)	6.35 mm/Flare (E*SD-* ) 9.52 mm/Flare (E*SC-* )
D	Refrigerant (Gas)	12.7 mm/Flare (E*SD-* ) 15.88 mm/Flare (E*SC-* )
E	Flow connection from heat pump	28 mm/Compression (EHPX-*)
F	Return connection to heat pump	28 mm/Compression (EHPX-*)
G	Discharge pipe (by installer) from pressure relief valve	G1/2" female (valve port within hydrobox casing)
H	Electrical cable inlets ① ② ③ ④	For inlets ① and ②, run high-voltage wires including power cable, indoor-outdoor cable, and external output wires. For inlets ③ and ④, run low-voltage wires including external input wires and thermistor wires. For a wireless receiver (option) cable, use inlet ④.
I	Drain socket	O.D. ø20

<Table 5-1>




### 5-2. Service access diagrams

Service access	
Parameter	Dimension (mm)
a	200
b	150
c	500
d	500


Sufficient space MUST be left for the provision of discharge pipework as detailed in National and Local building regulations.

The hydrobox must be located indoors and in a frost-free environment, for example in a utility room.



Service access

## 6-1. EHSC-MEC.UK, EHSD-MEC.UK, EHSD-MC.UK, ERSC-MEC.UK



**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation   Heater operation/ Boiler operation *2	
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1		
IN9	TBI.3 3-4	—	Electric energy meter 2	Refer to installation manual.	
IN10	TBI.3 5-6	—	Heat meter		

\*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.

\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TBO.1-4	Terminal block <Power supply, Outdoor unit>
MP1	Water circulation pump 1 (Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone1)(Local supply)
2WV2b	2-way valve (For Zone2)(Local supply)
MXV	Mixing valve (Local supply)
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
<b>FLOW TEMP. CONTROLLER (FTCS5)</b>	
TBO.1-4	Terminal block <OutFCs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (T10AL250V)
F2	Fuse (T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTCS5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTCS5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-2. EHSC-MECR1.UK, EHSD-MECR1.UK, EHSD-MCR1.UK, ERSC-MECR1.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

\*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.


\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
MP1	Water circulation pump 1 (Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)

Symbol	Name
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)

Symbol	Name
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

### 6-3. EHSC-MECR2.UK, EHSD-MECR2.UK, EHSD-MCR2.UK, ERSC-MECR2.UK EHSC-MECR3.UK, EHSD-MECR3.UK, EHSD-MCR3.UK, ERSC-MECR3.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input *1	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *3
IN5	TBI.1 5-6	—	Outdoor thermostat input *2	Standard operation	Heater operation/ Boiler operation *3
IN6	TBI.1 3-4	—	Room thermostat 2 input *1	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN11	TBI.3 7-8	—	Smart grid ready input		
IN12	TBI.3 9-10	—	Smart grid ready input		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. Set the ON/OFF cycle time of the room thermostat for 10 minutes or more; otherwise the compressor may be damaged.
- \*2. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.
- \*3. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
			2-way valve 2b output *2	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
				Open	Open
OUT6	—	CNBH 1:3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5:7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

- \*1. For 2-zone temperature control.
- \*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
MP1	Water circulation pump 1 (Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN11	Smart grid ready input (Local supply)
IN12	Smart grid ready input (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector



6-4. EHSC-VM2C.UK, EHSC-VM2EC.UK, EHSD-VM2C.UK, ERSC-VM2C.UK, ERSD-VM2C.UK, EHPX-VM2C.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings,
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

Table 1 Signal Inputs

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/ Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1		
IN9	TBI.3 3-4	—	Electric energy meter 2	Refer to installation manual.	
IN10	TBI.3 5-6	—	Heat meter		

\*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

Table 2 Outputs

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1 2-way valve 2b output *2	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2 TBO.2 2-3	—	Mixing valve output *1	Stop	Close Open
OUT6	—	CNBH1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.

\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1(Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3W/2W1	3-way valve (2-way valve 1)(Local supply)
2W2a	2-way valve (For Zone1)(Local supply)
2W2b	2-way valve (For Zone2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BHC1	Contact for booster heater 1
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (T10A/250V)
F2	Fuse (T6.3A/250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
Power supply (FTC5)	
LED1	Power supply (Main remote controller)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-5. EHSC-VM2CR1.UK, EHSC-VM2ECR1.UK, EHSD-VM2CR1.UK, ERSC-VM2CR1.UK, ERSD-VM2CR1.UK, EHPX-VM2CR1.UK



- Symbols used in wiring diagram are, : connector, : terminal block.
- Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
- Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1		
IN9	TBI.3 3-4	—	Electric energy meter 2	Refer to installation manual.	
IN10	TBI.3 5-6	—	Heat meter		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.
- \*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1 2-way valve 2b output *2	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2 TBO.2 2-3	—	Mixing valve output *1	Stop	Close Open
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.  
\*1. For 2-zone temperature control.  
\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BHC1	Contact for booster heater 1
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)

Symbol	Name
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)

Symbol	Name
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

6-6. EHSC-VM2CR2.UK, EHSC-VM2ECR2.UK, EHSD-VM2CR2.UK, ERSC-VM2CR2.UK, ERSD-VM2CR2.UK, EHPX-VM2CR2.UK  
EHSC-VM2CR3.UK, EHSC-VM2ECR3.UK, EHSD-VM2CR3.UK, ERSC-VM2CR3.UK, ERSD-VM2CR3.UK, EHPX-VM2CR3.UK




Table 1 Signal Inputs

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input *1	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *3
IN5	TBI.1 5-6	—	Outdoor thermostat input *2	Standard operation   Heater operation/ Boiler operation *3	
IN6	TBI.1 3-4	—	Room thermostat 2 input *1	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN11	TBI.3 7-8	—	Smart grid ready input		
IN12	TBI.3 9-10	—	Smart grid ready input		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

\*1. Set the ON/OFF cycle time of the room thermostat for 10 minutes or more; otherwise the compressor may be damaged.

\*2. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*3. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

Table 2 Outputs

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT5	TBO.2 2-3	—		Open	
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.


\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BHC1	Contact for booster heater 1
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN11	Smart grid ready input (Local supply)
IN12	Smart grid ready input (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-7. EHSC-VM6C.UK, EHSC-VM6EC.UK, EHPX-VM6C.UK



## 6-8. EHSC-VM6CR1.UK, EHSC-VM6ECR1.UK, EHPX-VM6CR1.UK



1. Symbols in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <-6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <-6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <-6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input	Standard operation	Heater operation/Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <-6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <-6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.  
 \*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


- Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.  
 \*1. For 2-zone temperature control.  
 \*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1(Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contactor for booster heater 1
BHC2	Contactor for booster heater 2
BHCP	Contactor for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)

Symbol	Name
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN1A	Flow sensor

Symbol	Name
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <-6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-9. EHSC-VM6CR2.UK, EHSC-VM6ECR2.UK, EHPX-VM6CR2.UK EHSC-VM6CR3.UK, EHSC-VM6ECR3.UK, EHPX-VM6CR3.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input *1	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *3
IN5	TBI.1 5-6	—	Outdoor thermostat input *2	Standard operation / Heater operation/ Boiler operation *3	
IN6	TBI.1 3-4	—	Room thermostat 2 input *1	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN11	TBI.3 7-8	—	Smart grid ready input		
IN12	TBI.3 9-10	—	Flow sensor		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. Set the ON/OFF cycle time of the room thermostat for 10 minutes or more; otherwise the compressor may be damaged.
- \*2. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.
- \*3. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**


Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve 2b output *2	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Close	Open
OUT5	TBO.2 2-3	—		Stop	Open
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

- \*1. For 2-zone temperature control.
- \*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contact for booster heater 1
BHC2	Contact for booster heater 2
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN11	Smart grid ready input (Local supply)
IN12	Flow sensor
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10A250V)
F2	Fuse (IEC T6.3A250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-10. EHSC-YM9C.UK, EHSC-YM9EC.UK, EHSD-YM9C.UK, EHPX-YM9C.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings,
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation Heater operation/ Boiler operation *2	
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		

\*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.

\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1) (Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2) (Local supply)
MP4	Water circulation pump 4 (DHW) (Local supply)
3WV/2WV1	3-way valve (2-way valve 1) (Local supply)
2WV2a	2-way valve (For Zone1) (Local supply)
2WV2b	2-way valve (For Zone2) (Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contact for booster heater 1
BHC2	Contact for booster heater 2
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.) (Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.) (Option)
THW6	Thermistor (Zone1 flow temp.) (Option)
THW7	Thermistor (Zone1 return temp.) (Option)
THW8	Thermistor (Zone2 flow temp.) (Option)
THW9	Thermistor (Zone2 return temp.) (Option)
THWB1	Thermistor (Boiler flow temp.) (Option)
THWB2	Thermistor (Boiler return temp.) (Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (T10AL250V)
F2	Fuse (T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-11. EHSC-YM9CR1.UK, EHSC-YM9ECR1.UK, EHSD-YM9CR1.UK, EHPX-YM9CR1.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

Table 1 Signal Inputs

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1		
IN9	TBI.3 3-4	—	Electric energy meter 2		Refer to installation manual.
IN10	TBI.3 5-6	—	Heat meter		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.  
 \*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

Table 2 Outputs

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

- Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.  
 \*1. For 2-zone temperature control.  
 \*2. For 2-zone valve ON/OFF control.


Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1(Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contactor for booster heater 1
BHC2	Contactor for booster heater 2
BHCP	Contactor for booster heater protection

Symbol	Name
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)

Symbol	Name
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector



## 6-12. EHSC-YM9CR2.UK, EHSC-YM9ECR2.UK, EHSD-YM9CR2.UK, EHPX-YM9CR2.UK EHSC-YM9CR3.UK, EHSC-YM9ECR3.UK, EHSD-YM9CR3.UK, EHPX-YM9CR3.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input *1	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *3
IN5	TBI.1 5-6	—	Outdoor thermostat input *2	Standard operation Heater operation/Boiler operation *3	
IN6	TBI.1 3-4	—	Room thermostat 2 input *1	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN11	TBI.3 7-8	—	Smart grid ready input		
IN12	TBI.3 9-10	—	Smart grid ready input		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. Set the ON/OFF cycle time of the room thermostat for 10 minutes or more; otherwise the compressor may be damaged.
- \*2. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.
- \*3. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**


Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH3-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

- \*1. For 2-zone temperature control.  
\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TBI	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1(Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contactors for booster heater 1
BHC2	Contactors for booster heater 2
BHCP	Contactors for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN11	Smart grid ready input (Local supply)
IN12	Smart grid ready input (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

### 6-13. EHSC-TM9C.UK



- Symbols used in wiring diagram are, : connector, : terminal block.
- Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings,
- Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <-6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <-6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <-6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/ Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <-6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <-6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1		
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter	Refer to installation manual.	

\*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.

\*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	TBO.2 2-3	—	2-way valve 2b output *2	Open	Open
OUT7	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT8	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT9	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT10	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT11	TBO.3 1-2	—	Boiler output	OFF	ON
OUT12	TBO.3 3-4	—	Error output	Normal	Error
OUT13	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT14	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT15	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT16	TBO.3 7-8	—	Comp. ON signal	OFF	ON


Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.

\*1. For 2-zone temperature control.

\*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1(Space heating/cooling & DHW)
MP2	Water circulation pump 2 (Space heating/cooling for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating/cooling for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone1)(Local supply)
2WV2b	2-way valve (For Zone2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contact for booster heater 1
BHC2	Contact for booster heater 2
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (T10AL250V)
F2	Fuse (T6.3AL250V)
SW1-5	DIP switch *See <-6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-14. EHSC-TM9CR1.UK



1. Symbols used in wiring diagram are, : connector, : terminal block.
2. Indoor unit and outdoor unit connecting wires have polarities, make sure to match terminal numbers (S1, S2, S3) for correct wirings.
3. Since the outdoor unit side electric wiring may change, be sure to check the outdoor unit electric wiring diagram for service.

**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/Boiler operation *2
IN5	TBI.1 5-6	—	Outdoor thermostat input *1	Standard operation	Heater operation/Boiler operation *2
IN6	TBI.1 3-4	—	Room thermostat 2 input	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.  
 \*2. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	TBO.2 2-3	—		2-way valve 2b output *2	
OUT7	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT8	TBO.4 5-6	—	Booster heater 2 output	OFF	ON
OUT9	TBO.4 3-4	—	Cooling signal output	OFF	ON
OUT10	TBO.3 1-2	—	Immersion heater output	OFF	ON
OUT11	TBO.3 3-4	—	Boiler output	OFF	ON
OUT12	TBO.3 5-6	—	Error output	Normal	Error
OUT13	TBO.3 7-8	—	Defrost output	Normal	Defrost
OUT14	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT15	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT16	TBO.3 7-8	—	Comp. ON signal	OFF	ON


- Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.  
 \*1. For 2-zone temperature control.  
 \*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contact for booster heater 1
BHC2	Contact for booster heater 2
BHCP	Contact for booster heater protection

Symbol	Name
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)

Symbol	Name
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3 Terminal block <Signal Inputs, Thermistor>	
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-15. EHSC-TM9CR2.UK EHSC-TM9CR3.UK



**Table 1 Signal Inputs**

Name	Terminal block	Connector	Item	OFF (Open)	ON (Short)
IN1	TBI.1 13-14	—	Room thermostat 1 input *1	Refer to SW2-1 in <6-16. DIP switch functions>.	
IN2	TBI.1 11-12	—	Flow switch 1 input	Refer to SW2-2 in <6-16. DIP switch functions>.	
IN3	TBI.1 9-10	—	Flow switch 2 input (Zone1)	Refer to SW3-2 in <6-16. DIP switch functions>.	
IN4	TBI.1 7-8	—	Demand control input	Normal	Heat source OFF/ Boiler operation *3
IN5	TBI.1 5-6	—	Outdoor thermostat input *2	Standard operation	Heater operation/ Boiler operation *3
IN6	TBI.1 3-4	—	Room thermostat 2 input *1	Refer to SW3-1 in <6-16. DIP switch functions>.	
IN7	TBI.1 1-2	—	Flow switch 3 input (Zone2)	Refer to SW3-3 in <6-16. DIP switch functions>.	
IN8	TBI.3 1-2	—	Electric energy meter 1	Refer to installation manual.	
IN9	TBI.3 3-4	—	Electric energy meter 2		
IN10	TBI.3 5-6	—	Heat meter		
IN11	TBI.3 7-8	—	Smart grid ready input		
IN12	TBI.3 9-10	—	—		
IN1A	TBI.3 12-14	CN1A	Flow sensor		

- \*1. Set the ON/OFF cycle time of the room thermostat for 10 minutes or more; otherwise the compressor may be damaged.
- \*2. If using outdoor thermostat for controlling operation of heaters, the lifetime of the heaters and related parts may be reduced.
- \*3. To turn on the boiler operation, use the main remote controller to select "Boiler" in "External input setting" screen in the service menu.

**Table 2 Outputs**

Name	Terminal block	Connector	Item	OFF	ON
OUT1	TBO.1 1-2	CNP1	Water circulation pump 1 output (Space heating/cooling & DHW)	OFF	ON
OUT2	TBO.1 3-4	—	Water circulation pump 2 output (Space heating/cooling for Zone1)	OFF	ON
OUT3	TBO.1 5-6	—	Water circulation pump 3 output (Space heating/cooling for Zone2) *1	OFF	ON
OUT4	TBO.2 4-6	CNV1	3-way valve (2-way valve) output	Heating	DHW
OUT5	TBO.2 1-2	—	Mixing valve output *1	Stop	Close
OUT6	—	CNBH 1-3	Booster heater 1 output	OFF	ON
OUT7	—	CNBH 5-7	Booster heater 2 output	OFF	ON
OUT8	TBO.4 5-6	—	Cooling signal output	OFF	ON
OUT9	TBO.4 3-4	CNIH	Immersion heater output	OFF	ON
OUT10	TBO.3 1-2	—	Boiler output	OFF	ON
OUT11	TBO.3 3-4	—	Error output	Normal	Error
OUT12	TBO.3 5-6	—	Defrost output	Normal	Defrost
OUT13	TBO.4 1-2	—	2-way valve 2a output *2	OFF	ON
OUT14	—	CNP4	Water circulation pump 4 output (DHW)	OFF	ON
OUT15	TBO.3 7-8	—	Comp. ON signal	OFF	ON

Do not connect to the terminals that are indicated as "—" in the "Terminal block" field.


- \*1. For 2-zone temperature control.
- \*2. For 2-zone valve ON/OFF control.

Symbol	Name
TB1	Terminal block <Power supply, Outdoor unit>
ECB1	Earth leakage circuit breaker for booster heater
MP1	Water circulation pump 1 (Space heating & DHW)
MP2	Water circulation pump 2 (Space heating for Zone1)(Local supply)
MP3	Water circulation pump 3 (Space heating for Zone2)(Local supply)
MP4	Water circulation pump 4 (DHW)(Local supply)
3WV(2WV1)	3-way valve (2-way valve 1)(Local supply)
2WV2a	2-way valve (For Zone 1)(Local supply)
2WV2b	2-way valve (For Zone 2)(Local supply)
MXV	Mixing valve (Local supply)
BHT	Thermostat for booster heater
BHF	Thermal fuse for booster heater
BH1	Booster heater 1
BH2	Booster heater 2
BHC1	Contact for booster heater 1
BHC2	Contact for booster heater 2
BHCP	Contact for booster heater protection
TH1	Thermistor (Room temp.)(Option)
TH2	Thermistor (Ref. liquid temp.)
THW1	Thermistor (Flow water temp.)
THW2	Thermistor (Return water temp.)
THW5	Thermistor (DHW tank water temp.)(Option)
THW6	Thermistor (Zone1 flow temp.)(Option)
THW7	Thermistor (Zone1 return temp.)(Option)
THW8	Thermistor (Zone2 flow temp.)(Option)
THW9	Thermistor (Zone2 return temp.)(Option)
THWB1	Thermistor (Boiler flow temp.)(Option)
THWB2	Thermistor (Boiler return temp.)(Option)
IN1	Room thermostat 1 (Local supply)
IN2	Flow switch 1 (Local supply)
IN3	Flow switch 2 (Local supply)
IN4	Demand control (Local supply)
IN5	Outdoor thermostat (Local supply)
IN6	Room thermostat 2 (Local supply)
IN7	Flow switch 3 (Local supply)
IN8	Electric energy meter 1 (Local supply)
IN9	Electric energy meter 2 (Local supply)
IN10	Heat meter (Local supply)
IN11	Smart grid ready input (Local supply)
IN12	—
IN1A	Flow sensor
FLOW TEMP. CONTROLLER (FTC5)	
TBO.1-4	Terminal block <Outputs>
TBI.1-3	Terminal block <Signal Inputs, Thermistor>
F1	Fuse (IEC T10AL250V)
F2	Fuse (IEC T6.3AL250V)
SW1-5	DIP switch *See <6-16. DIP switch functions>.
X1-15	Relay
LED1	Power supply (FTC5)
LED2	Power supply (Main remote controller)
LED3	Communication (FTC5-Outdoor unit)
LED4	Reading or writing data to SD card
CNPWM	Pump speed control signal for MP1
CN108	SD card connector

## 6-16. DIP switch functions

Located on the FTC printed circuit board are 5 sets of small white switches known as DIP switches. The DIP switch number is printed on the circuit board next to the relevant switches. The word ON is printed on the circuit board and on the DIP switch block itself. To move the switch you will need to use a pin or the corner of a thin metal ruler or similar.

DIP switch settings are listed in the table below. Only an authorised installer can change DIP switch setting under one's own responsibility according to the installation condition. Make sure to turn off both indoor unit and outdoor unit power supplies before changing the switch settings.



DIP switch	Function	OFF	ON	Default settings: Indoor unit model			
SW1	SW1-1	Boiler	WITHOUT Boiler	WITH Boiler	OFF		
	SW1-2	Heat pump maximum outlet water temperature	55°C	60°C	ON *1		
	SW1-3	DHW tank	WITHOUT DHW tank	WITH DHW tank	OFF		
	SW1-4	Immersion heater	WITHOUT Immersion heater	WITH Immersion heater	OFF		
	SW1-5	Booster heater	WITHOUT Booster heater	WITH Booster heater	OFF: E***-M°C ON : E***-M2/6/9C		
	SW1-6	Booster heater function	For heating only	For heating and DHW	OFF: E***-M°C ON : E***-M2/6/9C		
	SW1-7	Outdoor unit type	Split type	Packaged type	OFF: E*S*-M°C ON : EHPX-*M°C		
	SW1-8	Wireless remote controller	WITHOUT Wireless remote controller	WITH Wireless remote controller	OFF		
SW2	SW2-1	Room thermostat1 input (IN1) logic change	Zone1 operation stop at thermostat short	Zone1 operation stop at thermostat open	OFF		
	SW2-2	Flow switch1 input (IN2) logic change	Failure detection at short	Failure detection at open	OFF		
	SW2-3	Booster heater capacity restriction	Inactive	Active	OFF: Except E***-VM2°C ON : E***-VM2°C		
	SW2-4	Cooling mode function	Inactive	Active	OFF: Except ERS*-*M**C ON : ERS*-*M**C		
	SW2-5	Automatic switch to backup heat source operation (When outdoor unit stops by error)	Inactive	Active *2	OFF		
	SW2-6	Mixing tank	WITHOUT Mixing tank	WITH Mixing tank	OFF		
	SW2-7	2-zone temperature control	Inactive	Active *3	OFF		
	SW2-8	Flow sensor	WITHOUT Flow sensor	WITH Flow sensor	ON		
SW3	SW3-1	Room thermostat 2 input (IN6) logic change	Zone2 operation stop at thermostat short	Zone2 operation stop at thermostat open	OFF		
	SW3-2	Flow switch 2 input (IN3) logic change	Failure detection at short	Failure detection at open	OFF		
	SW3-3	Flow switch 3 input (IN7) logic change	Failure detection at short	Failure detection at open	OFF		
	SW3-4	Electric energy meter	WITHOUT Electric energy meter	WITH Electric energy meter	OFF		
	SW3-5	Heating mode function *4	Inactive	Active	ON		
	SW3-6	2-zone valve ON/OFF control	Inactive	Active	OFF		
	SW3-7	Heat exchanger for DHW	Coil in tank	External plate HEX	OFF		
	SW3-8	Heat meter	WITHOUT Heat meter	WITH Heat meter	OFF		
SW4	SW4-1	Multiple outdoor units control	Inactive	Active	OFF		
	SW4-2	Position of multiple outdoor units control *5	Slave	Master	OFF		
	SW4-3	—	—	—	OFF		
	SW4-4	Indoor unit only operation (during installation work) *6	Inactive	Active	OFF		
	SW4-5	Emergency mode (Heater only operation)	Normal	Emergency mode (Heater only operation)	OFF *7		
	SW4-6	Emergency mode (Boiler operation)	Normal	Emergency mode (Boiler operation)	OFF *7		
SW5	SW5-1	DHW tank water temperature over heat protection (L4)	Active	Inactive *8	OFF		
	SW5-2	Advanced auto adaptation *9	Inactive	Active	OFF: Other than R1/R2 models ON: R1/R2 models		
	SW5-3	Capacity code					
	SW5-4		SW5-3	SW5-4	SW5-5	SW5-6	SW5-7
	SW5-5	E*SC-*M°C	ON	ON	ON	ON	OFF
	SW5-6	E*SD-*M°C	ON	OFF	OFF	ON	OFF
	SW5-7	EHPX-*M°C	OFF	OFF	OFF	OFF	OFF
	SW5-8	—	—	—	—	—	OFF

### Notes:

- \*1. When the hydrobox is connected with a PUHZ-RP/SUHZ-SW outdoor unit of which maximum outlet water temperature is 55°C, DIP SW1-2 must be changed to OFF.
- \*2. OUT11 will be available. For safety reasons, this function is not available for certain errors. (In that case, system operation must be stopped and only the water circulation pump keeps running.)
- \*3. Active only when SW3-6 is set to OFF.
- \*4. This switch functions only when the hydrobox is connected with a PUHZ-FRP outdoor unit. When another type of outdoor unit is connected, the heating mode function is active regardless of the fact that this switch is ON or OFF.
- \*5. Active only when SW4-1 is set to ON.
- \*6. Space heating and DHW can be operated only in indoor unit, like an electric boiler. (Refer to "Indoor unit only operation" in page 53.)
- \*7. If emergency mode is no longer required, return the switch to OFF position.
- \*8. Please make sure to have necessary overheat protection on locally supplied solar thermal system side to secure safety, as the tank temperature could be much higher (than current).
- \*9. SW5-2, "Advanced auto adaptation" is available only for R1 and R2 models.

## Automatic switch to heat source only operation

Back-up heat source operation (\*1) will automatically run when the outdoor unit stops abnormally. To enable the function, switch DIP SW 2-5 to ON. During the back-up operation, an error code(s) and the contact number will be displayed alternately. External output (OUT11) will be available. To clear the fault(s), reset the power breakers on the indoor and outdoor units.

<Applicable error codes (\*2)>

E6 to E9, ED, P6, P8, U1 to U8, UD, UE, UF, UL, UP


(\*1) Prolonged running of the back-up operation may affect the life of the heat source.

(\*2) For safety reasons, this function is not available for certain faults. (System operation must be stopped and only pump keeps running.)

Breaker abbreviation	Meaning
ECB1	Earth leakage circuit breaker for booster heater
TB1	Terminal block 1

Option 1: Hydrobox powered via outdoor unit  
**<1 phase>**

Affix label A that is included with the manuals near each wiring diagram for hydrobox and outdoor units.




\*1 If the installed earth leakage circuit breaker does not have an over-current protection function, install a breaker with that function along the same power line.  
 \*2 A breaker with at least 3.0 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).  
 The breaker shall be provided to ensure disconnection of all active phase conductors of the supply.

Description	Power supply	Capacity	Breaker	Wiring
Booster heater (Primary circuit)	~N 230 V	2 kW	16 A *2	2.5 mm <sup>2</sup>
	50 Hz	6 kW	32 A *2	6.0 mm <sup>2</sup>

<Figure 7-1>  
 Electrical connections 1 phase

**<3 phase>**

Affix label A that is included with the manuals near each wiring diagram for hydrobox and outdoor units.



\*1 If the installed earth leakage circuit breaker does not have an over-current protection function, install a breaker with that function along the same power line.  
 \*2 A breaker with at least 3.0 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).  
 The breaker shall be provided to ensure disconnection of all active phase conductors of the supply.

Description	Power supply	Capacity	Breaker	Wiring
Booster heater (Primary circuit)	3~ 400 V 50 Hz	9 kW	16 A *2	2.5 mm <sup>2</sup>
	3~ 230 V 50 Hz	9 kW	32 A *2	6.0 mm <sup>2</sup>

<Figure 7-2>  
 Electrical connections 3 phase

Wiring No. x size (mm <sup>2</sup> )	Hydrobox - Outdoor unit	*3	3 × 1.5 (polar)
	Hydrobox - Outdoor unit earth	*3	1 × Min. 1.5
Circuit rating	Hydrobox - Outdoor unit S1 - S2	*4	230 V AC
	Hydrobox - Outdoor unit S2 - S3	*4	24 V DC

\*3 Maximum 45 m  
 If 2.5 mm<sup>2</sup> is used, maximum 50 m.  
 If 2.5 mm<sup>2</sup> is used and S3 is separated, maximum 80 m.  
 \*4 The values given in the table above are not always measured against the ground value.

- Notes:**
1. Wiring size must comply with the applicable local and national codes.
  2. Indoor unit/outdoor unit connecting cords shall not be lighter than polychloroprene sheathed flexible cord. (Design 60245 IEC 57)  
 Indoor unit power supply cords shall not be lighter than polychloroprene sheathed flexible cord. (Design 60227 IEC 53)
  3. Install an earth longer than other cables.
  4. Please keep enough output capacity of power supply for each heater. Insufficient power supply capacity might cause chattering.


### Option2: Hydrobox powered by independent source

If the hydrobox and outdoor units have separate power supplies, the following requirements MUST be carried out:

- Change connector connections in hydrobox control and electrical box (see Figure 7-3).
  - Turn the outdoor unit DIP switch SW8-3 to ON.
  - Turn on the outdoor unit BEFORE the hydrobox.
  - Power by independent source is not available for particular models of outdoor unit model.
- For more detail, refer to the connecting outdoor unit installation manual.

#### <1 phase>


Affix label B that is included with the manuals near each wiring diagram for hydrobox and outdoor units.



<Figure 7-4>  
Electrical connections 1 phase

#### <3 phase>


Affix label B that is included with the manuals near each wiring diagram for hydrobox and outdoor units.



<Figure 7-5>  
Electrical connections 3 phase

Hydrobox power supply		~N 230 V 50 Hz
Hydrobox input capacity		16 A
Main switch (Breaker)	*2	16 A
Wiring No. x size (mm <sup>2</sup> )	Hydrobox power supply	2 × Min. 1.5
	Hydrobox power supply earth	1 × Min. 1.5
	Hydrobox - Outdoor unit	*3 2 × Min. 0.3
	Hydrobox - Outdoor unit earth	—
Circuit rating	Hydrobox L - N	*4 230 V AC
	Hydrobox - Outdoor unit S1 - S2	*4 —
	Hydrobox - Outdoor unit S2 - S3	*4 24 V DC

- Notes:
1. Wiring size must comply with the applicable local and national codes.
  2. Indoor unit/outdoor unit connecting cords shall not be lighter than polychloroprene sheathed flexible cord. (Design 60245 IEC 57)  
Indoor unit power supply cords shall not be lighter than polychloroprene sheathed flexible cord. (Design 60227 IEC 53)
  3. Install an earth longer than other cables.
  4. Please keep enough output capacity of power supply for each heater. Insufficient power supply capacity might cause chattering.



<Figure 7-3>

- \*1 If the installed earth leakage circuit breaker does not have an over-current protection function, install a breaker with that function along the same power line.  
\*2 A breaker with at least 3.0 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).  
The breaker shall be provided to ensure disconnection of all active phase conductors of the supply.


Description	Power supply	Capacity	Breaker	Wiring
Booster heater (Primary circuit)	~N 230 V 50 Hz	2 kW	16 A *2	2.5 mm <sup>2</sup>
		6 kW	32 A *2	6.0 mm <sup>2</sup>

- \*1 If the installed earth leakage circuit breaker does not have an over-current protection function, install a breaker with that function along the same power line.  
\*2 A breaker with at least 3.0 mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).  
The breaker shall be provided to ensure disconnection of all active phase conductors of the supply.


Description	Power supply	Capacity	Breaker	Wiring
Booster heater (Primary circuit)	3~ 400 V 50 Hz	9 kW	16 A *2	2.5 mm <sup>2</sup>
		3~ 230 V 50 Hz	9 kW	32 A *2

\*3 Maximum 120 m

\*4 The values given in the table above are not always measured against the ground value.



<Figure 8-1> Water system diagram for Split model



<Figure 8-2> Water system diagram for Packaged model

Notes:

- Be sure to follow your local regulations to perform system configuration of the DHW connections.
- DHW connections are not included in the hydrobox package. All required parts are to be sourced locally.
- To enable draining of the hydrobox an isolating valve should be positioned on both the inlet and outlet pipework.
- Be sure to install a strainer on the inlet pipe work to the hydrobox.
- Suitable drain pipe work should be attached to pressure relief valves, in accordance with local regulations, with the exception of 5bar PRV located next to the expansion vessel.
- The outlet for the 5bar PRV should be open ended and facing the rear panel. Nothing should be placed below the Hydrobox.
- A backflow prevention device must be installed on water supply pipework (IEC 61770).
- When using components made from different metals or connecting pipes made of different metals insulate the joints to prevent a corrosive reaction taking place which will damage the pipework.

\*1 Refer to the following section [Local system].

No.	Part name	EHS*-MEC	EHSD-MC	EHS*-M*C	EHSC-*M*EC	ERS*-VM2C	ERSC-MEC	EHPX-*M*C
1	Control and electrical box	✓	✓	✓	✓	✓	✓	✓
2	Main remote controller	✓	✓	✓	✓	✓	✓	✓
3	Plate heat exchanger (Refrigerant - Water)	✓	✓	✓	✓	✓	✓	-
4	Water circulation pump 1	✓	✓	✓	✓	✓	✓	✓
5	Pump valve	✓	✓	✓	✓	✓	✓	✓
6	Drain cock (Primary circuit)	✓	✓	✓	✓	✓	✓	✓
7	Booster heater 1, 2	-	-	✓	✓	✓	-	✓
8	Flow sensor	✓	✓	✓	✓	✓	✓	✓
9	Manometer	✓	✓	✓	✓	✓	✓	✓
10	Pressure relief valve (3 bar)	✓	✓	✓	✓	✓	✓	✓
11	Automatic air vent	✓	✓	✓	✓	✓	✓	✓
12	Expansion vessel	-	✓	✓	-	✓	-	✓
13	Strainer valve	✓	✓	✓	✓	✓	✓	✓
14	Drain pan	-	-	-	-	✓	✓	-
15	THW1	✓	✓	✓	✓	✓	✓	✓
16	THW2	✓	✓	✓	✓	✓	✓	✓
17	TH2	✓	✓	✓	✓	✓	✓	-
18	THW5 (Optional part PAC-TH011TK-E or PAC-TH011TKL-E)	-	-	-	-	-	-	-
19	Outdoor unit	-	-	-	-	-	-	-
20	Drain pipe (Local supply)	-	-	-	-	-	-	-
21	3-way valve (Local supply)	-	-	-	-	-	-	-
22	DHW indirect unvented tank (Local supply)	-	-	-	-	-	-	-
23	Cold water inlet pipe (Local supply)	-	-	-	-	-	-	-
24	DHW outlet pipe (Local supply)	-	-	-	-	-	-	-
25	Back flow prevention device (Local supply)	-	-	-	-	-	-	-
26	Isolating valve (Local supply)	-	-	-	-	-	-	-
27	Magnetic filter (Local supply) (Recommended)	-	-	-	-	-	-	-
28	Strainer (Local supply)	-	-	-	-	-	-	-
29	Pressure relief valve (5 bar)	-	✓ *1	✓ *1	-	✓ *1	-	✓ *1


\*1 Only E\*\*\*-M\*CR3.UK model

<Table 8-1>




## Local system


### 1-zone temperature control




### 2-zone temperature control




### 1-zone temperature control with boiler



### 2-zone temperature control with boiler



### 1-zone temperature control (2-zone valve ON/OFF control)



- 1. Zone1 heat emitters (e.g. radiator, fan coil unit) (local supply)
- 2. Mixing tank (local supply)
- 3. Zone1 flow water temp. thermistor (THW6)
- 4. Zone1 return water temp. thermistor (THW7)
- 5. Zone1 water circulation pump (local supply)
- 6. Zone1 flow switch (local supply) \*1
- 7. Motorized mixing valve (local supply)
- 8. Zone2 flow water temp. thermistor (THW8)
- 9. Zone2 return water temp. thermistor (THW9)

} Optional part :  
PAC-TH011-E

} Optional part :  
PAC-TH011-E

- 10. Zone2 water circulation pump (local supply)
- 11. Zone2 flow switch (local supply) \*1
- 12. Zone2 heat emitters (e.g. underfloor heating) (local supply)
- 13. Boiler flow water temp. thermistor (THWB1)
- 14. Boiler return water temp. thermistor (THWB2)
- 15. Boiler (local supply)
- 16. Zone1 2-way valve (local supply)
- 17. Zone2 2-way valve (local supply)
- 18. Bypass valve (local supply)

} Optional part :  
PAC-TH011HT-E


\*1 Flow switch specifications: 12 V DC / 1 mA / Both normally-open and normally-closed types can be used. (Set DIP switch 3 to select the logics. Refer to "6-16. DIP switch functions".)

## Filling the System (Primary Circuit)

1. Check and charge expansion vessel.
2. Check all connections including factory fitted ones are tight.
3. Insulate pipe work between hydrobox and outdoor unit.
4. Thoroughly clean and flush, system of all debris. (Refer to 4.2 in the installation manual.)
5. Fill primary heating circuit with water and suitable anti-freeze and inhibitor as necessary. **Always use a filling loop with double check valve when filling the primary circuit to avoid back flow contamination of water supply.**

- Anti-freeze should always be used for package systems. It is the responsibility of the installer to decide if anti-freeze solution should be used in split systems depending on each site's conditions. Corrosion inhibitor should be used in both split and package systems. Figure below shows freezing temperature against anti-freeze concentration. This figure is an example for FERNOX ALPHI-11. For other anti-freeze, please refer to relevant manual.
- When connecting metal pipes of different materials insulate the joints to prevent a corrosive reaction taking place which will damage the pipework.

6. Check for leaks. If leaks are found, retighten the screws on the connections.
7. Pressurise system to 1 bar.
8. Release all trapped air using air vents during and following heating period.
9. Top up with water as necessary. (If pressure falls below 1 bar)




## Draining the Hydrobox

### WARNING: DRAINED WATER MAY BE VERY HOT

1. Before attempting to drain the hydrobox, isolate from the electrical supply to prevent booster heater burning out.
2. Isolate hydrobox from primary water circuit and drain water from hydrobox. Use a suitable heat resistant hose to assist in these operations.
3. Drain any remaining water from booster heater using fitted drain cock and hose, and the drain valve on the primary circuit to safely drain the unit.
4. After the hydrobox is drained, water remains in the following component parts. Drain water completely by checking the inside of the parts.
  - Strainer (Remove the strainer cover.)
  - Pressure relief valve (Operate the valve.)

9-1. Main remote controller




<Main remote controller parts>

Letter	Name	Function
A	Screen	Screen in which all information is displayed
B	Menu	Access to system settings for initial set up and modifications.
C	Back	Return to previous menu.
D	Confirm	Used to select or save. (Enter key)
E	Power/Holiday	If system is switched off pressing once will turn system on. Pressing again when system is switched on will enable Holiday Mode. Holding the button down for 3 seconds will turn the system off. (*1)
F1-4	Function keys	Used to scroll through menu and adjust settings. Function is determined by the menu screen visible on screen A.

\*1

When the system is switched off or the power supply is disconnected, the hydrobox protection functions (e.g. freeze stat. function) will NOT operate. Please beware that without these safety functions enabled the hydrobox may potentially become exposed to damage.

<Main screen icons>



Icon	Description
1	Legionella prevention When this icon is displayed 'Legionella prevention mode' is active.
2	Heat pump <ul style="list-style-type: none"> <li>Heat pump is running.</li> <li>Defrosting</li> <li>Emergency heating</li> </ul>
3	Electric heater When this icon is displayed the 'Electric heaters' (booster or immersion heater) are in use.
4	Target temperature <ul style="list-style-type: none"> <li>Target flow temperature</li> <li>Target room temperature</li> <li>Compensation curve</li> </ul>
5	OPTION Pressing the function button below this icon will display the option screen.
6	+ Increase desired temperature.
7	- Decrease desired temperature.
8	Z1 Z2 Pressing the function button below this icon switches between Zone1 and Zone2. Information Pressing the function button below this icon displays the information screen.
9	Space heating/cooling mode <ul style="list-style-type: none"> <li>Heating mode Zone1 or Zone2</li> <li>Cooling mode Zone1 or Zone2</li> </ul>
10	DHW mode Normal or ECO mode
11	Holiday mode When this icon is displayed 'Holiday mode' activated.
12	<ul style="list-style-type: none"> <li>Timer</li> <li>Prohibited</li> <li>Server control</li> <li>Stand-by</li> <li>Stand-by (*2)</li> <li>Stop</li> <li>Operating</li> </ul>
13	Current temperature <ul style="list-style-type: none"> <li>Current room temperature</li> <li>Current water temperature of DHW tank</li> </ul>
14	The Menu button is locked or the switching of the operation modes between DHW and Heating operations are disabled in the Option screen. (*3)
15	<ul style="list-style-type: none"> <li>SD memory card is inserted. Normal operation.</li> <li>SD memory card is inserted. Abnormal operation.</li> </ul>

\*2 This unit is in Stand-by whilst other indoor unit(s) is in operation by priority.

\*3 To lock or unlock the Menu, press the BACK and CONFIRM keys simultaneously for 3 seconds.

## 9-2. Setting the Main remote controller

After the power has been connected to the outdoor and hydrobox (See "7. FIELD WIRING") the initial system settings can be entered via the main remote controller.

1. Check all breakers and other safety devices are correctly installed and turn on power to the system.
2. When the main remote controller is switched on for the first time, the screen automatically goes to Initial settings menu, Language setting screen and Date/Time setting screen in order.
3. Main remote controller will automatically start up. Wait approximately 6 minutes whilst the control menus load.
4. When the controller is ready, a blank screen with a line running across the top will be displayed.
5. Press button E (Power) (refer to page 34) to turn on the system. Before turning on the system, perform initial settings as instructed below.

## 9-3. Main Settings Menu

The main settings menu can be accessed by pressing the MENU button. To reduce the risk of untrained end users altering the settings accidentally, there are 2 access levels to the main settings; and the service section menu is password protected.

### User Level – Short press

If the MENU button is pressed once for a short time, the main settings will be displayed but without the edit function. This will enable the user to view current settings but **NOT** change the parameters.


### Installer Level – Long press

If the MENU button is pressed down for 3 seconds, the main settings will be displayed with all functionality available.


The color of ◀▶ buttons is inverted as per right figure.

The following items can be viewed and/or edited (dependent on access level).

- Domestic Hot water (DHW)
- Heating/Cooling
- Schedule timer
- Holiday mode
- Initial settings
- Service (Password protected)




Main menu



## General Operation

- To find the icon that you wish to set, use the F2 and F3 buttons to move between the icons.
- The highlighted icon will appear as a larger version of the center of the screen.
- Press CONFIRM to select and edit the highlighted mode.
- Follow the <Main remote controller Menu Tree> for further setting, using ◀▶ buttons for scrolling or F1 to F4 for selecting.

<Main remote controller Menu Tree>




— Unrestricted access  
 - - - - Installer only  
 Shaded items relate to DHW functions. These are only available if the system includes a DHW tank.  
 ◻ ◯ Long press

<Continued to next page.>

<Continued from the previous page.>

<Main remote controller Menu Tree>



— Unrestricted access  
 - - - - - Installer only  
 ■ Shaded items relate to DHW functions. These are only available if the system includes a DHW tank.

□ Long press

\*1 For more details, refer to the installation manual of PAC-TH011HT-E.

## 9-4. Service Menu

The service menu provides functions for use by installer or service engineer. It is NOT intended the home owner alters settings within this menu. It is for this reason password protection is required to prevent unauthorised access to the service settings.

The factory default password is "0000".

Follow the procedure described in General Operation for the set up operation.

The service menu is navigated using the F1 and F2 buttons to scroll through the functions. The menu is split across 2 screens and is comprised of the following functions;

1. Manual operation
2. Function settings
3. Thermistor adjustment
4. Auxiliary settings
5. Heat source setting
6. Pump speed
7. Operation settings
8. Energy monitor settings
9. External input settings
10. Running information
11. Thermistor reading
12. Summary of settings
13. Error history
14. Password protection
15. Manual reset
16. SD card

Many functions cannot be set whilst the indoor unit is running. The installer should turn off the unit before trying to set these functions. If the installer attempts to change the settings whilst the unit is running, the main remote controller will display a reminder message prompting the installer to stop operation before continuing. By selecting "Yes", the unit will cease operation.

### <Manual operation>


During the filling of the system the water circulation pump and 3-way valve can be manually overridden using manual operation mode.

When manual operation is selected a small timer icon appears in the screen.

The function selected will only remain in manual operation for a maximum of 2 hours. This is to prevent accidental permanent override of the FTC.

#### ► Example

Pressing F3 button will switch manual operation mode ON for the main 3-way valve. When filling of the DHW tank is complete the installer should access this menu again and press F3 to deactivate manual operation of the part. Alternatively after 2 hours manual operation mode will no longer be active and FTC will resume control of the part.



Manual operation menu screen

Manual operation and heat source setting cannot be selected if the system is running. A screen will be displayed asking the installer to stop the system before these modes can be activated. The system automatically stops 2 hours after the last operation.

### <Function settings>

Function Setting allows the setting of auto recovery after power failure and of smart grid ready.



1. From the service menu use F1 and F2 to highlight Function Setting.
2. Press CONFIRM.
3. Ensure the Ref address and unit number are displayed to the right.
4. Press CONFIRM.
5. Use F3 and F4 to highlight either 1/2/3 (see below).
6. Press CONFIRM.

Setting	Unit	Mode	Number
Auto recovery after power failure	Grp	Mode1	1 - Inactive 2 - Active *1 3 - NO FUNCTION
Smart grid ready *2 (Hot water operation)	1	Mode7 *3	1 - Inactive 2 - Target temp. +3°C 3 - Target temp. +5°C
Smart grid ready *2 (Heating operation)	1	Mode8 *3	1 - Inactive 2 - Thermo ON temp. +2°C 3 - Thermo ON temp. +3°C

\*1 Approx. 4-minute delay after power is restored.

\*2 Refer to "Smart grid ready" in the indoor unit installation manual.


\*3 If the mode is not displayed, Function Setting must be initialised. Enter Request code "200" in "Running Information".



### <Thermistor adjustment>

This function allows adjustments to be made to the thermistor readings from -10 to 10°C in 0.5°C intervals.

- THW1: Thermistor (Flow water temp.)
- THW2: Thermistor (Return water temp.)
- THW5: Thermistor (DHW tank water temp.)(Option)
- THW6: Thermistor (Zone1 flow temp.)(Option)
- THW7: Thermistor (Zone1 return temp.)(Option)
- THW8: Thermistor (Zone2 flow temp.)(Option)
- THW9: Thermistor (Zone2 return temp.)(Option)
- THWB1: Thermistor (Boiler flow temp.)(Option)
- THWB2: Thermistor (Boiler return temp.)(Option)



### <Auxiliary settings>

This function is used to set the parameters for any auxiliary parts used in the system

Menu subtitle	Function/Description
Economy settings for pump	Water pump stops automatically in certain period of time from when operation is finished.
Delay	Time before pump switched off *1
Electric heater (Heating)	To select "WITH booster heater (ON)" or "WITHOUT booster heater (OFF)" in Heating mode.
Delay	The minimum time required for the booster heater to turn ON from after Heating mode has started.
Electric heater (DHW)	To select "WITH (ON)" or "WITHOUT (OFF)" booster heater or immersion heater individually in DHW mode.
Delay	The minimum time required for the booster heater or immersion heater to turn ON from after DHW mode has started. (This setting is applied for both booster and immersion heater.)
Mixing valve control *2	Period from valve fully open (at a hot water mixing ratio of 100%) to valve fully closed (at a cold water mixing ratio of 100%)
Running Interval	Interval (min.) to control the Mixing valve.
Flow sensor *3	The minimum flow rate to be detected at Flow sensor.
Maximum	The maximum flow rate to be detected at Flow sensor.


\*1 Decreasing "time before pump switched off" may increase the duration of stand-by in Heating/Cooling mode.

\*2 Set the Running time according to the specifications of the actuator of each mixing valve. It is recommended to set the interval to 2 minutes that is a default value. With the interval set longer, it could take longer to warm up a room.

\*3 Do not change the setting since it is set according to the specification of Flow sensor attached to the hydrobox.

#### Economy settings for pump


1. From the Auxiliary settings menu, highlight Economy Settings for water circulation pump.
2. Press CONFIRM.
3. The economy settings for water circulation pump screen is displayed.
4. Use button F1 to switch the economy settings ON/OFF.
5. Use buttons F3 and F4 to adjust the time the water circulation pump will run. (3–60 minutes)



Auxiliary settings menu screen

#### Electric heater (Heating)


1. From the Auxiliary settings menu, highlight Electric heater (Heating).
2. Press CONFIRM.
3. The Electric heater (Heating) screen is displayed.
4. Press F1 button to switch the function ON/OFF.
5. Use F3 and F4 buttons to adjust the time period of heat pump only operation before the booster heater will assist in space heating. (5–180 minutes)




Economy settings for pump screen

#### Electric heater (DHW)

1. From the Auxiliary settings menu, highlight Electric heater (DHW).
2. Press CONFIRM.
3. The Electric heater (DHW) screen is displayed.
4. Press F1 button to switch the function ON/OFF.
5. Use F3 and F4 buttons to adjust the time period of heat pump only operation before the booster heater and the immersion heater (if present) will assist in DHW heating. (15–30 minutes)



Electric heater (Heating) screen



Electric heater (DHW) screen



### Mixing valve control

1. From the Auxiliary settings menu, highlight Mixing valve control.
2. Press CONFIRM.
3. The Mixing valve control screen is displayed.
4. Use F1 and F2 buttons to set Running time between 10 to 240 seconds. The Running time equals to a period from full open of the valve (at a hot water mixing ratio of 100%) to full close (at a cold water mixing ratio of 100%).

**Note: Set the Running time according to the specifications of the actuator of each mixing valve.**

1. From the Auxiliary settings menu, highlight Mixing valve control.
2. Press CONFIRM.
3. The Mixing valve control screen is displayed.
4. Press F3 and F4 buttons to set the interval between 2-zone temperature controls of the mixing valve between 1 to 30 minutes.

**Note: It is recommended to set the interval to 2 minutes that is a default value. With the interval set longer, it could take longer to warm up a room.**




Mixing valve control setting screen

### Flow sensor

1. From the Auxiliary settings menu, highlight Flow sensor.
  2. Press CONFIRM.
  3. Press F3 or F4 buttons to select a refrigerant address of which you wish to configure or check the settings, and press CONFIRM. \*1.
  4. The Flow sensor screen is displayed.
  5. Use F1 and F2 buttons to set the minimum flow rate of flow sensor between 0 to maximum L/min.
  6. Use F1 and F2 buttons to set the maximum flow rate of flow sensor between minimum to 100L/min.
- \*1 For multiple outdoor units control system only.

**Note: Do not change the setting since it is set according to the specification of Flow sensor attached to the hydrobox.**



Flow sensor setting screen

### <Heat source setting>


The default heat source setting is heat pump and all electric heaters present in the system to be operational. This is referred to as Standard operation on the menu.



Heat source setting screen

### <Pump speed>

1. From the Service menu, highlight Pump speed.
  2. Press CONFIRM.
  3. Press F3 and F4 buttons to select a refrigerant address of which you wish to configure or check the settings, and press CONFIRM. \*1
  4. The Pump speed screen is displayed.
  5. Use F2 and F3 buttons to set the pump speed of the water circulation pump between 1 and 5.
- \*1 For multiple outdoor units control system only.



Pump speed setting screen

## <Operation settings>

### Heating operation

This function allows operational setting of flow temperature range from the Ecodan and also the time interval at which the FTC collects and processes data for the auto adaptation mode.

Menu subtitle		Function	Range	Unit	Default
Flow temp. range	Minimum temp.	To minimize the loss by frequent ON and OFF in mild outdoor ambient temperature seasons.	25–45	°C	30
	Maximum temp.	To set max. possible flow temperature according to the type of heat emitters.	35–60	°C	50
Room temp. control	Mode	Setting for Room temp. control At Fast mode, target outlet water temperature is set higher than the one set at normal mode. This reduces the time to reach the target room temperature when the room temperature is relatively low.*1	Normal/ Fast	—	Normal
	Interval	Selectable according to the heat emitter type and the materials of floor (i.e. radiators, floor heating-thick, -thin concrete, wood, etc.)	10–60	min	10
Heat pump thermo diff.adjust	ON/OFF	To minimize the loss by frequent ON and OFF in mild outdoor ambient temperature seasons.	ON/OFF	—	ON
	Lower limit	Prohibits heat pump operation until the flow temperature drops below the target flow temperature plus lower limit value.	-9--1	°C	-5
	Upper limit	Allows heat pump operation until the flow temperature rises above the target flow temperature plus upper limit value.	+3--+5	°C	+5

< Heating operation (Room temp. control table) >

#### Note:

1. The minimum flow temperature that prohibits heat pump operation is 20°C.
2. The maximum flow temperature that allows heat pump operation equals to the maximum temperature set in the Flow temp. range menu.

\*1 Fast mode is not efficient and will increase running cost compared to normal mode.

### Freeze stat function

Menu subtitle	Function/Description
Freeze stat function *2	An operational function to prevent the water circuit from freezing when outdoor ambient temperature drops.
Flow t.	The target outlet water temperature at water circuit when operating in Freeze stat function.*3
Outdoor ambient temp.	Minimum outdoor ambient temperature which freeze stat function will begin to operate, (3–20°C) or choose**. If asterisk (**) is chosen freeze stat function is deactivated. (i.e. primary water freeze risk)

\*2 When the system is turned off, freeze stat function is not enabled.

\*3 Flow t. is fixed to 20°C and unchangeable.

### Simultaneous Operation

For periods of very low outside temperature, this mode can be used. Simultaneous operation allows both DHW and space heating to run together by using the heat pump and/or booster heater to provide space heating whilst only the immersion heater provides heating for DHW. This operation is only available if BOTH a DHW tank AND immersion heater are present on the system.

- Range of outdoor ambient temperature at which simultaneous operation starts is -30 to 10°C (default -15°C).
- System shall automatically return to routine operation. This will happen when the outdoor ambient temperature rises above the selected temperature for this specific mode of operation.

### Cold weather function

For extremely low outdoor ambient temperature conditions when the heat pump's capacity is restricted, the heating or DHW is provided only by the electric booster heater (and immersion if present). This function is intended for use during extreme cold periods only. Extensive use of direct electrical heaters ONLY will result in higher power consumption and may reduce working life of heaters and related parts.


- Range of outdoor ambient temperature at which cold weather function starts is -30 to -10°C (default -15°C).
- System shall automatically return to routine operation. This will happen when the outdoor ambient temperature rises above the selected temperature for this specific mode of operation.

### Floor dry up function

The Floor dry up function automatically changes the target hot water temperature in stages to gradually dry concrete when this particular type of underfloor heating system is installed.


Upon completion of the operation, the system stops all the operations except the Freeze stat. operation.

For Floor dry up function, the target flow temp. of Zone1 is the same as that of Zone2.



- This function is not available when a PUHZ-FRP outdoor unit is connected.
- Disconnect wiring to external inputs of room thermostat, demand control, and outdoor thermostat, or the target flow temperature may not be maintained.

Functions	Symbol	Description	Option/Range	Unit	Default	
Floor dry up function	a	Sets the function to ON and power on the system using the main remote controller, and the dry up heating operation will start.	ON/OFF	—	OFF	
Flow temp. (increase)	Flow temp. increase step	b	Sets the increase step of the target flow temperature.	+1--+10	°C	+5
	Increase interval	c	Sets the period for which the same target flow temperature is maintained.	1–7	day	2
Flow temp. (decrease)	Flow temp. decrease step	d	Sets the decrease step of the target flow temperature.	-1--10	°C	-5
	Decrease interval	e	Sets the period for which the same target flow temperature is maintained.	1–7	day	2
Target temperature	Start & Finish	f	Sets the target flow temperature at the start and the finish of the operation.	25–60	°C	30
	Max. target temp.	g	Sets the maximum target flow temperature.	25–60	°C	45
	Max. temp. period	h	Sets the period for which the maximum target flow temperature is maintained.	1–20	day	5



## <Energy monitor settings>

### 1. General description

End user can monitor accumulated (\*1) 'Consumed electrical energy' and 'Delivered heat energy' in each operation mode (\*2) on the main remote controller.

\*1 Monthly and Year to date

\*2 - DHW operation

- Space heating
- Space cooling

Refer to the menu tree in "9-3. Main Settings Menu" for how to check the energy, and "6-16. DIP switch functions" for the details on DIP-SW setting.

Either one of the following 2 methods is used for monitoring.

**Note: Method 1 should be used as a guide. If a certain accuracy is required, the 2nd method should be used.**

#### (1) Calculation internally [Method 1]

Electricity consumption is calculated internally based on the energy consumption of outdoor unit, electric heater, water pump(s) and other auxiliaries.\*3

Delivered heat is calculated internally by multiplying delta T (Flow and Return temp.) and flow rate measured by the factory fitted sensors.

Set the electric heater capacity and water pump(s) input according to indoor unit model and specs of additional pump(s) supplied locally. (Refer to the menu tree in "9-3. Main Settings Menu")

	Booster heater1	Booster heater2	Immersion heater *1	Pump1 *2	Pump2	Pump3
Default	2 kW	4 kW	0 kW	*** (factory fitted pump)	0 kW	0 kW
EHSD-MEC	0 kW	0 kW	0 kW *1	***	When additional pumps supplied locally are connected as Pump2/3, change setting according to specs of the pumps.	
EHSD-MC	0 kW	0 kW	0 kW *1	***		
EHSD-VM2C	2 kW	0 kW	0 kW *1	***		
EHSD-YM9C	3 kW	6 kW	0 kW *1	***		
EHSC-MEC	0 kW	0 kW	0 kW *1	***		
EHSC-VM2C	2 kW	0 kW	0 kW *1	***		
EHSC-VM2EC	2 kW	0 kW	0 kW *1	***		
EHSC-VM6C	2 kW	4 kW	0 kW *1	***		
EHSC-VM6EC	2 kW	4 kW	0 kW *1	***		
EHSC-YM9C	3 kW	6 kW	0 kW *1	***		
EHSC-YM9EC	3 kW	6 kW	0 kW *1	***		
EHSC-TM9C	3 kW	6 kW	0 kW *1	***		
ERSD-VM2C	2 kW	0 kW	0 kW *1	***		
ERSC-MEC	0 kW	0 kW	0 kW *1	***		
ERSC-VM2C	2 kW	0 kW	0 kW *1	***		
EHPX-VM2C	2 kW	0 kW	0 kW *1	***		
EHPX-VM6C	2 kW	4 kW	0 kW *1	***		
EHPX-YM9C	3 kW	6 kW	0 kW *1	***		

\*1 Change setting to 3 kW when connecting optional immersion heater "PAC-IH03V2-E".

\*2 \*\*\*\*\* displayed in the energy monitor setting mode means the factory fitted pump is connected as Pump 1 so that the input is automatically calculated.

\*3 When the hydrobox is connected with a PUAZ-FRP or PUMY models, electricity consumption is not calculated internally. To display the electricity consumption, conduct the 2nd method.

When anti-freeze solution (propylene glycol) is used for primary water circuit, set the delivered energy adjustment if necessary.

For further detail of above, refer to the menu tree in "9-3. Main Settings Menu".

#### (2) Actual measurement by external meter [Method 2] (locally supplied)

FTC has external input terminals for 2 'Electric energy meters' and a 'Heat meter'.

If two 'Electric energy meters' are connected, the 2 recorded values will be combined at the FTC and shown on the main remote controller.

(e.g. Meter 1 for H/P power line, Meter 2 for heater power line)

Refer to the [Signal inputs] in "6. WIRING DIAGRAM" for more information on connectable electric energy meter and heat meter.

#### • Connectable electric energy meter and heat meter

- Pulse meter type Voltage free contact for 12 V DC detection by FTC (TBI.3 1, 3 and 5 pin have a positive voltage.)
- Pulse duration Minimum ON time: 40 ms  
Minimum OFF time: 100 ms
- Possible unit of pulse 0.1 pulse/kWh    1 pulse/kWh    10 pulse/kWh  
100 pulse/kWh    1000 pulse/kWh

Those values can be set by the main remote controller. (Refer to the menu tree in "9-3. Main Settings Menu".)


### 2. Settings using the main remote controller

In this menu, all parameters required to record the consumed electrical energy and the delivered heat energy which is displayed on the main remote controller can be set. The parameters are an electric heater capacity, supply power of water pump and heat meter pulse.

Follow the procedure described in General Operation for the set up operation.

For Pump 1, \*\*\* can be also set besides this setting.

In the case \*\*\* is selected, the system acknowledges "factory fitted pump" is selected.



Energy monitor settings menu screen


## <External input settings>

### Demand control(IN4)


The selection of "OFF", whilst a signal is being sent to IN4, forcefully stops all the heat source operations and the selection of "Boiler" stops operations of heat pump and electric heater and performs boiler operation.

### Outdoor thermostat (IN5)


The selection of "Heater", whilst a signal is being sent to IN5, performs electric-heater-only operation and the selection of "Boiler" performs boiler operation.



External input settings menu screen



Demand control screen




Outdoor thermostat setting screen

## <Running information>

This function shows current temperature and other data of main component parts of both the indoor and outdoor units.

1. From the Service menu highlight Running information.
2. Press CONFIRM.
3. Press F3 and F4 buttons to set the Ref. address. \*1
4. Use the function buttons to enter index code for the component to be viewed.  
(See the Table 9-4-1 for component index codes.)
5. Press CONFIRM.


\*1 For multiple outdoor units control system only.



## <Thermistor reading>

This function shows the current readings of thermistors located on the water and refrigerant circuit


Thermistor	Description	Thermistor	Description
TH1A	Zone1 room temperature	THW6	Zone1 flow water temperature
TH1B	Zone2 room temperature	THW7	Zone1 return water temperature
TH2	Refrigerant return temperature	THW8	Zone2 flow water temperature
THW1	Water flow temperature	THW9	Zone2 return water temperature
THW2	Water return temperature	THWB1	Boiler flow water temperature
THW5	DHW tank water temperature	THWB2	Boiler return water temperature
TH7	Ambient (outdoor) temperature		



### <Summary of settings>

This function shows the current installer/user entered settings.

Abbreviation	Explanation	Abbreviation	Explanation
<b>HWtemp</b>	DHW max temperature	<b>Z2 mode</b>	Operation mode
<b>HWdrop</b>	DHW temperature drop		- HER (Heating room temperature)
<b>HWtime</b>	DHW max operation time		- HE (Heating flow temperature)
<b>NO HW</b>	DHW mode restriction		- HCC (Heating compensation curve)
<b>HWset</b>	DHW operation mode (Normal/Eco)		- COR (—)
			- CO (Cooling flow temperature)
<b>Ltemp</b>	Legionella hot water temperature	<b>Hroom 1</b>	Heating target room temperature
<b>Lfreq</b>	Legionella operation Frequency	<b>Hroom 2</b>	Heating target room temperature
<b>Lstart</b>	Legionella mode start time	<b>Hflow 1</b>	Heating target flow temperature
<b>Ltime</b>	Legionella max operation time	<b>Hflow 2</b>	Heating target flow temperature
<b>Lkeep</b>	Duration of max (Legionella) hot water temperature	<b>Croom 1</b>	Cooling target room temperature
		<b>Croom 2</b>	Cooling target room temperature
<b>Z1 mode</b>	Operation mode	<b>Cflow 1</b>	Cooling target flow temperature
	- HER (Heating room temperature)	<b>Cflow 2</b>	Cooling target flow temperature
	- HE (Heating flow temperature)	<b>FSflow</b>	Freeze stat function flow temperature
	- HCC (Heating compensation curve)	<b>FSout</b>	Freeze stat function ambient temperature
	- COR (—)		
	- CO (Cooling flow temperature)		





### <Error history>

Error history allows the service engineer to view previous Error codes, the unit address and the date on which they occurred. Up to 16 Error codes can be stored in the history and the most recent Error event is displayed at the top of the list.

1. From the service menu, select Error history
  2. Press CONFIRM.
- Please see "10-4. Self diagnosis and action" for error code diagnosis and actions.

To delete an Error history item;

1. From Error history screen, press F4 button (Rubbish bin icon)
2. Then press F3 button (Yes).



### <Password protection>

Password protection is available to prevent unauthorised access to the service menu by untrained persons.

1. From the service menu, use F1 and F2 buttons to scroll through list until Password protection is highlighted.
2. Press CONFIRM.
3. When password input screen is displayed, use buttons F1 and F2 to move left and right between the 4 digits, F3 to lower the selected digit by 1, and F4 to increase the selected digit by 1.
4. When you have input your password, press CONFIRM.
5. The password verify screen is displayed.
6. To verify your new password, press button F3.
7. Your password is now set and the completion screen is displayed.



Password input screen



Password verify screen

### Resetting the password

If you forget the password you entered, or have to service a unit somebody else installed, you can reset the password to the factory default of **0000**.

1. From the main settings menu, scroll down the functions until Service Menu is highlighted.
2. Press CONFIRM.
3. You will be prompted to enter a password.
4. Hold down buttons F3 and F4 together for 3 seconds.
5. You will be asked if you wish to continue and reset the password to default setting.
6. To reset press button F3.
7. The password is now reset to **0000**.





Completion screen

### <Manual reset>

Should you wish to restore the factory settings at any time, you should use the manual reset function. Please note this will reset ALL functions to the factory default settings.

1. From the service menu, use F1 and F2 buttons to scroll through list until Manual Reset is highlighted.
  2. Press CONFIRM.
  3. The Manual reset screen is displayed.
  4. Choose either Manual Reset for FTC or Main remote controller.
5. Press F3 button to confirm manual reset of chosen device.





### <SD card>

The use of an SD memory card simplifies the main remote controller settings in the field.

\*Ecodan service tool (for use with PC tool) is necessary for the setting.


#### SD → Main RC

1. From the SD card setting, use F1 and F2 buttons to scroll through list until "SD → Main RC" is highlighted.
  2. Press CONFIRM.
  3. Press F3 and F4 buttons to set the Ref. address. \*1
  4. Use F1, F2 and F3 buttons to select a menu to write to the main remote controller.
  5. Press CONFIRM to start downloading.
  6. Wait for a few minutes until "Complete!" appears.
- \*1 For multiple outdoor units control system only.



#### Main RC → SD

1. From the SD card setting, use F1 and F2 buttons to scroll through list until Main RC → SD is highlighted.
  2. Press CONFIRM.
  3. Press F3 and F4 buttons to set the Ref. address. \*1
  4. Use F1, F2 and F3 buttons to select a menu to write to the SD memory card.
  5. Press CONFIRM to start uploading.
  6. Wait for a few minutes until "Complete!" appears.
- \*1 For multiple outdoor units control system only.



<Table 9-4-1> Request code in running information

Request code	Request content	Range	Unit
103	Error history 1 (latest)	Displays error history. ("--" is displays if no history is present.)	Code
104	Error history 2 (second to last)	Displays error history. ("--" is displays if no history is present.)	—
105	Error history 3 (third to last)	Displays error history. ("--" is displays if no history is present.)	—
154	Water circulation pump 1 - Accumulated operating time (after reset)	0-9999	10 hours
156	Water circulation pump 2 - Accumulated operating time (after reset)	0-9999	10 hours
157	Water circulation pump 3 - Accumulated operating time (after reset)	0-9999	10 hours
158	Water circulation pump 4 - Accumulated operating time (after reset)	0-9999	10 hours
162	Indoor unit - DIP SW1 setting information	Refer to detail contents described hereinafter.	—
163	Indoor unit - DIP SW2 setting information	Refer to detail contents described hereinafter.	—
164	Indoor unit - DIP SW3 setting information	Refer to detail contents described hereinafter.	—
165	Indoor unit - DIP SW4 setting information	Refer to detail contents described hereinafter.	—
166	Indoor unit - DIP SW5 setting information	Refer to detail contents described hereinafter.	—
175	Indoor unit - Output signal information	Refer to detail contents described hereinafter.	—
176	Indoor unit - Input signal information	Refer to detail contents described hereinafter.	—
177	Mixing valve opening step	0-10	Step
190	Indoor unit - Software version 1st 4 digits	Refer to Note below.	—
191	Indoor unit - Software version last 4 digits	Refer to Note below.	—
200	Initialisation of Function Setting	—	—
340	Water circulation pump 1 - Accumulated operating time reset	—	—
342	Water circulation pump 2 - Accumulated operating time reset	—	—
343	Water circulation pump 3 - Accumulated operating time reset	—	—
344	Water circulation pump 4 - Accumulated operating time reset	—	—
504	Indoor unit - Zone1 room temp. (TH1A)	-39- +88	°C
505	Indoor unit - Ref. liquid temp. (TH2)	-39- +88	°C
506	Indoor unit - Return water temp. (THW2)	-39- +88	°C
507	Indoor unit - Zone2 room temp. (TH1B)	-39- +88	°C
508	Indoor unit - DHW tank water temp. (THW5)	-39- +88	°C
509	Indoor unit - Zone1 flow water temp. (THW6)	-39- +88	°C
510	Indoor unit - Outside air temp. (TH7)	-39- +88	°C
511	Indoor unit - Flow water temp. (THW1)	-39- +88	°C
512	Indoor unit - Zone1 return water temp. (THW7)	-39- +88	°C
513	Indoor unit - Zone2 flow water temp. (THW8)	-39- +88	°C
514	Indoor unit - Zone2 return water temp. (THW9)	-39- +88	°C
515	Indoor unit - Boiler flow water temp. (THWB1)	-40- +140	°C
516	Indoor unit - Boiler return water temp. (THWB2)	-40- +140	°C
540	Flow rate of the primary circuit	0-100	L/min
550	Indoor unit - Error postponement history 1 (latest)	Displays postponement code. ("--" is displays if no postponement code is present.)	—
551	Indoor unit - Operation control at time of error	0 Standard, 1 Heater, 2 Boiler	—
552	Indoor unit - Operation mode at time of error	0: OFF, 1: DHW, 2 :Heating, 3: Cooling, 4: Legionella prevention,5: Freeze protection, 6: Operation stop, 7: Defrost	—
553	Indoor unit - Output signal information at time of error	Refer to detail contents described hereinafter.	—
554	Indoor unit - Input signal information at time of error	Refer to detail contents described hereinafter.	—
555	Indoor unit - Zone1 room temp. (TH1A) at time of error	-39- +88	°C
556	Indoor unit - Zone2 room temp. (TH1B) at time of error	-39- +88	°C
557	Indoor unit - Ref. liquid temp. (TH2) at time of error	-39- +88	°C
558	Indoor unit - Flow water temp. (THW1) at time of error	-39- +88	°C
559	Indoor unit - Return water temp. (THW2) at time of error	-39- +88	°C
560	Indoor unit - DHW tank water temp. (THW5) at time of error	-39- +88	°C
561	Indoor unit - Zone1 flow water temp. (THW6) at time of error	-39- +88	°C
562	Indoor unit - Zone1 return water temp. (THW7) at time of error	-39- +88	°C
563	Indoor unit - Zone2 flow water temp. (THW8) at time of error	-39- +88	°C
564	Indoor unit - Zone2 return water temp. (THW9) at time of error	-39- +88	°C
565	Indoor unit - Boiler flow water temp. (THWB1) at time of error	-40- +140	°C
566	Indoor unit - Boiler return water temp. (THWB2) at time of error	-40- +140	°C
567	Indoor unit - Failure (P1/P2/L5/L8/Ld) thermistor	0: Failure thermistor is none, 1: TH1A, 2: TH2, 3: THW1, 4: THW2, 5: THWB1, 6: THW5, 7: THWB2, 8: TH1B, A: THW6, B: THW7, C: THW8, D: THW9	—
568	Mixing valve opening step at time of error	0- +10	Step
569	Operated Flow switch at time of failure (L9)	0: No operated flow switch, 1: Flow switch 1, 2: Flow switch 2, 3: Flow switch 3	—
571	Flow rate at time of error	0- +100	L/min

**Note:**

Refer to outdoor unit service manual for request code 0 to 102, 106 to 149.

Request codes 103 to 105 indicate error histories of both indoor and outdoor units.

As only 4 digits can be displayed at one time the software version number is displayed in two halves.

Enter code 190 to see the first 4 digits and code 191 to see the last 4 digits.

For example software version No. 5.01 A000, when code 190 is entered 0501 is displayed, when code 191 is entered A000 is displayed.

Request code 200 resets all Function Setting to the factory default settings.

**Indoor unit switch setting display (Request code: 162 to 166)**

0: OFF 1: ON

SW1, SW2, SW3, SW4, SW5								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	0	0	00 00
1	0	0	0	0	0	0	0	00 01
0	1	0	0	0	0	0	0	00 02
1	1	0	0	0	0	0	0	00 03
0	0	1	0	0	0	0	0	00 04
1	0	1	0	0	0	0	0	00 05
0	1	1	0	0	0	0	0	00 06
1	1	1	0	0	0	0	0	00 07
0	0	0	1	0	0	0	0	00 08
1	0	0	1	0	0	0	0	00 09
0	1	0	1	0	0	0	0	00 0A
1	1	0	1	0	0	0	0	00 0B
0	0	1	1	0	0	0	0	00 0C
1	0	1	1	0	0	0	0	00 0D
0	1	1	1	0	0	0	0	00 0E
1	1	1	1	0	0	0	0	00 0F
0	0	0	0	1	0	0	0	00 10
1	0	0	0	1	0	0	0	00 11
0	1	0	0	1	0	0	0	00 12
1	1	0	0	1	0	0	0	00 13
0	0	1	0	1	0	0	0	00 14
1	0	1	0	1	0	0	0	00 15
0	1	1	0	1	0	0	0	00 16
1	1	1	0	1	0	0	0	00 17
0	0	0	1	1	0	0	0	00 18
1	0	0	1	1	0	0	0	00 19
0	1	0	1	1	0	0	0	00 1A
1	1	0	1	1	0	0	0	00 1B
0	0	1	1	1	0	0	0	00 1C
1	0	1	1	1	0	0	0	00 1D
0	1	1	1	1	0	0	0	00 1E
1	1	1	1	1	0	0	0	00 1F
0	0	0	0	0	1	0	0	00 20
1	0	0	0	0	1	0	0	00 21
0	1	0	0	0	1	0	0	00 22
1	1	0	0	0	1	0	0	00 23
0	0	1	0	0	1	0	0	00 24
1	0	1	0	0	1	0	0	00 25
0	1	1	0	0	1	0	0	00 26
1	1	1	0	0	1	0	0	00 27
0	0	0	1	0	1	0	0	00 28
1	0	0	1	0	1	0	0	00 29
0	1	0	1	0	1	0	0	00 2A
1	1	0	1	0	1	0	0	00 2B
0	0	1	1	0	1	0	0	00 2C
1	0	1	1	0	1	0	0	00 2D
0	1	1	1	0	1	0	0	00 2E
1	1	1	1	0	1	0	0	00 2F
0	0	0	0	1	1	0	0	00 30
1	0	0	0	1	1	0	0	00 31
0	1	0	0	1	1	0	0	00 32
1	1	0	0	1	1	0	0	00 33
0	0	1	0	1	1	0	0	00 34
1	0	1	0	1	1	0	0	00 35
0	1	1	0	1	1	0	0	00 36
1	1	1	0	1	1	0	0	00 37
0	0	0	1	1	1	0	0	00 38
1	0	0	1	1	1	0	0	00 39
0	1	0	1	1	1	0	0	00 3A
1	1	0	1	1	1	0	0	00 3B
0	0	1	1	1	1	0	0	00 3C
1	0	1	1	1	1	0	0	00 3D
0	1	1	1	1	1	0	0	00 3E
1	1	1	1	1	1	0	0	00 3F

0: OFF 1: ON

SW1, SW2, SW3, SW4, SW5								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	1	0	00 40
1	0	0	0	0	0	1	0	00 41
0	1	0	0	0	0	1	0	00 42
1	1	0	0	0	0	1	0	00 43
0	0	1	0	0	0	1	0	00 44
1	0	1	0	0	0	1	0	00 45
0	1	1	0	0	0	1	0	00 46
1	1	1	0	0	0	1	0	00 47
0	0	0	1	0	0	1	0	00 48
1	0	0	1	0	0	1	0	00 49
0	1	0	1	0	0	1	0	00 4A
1	1	0	1	0	0	1	0	00 4B
0	0	1	1	0	0	1	0	00 4C
1	0	1	1	0	0	1	0	00 4D
0	1	1	1	0	0	1	0	00 4E
1	1	1	1	0	0	1	0	00 4F
0	0	0	0	1	0	1	0	00 50
1	0	0	0	1	0	1	0	00 51
0	1	0	0	1	0	1	0	00 52
1	1	0	0	1	0	1	0	00 53
0	0	1	0	1	0	1	0	00 54
1	0	1	0	1	0	1	0	00 55
0	1	1	0	1	0	1	0	00 56
1	1	1	0	1	0	1	0	00 57
0	0	0	1	1	0	1	0	00 58
1	0	0	1	1	0	1	0	00 59
0	1	0	1	1	0	1	0	00 5A
1	1	0	1	1	0	1	0	00 5B
0	0	1	1	1	0	1	0	00 5C
1	0	1	1	1	0	1	0	00 5D
0	1	1	1	1	0	1	0	00 5E
1	1	1	1	1	0	1	0	00 5F
0	0	0	0	0	1	1	0	00 60
1	0	0	0	0	1	1	0	00 61
0	1	0	0	0	1	1	0	00 62
1	1	0	0	0	1	1	0	00 63
0	0	1	0	0	1	1	0	00 64
1	0	1	0	0	1	1	0	00 65
0	1	1	0	0	1	1	0	00 66
1	1	1	0	0	1	1	0	00 67
0	0	0	1	0	1	1	0	00 68
1	0	0	1	0	1	1	0	00 69
0	1	0	1	0	1	1	0	00 6A
1	1	0	1	0	1	1	0	00 6B
0	0	1	1	0	1	1	0	00 6C
1	0	1	1	0	1	1	0	00 6D
0	1	1	1	0	1	1	0	00 6E
1	1	1	1	0	1	1	0	00 6F
0	0	0	0	1	1	1	0	00 70
1	0	0	0	1	1	1	0	00 71
0	1	0	0	1	1	1	0	00 72
1	1	0	0	1	1	1	0	00 73
0	0	1	0	1	1	1	0	00 74
1	0	1	0	1	1	1	0	00 75
0	1	1	0	1	1	1	0	00 76
1	1	1	0	1	1	1	0	00 77
0	0	0	1	1	1	1	0	00 78
1	0	0	1	1	1	1	0	00 79
0	1	0	1	1	1	1	0	00 7A
1	1	0	1	1	1	1	0	00 7B
0	0	1	1	1	1	1	0	00 7C
1	0	1	1	1	1	1	0	00 7D
0	1	1	1	1	1	1	0	00 7E
1	1	1	1	1	1	1	0	00 7F



**Indoor unit switch setting display (Request code: 162 to 166)**

0: OFF 1: ON

SW1, SW2, SW3, SW4, SW5								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	0	1	00 80
1	0	0	0	0	0	0	1	00 81
0	1	0	0	0	0	0	1	00 82
1	1	0	0	0	0	0	1	00 83
0	0	1	0	0	0	0	1	00 84
1	0	1	0	0	0	0	1	00 85
0	1	1	0	0	0	0	1	00 86
1	1	1	0	0	0	0	1	00 87
0	0	0	1	0	0	0	1	00 88
1	0	0	1	0	0	0	1	00 89
0	1	0	1	0	0	0	1	00 8A
1	1	0	1	0	0	0	1	00 8B
0	0	1	1	0	0	0	1	00 8C
1	0	1	1	0	0	0	1	00 8D
0	1	1	1	0	0	0	1	00 8E
1	1	1	1	0	0	0	1	00 8F
0	0	0	0	1	0	0	1	00 90
1	0	0	0	1	0	0	1	00 91
0	1	0	0	1	0	0	1	00 92
1	1	0	0	1	0	0	1	00 93
0	0	1	0	1	0	0	1	00 94
1	0	1	0	1	0	0	1	00 95
0	1	1	0	1	0	0	1	00 96
1	1	1	0	1	0	0	1	00 97
0	0	0	1	1	0	0	1	00 98
1	0	0	1	1	0	0	1	00 99
0	1	0	1	1	0	0	1	00 9A
1	1	0	1	1	0	0	1	00 9B
0	0	1	1	1	0	0	1	00 9C
1	0	1	1	1	0	0	1	00 9D
0	1	1	1	1	0	0	1	00 9E
1	1	1	1	1	0	0	1	00 9F
0	0	0	0	0	1	0	1	00 A0
1	0	0	0	0	1	0	1	00 A1
0	1	0	0	0	1	0	1	00 A2
1	1	0	0	0	1	0	1	00 A3
0	0	1	0	0	1	0	1	00 A4
1	0	1	0	0	1	0	1	00 A5
0	1	1	0	0	1	0	1	00 A6
1	1	1	0	0	1	0	1	00 A7
0	0	0	1	0	1	0	1	00 A8
1	0	0	1	0	1	0	1	00 A9
0	1	0	1	0	1	0	1	00 AA
1	1	0	1	0	1	0	1	00 AB
0	0	1	1	0	1	0	1	00 AC
1	0	1	1	0	1	0	1	00 AD
0	1	1	1	0	1	0	1	00 AE
1	1	1	1	0	1	0	1	00 AF
0	0	0	0	1	1	0	1	00 B0
1	0	0	0	1	1	0	1	00 B1
0	1	0	0	1	1	0	1	00 B2
1	1	0	0	1	1	0	1	00 B3
0	0	1	0	1	1	0	1	00 B4
1	0	1	0	1	1	0	1	00 B5
0	1	1	0	1	1	0	1	00 B6
1	1	1	0	1	1	0	1	00 B7
0	0	0	1	1	1	0	1	00 B8
1	0	0	1	1	1	0	1	00 B9
0	1	0	1	1	1	0	1	00 BA
1	1	0	1	1	1	0	1	00 BB
0	0	1	1	1	1	0	1	00 BC
1	0	1	1	1	1	0	1	00 BD
0	1	1	1	1	1	0	1	00 BE
1	1	1	1	1	1	0	1	00 BF

0: OFF 1: ON

SW1, SW2, SW3, SW4, SW5								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	1	1	00 C0
1	0	0	0	0	0	1	1	00 C1
0	1	0	0	0	0	1	1	00 C2
1	1	0	0	0	0	1	1	00 C3
0	0	1	0	0	0	1	1	00 C4
1	0	1	0	0	0	1	1	00 C5
0	1	1	0	0	0	1	1	00 C6
1	1	1	0	0	0	1	1	00 C7
0	0	0	1	0	0	1	1	00 C8
1	0	0	1	0	0	1	1	00 C9
0	1	0	1	0	0	1	1	00 CA
1	1	0	1	0	0	1	1	00 CB
0	0	1	1	0	0	1	1	00 CC
1	0	1	1	0	0	1	1	00 CD
0	1	1	1	0	0	1	1	00 CE
1	1	1	1	0	0	1	1	00 CF
0	0	0	0	1	0	1	1	00 D0
1	0	0	0	1	0	1	1	00 D1
0	1	0	0	1	0	1	1	00 D2
1	1	0	0	1	0	1	1	00 D3
0	0	1	0	1	0	1	1	00 D4
1	0	1	0	1	0	1	1	00 D5
0	1	1	0	1	0	1	1	00 D6
1	1	1	0	1	0	1	1	00 D7
0	0	0	1	1	0	1	1	00 D8
1	0	0	1	1	0	1	1	00 D9
0	1	0	1	1	0	1	1	00 DA
1	1	0	1	1	0	1	1	00 DB
0	0	1	1	1	0	1	1	00 DC
1	0	1	1	1	0	1	1	00 DD
0	1	1	1	1	0	1	1	00 DE
1	1	1	1	1	0	1	1	00 DF
0	0	0	0	0	1	1	1	00 E0
1	0	0	0	0	1	1	1	00 E1
0	1	0	0	0	1	1	1	00 E2
1	1	0	0	0	1	1	1	00 E3
0	0	1	0	0	1	1	1	00 E4
1	0	1	0	0	1	1	1	00 E5
0	1	1	0	0	1	1	1	00 E6
1	1	1	0	0	1	1	1	00 E7
0	0	0	1	0	1	1	1	00 E8
1	0	0	1	0	1	1	1	00 E9
0	1	0	1	0	1	1	1	00 EA
1	1	0	1	0	1	1	1	00 EB
0	0	1	1	0	1	1	1	00 EC
1	0	1	1	0	1	1	1	00 ED
0	1	1	1	0	1	1	1	00 EE
1	1	1	1	0	1	1	1	00 EF
0	0	0	0	0	1	1	1	00 F0
1	0	0	0	0	1	1	1	00 F1
0	1	0	0	0	1	1	1	00 F2
1	1	0	0	0	1	1	1	00 F3
0	0	1	0	0	1	1	1	00 F4
1	0	1	0	0	1	1	1	00 F5
0	1	1	0	0	1	1	1	00 F6
1	1	1	0	0	1	1	1	00 F7
0	0	0	1	1	1	1	1	00 F8
1	0	0	1	1	1	1	1	00 F9
0	1	0	1	1	1	1	1	00 FA
1	1	0	1	1	1	1	1	00 FB
0	0	1	1	1	1	1	1	00 FC
1	0	1	1	1	1	1	1	00 FD
0	1	1	1	1	1	1	1	00 FE
1	1	1	1	1	1	1	1	00 FF

**Output signal display (Request code: 175/553)**

Please refer to Table 2 on relevant wiring diagram whilst using the following.

0: OFF 1: ON

OUT								Display
1	2	3	4	5A	5B	6	7	
0	0	0	0	0	0	0	0	xx 00
1	0	0	0	0	0	0	0	xx 01
0	1	0	0	0	0	0	0	xx 02
1	1	0	0	0	0	0	0	xx 03
0	0	1	0	0	0	0	0	xx 04
1	0	1	0	0	0	0	0	xx 05
0	1	1	0	0	0	0	0	xx 06
1	1	1	0	0	0	0	0	xx 07
0	0	0	1	0	0	0	0	xx 08
1	0	0	1	0	0	0	0	xx 09
0	1	0	1	0	0	0	0	xx 0A
1	1	0	1	0	0	0	0	xx 0B
0	0	1	1	0	0	0	0	xx 0C
1	0	1	1	0	0	0	0	xx 0D
0	1	1	1	0	0	0	0	xx 0E
1	1	1	1	0	0	0	0	xx 0F
0	0	0	0	1	0	0	0	xx 10
1	0	0	0	1	0	0	0	xx 11
0	1	0	0	1	0	0	0	xx 12
1	1	0	0	1	0	0	0	xx 13
0	0	1	0	1	0	0	0	xx 14
1	0	1	0	1	0	0	0	xx 15
0	1	1	0	1	0	0	0	xx 16
1	1	1	0	1	0	0	0	xx 17
0	0	0	1	1	0	0	0	xx 18
1	0	0	1	1	0	0	0	xx 19
0	1	0	1	1	0	0	0	xx 1A
1	1	0	1	1	0	0	0	xx 1B
0	0	1	1	1	0	0	0	xx 1C
1	0	1	1	1	0	0	0	xx 1D
0	1	1	1	1	0	0	0	xx 1E
1	1	1	1	1	0	0	0	xx 1F
0	0	0	0	0	1	0	0	xx 20
1	0	0	0	0	1	0	0	xx 21
0	1	0	0	0	1	0	0	xx 22
1	1	0	0	0	1	0	0	xx 23
0	0	1	0	0	1	0	0	xx 24
1	0	1	0	0	1	0	0	xx 25
0	1	1	0	0	1	0	0	xx 26
1	1	1	0	0	1	0	0	xx 27
0	0	0	1	0	1	0	0	xx 28
1	0	0	1	0	1	0	0	xx 29
0	1	0	1	0	1	0	0	xx 2A
1	1	0	1	0	1	0	0	xx 2B
0	0	1	1	0	1	0	0	xx 2C
1	0	1	1	0	1	0	0	xx 2D
0	1	1	1	0	1	0	0	xx 2E
1	1	1	1	0	1	0	0	xx 2F
0	0	0	0	1	1	0	0	xx 30
1	0	0	0	1	1	0	0	xx 31
0	1	0	0	1	1	0	0	xx 32
1	1	0	0	1	1	0	0	xx 33
0	0	1	0	1	1	0	0	xx 34
1	0	1	0	1	1	0	0	xx 35
0	1	1	0	1	1	0	0	xx 36
1	1	1	0	1	1	0	0	xx 37
0	0	0	1	1	1	0	0	xx 38
1	0	0	1	1	1	0	0	xx 39
0	1	0	1	1	1	0	0	xx 3A
1	1	0	1	1	1	0	0	xx 3B
0	0	1	1	1	1	0	0	xx 3C
1	0	1	1	1	1	0	0	xx 3D
0	1	1	1	1	1	0	0	xx 3E
1	1	1	1	1	1	0	0	xx 3F

0: OFF 1: ON

OUT								Display
1	2	3	4	5A	5B	6	7	
0	0	0	0	0	0	1	0	xx 40
1	0	0	0	0	0	1	0	xx 41
0	1	0	0	0	0	1	0	xx 42
1	1	0	0	0	0	1	0	xx 43
0	0	1	0	0	0	1	0	xx 44
1	0	1	0	0	0	1	0	xx 45
0	1	1	0	0	0	1	0	xx 46
1	1	1	0	0	0	1	0	xx 47
0	0	0	1	0	0	1	0	xx 48
1	0	0	1	0	0	1	0	xx 49
0	1	0	1	0	0	1	0	xx 4A
1	1	0	1	0	0	1	0	xx 4B
0	0	1	1	0	0	1	0	xx 4C
1	0	1	1	0	0	1	0	xx 4D
0	1	1	1	0	0	1	0	xx 4E
1	1	1	1	0	0	1	0	xx 4F
0	0	0	0	1	0	1	0	xx 50
1	0	0	0	1	0	1	0	xx 51
0	1	0	0	1	0	1	0	xx 52
1	1	0	0	1	0	1	0	xx 53
0	0	1	0	1	0	1	0	xx 54
1	0	1	0	1	0	1	0	xx 55
0	1	1	0	1	0	1	0	xx 56
1	1	1	0	1	0	1	0	xx 57
0	0	0	1	1	0	1	0	xx 58
1	0	0	1	1	0	1	0	xx 59
0	1	0	1	1	0	1	0	xx 5A
1	1	0	1	1	0	1	0	xx 5B
0	0	1	1	1	0	1	0	xx 5C
1	0	1	1	1	0	1	0	xx 5D
0	1	1	1	1	0	1	0	xx 5E
1	1	1	1	1	0	1	0	xx 5F
0	0	0	0	0	1	1	0	xx 60
1	0	0	0	0	1	1	0	xx 61
0	1	0	0	0	1	1	0	xx 62
1	1	0	0	0	1	1	0	xx 63
0	0	1	0	0	1	1	0	xx 64
1	0	1	0	0	1	1	0	xx 65
0	1	1	0	0	1	1	0	xx 66
1	1	1	0	0	1	1	0	xx 67
0	0	0	1	0	1	1	0	xx 68
1	0	0	1	0	1	1	0	xx 69
0	1	0	1	0	1	1	0	xx 6A
1	1	0	1	0	1	1	0	xx 6B
0	0	1	1	0	1	1	0	xx 6C
1	0	1	1	0	1	1	0	xx 6D
0	1	1	1	0	1	1	0	xx 6E
1	1	1	1	0	1	1	0	xx 6F
0	0	0	0	1	1	1	0	xx 70
1	0	0	0	1	1	1	0	xx 71
0	1	0	0	1	1	1	0	xx 72
1	1	0	0	1	1	1	0	xx 73
0	0	1	0	1	1	1	0	xx 74
1	0	1	0	1	1	1	0	xx 75
0	1	1	0	1	1	1	0	xx 76
1	1	1	0	1	1	1	0	xx 77
0	0	0	1	1	1	1	0	xx 78
1	0	0	1	1	1	1	0	xx 79
0	1	0	1	1	1	1	0	xx 7A
1	1	0	1	1	1	1	0	xx 7B
0	0	1	1	1	1	1	0	xx 7C
1	0	1	1	1	1	1	0	xx 7D
0	1	1	1	1	1	1	0	xx 7E
1	1	1	1	1	1	1	0	xx 7F

**Output signal display (Request code: 175/553)**

Please refer to Table 2 on relevant wiring diagram whilst using the following.

0: OFF 1: ON

OUT								Display
1	2	3	4	5A	5B	6	7	
0	0	0	0	0	0	0	1	xx 80
1	0	0	0	0	0	0	1	xx 81
0	1	0	0	0	0	0	1	xx 82
1	1	0	0	0	0	0	1	xx 83
0	0	1	0	0	0	0	1	xx 84
1	0	1	0	0	0	0	1	xx 85
0	1	1	0	0	0	0	1	xx 86
1	1	1	0	0	0	0	1	xx 87
0	0	0	1	0	0	0	1	xx 88
1	0	0	1	0	0	0	1	xx 89
0	1	0	1	0	0	0	1	xx 8A
1	1	0	1	0	0	0	1	xx 8B
0	0	1	1	0	0	0	1	xx 8C
1	0	1	1	0	0	0	1	xx 8D
0	1	1	1	0	0	0	1	xx 8E
1	1	1	1	0	0	0	1	xx 8F
0	0	0	0	1	0	0	1	xx 90
1	0	0	0	1	0	0	1	xx 91
0	1	0	0	1	0	0	1	xx 92
1	1	0	0	1	0	0	1	xx 93
0	0	1	0	1	0	0	1	xx 94
1	0	1	0	1	0	0	1	xx 95
0	1	1	0	1	0	0	1	xx 96
1	1	1	0	1	0	0	1	xx 97
0	0	0	1	1	0	0	1	xx 98
1	0	0	1	1	0	0	1	xx 99
0	1	0	1	1	0	0	1	xx 9A
1	1	0	1	1	0	0	1	xx 9B
0	0	1	1	1	0	0	1	xx 9C
1	0	1	1	1	0	0	1	xx 9D
0	1	1	1	1	0	0	1	xx 9E
1	1	1	1	1	0	0	1	xx 9F
0	0	0	0	0	1	0	1	xx A0
1	0	0	0	0	1	0	1	xx A1
0	1	0	0	0	1	0	1	xx A2
1	1	0	0	0	1	0	1	xx A3
0	0	1	0	0	1	0	1	xx A4
1	0	1	0	0	1	0	1	xx A5
0	1	1	0	0	1	0	1	xx A6
1	1	1	0	0	1	0	1	xx A7
0	0	0	1	0	1	0	1	xx A8
1	0	0	1	0	1	0	1	xx A9
0	1	0	1	0	1	0	1	xx AA
1	1	0	1	0	1	0	1	xx AB
0	0	1	1	0	1	0	1	xx AC
1	0	1	1	0	1	0	1	xx AD
0	1	1	1	0	1	0	1	xx AE
1	1	1	1	0	1	0	1	xx AF
0	0	0	0	1	1	0	1	xx B0
1	0	0	0	1	1	0	1	xx B1
0	1	0	0	1	1	0	1	xx B2
1	1	0	0	1	1	0	1	xx B3
0	0	1	0	1	1	0	1	xx B4
1	0	1	0	1	1	0	1	xx B5
0	1	1	0	1	1	0	1	xx B6
1	1	1	0	1	1	0	1	xx B7
0	0	0	1	1	1	0	1	xx B8
1	0	0	1	1	1	0	1	xx B9
0	1	0	1	1	1	0	1	xx BA
1	1	0	1	1	1	0	1	xx BB
0	0	1	1	1	1	0	1	xx BC
1	0	1	1	1	1	0	1	xx BD
0	1	1	1	1	1	0	1	xx BE
1	1	1	1	1	1	0	1	xx BF

0: OFF 1: ON

OUT								Display
1	2	3	4	5A	5B	6	7	
0	0	0	0	0	0	1	1	xx C0
1	0	0	0	0	0	1	1	xx C1
0	1	0	0	0	0	1	1	xx C2
1	1	0	0	0	0	1	1	xx C3
0	0	1	0	0	0	1	1	xx C4
1	0	1	0	0	0	1	1	xx C5
0	1	1	0	0	0	1	1	xx C6
1	1	1	0	0	0	1	1	xx C7
0	0	0	1	0	0	1	1	xx C8
1	0	0	1	0	0	1	1	xx C9
0	1	0	1	0	0	1	1	xx CA
1	1	0	1	0	0	1	1	xx CB
0	0	1	1	0	0	1	1	xx CC
1	0	1	1	0	0	1	1	xx CD
0	1	1	1	0	0	1	1	xx CE
1	1	1	1	0	0	1	1	xx CF
0	0	0	0	1	0	1	1	xx D0
1	0	0	0	1	0	1	1	xx D1
0	1	0	0	1	0	1	1	xx D2
1	1	0	0	1	0	1	1	xx D3
0	0	1	0	1	0	1	1	xx D4
1	0	1	0	1	0	1	1	xx D5
0	1	1	0	1	0	1	1	xx D6
1	1	1	0	1	0	1	1	xx D7
0	0	0	1	1	0	1	1	xx D8
1	0	0	1	1	0	1	1	xx D9
0	1	0	1	1	0	1	1	xx DA
1	1	0	1	1	0	1	1	xx DB
0	0	1	1	1	0	1	1	xx DC
1	0	1	1	1	0	1	1	xx DD
0	1	1	1	1	0	1	1	xx DE
1	1	1	1	1	0	1	1	xx DF
0	0	0	0	0	1	1	1	xx E0
1	0	0	0	0	1	1	1	xx E1
0	1	0	0	0	1	1	1	xx E2
1	1	0	0	0	1	1	1	xx E3
0	0	1	0	0	1	1	1	xx E4
1	0	1	0	0	1	1	1	xx E5
0	1	1	0	0	1	1	1	xx E6
1	1	1	0	0	1	1	1	xx E7
0	0	0	1	0	1	1	1	xx E8
1	0	0	1	0	1	1	1	xx E9
0	1	0	1	0	1	1	1	xx EA
1	1	0	1	0	1	1	1	xx EB
0	0	1	1	0	1	1	1	xx EC
1	0	1	1	0	1	1	1	xx ED
0	1	1	1	0	1	1	1	xx EE
1	1	1	1	0	1	1	1	xx EF
0	0	0	0	1	1	1	1	xx F0
1	0	0	0	1	1	1	1	xx F1
0	1	0	0	1	1	1	1	xx F2
1	1	0	0	1	1	1	1	xx F3
0	0	1	0	1	1	1	1	xx F4
1	0	1	0	1	1	1	1	xx F5
0	1	1	0	1	1	1	1	xx F6
1	1	1	0	1	1	1	1	xx F7
0	0	0	1	1	1	1	1	xx F8
1	0	0	1	1	1	1	1	xx F9
0	1	0	1	1	1	1	1	xx FA
1	1	0	1	1	1	1	1	xx FB
0	0	1	1	1	1	1	1	xx FC
1	0	1	1	1	1	1	1	xx FD
0	1	1	1	1	1	1	1	xx FE
1	1	1	1	1	1	1	1	xx FF

**Output signal display (Request code: 175/553)**

Please refer to Table 2 on relevant wiring diagram whilst using the following.

0: OFF                      1: ON

OUT								Display
8*	9	10	11	12	13	14	15	
0	0	0	0	0	0	0	0	00 xx
1	0	0	0	0	0	0	0	01 xx
0	1	0	0	0	0	0	0	02 xx
1	1	0	0	0	0	0	0	03 xx
0	0	1	0	0	0	0	0	04 xx
1	0	1	0	0	0	0	0	05 xx
0	1	1	0	0	0	0	0	06 xx
1	1	1	0	0	0	0	0	07 xx
0	0	0	1	0	0	0	0	08 xx
1	0	0	1	0	0	0	0	09 xx
0	1	0	1	0	0	0	0	0A xx
1	1	0	1	0	0	0	0	0B xx
0	0	1	1	0	0	0	0	0C xx
1	0	1	1	0	0	0	0	0D xx
0	1	1	1	0	0	0	0	0E xx
1	1	1	1	0	0	0	0	0F xx
0	0	0	0	1	0	0	0	10 xx
1	0	0	0	1	0	0	0	11 xx
0	1	0	0	1	0	0	0	12 xx
1	1	0	0	1	0	0	0	13 xx
0	0	1	0	1	0	0	0	14 xx
1	0	1	0	1	0	0	0	15 xx
0	1	1	0	1	0	0	0	16 xx
1	1	1	0	1	0	0	0	17 xx
0	0	0	1	1	0	0	0	18 xx
1	0	0	1	1	0	0	0	19 xx
0	1	0	1	1	0	0	0	1A xx
1	1	0	1	1	0	0	0	1B xx
0	0	1	1	1	0	0	0	1C xx
1	0	1	1	1	0	0	0	1D xx
0	1	1	1	1	0	0	0	1E xx
1	1	1	1	1	0	0	0	1F xx
0	0	0	0	0	1	0	0	20 xx
1	0	0	0	0	1	0	0	21 xx
0	1	0	0	0	1	0	0	22 xx
1	1	0	0	0	1	0	0	23 xx
0	0	1	0	0	1	0	0	24 xx
1	0	1	0	0	1	0	0	25 xx
0	1	1	0	0	1	0	0	26 xx
1	1	1	0	0	1	0	0	27 xx
0	0	0	1	0	1	0	0	28 xx
1	0	0	1	0	1	0	0	29 xx
0	1	0	1	0	1	0	0	2A xx
1	1	0	1	0	1	0	0	2B xx
0	0	1	1	0	1	0	0	2C xx
1	0	1	1	0	1	0	0	2D xx
0	1	1	1	0	1	0	0	2E xx
1	1	1	1	0	1	0	0	2F xx
0	0	0	0	1	1	0	0	30 xx
1	0	0	0	1	1	0	0	31 xx
0	1	0	0	1	1	0	0	32 xx
1	1	0	0	1	1	0	0	33 xx
0	0	1	0	1	1	0	0	34 xx
1	0	1	0	1	1	0	0	35 xx
0	1	1	0	1	1	0	0	36 xx
1	1	1	0	1	1	0	0	37 xx
0	0	0	1	1	1	0	0	38 xx
1	0	0	1	1	1	0	0	39 xx
0	1	0	1	1	1	0	0	3A xx
1	1	0	1	1	1	0	0	3B xx
0	0	1	1	1	1	0	0	3C xx
1	0	1	1	1	1	0	0	3D xx
0	1	1	1	1	1	0	0	3E xx
1	1	1	1	1	1	0	0	3F xx

\* Displayed only when the request code is 533.

OUT								Display
8	9	10	11	12	13	14	15	
0	0	0	0	0	0	1	0	40 xx
1	0	0	0	0	0	1	0	41 xx
0	1	0	0	0	0	1	0	42 xx
1	1	0	0	0	0	1	0	43 xx
0	0	1	0	0	0	1	0	44 xx
1	0	1	0	0	0	1	0	45 xx
0	1	1	0	0	0	1	0	46 xx
1	1	1	0	0	0	1	0	47 xx
0	0	0	1	0	0	1	0	48 xx
1	0	0	1	0	0	1	0	49 xx
0	1	0	1	0	0	1	0	4A xx
1	1	0	1	0	0	1	0	4B xx
0	0	1	1	0	0	1	0	4C xx
1	0	1	1	0	0	1	0	4D xx
0	1	1	1	0	0	1	0	4E xx
1	1	1	1	0	0	1	0	4F xx
0	0	0	0	1	0	1	0	50 xx
1	0	0	0	1	0	1	0	51 xx
0	1	0	0	1	0	1	0	52 xx
1	1	0	0	1	0	1	0	53 xx
0	0	1	0	1	0	1	0	54 xx
1	0	1	0	1	0	1	0	55 xx
0	1	1	0	1	0	1	0	56 xx
1	1	1	0	1	0	1	0	57 xx
0	0	0	1	1	0	1	0	58 xx
1	0	0	1	1	0	1	0	59 xx
0	1	0	1	1	0	1	0	5A xx
1	1	0	1	1	0	1	0	5B xx
0	0	1	1	1	0	1	0	5C xx
1	0	1	1	1	0	1	0	5D xx
0	1	1	1	1	0	1	0	5E xx
1	1	1	1	1	0	1	0	5F xx
0	0	0	0	0	1	1	0	60 xx
1	0	0	0	0	1	1	0	61 xx
0	1	0	0	0	1	1	0	62 xx
1	1	0	0	0	1	1	0	63 xx
0	0	1	0	0	1	1	0	64 xx
1	0	1	0	0	1	1	0	65 xx
0	1	1	0	0	1	1	0	66 xx
1	1	1	0	0	1	1	0	67 xx
0	0	0	1	0	1	1	0	68 xx
1	0	0	1	0	1	1	0	69 xx
0	1	0	1	0	1	1	0	6A xx
1	1	0	1	0	1	1	0	6B xx
0	0	1	1	0	1	1	0	6C xx
1	0	1	1	0	1	1	0	6D xx
0	1	1	1	0	1	1	0	6E xx
1	1	1	1	0	1	1	0	6F xx
0	0	0	0	1	1	1	0	70 xx
1	0	0	0	1	1	1	0	71 xx
0	1	0	0	1	1	1	0	72 xx
1	1	0	0	1	1	1	0	73 xx
0	0	1	0	1	1	1	0	74 xx
1	0	1	0	1	1	1	0	75 xx
0	1	1	0	1	1	1	0	76 xx
1	1	1	0	1	1	1	0	77 xx
0	0	0	1	1	1	1	0	78 xx
1	0	0	1	1	1	1	0	79 xx
0	1	0	1	1	1	1	0	7A xx
1	1	0	1	1	1	1	0	7B xx
0	0	1	1	1	1	1	0	7C xx
1	0	1	1	1	1	1	0	7D xx
0	1	1	1	1	1	1	0	7E xx
1	1	1	1	1	1	1	0	7F xx

**Mixing valve state**

OUT		Mixing valve state
5A	5B	
0	0	Stop
0	1	Stop
1	0	Open
1	1	Close

**Input signal display (Request code: 176/554)**

Please refer to Table 1 on relevant wiring diagram whilst using the following.

0: OFF (open)    1: ON (short)

IN								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	0	0	00 00
1	0	0	0	0	0	0	0	00 01
0	1	0	0	0	0	0	0	00 02
1	1	0	0	0	0	0	0	00 03
0	0	1	0	0	0	0	0	00 04
1	0	1	0	0	0	0	0	00 05
0	1	1	0	0	0	0	0	00 06
1	1	1	0	0	0	0	0	00 07
0	0	0	1	0	0	0	0	00 08
1	0	0	1	0	0	0	0	00 09
0	1	0	1	0	0	0	0	00 0A
1	1	0	1	0	0	0	0	00 0B
0	0	1	1	0	0	0	0	00 0C
1	0	1	1	0	0	0	0	00 0D
0	1	1	1	0	0	0	0	00 0E
1	1	1	1	0	0	0	0	00 0F
0	0	0	0	1	0	0	0	00 10
1	0	0	0	1	0	0	0	00 11
0	1	0	0	1	0	0	0	00 12
1	1	0	0	1	0	0	0	00 13
0	0	1	0	1	0	0	0	00 14
1	0	1	0	1	0	0	0	00 15
0	1	1	0	1	0	0	0	00 16
1	1	1	0	1	0	0	0	00 17
0	0	0	1	1	0	0	0	00 18
1	0	0	1	1	0	0	0	00 19
0	1	0	1	1	0	0	0	00 1A
1	1	0	1	1	0	0	0	00 1B
0	0	1	1	1	0	0	0	00 1C
1	0	1	1	1	0	0	0	00 1D
0	1	1	1	1	0	0	0	00 1E
1	1	1	1	1	0	0	0	00 1F
0	0	0	0	0	1	0	0	00 20
1	0	0	0	0	1	0	0	00 21
0	1	0	0	0	1	0	0	00 22
1	1	0	0	0	1	0	0	00 23
0	0	1	0	0	1	0	0	00 24
1	0	1	0	0	1	0	0	00 25
0	1	1	0	0	1	0	0	00 26
1	1	1	0	0	1	0	0	00 27
0	0	0	1	0	1	0	0	00 28
1	0	0	1	0	1	0	0	00 29
0	1	0	1	0	1	0	0	00 2A
1	1	0	1	0	1	0	0	00 2B
0	0	1	1	0	1	0	0	00 2C
1	0	1	1	0	1	0	0	00 2D
0	1	1	1	0	1	0	0	00 2E
1	1	1	1	0	1	0	0	00 2F
0	0	0	0	1	1	0	0	00 30
1	0	0	0	1	1	0	0	00 31
0	1	0	0	1	1	0	0	00 32
1	1	0	0	1	1	0	0	00 33
0	0	1	0	1	1	0	0	00 34
1	0	1	0	1	1	0	0	00 35
0	1	1	0	1	1	0	0	00 36
1	1	1	0	1	1	0	0	00 37
0	0	0	1	1	1	0	0	00 38
1	0	0	1	1	1	0	0	00 39
0	1	0	1	1	1	0	0	00 3A
1	1	0	1	1	1	0	0	00 3B
0	0	1	1	1	1	0	0	00 3C
1	0	1	1	1	1	0	0	00 3D
0	1	1	1	1	1	0	0	00 3E
1	1	1	1	1	1	0	0	00 3F

0: OFF (open)    1: ON (short)

IN								Display
1	2	3	4	5	6	7	8	
0	0	0	0	0	0	1	0	00 40
1	0	0	0	0	0	1	0	00 41
0	1	0	0	0	0	1	0	00 42
1	1	0	0	0	0	1	0	00 43
0	0	1	0	0	0	1	0	00 44
1	0	1	0	0	0	1	0	00 45
0	1	1	0	0	0	1	0	00 46
1	1	1	0	0	0	1	0	00 47
0	0	0	1	0	0	1	0	00 48
1	0	0	1	0	0	1	0	00 49
0	1	0	1	0	0	1	0	00 4A
1	1	0	1	0	0	1	0	00 4B
0	0	1	1	0	0	1	0	00 4C
1	0	1	1	0	0	1	0	00 4D
0	1	1	1	0	0	1	0	00 4E
1	1	1	1	0	0	1	0	00 4F
0	0	0	0	1	0	1	0	00 50
1	0	0	0	1	0	1	0	00 51
0	1	0	0	1	0	1	0	00 52
1	1	0	0	1	0	1	0	00 53
0	0	1	0	1	0	1	0	00 54
1	0	1	0	1	0	1	0	00 55
0	1	1	0	1	0	1	0	00 56
1	1	1	0	1	0	1	0	00 57
0	0	0	1	1	0	1	0	00 58
1	0	0	1	1	0	1	0	00 59
0	1	0	1	1	0	1	0	00 5A
1	1	0	1	1	0	1	0	00 5B
0	0	1	1	1	0	1	0	00 5C
1	0	1	1	1	0	1	0	00 5D
0	1	1	1	1	0	1	0	00 5E
1	1	1	1	1	0	1	0	00 5F
0	0	0	0	0	1	1	0	00 60
1	0	0	0	0	1	1	0	00 61
0	1	0	0	0	1	1	0	00 62
1	1	0	0	0	1	1	0	00 63
0	0	1	0	0	1	1	0	00 64
1	0	1	0	0	1	1	0	00 65
0	1	1	0	0	1	1	0	00 66
1	1	1	0	0	1	1	0	00 67
0	0	0	1	0	1	1	0	00 68
1	0	0	1	0	1	1	0	00 69
0	1	0	1	0	1	1	0	00 6A
1	1	0	1	0	1	1	0	00 6B
0	0	1	1	0	1	1	0	00 6C
1	0	1	1	0	1	1	0	00 6D
0	1	1	1	0	1	1	0	00 6E
1	1	1	1	0	1	1	0	00 6F
0	0	0	0	1	1	1	0	00 70
1	0	0	0	1	1	1	0	00 71
0	1	0	0	1	1	1	0	00 72
1	1	0	0	1	1	1	0	00 73
0	0	1	0	1	1	1	0	00 74
1	0	1	0	1	1	1	0	00 75
0	1	1	0	1	1	1	0	00 76
1	1	1	0	1	1	1	0	00 77
0	0	0	1	1	1	1	0	00 78
1	0	0	1	1	1	1	0	00 79
0	1	0	1	1	1	1	0	00 7A
1	1	0	1	1	1	1	0	00 7B
0	0	1	1	1	1	1	0	00 7C
1	0	1	1	1	1	1	0	00 7D
0	1	1	1	1	1	1	0	00 7E
1	1	1	1	1	1	1	0	00 7F

## ■ Indoor unit only operation

In indoor unit only operation, an operation without connecting outdoor unit is possible. During Indoor unit only operation, the main control has control functions.

### <Heater>

Heating for DHW and space heating is provided by the heater.

- Activating indoor unit only operation mode

To activate indoor unit only operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-4 and SW4-5 to ON.
3. Switch ON the breaker(s).
4. Indoor unit only operation is now activated.

- Deactivating indoor unit only operation mode

To deactivate indoor unit only operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-4 and SW4-5 to OFF.
3. Switch ON the breaker(s).
4. Indoor unit only operation is now deactivated.

### <Boiler>

Heating for space heating is provided by the boiler.

- Activating indoor unit only operation mode

To activate indoor unit only operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-4 and SW4-6 to ON.
3. Switch ON the breaker(s).
4. Indoor unit only operation is now activated.

- Deactivating indoor unit only operation mode

To deactivate indoor unit only operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-4 and SW4-6 to OFF.
3. Switch ON the breaker(s).
4. Indoor unit only operation is now deactivated.

## ■ Emergency operation

In emergency operation, an operation without connecting outdoor unit and main remote controller is possible.

During Emergency operation, the main control has NO control functions.

Space heating flow temp. is restarted 40°C and DHW tank temp. is restricted 50°C. \*1

### <Heater>

Heating for DHW and space heating is provided by the heater.

- Activating emergency operation mode

To activate emergency operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-5 to ON.
3. Switch ON the breaker(s).
4. Emergency operation is now activated.

- Deactivating emergency operation mode

To deactivate emergency operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-5 to OFF.
3. Switch ON the breaker(s).
4. Emergency operation is now deactivated.

### <Boiler>

Heating for space heating is provided by the boiler.

- Activating emergency operation mode

To activate emergency operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-6 to ON.
3. Switch ON the breaker(s).
4. Emergency operation is now activated.

- Deactivating emergency operation mode

To deactivate emergency operation, see the following:

1. Switch OFF the breaker for the outdoor unit (or both breakers if cylinder is powered independently).
2. Change DIP switch SW4-6 to OFF.
3. Switch ON the breaker(s).
4. Emergency operation is now deactivated.

### ⚠ WARNING

Do not attempt to change the DIP switches whilst the breaker(s) are ON as this could result in ELECTROCUTION.

	Indoor unit only operation
Indoor unit	Necessary
Heat pump	Not necessary
Main remote controller	Necessary
DIP switch setting	Electric heater SW4-4 ON, SW4-5 ON
	Boiler SW4-4 ON, SW4-6 ON
Setting range for flow temp.	25–60°C Selectable
Setting range for tank temp.	40–60°C Selectable

	Emergency operation
Indoor unit	Necessary
Heat pump	Not necessary
Main remote controller	Not necessary
DIP switch setting	Electric heater SW4-5 ON
	Boiler SW4-6 ON
Setting range for flow temp.	Fixed at 40°C
Setting range for tank temp.	Fixed at 50°C *1

\*1 Default setting is 50°C. Once system has started running, emergency operation runs at the latest set temp.

### 10-1. Troubleshooting

#### <Summary of self diagnosis based on Error Codes and Service Procedures>

Present and past Error codes are logged and displayed on the main remote controller or control board of the outdoor unit.

Please refer to the table below and subsequent explanations to diagnose and remedy typical problems that may occur in the field.

Unit Condition	Error Code	Action
Reoccurring problem	Displayed	Use table "10-4. Self diagnosis and action" to identify fault and correct.
	Not Displayed	Use table "10-5. Troubleshooting by inferior phenomena" to identify fault and correct.
Non reoccurring problem	Logged	1. Check temporary causes of defects such as the operation of safety devices on the refrigerant/water circuit including compressor, poor wiring, electrical noise, etc. Re-check the symptom and the installation environment, refrigerant amount (Split systems only), weather conditions at time of fault, etc. 2. Reset Error code logs, Service the unit and restart system.
	Not Logged	1. Recheck the abnormal symptom. 2. Identify cause of problem and take corrective action according to Table "10-5. Troubleshooting by inferior phenomena". 3. If no obvious problem can be found, continue to operate the unit.

#### NOTE

Electrical components should only be replaced as a final option. Please follow instructions in "10-4. Self diagnosis and action" and "10-5. Troubleshooting by inferior phenomena" fully before resorting to replacing parts.

### 10-2. Test Run

Before a test run

- After installation of outdoor unit, pipework and electrical wiring, recheck that there is no water leakage, loosened connections or miswiring.
- Measure impedance between the ground and the power supply terminal block (L,N) on the outdoor and indoor units with suitable (500 V) ohmmeter. Resistance should be  $\geq 1.0 \text{ M}\Omega$ .
- Read the Installation and Operation Manuals fully especially the safety requirements before carrying out any test runs.

### 10-3. Malfunction diagnosis method by main remote controller



If a malfunction occurs during start up or operation, the error code screen may be displayed on the main remote controller.

The error code screen shows the following; code, unit, ref. address, and telephone number of installer (only if previously entered by the installer)

Please note in the case of some malfunctions an error code is not generated, please refer to table "10-5. Troubleshooting by inferior phenomena" for more details.

To reset

1. To reset the main remote controller press F4 button (Reset).
2. Then press F3 (Yes) to confirm.




## 10-4. Self diagnosis and action

Check if DIP SW is set correctly. (Refer to "6-16. DIP switch functions".)

Error code	Title and display conditions	Possible Cause	Diagnosis and action
L3	<p><b>Circulation water temperature overheat protection</b> &lt;DHW/Heating/Cooling/LP/FS/OS&gt; Error code displayed when THW1 detects a temp. <math>\geq 80^{\circ}\text{C}</math> for 10 consecutive seconds or THW2 detects a temp. <math>\geq 80^{\circ}\text{C}</math> for 10 consecutive seconds.</p> <p>DHW : Domestic hot water mode Heating : Heating mode Cooling : Cooling mode LP : Legionella prevention mode FS : Freeze stat OS : Operation stop TH1A/B : Room temperature thermistor TH2 : Liquid refrigerant temperature thermistor THW1 : Flow water temperature thermistor THW2 : Return water temperature thermistor THW5 : Tank water temperature thermistor THW6 : Zone1 flow water temperature thermistor THW7 : Zone1 return water temperature thermistor THW8 : Zone2 flow water temperature thermistor THW9 : Zone2 return water temperature thermistor THWB1 : Boiler flow water temperature thermistor THWB2 : Boiler return water temperature thermistor</p>	<ol style="list-style-type: none"> <li>Insufficient system head</li> <li>Reduced flow in primary water circuit Due to 1 or more of the following; Faulty pump, insufficient air purge, blocked strainer, leak in water circuit.</li> <li>Valve operation fault</li> <li>2-way valve (local supply) actuator fault</li> <li>3-way valve (local supply) actuator fault</li> <li>Booster heater relay (BHC1, BHC2, BHCP) operating fault</li> <li>Power supply voltage increase</li> <li>THW1 or THW5 has become detached from its holder.</li> <li>THW1 or THW2 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Refer to table in "10-6. Checking Component Parts' Function" to determine if system pump meets requirements. If more head required either add a pump of the same size or replace existing pump with capacity model. See "11. DISASSEMBLY PROCEDURE" for how to replace pump.</li> <li>Check circulation pump (See "10-6. Checking Component Parts' Function" for how to check). Open purge valve to remove trapped air. Check the strainer for blockages. Check the primary water circuit for leaks. Check that the flow amount is within the recommended range.</li> <li>Check valves on primary water circuit are installed level.</li> <li>Electrically test to determine fault.</li> <li>1) Electrically test to determine fault. 2) Operate 3-way valve manually using the main remote controller. (Refer to &lt;Manual operation&gt; in "9-4. Service Menu".) 3) Replace 3-way valve.</li> <li>Electrically test the relays (BHC1, BHC2, BHCP) to determine fault. See "10-6. Checking Component Parts' Function" for how to check.</li> <li>Check the supply voltage.</li> <li>Visually inspect location and reattach as necessary.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>
L4	<p><b>Tank water temperature overheat protection</b> &lt;DHW/Heating/Cooling/LP/FS/OS&gt; Error code display when THW5 detects a temp. <math>\geq 75^{\circ}\text{C}</math> for 10 consecutive seconds.</p>	<ol style="list-style-type: none"> <li>3-way valve (local supply) actuator fault</li> <li>Immersion heater relay (IHC) operating fault</li> <li>THW5 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>1) Electrically test to determine fault. 2) Operate 3-way valve manually using the main remote controller. (Refer to &lt;Manual operation&gt; in "9-4. Service Menu".) 3) Replace 3-way valve.</li> <li>Check immersion heater relay (IHC).</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>






Error code	Title and display conditions	Possible Cause	Diagnosis and action																																																											
P1/P2/L5/LD	<p><b>Indoor unit temperature thermistor failure</b>            Note: The thermistors subject to failure can be checked in "Request code: 567" in "Running information."</p> <p>&lt;DHW/Heating/Cooling/LP/FS/OS&gt;            Error code displayed when thermistor is at open or short (see table).</p> <p><u>Exceptions</u>            Error code will not be displayed for TH2; During defrost and for 10 minutes after defrost operation.</p>	<ol style="list-style-type: none"> <li>Connector/terminal wire has become detached or loose wiring.</li> <li>Thermistor fault</li> <li>FTC board failure</li> <li>The thermistor on the wireless remote controller or the main remote controller may be defective. (when Room temp. is chosen for the Heating operation and when Main remote controller or Room RC 1-8 is chosen for the Room Sensor setting in the Initial setting)</li> <li>Incorrect setting of the DIP switch(es)</li> </ol>	<ol style="list-style-type: none"> <li>Visually check the terminals and connections and reattaches appropriate.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> <li>Replace wireless remote controller or main remote controller.</li> <li>Check the DIP switch setting(s).</li> </ol>																																																											
				<table border="1"> <thead> <tr> <th rowspan="2">Error code</th> <th colspan="2">Thermistor</th> <th rowspan="2">Open detection</th> <th rowspan="2">Short detection</th> </tr> <tr> <th>Symbol</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>P1</td> <td>TH1A/TH1B</td> <td>Room temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>P2</td> <td>TH2</td> <td>Liquid temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td rowspan="7">L5</td> <td>THW1</td> <td>Flow water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW2</td> <td>Return water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW5</td> <td>Tank water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW6</td> <td>Zone1 flow water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW7</td> <td>Zone1 return water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW8</td> <td>Zone2 flow water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td>THW9</td> <td>Zone2 return water temperature thermistor</td> <td>-39°C or below</td> <td>88.5°C or above</td> </tr> <tr> <td rowspan="2">LD</td> <td>THWB1</td> <td>Boiler flow water temperature thermistor</td> <td>-40°C or below</td> <td>140°C or above</td> </tr> <tr> <td>THWB2</td> <td>Boiler return water temperature thermistor</td> <td>-40°C or below</td> <td>140°C or above</td> </tr> </tbody> </table>				Error code	Thermistor		Open detection	Short detection	Symbol	Name	P1	TH1A/TH1B	Room temperature thermistor	-39°C or below	88.5°C or above	P2	TH2	Liquid temperature thermistor	-39°C or below	88.5°C or above	L5	THW1	Flow water temperature thermistor	-39°C or below	88.5°C or above	THW2	Return water temperature thermistor	-39°C or below	88.5°C or above	THW5	Tank water temperature thermistor	-39°C or below	88.5°C or above	THW6	Zone1 flow water temperature thermistor	-39°C or below	88.5°C or above	THW7	Zone1 return water temperature thermistor	-39°C or below	88.5°C or above	THW8	Zone2 flow water temperature thermistor	-39°C or below	88.5°C or above	THW9	Zone2 return water temperature thermistor	-39°C or below	88.5°C or above	LD	THWB1	Boiler flow water temperature thermistor	-40°C or below	140°C or above	THWB2	Boiler return water temperature thermistor	-40°C or below	140°C or above
				Error code	Thermistor		Open detection		Short detection																																																					
					Symbol	Name																																																								
				P1	TH1A/TH1B	Room temperature thermistor	-39°C or below	88.5°C or above																																																						
				P2	TH2	Liquid temperature thermistor	-39°C or below	88.5°C or above																																																						
				L5	THW1	Flow water temperature thermistor	-39°C or below	88.5°C or above																																																						
					THW2	Return water temperature thermistor	-39°C or below	88.5°C or above																																																						
					THW5	Tank water temperature thermistor	-39°C or below	88.5°C or above																																																						
					THW6	Zone1 flow water temperature thermistor	-39°C or below	88.5°C or above																																																						
					THW7	Zone1 return water temperature thermistor	-39°C or below	88.5°C or above																																																						
					THW8	Zone2 flow water temperature thermistor	-39°C or below	88.5°C or above																																																						
THW9	Zone2 return water temperature thermistor	-39°C or below	88.5°C or above																																																											
LD	THWB1	Boiler flow water temperature thermistor	-40°C or below	140°C or above																																																										
	THWB2	Boiler return water temperature thermistor	-40°C or below	140°C or above																																																										
L6	<p><b>Circulation water freeze protection</b>            &lt;DHW/Heating/Cooling/LP/FS/OS&gt;            Error code displayed when THW1 detects a temp. ≤ 1°C for 10 consecutive seconds or THW2 detects a temp. ≤ 3°C for 10 consecutive seconds.</p> <p><u>Exception</u>            Error code will not be displayed if; FS function is disabled, For 10 minutes after water circulation pump1 is switched on.</p>	<ol style="list-style-type: none"> <li>Insufficient system head</li> <li>Reduced flow in primary water circuit. Due to 1 or more of the following; Faulty pump, insufficient air purge, blocked strainer, leak in water circuit.</li> <li>Valve operation fault</li> <li>2-way valve (local supply) actuator fault</li> <li>3-way valve (local supply) actuator fault</li> <li>THW1 has become detached from its holder.</li> <li>THW1 or THW2 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Refer to table in "10-6. Checking Component Parts' Function" to determine if system pump meets requirements. If more head required either add a pump of the same size or replace existing pump with capacity model. See "11. DISASSEMBLY PROCEDURE" for how to replace pump.</li> <li>Check circulation pump (See "10-6. Checking Component Parts' Function" for how to check). Open purge valve to remove trapped air. Check the strainer for blockages. Check the primary water circuit for leaks. Check that the flow amount is within the recommended range.</li> <li>Check valves on primary water circuit are installed level.</li> <li>Electrically test to determine fault.</li> <li>1) Electrically test to determine fault. 2) Operate 3-way valve manually using the main remote controller. (Refer to &lt;Manual operation&gt; in "9-4. Service Menu".) 3) Replace 3-way valve.</li> <li>Visually inspect location and reattach as necessary.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>																																																											




Error code	Title and display conditions	Possible Cause	Diagnosis and action
L8	<b>Heating operation error</b> Note: "3" is displayed in "Request code: 567" in "Running information". <Heating/FS> If a), b) and c) occur, L8 is displayed; a) No change on THW1 and THW5 (under 1°C for 20 minutes from unit starts operation) b) No change on THW1 (under 1°C for 10 minutes from booster heater starts operation) c) THW1-THW2 < -5°C (for 10 minutes continuously)	<ol style="list-style-type: none"> <li>THW1 has become detached from its holder.</li> <li>Booster heater fault</li> <li>THW1 or THW2 or THW5 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Visually inspect location and reattach as necessary.</li> <li>Electrically test to determine fault. See "10-6. Checking Component Parts' Function" for how to check.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>
	<b>Heating operation error</b> Note: "A" is displayed in "Request code: 567" in "Running information".	<ol style="list-style-type: none"> <li>THW6 has become detached from its holder.</li> <li>THW6 or THW7 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Visually inspect location and reattach as necessary.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>
	<b>Heating operation error</b> Note: "C" is displayed in "Request code: 567" in "Running information".	<ol style="list-style-type: none"> <li>THW8 has become detached from its holder.</li> <li>THW8 or THW9 fault</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Visually inspect location and reattach as necessary.</li> <li>Check resistance of thermistor against table in "10-6. Checking Component Parts' Function". Compare FTC detected temperature to hand held detector.</li> <li>Replace board.</li> </ol>
L9	<b>Low primary circuit (Heat source side) flow rate detected by flow sensor</b> Note: "1" is displayed in "Request code: 569" in "Running information". <DHW/Heating/Cooling/LP/FS> Error code displayed when flow sensor detects low flow rate for 10 seconds.  <u>Exception</u> For 1 minute after water circulation pump1 is switched on.	<ol style="list-style-type: none"> <li>Insufficient system head</li> <li>Reduced flow in primary water circuit Due to 1 or more of the following; Faulty pump, insufficient air purge, blocked strainer, leak in water circuit.</li> <li>Valve operation fault</li> <li>2-way valve (local supply) actuator fault</li> <li>Connector wire has become detached or loose wiring.</li> <li>Flow sensor fault</li> <li>Incorrect setting of the SW2-2</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Refer to table in "10-6. Checking Component Parts' Function" to determine if system pump meets requirements. If more head required either add a pump of the same size or replace existing pump with capacity model. See "11. DISASSEMBLY PROCEDURE" for how to replace pump.</li> <li>Check circulation pump (See "10-6. Checking Component Parts' Function" for how to check). Open purge valve to remove trapped air. Check the strainer for blockages. Check the primary water circuit for leaks. Check that the flow amount is within the recommended range.</li> <li>Check valves on primary water circuit are installed level.</li> <li>Electrically test to determine fault.</li> <li>Visually check the CN1A connector and reattach if necessary.</li> <li>Electrically test to determine fault. See "10-6. Checking Component Parts' Function" for how to check.</li> <li>Check the SW2-2 setting.</li> <li>Replace board.</li> </ol>
	<b>Low primary circuit (Zone1 side) flow rate detected by flow switch</b> Note: "2" is displayed in "Request code: 569" in "Running information".	<ol style="list-style-type: none"> <li>Insufficient system head</li> <li>Reduced flow in primary water circuit Due to 1 or more of the following; Faulty pump, insufficient air purge, blocked strainer, leak in water circuit.</li> <li>Terminal wire has become detached or loose wiring.</li> <li>Flow switch fault</li> <li>Incorrect setting of the SW3-2</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>If more head required either add a pump of the same size or replace existing pump.</li> <li>Check circulation pump (See "10-6. Checking Component Parts' Function" for how to check). Open purge valve to remove trapped air. Check the strainer for blockages. Check the primary water circuit for leaks. Check that the flow amount is within the recommended range.</li> <li>Visually check the IN3 terminal and reattach if necessary.</li> <li>Electrically test to determine fault.</li> <li>Check the SW3-2 setting.</li> <li>Replace board.</li> </ol>



Error code	Title and display conditions	Possible Cause	Diagnosis and action
L9	<b>Low primary circuit (Zone2 side) flow rate detected by flow switch</b> Note: "3" is displayed in "Request code: 569" in "Running information".	<ol style="list-style-type: none"> <li>Insufficient system head</li> <li>Reduced flow in primary water circuit Due to 1 or more of the following; Faulty pump, insufficient air purge, blocked strainer, leak in water circuit.</li> <li>Terminal wire has become detached or loose wiring.</li> <li>Flow switch fault</li> <li>Incorrect setting of the SW3-3</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>If more head required either add a pump of the same size or replace existing pump.</li> <li>Check circulation pump (See "10-6. Checking Component Parts' Function" for how to check). Open purge valve to remove trapped air. Check the strainer for blockages. Check the primary water circuit for leaks. Check that the flow amount is within the recommended range.</li> <li>Visually check the IN7 terminal and reattach if necessary.</li> <li>Electrically test to determine fault.</li> <li>Check the SW3-3 setting.</li> <li>Replace board.</li> </ol>
LC	Boiler circulation water temperature overheat protection <DHW/Heating/LP/FS/OS> Error code displayed when THWB1 detects a temperature $\geq 80^{\circ}\text{C}$ for 10 consecutive seconds or THWB2 detects a temperature $\geq 80^{\circ}\text{C}$ for 10 consecutive seconds	<ol style="list-style-type: none"> <li>The set temperature for Boiler is too high.</li> <li>Flow rate of the heating circuit from the boiler may be reduced.</li> </ol>	<ol style="list-style-type: none"> <li>Check if the set temperature for Boiler for heating exceeds the restriction. (See the manual for the thermistors "PAC-TH011HT-E")</li> <li>Check for <ul style="list-style-type: none"> <li>water leakage</li> <li>strainer blockage</li> <li>water circulation pump function</li> </ul> </li> </ol>
LD	Boiler temperature thermistor (THWB1, THWB2) failure	Refer to error codes (P1/P2/L5/LD).	
LE	Boiler operation error <Heating> Boiler is running and THW6 detects a temperature $< 30^{\circ}\text{C}$ for consecutive 60 minutes.	<ol style="list-style-type: none"> <li>THW6 has become detached from its holder.</li> <li>Incorrect wiring between FTC (OUT10) and the boiler.</li> <li>Boiler fuel has run out or the system is OFF.</li> <li>Boiler failure</li> <li>FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>Visually inspect location and reattach as necessary.</li> <li>See the manual of the thermistors "PAC-TH011HT-E".</li> <li>Check the status of the boiler.</li> <li>Check the status of the boiler.</li> <li>Replace board.</li> </ol>
LF	Flow sensor failure	Disconnection or loose connection of flow sensor	Check flow sensor cable for damage or loose connections.
LH	Boiler circulation water freeze protection	Flow rate of the heating circuit from the boiler may be reduced.	Check for <ul style="list-style-type: none"> <li>water leakage</li> <li>strainer blockage</li> <li>water circulation pump function</li> </ul>
LJ	DHW operation error (type of external plate HEX)	<ol style="list-style-type: none"> <li>DHW tank water temp. thermistor (THW5) has become detached from its holder.</li> <li>Flow rate of the sanitary circuit may be reduced.</li> </ol>	<ol style="list-style-type: none"> <li>Check for disconnection of DHW tank water temp. thermistor (THW5).</li> <li>Check for water circulation pump function.</li> </ol>
LL	Setting errors of DIP switches on FTC control board	Incorrect setting of DIP switches. <ol style="list-style-type: none"> <li>Boiler operation</li> <li>2-zone temperature control</li> <li>Multiple outdoor units control</li> </ol>	<ol style="list-style-type: none"> <li>For boiler operation, check that DIP SW1-1 is set to ON (With Boiler) and DIP SW2-6 is set to ON (With Mixing Tank).</li> <li>For 2-zone temperature control, check DIP SW2-7 is set to ON (2-zone) and DIP SW2-6 is set to ON (With Mixing Tank).</li> <li>For multiple outdoor units control, check DIP SW1-3 is set to ON on FTC (slave) that runs DHW operation .</li> </ol>
P1	Indoor unit temperature thermistor (TH1A/TH1B) failure	Refer to error codes (P1/P2/L5/LD).	
P2	Indoor unit temperature thermistor (TH2) failure	Refer to error codes (P1/P2/L5/LD).	
P6	Anti-freeze protection of plate heat exchanger <Cooling> The error code displayed when Ref. liquid temp. (TH2) stays at $-5^{\circ}\text{C}$ or lower for 10 seconds after compressor operates for 6 minutes.	<Cooling> <ol style="list-style-type: none"> <li>Reduced water flow <ul style="list-style-type: none"> <li>Clogged filter</li> <li>Leakage of water</li> </ul> </li> <li>Low temperature <ul style="list-style-type: none"> <li>Low load</li> <li>Inlet water is too cold.</li> </ul> </li> <li>Defective water pump</li> <li>Defective outdoor fan control.</li> <li>Overcharge of refrigerant</li> <li>Defective refrigerant circuit (clogs)</li> <li>Malfunction of linear expansion valve</li> </ol>	<ol style="list-style-type: none"> <li>1., 2. Check water piping.</li> <li>3. Check water pump.</li> <li>4. Check outdoor fan motor.</li> <li>5., 6. Check operating condition of refrigerant circuit.</li> <li>7. Check linear expansion valve.</li> </ol>



Error code	Title and display conditions	Possible Cause	Diagnosis and action
P6	<p>&lt;Defrosting&gt;            THW2 detects a temperature <math>\leq 15^{\circ}\text{C}</math> and TH2 detects a temperature <math>\leq -16^{\circ}\text{C}</math> for consecutive 10 seconds.</p>	<p>&lt;Defrosting&gt;</p> <ol style="list-style-type: none"> <li>Reduced water flow               <ul style="list-style-type: none"> <li>Clogged filter</li> <li>Leakage of water</li> </ul> </li> <li>Low temperature               <ul style="list-style-type: none"> <li>Low load</li> <li>Inlet water is cold.</li> </ul> </li> <li>Defective water pump</li> <li>Leakage or shortage of refrigerant</li> <li>Malfunction of linear expansion valve</li> </ol>	<ol style="list-style-type: none"> <li>2. Check water piping.</li> <li>3. Check water pump.</li> <li>4. Correct to proper amount of refrigerant.</li> <li>5. Check linear expansion valve.</li> </ol>
E0/E4	<p><b>Main remote controller communication failure (Reception error)</b>            Error code E0 is displayed if main remote controller does not receive any signal from the indoor unit for ref. address "0" for 3 minutes.            Error code E4 is displayed if indoor unit does not receive any data from the main remote controller for 3 minutes or indoor unit does not receive any signal from the main remote controller for 2 minutes.</p>	<ol style="list-style-type: none"> <li>Contact failure with transmission cable</li> <li>Wiring procedure not observed. (Cable length/cable diameter/number of indoor units/number of main remote controllers)</li> <li>Fault on the indoor unit FTC board section controlling Ref. address "0"</li> <li>Fault with the main remote controller circuit board</li> <li>Electrical noise causes interference with transmission/reception of data for main remote controller.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check connection cable for damage or loose connections at the FTC and main remote controller terminals.</li> <li>2. Check main remote controller and FTC common wiring max cable length 500 m. Only use 2-core cable. Only connect 1 main remote controller to 1 FTC indoor unit board.</li> <li>3. to 5.            If the problem is not solved by the above measures then:            Turn the power to the indoor unit OFF and then ON.            Power to both the indoor unit and outdoor units should be switched OFF then ON. (This may require switching 1 or 2 breakers depending if the unit is powered independently from the outdoor unit).            If the E4 code is still displayed the FTC and/or the main remote controller circuit board should be replaced.</li> </ol>
E3/E5	<p><b>Main remote controller communication failure (Transmission error)</b>            Error code E3 is displayed if the main remote controller can not find an empty transmission path and thus fails to transmit for 6 seconds or the data received by the main remote controller is different to what was sent (by the main remote controller) 30 consecutive times.             Error code E5 is displayed if the FTC cannot find an empty transmission path for 3 minutes and thus cannot transmit or the data sent by the FTC is different to what was expected 30 consecutive times.</p>	<ol style="list-style-type: none"> <li>2 or more main remote controllers have been connected to the FTC.</li> <li>Fault with main remote controller transmission/receiving circuit board</li> <li>Fault with the main remote controller circuit board</li> <li>Electrical noise causes interference with transmission/reception of data for main remote controller.</li> </ol>	<ol style="list-style-type: none"> <li>1. Only connect 1 main remote controller to 1 FTC indoor unit board.</li> <li>2. to 4.            Turn the power to the indoor unit OFF and then ON.            Power to both the indoor unit and outdoor units should be switched OFF then ON. (This may require switching 1 or 2 breakers depending if the unit is powered independently from the outdoor unit).            If the E3/E5 code is still displayed the FTC and/or the main remote controller circuit board should be replaced.</li> </ol>
E6	<p><b>Indoor/outdoor communication failure (Reception error)</b>            Error code E6 is displayed if after the power is switched ON to the indoor unit, the FTC board does not receive any signal or the signal received is not complete for 6 minutes, or after a period of operation the FTC board does not receive any signal or the signal received is not complete for 3 minutes.</p>	<ol style="list-style-type: none"> <li>Contact failure/short circuit/miswiring</li> <li>Fault with outdoor unit transmission/receiving circuit board</li> <li>Fault with FTC transmission/receiving circuit board</li> <li>Electrical noise causes interference with FTC-Outdoor unit transmission cable.</li> </ol>	<p>Note:            Check the LED display on the outdoor unit circuit board.            (Connect the A-control service tool, PAC-SK52ST to test.) Refer to the outdoor unit service manual for explanation of EA-EC codes.</p> <ol style="list-style-type: none"> <li>1. Check the connections on the indoor and outdoor units have not become loose and that the connecting cable is not damaged.</li> <li>2. to 4.            Turn the power to the indoor unit OFF and then ON.            Power to both the indoor unit and outdoor units should be switched OFF then ON. (This may require switching 1 or 2 breakers depending if the unit is powered independently from the outdoor unit).            If the E6 code is still displayed the FTC and/or the outdoor unit circuit board should be replaced.</li> </ol>
E7	<p><b>Indoor/outdoor communication failure (Transmission error)</b>            Error code E7 is displayed if signal "1" is received 30 consecutive times despite the FTC board sending signal "0".</p>	<ol style="list-style-type: none"> <li>Fault with FTC transmission/receiving circuit board</li> <li>Electrical noise causes interference with power supply.</li> <li>Electrical noise causes interference with FTC-outdoor unit transmission cable.</li> </ol>	<ol style="list-style-type: none"> <li>1. to 3.            Turn the power to the indoor unit OFF and then ON.            Power to both the indoor unit and outdoor units should be switched OFF then ON. (This may require switching 1 or 2 breakers depending if the unit is powered independently from the outdoor unit).            If the E7 code is still displayed the FTC circuit board should be replaced.</li> </ol>





Error code	Title and display conditions	Possible Cause	Diagnosis and action
E1/E2	<b>Main remote controller control board failure</b> Error code E1 displayed if main remote controller cannot access its non-volatile (non power dependent) memory. Error code E2 is displayed when there is a fault with the main remote controller's internal clock.	1. Fault with the main remote controller circuit board	1. Replace main remote controller circuit board.
J0	<b>Indoor unit/wireless receiver communication failure</b> Error code J0 is displayed when the FTC cannot receive data from the wireless receiver for 1 minute.	1. Connection fault with wireless receiver-FTC connection 2. Fault with FTC receiving circuit board 3. Fault with wireless receiver's transmission circuit board 4. Electrical noise causes interference with wireless receiver communication cable.	1. Check the connections to the wireless receiver and FTC have not become loose and that the connecting cable is not damaged. 2. to 4. Turn the power to the indoor unit OFF and then ON. Power to both the indoor unit and outdoor units should be switched OFF then ON. (This may require switching 1 or 2 breakers depending if the unit is powered independently from the outdoor unit). If the J0 code is still displayed, the FTC and/or the wireless receiver circuit board should be replaced.
J1 to J8	<b>Wireless remote controller/wireless receiver communication failure (Reception error)</b> Error code displayed if wireless receiver receives no/incomplete data from the wireless remote controller for 15 consecutive minutes.  The digit after the J refers to the address of the wireless remote controller that has the error. E.g. Error code "J3" refers to a communication fault between the wireless receiver and wireless remote control with address 3.	1. Battery on wireless remote control may be flat. 2. The wireless remote controller is out of range of the wireless receiver. 3. Fault with wireless remote controller transmission circuit board 4. Fault with wireless receiver's reception circuit board	1. Check and replace the battery on wireless remote control if necessary.. 2. to 4. Reposition the wireless remote control closer to the receiver and perform a communication test. For procedure, refer to wireless remote controller installation manual. If "OK" is displayed, then the cause of the J1 to J8 error was the controller was out of range of the receiver. The wireless remote controller should be installed within range of the receiver. If "Err" is displayed, replace wireless remote controller with a new controller and perform the pairing procedure. If the "Err" code is still displayed after this procedure, the fault is with the receiver unit (attached to the indoor unit). The receiver unit should be replaced with a new part and the original remote control can be reconnected. If "OK" is displayed, then the fault is with the remote control and this should be replaced.
J9	Main remote controller communication failure Error code J9 is displayed when signal is not received normally from FTC (slave) for 3 minutes.	Refer to error codes (E0 and E4)	
U*, F*, A*	Outdoor unit failure	Outdoor unit failure	Refer to outdoor unit service manual.


Note: To cancel error codes please switch system off (press button F4 (RESET) on main remote controller).


## 10-5. Troubleshooting by inferior phenomena

No.	Fault symptom	Possible cause	Explanation - Solution
1	Main remote controller display is blank.	<ol style="list-style-type: none"> <li>There is no power supply to main remote controller.</li> <li>Power is supplied to main remote controller, however, the display on the main remote controller does not appear.</li> </ol>	<ol style="list-style-type: none"> <li>Check LED2 on FTC. (See "6. WIRING DIAGRAM".)               <ol style="list-style-type: none"> <li>When LED2 is lit. Check for damage or contact failure of the main remote controller wiring.</li> <li>When LED2 is blinking. Refer to No. 5 below.</li> <li>When LED2 is not lit. Refer to No. 4 below.</li> </ol> </li> <li>Check the following:               <ul style="list-style-type: none"> <li>Disconnection between the main remote controller cable and the FTC control board</li> <li>Failure of the main remote controller if "Please Wait" is not displayed.</li> <li>Refer to No. 2 below if "Please Wait" is displayed.</li> </ul> </li> </ol>
2	"Please Wait" remains displayed on the main remote controller.	<ol style="list-style-type: none"> <li>"Please Wait" is displayed for up to 6 minutes.</li> <li>Communication failure between the main remote controller and FTC.</li> <li>Communication failure between FTC and outdoor unit.</li> </ol>	<ol style="list-style-type: none"> <li>Normal operation, no action necessary.</li> <li>3. Main remote controller start up checks/procedure               <ol style="list-style-type: none"> <li>If "0%" or "50-99%" is displayed below "Please Wait" there is a communication error between the main remote controller and the FTC control board.                   <ul style="list-style-type: none"> <li>Check wiring connections on the main remote controller.</li> <li>Replace the main remote controller or the FTC control board.</li> </ul> </li> <li>If "1-49%" is displayed there is a communication error between the outdoor unit's and FTC's control boards.                   <ul style="list-style-type: none"> <li>Check the wiring connections on the outdoor unit control board and the FTC control board. (Ensure S1 and S2 are not cross-wired and S3 is securely wired with no damage. See "7. FIELD WIRING".)</li> <li>Replace the outdoor unit's and/or the FTC's control boards.</li> </ul> </li> </ol> </li> </ol>
3	The main screen appears with a press of the "ON" button, but disappears in a second.	The main remote controller operations do not work for a while after the settings are changed in the service menu. This is because the system takes time to apply the changes.	Normal operation, no action necessary. The indoor unit is applying updated settings made in the service menu. Normal operation will start shortly.
4	LED2 on FTC is off. (See "6. WIRING DIAGRAM".)	<p>When LED1 on FTC is also off. (See "6. WIRING DIAGRAM".) &lt;FTC powered via outdoor unit.&gt;</p> <ol style="list-style-type: none"> <li>The outdoor unit is not supplied at the rated voltage.</li> <li>Defective outdoor controller circuit board</li> <li>FTC is not supplied with 220 to 240 V AC.</li> <li>FTC failure.</li> <li>Faulty connector wiring.</li> </ol>	<ol style="list-style-type: none"> <li>Check the voltage across the terminals L and N or L3 and N on the outdoor power board. (See "7. FIELD WIRING".)               <ul style="list-style-type: none"> <li>When the voltage is not 220 to 240 V AC, check wiring of the outdoor unit and of the breaker.</li> <li>When the voltage is at 220 to 240 V AC, go to "2." below.</li> </ul> </li> <li>Check the voltage across the outdoor unit terminals S1 and S2. (See "7. FIELD WIRING".)               <ul style="list-style-type: none"> <li>When the voltage is not 220 to 240 V AC, check the fuse on the outdoor control board and check for faulty wiring.</li> <li>When the voltage is 220 to 240 V AC, go to "3." below.</li> </ul> </li> <li>Check the voltage across the indoor unit terminals S1 and S2. (See "7. FIELD WIRING".)               <ul style="list-style-type: none"> <li>When the voltage is not 220 to 240 V AC, check FTC-outdoor unit wiring for faults.</li> <li>When the voltage is 220 to 240 V AC, go to "4." below.</li> </ul> </li> <li>Check the FTC control board.               <ul style="list-style-type: none"> <li>Check the fuse on FTC control board.</li> <li>Check for faulty wiring.</li> <li>If no problem found with the wiring, the FTC control board is faulty.</li> </ul> </li> <li>Check the connector wiring.               <ul style="list-style-type: none"> <li>When the connectors are wired incorrectly, re-wire the connectors referring to below. (See "7. FIELD WIRING".)</li> </ul> </li> </ol>






No.	Fault symptom	Possible cause	Explanation - Solution
4	LED2 on FTC is off. (See "6. WIRING DIAGRAM".)	<FTC powered on independent source> 1. FTC is not supplied with 220 to 240 V AC.  2. There are problems in the method of connecting the connectors.  3. FTC failure	<ol style="list-style-type: none"> <li>1. Check the voltage across the L and N terminals on the indoor power supply terminal block. (See "7. FIELD WIRING".) <ul style="list-style-type: none"> <li>• When the voltage is not 220 to 240 V AC, check for faulty wiring to power supply.</li> <li>• When the voltage is 220 to 240 V AC, go to 2. below.</li> </ul> </li> <li>2. Check for faulty wiring between the connectors. <ul style="list-style-type: none"> <li>• When the connectors are wired incorrectly re-wire them correctly referring to below. (See "7. FIELD WIRING". and a wiring diagram on the control and electrical box cover.)</li> </ul> </li> </ol>  <ul style="list-style-type: none"> <li>• If no problem found with the wiring, go to 3. below.</li> </ul>
		When LED1 on FTC is lit. Incorrect setting of refrigerant address for outdoor unit. (None of the refrigerant address is set to "0".)	Recheck the refrigerant address setting on the outdoor unit. Set the refrigerant address to "0". (Set refrigerant address using SW1(3-6) on outdoor controller circuit board.)
5	LED2 on FTC is blinking. (See "6. WIRING DIAGRAM".)	When LED1 is also blinking on FTC . Faulty wiring between FTC and outdoor unit	Check for faulty wiring between FTC and outdoor unit.
		When LED1 on FTC is lit. 1. Faulty wiring in main remote controller Multiple indoor units have been wired to a single outdoor unit. 2. Short-circuited wiring in main remote controller 3. Main remote controller failure	<ol style="list-style-type: none"> <li>1. Check for faulty wiring in main remote controller. The number of indoor units that can be wired to a single outdoor unit is one. Additional indoor units must be wired individually to a single outdoor unit.</li> <li>2,3. Remove main remote controller wires and check LED2 on FTC. (See Figure 5.2.1. in installation manual) <ul style="list-style-type: none"> <li>• If LED2 is blinking check for short circuits in the main remote controller wiring.</li> <li>• If LED2 is lit, wire the main remote controller again and: <ul style="list-style-type: none"> <li>- if LED2 is blinking, the main remote controller is faulty;</li> <li>- if LED2 is lit, faulty wiring of the main remote controller has been corrected.</li> </ul> </li> </ul> </li> </ol>
6	LED4 on FTC is off. (See "6. WIRING DIAGRAM".)	1. SD memory card is NOT inserted into the memory card slot with correct orientation. 2. Not an SD standards compliant memory card	<ol style="list-style-type: none"> <li>1. Correctly insert SD memory card in place until a click is heard.</li> <li>2. Use an SD standards compliant memory card. (Refer to section 5.9 in installation manual)</li> </ol>
	LED4 on FTC is blinking. (See "6. WIRING DIAGRAM".)	1. Full of data 2. Write-protected 3. NOT formatted 4. Formatted in NTFS file system	<ol style="list-style-type: none"> <li>1. Move or delete data, or replace SD memory card with a new one.</li> <li>2. Release the write-protect switch.</li> <li>3. Refer to "5.9 Using SD memory card" in installation manual.</li> <li>4. FTC is Not compatible with NTFS file system. Use an SD memory card formatted in FAT file system.</li> </ol>
7	No water at hot tap.	1. Cold main off 2. Strainer (local supply) blocked	<ol style="list-style-type: none"> <li>1. Check and open stop cock.</li> <li>2. Isolate water supply and clean strainer.</li> </ol>
8	Cold water at tap.	<ol style="list-style-type: none"> <li>1. Hot water run out.</li> <li>2. Prohibit, schedule timer or holiday mode selected or demand control input (IN4) or smart grid ready (switch-off command).</li> <li>3. Heat pump not working</li> <li>4. Booster heater cut-out tripped.</li> <li>5. The earth leakage circuit breaker for booster heater breaker (ECB1) tripped.</li> <li>6. The booster heater thermal cut-out has tripped and cannot be reset using the manual reset button.</li> <li>7. Immersion heater cut-out tripped.</li> <li>8. Immersion heater breaker (ECB2) tripped.</li> <li>9. 3-way valve fault</li> </ol>	<ol style="list-style-type: none"> <li>1. Ensure DHW mode is operating and wait for DHW tank to re-heat.</li> <li>2. Check settings and change as appropriate.</li> <li>3. Check heat pump – consult outdoor unit service manual.</li> <li>4. Check booster heater thermostat and press reset button if safe. Reset button is located on the side of booster heater, covered with white rubber cap. See "4. PART NAMES AND FUNCTIONS" to find out its position.</li> <li>5. Check the cause and reset if safe.</li> <li>6. Check resistance across the thermal cut-out, if open then the connection is broken and the booster heater will have to be replaced. Contact your Mitsubishi Electric dealer.</li> <li>7. Check immersion heater thermostat and press reset button, located on immersion heater boss, if safe. If the heater has been operated with no water inside it may have failed, so please replace it with a new one.</li> <li>8. Check the cause and reset if safe.</li> <li>9. Check plumbing/wiring to 3-way valve. <ol style="list-style-type: none"> <li>(i) Manually override 3-way valve using the main remote controller. (Refer to &lt;Manual operation&gt; in section "9-4. Service menu".) If the valve does not still function, go to (ii) below.</li> <li>(ii) Replace 3-way valve.</li> </ol> </li> </ol>




No.	Fault symptom	Possible cause	Explanation - Solution
9	Water heating takes longer.	<ol style="list-style-type: none"> <li>1. Heat pump not working</li> <li>2. Booster heater cut-out tripped.</li> <li>3. Booster heater breaker (ECB1) tripped.</li> <li>4. The booster heater thermal cut-out has tripped and cannot be reset using the manual reset button.</li> <li>5. Immersion heater cut-out has been triggered.</li> <li>6. Immersion heater breaker (ECB2) tripped.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check heat pump – consult outdoor unit service manual.</li> <li>2. Check booster heater thermostat and press reset button if safe. Reset button is located on the side of booster heater, covered with white rubber cap. See "4. PART NAMES AND FUNCTIONS" to find out its position.</li> <li>3. Check the cause and reset if safe.</li> <li>4. Check resistance across the thermal cut-out, if open then connection is broken and the booster heater will have to be replaced. Contact your Mitsubishi Electric dealer.</li> <li>5. Check immersion heater thermostat and press reset button if safe. If the heater kept running with no water inside, this may have resulted in failure, so replace it with a new one.</li> <li>6. Check the cause and reset if safe.</li> </ol>
10	Temperature of DHW tank water dropped.	<p>When DHW operation is not running, the DHW tank emits heat and the water temperature decreases to a certain level. If water in the DHW tank is reheated frequently because of a significant drop in water temperature, check for the following.</p> <ol style="list-style-type: none"> <li>1. Water leakage in the pipes that connect to the DHW tank</li> <li>2. Insulation material coming loose or off</li> <li>3. 3-way valve failure</li> </ol>	<ol style="list-style-type: none"> <li>1. Take the following measures. <ul style="list-style-type: none"> <li>• Retighten the nuts holding the pipes onto the DHW tank.</li> <li>• Replace seal materials.</li> <li>• Replace the pipes.</li> </ul> </li> <li>2. Fix insulation.</li> <li>3. Check plumbing/wiring to 3-way valve. <ol style="list-style-type: none"> <li>(i) Manually override 3-way valve using the main remote controller. (Refer to &lt;Manual operation&gt; in "9-4. Service Menu".) If the valve does not still function, go to (ii) below.</li> <li>(ii) Replace 3-way valve.</li> </ol> </li> </ol>
11	Hot or warm water from cold tap.	Heat of hot water pipe is transferred to cold water pipe.	Insulate/re-route pipework.
12	Water leakage	<ol style="list-style-type: none"> <li>1. Poorly sealed connections of water circuit components</li> <li>2. Water circuit components reaching the end of life</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten connections as required.</li> <li>2. Refer to PARTS CATALOG in the service manual for expected part lifetimes and replace them as necessary.</li> </ol>
13	Heating system does not reach the set temperature.	<ol style="list-style-type: none"> <li>1. Prohibit, schedule timer or holiday mode selected or demand control input (IN4) or smart grid ready (switch-off command).</li> <li>2. Check settings and change as appropriate.</li> <li>3. The temperature sensor is located in a room that has a different temperature relative to that of the rest of the house.</li> <li>4. Heat pump not working</li> <li>5. Booster heater cut-out tripped.</li> <li>6. Booster heater breaker (ECB1) tripped.</li> <li>7. The booster heater thermal cut-out tripped and cannot be reset using the manual reset button.</li> <li>8. Incorrectly sized heat emitter</li> <li>9. 3-way valve failure</li> <li>10. Battery problem (*wireless control only)</li> <li>11. If a mixing tank is installed, the flow rate between the mixing tank and the hydrobox is less than that between the mixing tank and the local system.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check settings and change as appropriate.</li> <li>2. Check the battery power and replace if flat.</li> <li>3. Relocate the temperature sensor to a more suitable room.</li> <li>4. Check heat pump – consult outdoor unit service manual.</li> <li>5. Check booster heater thermostat and press reset button if safe. Reset button is located on the side of booster heater, covered with white rubber cap. (See "4. PART NAMES AND FUNCTIONS" for position.)</li> <li>6. Check the cause of the trip and reset if safe.</li> <li>7. Check resistance across the thermal cut-out, if open then the connection is broken and the booster heater will have to be replaced. Contact your Mitsubishi Electric dealer.</li> <li>8. Check the heat emitter surface area is adequate. Increase size if necessary.</li> <li>9. Check plumbing/wiring to 3-way valve.</li> <li>10. Check the battery power and replace if flat.</li> <li>11. Increase the flow rate between the mixing tank and the hydrobox or decrease that between the mixing tank and the local system.</li> </ol>





No.	Fault symptom	Possible cause	Explanation - Solution
14	In 2-zone temperature control, only Zone2 does not reach the set temperature.	<ol style="list-style-type: none"> <li>When Zone1 and Zone2 are both in heating mode, the hot water temperature in Zone2 does not exceed that in Zone1.</li> <li>Faulty wiring of motorized mixing valve</li> <li>Faulty installation of motorized mixing valve</li> <li>Incorrect setting of Running time</li> <li>Motorized mixing valve failure</li> </ol>	<ol style="list-style-type: none"> <li>Normal operation, no action necessary.</li> <li>Refer to "5.3 Wiring for 2-zone temperature control" in installation manual.</li> <li>Check for correct installation. (Refer to the manual included with each motorized mixing valve.)</li> <li>Check for correct setting of Running time.</li> <li>Inspect the mixing valve. (Refer to the manual included with each motorized mixing valve.)</li> </ol>
15	When a PUHZ-FRP outdoor unit is connected, DHW or Heating operation cannot run.	The outdoor unit is set to have operation of the indoor unit of air conditioner take precedence over that of the hydrobox, and in the main remote controller settings "Electric heater (Heating)" or "Electric heater (DHW)" is turned off.	Turn ON Electric heater (Heating) or Electric heater (DHW) using the main remote controller.
16	When a PUHZ-FRP outdoor unit is connected and is in heat recovery operation, the set temperature is not reached.	When the outdoor unit is set to have cooling operation of the indoor unit of air conditioner take precedence over that of the hydrobox, the outdoor unit controls the frequency of the compressor according to the load of air conditioner. The DHW and heating run according to that frequency.	Normal operation, no action necessary. If Air-to-Water system is given priority in operation, comp Hz can be regulated depending on the load of DHW or Heating. For more details, refer to the PUHZ-FRP installation manual.
17	After DHW operation room temperature rises slightly.	At the end of the DHW mode operation the 3-way valve diverts hot water away from the DHW circuit into space heating circuit. This is done to prevent the hydrobox components from overheating. The amount of hot water directed into the space heating circuit varies according to the type of the system and of the pipe run between the plate heat exchanger and the hydrobox.	Normal operation, no action necessary.
18	The room temperature rises during DHW operation.	3-way valve failure	Check the 3-way valve.
19	Water discharges from pressure relief valve. (Primary circuit)	<ol style="list-style-type: none"> <li>If continual – pressure relief valve may be damaged.</li> <li>If intermittent – expansion vessel charge may have reduced/bladder perished.</li> </ol>	<ol style="list-style-type: none"> <li>Turn the handle on the pressure relief valve to check for foreign objects in it. If the problem is not still solved, replace the pressure relief valve with a new one.</li> <li>Check pressure in expansion vessel. Recharge to 1 bar if necessary. If bladder perished, replace expansion vessel with a new one.</li> </ol>
20	Water discharges from pressure relief valve (field supplied item). (Sanitary circuit)	<ol style="list-style-type: none"> <li>If continual – field supplied pressure reducing valve not working.</li> <li>If continual – pressure relief valve seat may be damaged.</li> <li>If intermittent – expansion vessel charge may have reduced/bladder perished.</li> <li>DHW tank may have subjected to backflow.</li> </ol>	<ol style="list-style-type: none"> <li>Check function of pressure reducing valve and replace if necessary.</li> <li>Turn the handle on the pressure relief valve to check for foreign objects inside. If the problem is not still solved, replace the pressure relief valve.</li> <li>Check gas-side pressure in expansion vessel. Recharge to correct precharge pressure if necessary. If bladder perished, replace expansion vessel with a new one with appropriate pre-charge.</li> <li>Check the pressure in DHW tank. If pressure in DHW tank is similar to that in the incoming mains, cold water supply that merges with incoming mains water supply could flow back to DHW tank. Investigate source of back-feed and rectify error in pipework/fitting configuration. Adjust pressure in cold supply.</li> </ol>
21	Noisy water circulation pump	Air in water circulation pump .	Use manual and automatic air vents to remove air from system. Top up water if necessary to achieve 1 bar on primary circuit.
22	Noise during hot water draw off typically worse in the morning.	<ol style="list-style-type: none"> <li>Loose airing cupboard pipework.</li> <li>Heaters switching on/off.</li> </ol>	<ol style="list-style-type: none"> <li>Install extra pipe fastening clips.</li> <li>Normal operation, no action necessary.</li> </ol>
23	Mechanical noise heard coming from the hydrobox.	<ol style="list-style-type: none"> <li>Heaters switching on/off.</li> <li>3-way valve changing position between DHW and heating mode.</li> </ol>	Normal operation, no action necessary.
24	Water circulation pump runs for a short time unexpectedly .	Water circulation pump jam prevention mechanism (routine) to inhibit the build-up of scale.	Normal operation, no action necessary.
25	Milky/Cloudy water (Sanitary circuit)	Oxygenated water	Water from any pressurised system will release oxygen bubbles when water is running. The bubbles will settle out.
26	Heating mode has been on standby for a long time (does not start operation smoothly.)	The time of "Delay" set in "Economy settings for pump" is too short. (Go to "Service menu" → "Auxiliary settings" → "Economy settings for pump").	Increase the time of "Delay" in "Economy settings for pump" .



No.	Fault symptom	Possible cause	Explanation - Solution																
27	The hydrobox that was running in the heating mode before power failure is running in the DHW mode after power recovery.	The hydrobox is designed to run in an operation mode with a higher priority (i.e. DHW mode in this case) at power recovery.	<ul style="list-style-type: none"> <li>• Normal operation, no action necessary.</li> <li>• After the DHW max. operation time has elapsed or the DHW max. temperature has been reached, the DHW mode switches to the other mode (ex. Heating mode).</li> </ul>																
28	Cooling mode is NOT available.	DIP SW2-4 is OFF.	Turn DIP SW2-4 to ON. (Refer to "6-16 DIP switch functions".)																
29	The cooling system does not cool down to the set temperature.	<ol style="list-style-type: none"> <li>1. When the water in the circulation circuit is unduly hot, Cooling mode starts with a delay for the protection of the outdoor unit.</li> <li>2. When the outdoor ambient temperature is lower than the preset temperature that activates the freeze stat. function, Cooling mode does not start running.</li> </ol>	<ol style="list-style-type: none"> <li>1. Normal operation, no action necessary.</li> <li>2. To run Cooling mode overriding the freeze stat. function, adjust the preset temperature that activates the freeze stat. function. (Refer to "&lt;Freeze stat function&gt;" on Page 41.)</li> </ol>																
30	The electric heaters are activated shortly after DHW or LP mode starts running after Cooling mode.	The setting time period of Heat-pump-only operation is short.	Adjust the setting time period of Heat-pump only operation. (Refer to "<Electric heater (DHW)>" on Page 39.																
31	During DHW or LP mode following the cooling mode, error L6 (circulation water freeze protection error) occurs and the system stops all the operations.	The unit runs in Cooling mode when the outdoor ambient temperature is lower than 10°C (outside of the guaranteed operating range). (When defrosting operation is running at such a low outdoor ambient temperature after Cooling mode is switched to DHW or LP mode, the water temperature in the cooling circuit drops too low, which could result in L6 error to stop all the operations.	<p>Do not run Cooling operation when the outdoor ambient temperature is lower than 10°C.</p> <p>To automatically stop or recover only Cooling operation and keep other operations running, the freeze stat. function can be used. Set the preset temperature that activates the freeze stat. function to adjust the outdoor ambient temperature as follows. (Refer to "&lt;Freeze stat function&gt;" on Page 41.)</p> <table border="1"> <thead> <tr> <th>Outdoor ambient temperature</th> <th>Cooling operation</th> </tr> </thead> <tbody> <tr> <td>3°C higher than the preset temperature</td> <td>Stop</td> </tr> <tr> <td>5°C higher than the preset temperature</td> <td>Recover</td> </tr> </tbody> </table>	Outdoor ambient temperature	Cooling operation	3°C higher than the preset temperature	Stop	5°C higher than the preset temperature	Recover										
Outdoor ambient temperature	Cooling operation																		
3°C higher than the preset temperature	Stop																		
5°C higher than the preset temperature	Recover																		
32	<p>The energy monitor value seems not correct.</p> <p>Note: There could be some discrepancies between the actual and the calculated values. If you seek for accuracy, please make sure to connect power meter(s) and heat meter to FTC board. Both should be locally supplied.</p>	<ol style="list-style-type: none"> <li>1. Incorrect setting of the energy monitor</li> <li>2. Non-connectable type of external meter (local supply) is connected.</li> <li>3. External meter (local supply) failure</li> <li>4. FTC board failure</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the setting by following the procedure below.               <ol style="list-style-type: none"> <li>(1) Check if the DIP switch is set as the table below.                   <table border="1"> <thead> <tr> <th colspan="2">Consumed electric energy</th> <th colspan="2">Delivered heat energy</th> </tr> </thead> <tbody> <tr> <td>SW3-4</td> <td>Electric energy meter (Local supply)</td> <td>SW3-8</td> <td>Heat meter (Local supply)</td> </tr> <tr> <td>OFF</td> <td>Without</td> <td>OFF</td> <td>Without</td> </tr> <tr> <td>ON</td> <td>With</td> <td>ON</td> <td>With</td> </tr> </tbody> </table> </li> <li>(2) In the case external electric energy meter and/or heat meter is not used, check if the setting for electric heater and water pump(s) input is correct by referring to &lt;Energy monitor setting&gt; in "9-4 Service menu".</li> <li>(3) In the case external electric energy meter and/or heat meter is used, check if the unit of output pulse on external meter matches with the one set at the main remote controller by referring to &lt;Energy monitor setting&gt; in "9-4. Service menu".</li> </ol> </li> <li>2. Check if the external meter (local supply) is connectable type by referring to &lt;Energy monitor setting&gt; in "9-4 Service menu".</li> <li>3. Check if signal is sent to IN8 to IN10 properly. (Refer to "6. WIRING DIAGRAM".) Replace the external heat meter if defective.</li> <li>4. Check the FTC control board.               <ul style="list-style-type: none"> <li>• Check for faulty wiring.</li> <li>• If no problem found with the wiring, the FTC control board is faulty. Replace the board.</li> </ul> </li> </ol>	Consumed electric energy		Delivered heat energy		SW3-4	Electric energy meter (Local supply)	SW3-8	Heat meter (Local supply)	OFF	Without	OFF	Without	ON	With	ON	With
Consumed electric energy		Delivered heat energy																	
SW3-4	Electric energy meter (Local supply)	SW3-8	Heat meter (Local supply)																
OFF	Without	OFF	Without																
ON	With	ON	With																
33	Heat pump is forced to turn ON and OFF.	Smart grid ready input (IN11 and IN12) is used, and switch-on and off commands are input.	Normal operation, no action necessary.																

## Annual Maintenance







It is essential that the hydrobox is serviced at least once a year by a qualified individual any spare parts required MUST be purchased from Mitsubishi Electric (safety matter).

**NEVER** bypass safety devices or operate the unit without them being fully operational.







### <Annual maintenance points>


Use the Annual Maintenance Log Book ("13-2. Annual Maintenance Log Book") as a guide to carrying out the necessary checks on the hydrobox and outdoor unit.



## 10-6. Checking Component Parts' Function

Part Name	Check Points																																										
	<p><b>&lt;Water Circulation Pump Characteristics&gt;</b></p> <p><b>EHSC series</b></p>  <p><b>EHSD series</b></p>  <p><b>ERSC series</b></p>  <p><b>ERSD series</b></p>  <p><b>EHPX series</b></p> 																																										
<p><b>&lt;Recommended water flow rate range&gt;</b></p> <table border="1" data-bbox="175 1332 734 1836"> <thead> <tr> <th>Outdoor heat pump unit</th> <th>Water flow rate range [L/min]</th> </tr> </thead> <tbody> <tr> <td>Packaged model</td> <td></td> </tr> <tr> <td>PUHZ-W50</td> <td>7.1-14.3</td> </tr> <tr> <td>PUHZ-W85</td> <td>10.0-25.8</td> </tr> <tr> <td>PUHZ-W112</td> <td>14.4-27.7</td> </tr> <tr> <td>PUHZ-HW112</td> <td>14.4-27.7</td> </tr> <tr> <td>PUHZ-HW140</td> <td>17.9-27.7</td> </tr> <tr> <td>Split model</td> <td></td> </tr> <tr> <td>SUHZ-SW45</td> <td>7.1-12.9</td> </tr> <tr> <td>PUHZ-SW40</td> <td>7.1-11.8</td> </tr> <tr> <td>PUHZ-SW50</td> <td>7.1-17.2</td> </tr> <tr> <td>PUHZ-FRP71</td> <td>11.5-22.9</td> </tr> <tr> <td>PUHZ-SW75</td> <td>10.2-22.9</td> </tr> <tr> <td>PUHZ-SW100</td> <td>14.4-27.7</td> </tr> <tr> <td>PUHZ-SW120</td> <td>20.1-27.7</td> </tr> <tr> <td>PUHZ-SHW80</td> <td>10.2-22.9</td> </tr> <tr> <td>PUHZ-SHW112</td> <td>14.4-27.7</td> </tr> <tr> <td>PUHZ-SHW140</td> <td>17.9-27.7</td> </tr> <tr> <td>PUMY-P112</td> <td>17.9-27.7</td> </tr> <tr> <td>PUMY-P125</td> <td>17.9-27.7</td> </tr> <tr> <td>PUMY-P140</td> <td>17.9-27.7</td> </tr> </tbody> </table> <p>Note: If the water flow rate is less than 7.1 L/min, the flow rate error will be activated. If the water flow rate exceeds 27.7 L/min, the flow speed will be greater than 1.5 m/s, which could erode the pipes.</p>	Outdoor heat pump unit	Water flow rate range [L/min]	Packaged model		PUHZ-W50	7.1-14.3	PUHZ-W85	10.0-25.8	PUHZ-W112	14.4-27.7	PUHZ-HW112	14.4-27.7	PUHZ-HW140	17.9-27.7	Split model		SUHZ-SW45	7.1-12.9	PUHZ-SW40	7.1-11.8	PUHZ-SW50	7.1-17.2	PUHZ-FRP71	11.5-22.9	PUHZ-SW75	10.2-22.9	PUHZ-SW100	14.4-27.7	PUHZ-SW120	20.1-27.7	PUHZ-SHW80	10.2-22.9	PUHZ-SHW112	14.4-27.7	PUHZ-SHW140	17.9-27.7	PUMY-P112	17.9-27.7	PUMY-P125	17.9-27.7	PUMY-P140	17.9-27.7	<p>Note: For installation of EHPX series, set its pump speed with a pressure drop between the hydrobox and the outdoor unit factored into the external static pressure.</p>
Outdoor heat pump unit	Water flow rate range [L/min]																																										
Packaged model																																											
PUHZ-W50	7.1-14.3																																										
PUHZ-W85	10.0-25.8																																										
PUHZ-W112	14.4-27.7																																										
PUHZ-HW112	14.4-27.7																																										
PUHZ-HW140	17.9-27.7																																										
Split model																																											
SUHZ-SW45	7.1-12.9																																										
PUHZ-SW40	7.1-11.8																																										
PUHZ-SW50	7.1-17.2																																										
PUHZ-FRP71	11.5-22.9																																										
PUHZ-SW75	10.2-22.9																																										
PUHZ-SW100	14.4-27.7																																										
PUHZ-SW120	20.1-27.7																																										
PUHZ-SHW80	10.2-22.9																																										
PUHZ-SHW112	14.4-27.7																																										
PUHZ-SHW140	17.9-27.7																																										
PUMY-P112	17.9-27.7																																										
PUMY-P125	17.9-27.7																																										
PUMY-P140	17.9-27.7																																										



Part Name	Check Points									
<p><b>Earth leakage circuit breaker for heater</b></p>	<p>If a short circuit occurs on the booster heater, immersion heater, or each power line, a short-circuit breaker will trip and power source will be blocked. Eliminate the causes of short circuit and then turn on the breaker again.</p>									
<p><b>Relay for heater</b></p> 	<p>When the applied voltage is not 230 V AC across the terminals A1-A2, check the terminals R-U, S-V, and T-W are open. When the applied voltage is 230 V AC across the terminals A1-A2, check the terminals R-U, S-V, and T-W are short.</p>									
<p><b>Booster heater</b></p> <p>Thermostat (90°C) and thermal cut out (121°C)</p> 	<p>Measure the resistance between the terminals with a tester.</p> <table border="1" data-bbox="702 660 1316 728"> <thead> <tr> <th>Terminal</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>9-10</td> <td>80(±20) mΩ</td> <td>Open or Short</td> </tr> </tbody> </table>	Terminal	Normal	Abnormal	9-10	80(±20) mΩ	Open or Short			
Terminal	Normal	Abnormal								
9-10	80(±20) mΩ	Open or Short								
<p>2 kW heater (230 V, 1 phase)</p> 	<table border="1" data-bbox="702 996 1316 1064"> <thead> <tr> <th>Terminal</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>1-2</td> <td>26.5(+3/-1.3) Ω</td> <td>Open or Short</td> </tr> </tbody> </table>	Terminal	Normal	Abnormal	1-2	26.5(+3/-1.3) Ω	Open or Short			
Terminal	Normal	Abnormal								
1-2	26.5(+3/-1.3) Ω	Open or Short								
<p>2 + 4 kW heater (230 V, 1 phase)</p> 	<table border="1" data-bbox="702 1254 1316 1344"> <thead> <tr> <th>Terminal</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>1-2</td> <td>26.5(+3/-1.3) Ω</td> <td>Open or Short</td> </tr> <tr> <td>3-4</td> <td>13.3(+1.5/-0.6) Ω</td> <td>Open or Short</td> </tr> </tbody> </table>	Terminal	Normal	Abnormal	1-2	26.5(+3/-1.3) Ω	Open or Short	3-4	13.3(+1.5/-0.6) Ω	Open or Short
Terminal	Normal	Abnormal								
1-2	26.5(+3/-1.3) Ω	Open or Short								
3-4	13.3(+1.5/-0.6) Ω	Open or Short								
<p>3 + 6 kW heater (400 V, 3 phase)</p> 	<table border="1" data-bbox="702 1568 1316 1657"> <thead> <tr> <th>Terminal</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>1-2=2-3=1-3</td> <td>105.8(+11.8/-5) Ω</td> <td>Open or Short</td> </tr> <tr> <td>4-5=5-6=4-6</td> <td>52.9(+5.8/-2.5) Ω</td> <td>Open or Short</td> </tr> </tbody> </table>	Terminal	Normal	Abnormal	1-2=2-3=1-3	105.8(+11.8/-5) Ω	Open or Short	4-5=5-6=4-6	52.9(+5.8/-2.5) Ω	Open or Short
Terminal	Normal	Abnormal								
1-2=2-3=1-3	105.8(+11.8/-5) Ω	Open or Short								
4-5=5-6=4-6	52.9(+5.8/-2.5) Ω	Open or Short								
<p>3 + 6 kW heater (230V, 3 phase)</p> 	<table border="1" data-bbox="702 1881 1276 1971"> <thead> <tr> <th>Terminal</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>1-2=2-3=3-1</td> <td>35.3(+3.9/-1.8) Ω</td> <td>Open or Short</td> </tr> <tr> <td>4-5=5-6=6-4</td> <td>17.6(+1.9/-0.9) Ω</td> <td>Open or Short</td> </tr> </tbody> </table>	Terminal	Normal	Abnormal	1-2=2-3=3-1	35.3(+3.9/-1.8) Ω	Open or Short	4-5=5-6=6-4	17.6(+1.9/-0.9) Ω	Open or Short
Terminal	Normal	Abnormal								
1-2=2-3=3-1	35.3(+3.9/-1.8) Ω	Open or Short								
4-5=5-6=6-4	17.6(+1.9/-0.9) Ω	Open or Short								



Part Name	Check Points																		
<p><b>Thermistors</b></p>	<p>Disconnect the connector then measure the resistance with a tester. (At ambient temperatures of 10 to 30°C.)</p> <table border="1" data-bbox="715 338 1300 607"><thead><tr><th>Thermistor</th><th>Normal</th><th>Abnormal</th></tr></thead><tbody><tr><td>TH1</td><td rowspan="9">4.3–9.5 kΩ</td><td rowspan="9">Open or short</td></tr><tr><td>TH2</td></tr><tr><td>THW1</td></tr><tr><td>THW2</td></tr><tr><td>THW5</td></tr><tr><td>THW6</td></tr><tr><td>THW7</td></tr><tr><td>THW8</td></tr><tr><td>THW9</td></tr><tr><td>THWB1</td><td rowspan="2">40–100 kΩ</td><td rowspan="2">Open or short</td></tr><tr><td>THWB2</td></tr></tbody></table>	Thermistor	Normal	Abnormal	TH1	4.3–9.5 kΩ	Open or short	TH2	THW1	THW2	THW5	THW6	THW7	THW8	THW9	THWB1	40–100 kΩ	Open or short	THWB2
Thermistor	Normal	Abnormal																	
TH1	4.3–9.5 kΩ	Open or short																	
TH2																			
THW1																			
THW2																			
THW5																			
THW6																			
THW7																			
THW8																			
THW9																			
THWB1	40–100 kΩ	Open or short																	
THWB2																			
<p><b>Flow sensor</b></p> 	 <table border="1" data-bbox="802 797 1262 1133"><caption>Flow signal data points</caption><thead><tr><th>Flow [l/min]</th><th>Flow output signal [V]</th></tr></thead><tbody><tr><td>0</td><td>0.35</td></tr><tr><td>20</td><td>1.0</td></tr><tr><td>40</td><td>1.65</td></tr><tr><td>60</td><td>2.3</td></tr><tr><td>80</td><td>2.95</td></tr><tr><td>100</td><td>3.5</td></tr></tbody></table>	Flow [l/min]	Flow output signal [V]	0	0.35	20	1.0	40	1.65	60	2.3	80	2.95	100	3.5				
Flow [l/min]	Flow output signal [V]																		
0	0.35																		
20	1.0																		
40	1.65																		
60	2.3																		
80	2.95																		
100	3.5																		

<Thermistor Characteristics Charts>


- Room temperature thermistor (TH1)
- Liquid refrigerant temperature thermistor (TH2)
- Flow water temperature thermistor (THW1)
- Return water temperature thermistor (THW2)
- DHW tank temperature thermistor (THW5)
- Zone1 flow water temperature thermistor (THW6)
- Zone1 return water temperature thermistor (THW7)
- Zone2 flow water temperature thermistor (THW8)
- Zone2 return water temperature thermistor (THW9)

Thermistor R0 = 15kΩ ± 3%

B constant = 3480 ± 2%

$$R_t = 15 \exp \left\{ 3480 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	15 kΩ
10°C	9.6 kΩ
20°C	6.3 kΩ
25°C	5.2 kΩ
30°C	4.3 kΩ
40°C	3.0 kΩ




- Boiler flow water temperature thermistor (THWB1)
- Boiler return water temperature thermistor (THWB2)

Thermistor R100 = 3.3 kΩ ± 2%

B constant = 3970 ± 1%


$$R_t = 3.3 \exp \left\{ 3970 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	162.8 kΩ
10°C	97.4 kΩ
20°C	60.3 kΩ
25°C	48.1 kΩ
30°C	38.6 kΩ
40°C	25.4 kΩ
50°C	17.1 kΩ
60°C	11.9 kΩ
70°C	8.4 kΩ
80°C	6.0 kΩ



# 10-7. Test point diagram

## FTC (Controller board)



**<Preparation for the repair service>**

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the hydrobox and outdoor unit, turn off all the power-supply breaker.
- Discharge the condenser before the work involving the electric parts.
- Allow parts to cool.
- Do not expose the electric parts to water.
- When replacing or servicing water circuit parts, drain system first.

Check individual illustrations and positions of the parts by referring to the parts catalog.






Some lead wires and pipes are bundled with Bands. Cut the bands to undo the fastened pipes and lead wires if necessary. When bundling the lead wires and pipes again, use new commercially available bands.

When removing the parts associated with water pipe work, drain the hydrobox as necessary. (Refer to "Draining the Hydrobox" on page 33.)

When draining the hydrobox, keep water from splashing on the internal parts (mainly electric parts and insulations).

—————> : Indicates the visible parts in the photos/figures.

-----> : Indicates the invisible parts in the photos/figures.

DISASSEMBLY PROCEDURE	PHOTOS/ FIGURES
<p><b>1. How to remove the front panel</b></p> <p>(1) Remove the 2 screws at the bottom of the hydrobox. (Photo 1-1)</p> <p>(2) Slightly lift and pull out the front panel from the hydrobox. (Photo 1-1)</p> <p>(3) Disconnect the relay connector connecting from the main remote controller. (Photo 1-2)</p> <p><b>Photo 1-2</b></p> 	<p><b>Photo 1-1</b></p> 
<p><b>2. How to remove the main remote controller</b></p> <p>(1) Remove the front panel. (Refer to Procedure 1).</p> <p>(2) Turn the front panel over and remove the 5 claws at the white frame. (Photo 2-1)</p> <p>(3) Slide the main remote controller support upward, then remove it together with the main remote controller. (Photo 2-2)</p> <p>(4) Separate the main remote controller from the main remote controller support. (Photo 2-3)</p> <p><b>Photo 2-2</b></p>  <p><b>Photo 2-3</b></p> 	<p><b>Photo 2-1</b></p> 



## DISASSEMBLY PROCEDURE

### 3. How to remove the electrical parts

(Steps (1) through (3) are applied to all the following parts.)

- (1) Remove the front panel. (Refer to Procedure 1).
- (2) Remove the 3 screws holding the control box. (Photo 3-1)
- (3) Slightly lift and pull out the control box. (Photo 3-1)

#### <Earth leakage circuit breaker> (Photo 3-2)

- (4) Disconnect all the lead wires from the earth leakage circuit breaker.
- (5) Remove the 2 screws on the earth leakage circuit breaker.

Note: To avoid dropping of the breaker, hold the breaker by hand when removing the last screws.

#### <Contactor> (Photo 3-2)

- (4) Disconnect all the lead wires from the contactors.
- (5) Remove the 2 screws on each contactor.

Note: To avoid dropping of the contactors, hold the contactors by hand when removing the last screws. To prevent an electrical shock, wait until all the LED lamps on the FTC control board are turned off.

#### <Terminal block> (Photo 3-2)

- (4) Disconnect all the lead wires from the terminal block. (To disconnect the S1, S2 and S3 lead wires, disengage the locks by pressing on the claws.)
- (5) Remove the screw on the terminal block.

Note: To avoid dropping of the terminal block, hold the terminal block by hand when removing the screw .

#### <Controller board> (Photo 3-3)

- (4) Disconnect all the lead wires from the controller board.
- (5) Remove the controller board from the 4 board supports.

## PHOTOS/ FIGURES

Photo 3-1

Control box fixing screws





Photo 3-2

Earth leakage circuit breaker (ECB1)

Control box


Controller board



\* The photos shown are of the EHSC-YM9C model.

Photo 3-3

Board supports



## DISASSEMBLY PROCEDURE


### 4. How to swing the control box to the front

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Remove the screw from the control box bracket (R) and 2 screws from the control box bracket (L).
- (3) Release the coated clamp.
- (4) Disengage the control box bracket (R) from the right-hand side panel and pull the control box. At this point, lifting slightly and pulling the control box will swing the control box to the front. (Photo 4-2)

Note: Remove the field wiring as necessary.


## PHOTOS/ FIGURES

Photo 4-1



\* The photos shown are of the EHSC-YM9C model.

Photo 4-2



## DISASSEMBLY PROCEDURE

### 5. How to remove water pump/ pump valve

#### E\*S\* series


##### <Water pump>

- Close the pump valve (OFF) before removing the water pump, and open the valves (ON) after reinstalling the water pump.
- (1) Remove the front panel. (Refer to Procedure 1.)
  - (2) Disconnect the CNP1 connector, the earth cable, and the CNPWM connector in the control box. (Photo 5-1)
  - (3) Release the water pump lead wire from the 5 cable clamps, the 2 cable straps, the coated clamp and feed the lead wire out the control box without putting strain on the CNP1 connector. (Photo 5-1)
  - (4) Swing the control box to the front. (Refer to Procedure 4.)
  - (5) Close (OFF) the pump valve and remove the G1" nuts using 2 spanners: one to hold the G1" nut and the other to turn the other side of G1" nut.  
Remove the water pump by sliding it horizontally. (Photo 5-2)
- When the pump valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner.
  - When reinstalling the G1" nuts, use new G1" gaskets. (Photo 5-3)
  - Set the water pump in the way that the die stamped arrow facing down, and the terminal box facing to the left. (Photo 5-2)
  - When opening or closing the pump valve, ensure to do so fully, not halfway.

##### <Pump valve>

- (6) Remove the screws fixing the pump valve stay. (Photo 5-2)
  - (7) Remove the pump valve by detaching the quick connection. (Photo 5-2)
- When reinstalling the quick connection, use new O-ring.
  - When the pump valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner. (Photo 5-4)
  - When reinstalling the pump valve, place the handle to the left hand side of the pump valve.
  - When opening or closing the pump valve, ensure to do so fully, not halfway.
  - Reuse the removed pump valve stay and the pump valve stay fixing screws. (Photo 5-4)
  - Refer to page 90 for how to attach and detach the quick connection.
- Note: Skip Steps (2) and (3) above when replacing the pump valves only.

#### Photo 5-3(E\*S\* series)



## PHOTOS/ FIGURES

Photo 5-1




Photo 5-2(E\*S\* series)





Photo 5-4(E\*S\* series)



## DISASSEMBLY PROCEDURE

### 5. How to remove water pump/ pump valve(continued) EHPX series

#### <Water pump>

Close the pump valve and strainer valve (OFF) before removing the water pump, and open the valves (ON) after reinstalling the water pump.

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Disconnect the CNP1 connector, the earth cable, and the CNPWM connector in the control box. (Photo 5-1)
- (3) Release the water pump lead wire from the 5 cable clamps, the 2 cable straps, the coated clamp and feed the lead wire out the control box without putting strain on the CNP1 connector. (Photo 5-1)
- (4) Swing the control box to the front. (Refer to Procedure 4.)
- (5) Close (OFF) the pump valve and strainer valve, and remove the G1" nuts using 2 spanners: one to hold the G1" nut and the other to turn the other side of G1" nut. Remove the water pump by sliding it up. (Photos 5-5)
  - When either of the pump valve handle or strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner.
  - When reinstalling the G1" nuts, use new G1" gaskets. (Photo 5-3)
  - Set the water pump in the way that the die stamped arrow facing to the left, and the terminal box facing to the upper side. (Photo 5-2)
  - When opening or closing the pump valve and strainer valve, ensure to do so fully, not halfway.


#### <Pump valve>

- (6) Remove the screws fixing the pump valve stay. (Photo 5-5)
- (7) Remove the pump valve by detaching the quick connection. (Photo 5-5)
  - When reinstalling the quick connection, use new O-ring.
  - When either of the pump valve handle or strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner.
  - When reinstalling the pump valve, place the handle to the upper side of the pump valve.
  - When opening or closing the pump valve, ensure to do so fully, not halfway.
  - Reuse the removed pump valve stay and the pump valve stay fixing screws. (Photo 5-4)
  - Refer to page 90 for how to attach and detach the quick connection.

Note: Skip Steps (2) and (3) above when replacing the pump valves only.

## PHOTOS/ FIGURES

Photo 5-5(EHPX series)



## DISASSEMBLY PROCEDURE

### 6. How to remove the flow sensor

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Disconnect the CN1A connector on the controller board. (Photo 6-1)
- (3) Release the flow sensor lead wire from the cable clamp, the 2 cable straps, the coated clamp and feed the lead wire out the control box without putting strain on the CN1A connector. (Photo 6-1)
- (4) Swing the control box to the front. (Refer to Procedure 4.)
- (5) Remove the flow sensor by removing the nut. (Photo 6-2)

<For R2/R3 models>

- (5) Remove the flow sensor by detaching the same diameter quick connection. (Photos 6-4 and 6-5)

- When reinstalling the flow sensor, use new O-rings. (Photo 6-3 and 6-5)
- Set the flow sensor in the orientation of the arrow printed on the flow sensor and in the way that the sensor part faces to the left. (Photo 6-2 and 6-4)
- Refer to page 90 for how to attach and detach the quick connection.

### R2/R3 models

Photo 6-4





Photo 6-5



## PHOTOS/ FIGURES

Photo 6-1




Photo 6-2





Photo 6-3



## DISASSEMBLY PROCEDURE

### 7. How to remove the booster heater

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Disconnect the booster heater lead wires from the CNBHT connector on the controller board and from the BHC1 (Lead wire No.1, No.2 and No.3) and BHC2 (Lead wire No.4, No. 5 and No.6) contactors respectively. (Photo 7-1)
- (3) Swing the control box to the front. (Refer to Procedure 4.)

Note: Do not mix up the lead wire numbers when re-connecting the lead wires to the contactors as the lead wire numbers are different depending on the models.

Model	Lead wire No.	Contactor
EHSC-VM6C	No.1	BHC1-U
EHSC-VM6EC	No.2	BHC1-V
EHPX-VM6C	No.3	BHC2-U
	No.4	BHC2-V
EHSC-YM9C	No.1	BHC1-U
EHSC-YM9EC	No.2	BHC1-V
EHSC-TM9C	No.3	BHC1-W
EHSD-YM9C	No.4	BHC2-U
	No.5	BHC2-V
EHPX-YM9C	No.6	BHC2-W
	No.1	BHC1-U
EHSD-VM2C	No.2	BHC1-V
EHSC-VM2C		
EHSC-VM2EC		
ERSD-VM2C		
EHPX-VM2C		
ERSC-VM2C		


Refer to 6. WIRING DIAGRAM

### <E\*S\* series>

- (4) Remove the pump valve. (Refer to Procedure 5.)
- (5) Remove the flow sensor. (Refer to Procedure 6.)
- (6) Remove the L joint and the pipe (L-F.S.) by detaching the quick connection. (Photo 7-2)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (7) Remove the flare nut (Photo 7-2).
- (8) Remove the pipe (P.V.-B.H.) by detaching the quick connection. (Photo 7-2)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (9) Remove the 2 screws that hold the heater stay onto the back panel. Lift the booster heater slightly and remove the booster heater with the heater stay from the back panel. (Photo 7-2 and 7-3)
- (10) Remove the 2 screws on the back of the heater stay and remove the heater stay from the booster heater. (Photo 7-3)
  - Reuse the removed heater stay and the heater stay fixing screws.

## PHOTOS/ FIGURES

Photo 7-1



\* The photos shown are of the EHSC-YM9C model.

Photo 7-2(E\*S\* series)





Photo 7-3



## DISASSEMBLY PROCEDURE


## PHOTOS/ FIGURES

### 7. How to remove the booster heater (continued)

#### <EHPX series>

- (4) Detach the quick connection 1 and 2. (Photo 7-4)
  - When reinstalling the quick connections, use new O-rings.
  - Refer to page 90 for how to attach and detach the quick connection.
- (5) Remove the flare nut. (Photo 7-4)
- (6) Remove the saddle band by removing the screws on the saddle band. (Photo 7-4)
- (7) Remove the 2 screws that hold the heater stay onto the back panel. Lift the booster heater slightly and remove the booster heater with the heater stay and the pipe (to B.H.) from the back panel. (Photo 7-4 and 7-5)
- (8) Remove the pipe (to B.H.) from the booster heater by detaching the quick connection 3. (Photo 7-4)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
  - Reuse the removed pipe (to B.H.).
- (9) Remove the 2 screws on the back of the heater stay and remove the heater stay from the booster heater. (Photo 7-3)

**Photo 7-4(EHPX series)**



**Photo 7-5(EHPX series)**



## DISASSEMBLY PROCEDURE

### 8. How to remove the plate heat exchanger

- (1) Pump down the refrigerant circuit and close the stop valve on the outdoor unit. (Refer to "12. Supplementary information".)
- (2) Remove the front panel. (Refer to Procedure 1.)
- (3) Remove the water pump and the pump valve. (Refer to Procedure 5.)
- (4) Remove the expansion vessel. (Refer to Procedure 11.)

#### <ERSC series>

- (5) Remove the saddle band (upper the pump) by removing the 2 screws. (Photo 8-2)
- (6) Remove the pipe (W.C.-W.P.) and the pipe (P.V.-B.H.) by detaching the quick connections.
  - When reinstalling the quick connections, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.

## PHOTOS/ FIGURES

Photo 8-1





Photo 8-2(ERSC series)





## DISASSEMBLY PROCEDURE

### 8. How to remove the plate heat exchanger (continued) <ERSC series>

- (7) Close the strainer valve and remove the G1" nut on the water outlet side of the strainer valve using 2 spanners: one to hold the strainer valve and the other to turn the G1" nut. (Photo 8-2)
  - When reinstalling the G1" nut, use a new G1" gasket.
  - When the strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner. (Photo 8-2)
  - When opening or closing the strainer valve, ensure to do so fully, not halfway.
- (8) Remove the pipe (STR-W.C.) by detaching the quick connection for the pipe and heat exchanger, then slide it to the right. (Photo 8-2)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (9) Remove the TH2 thermistor from the thermistor holder. (Photo 8-3)
- (10) Remove the flare nuts on the gas and liquid pipes under the hydrobox using 2 spanners: one to hold each flare joint and the other to turn each flare nut.
- (11) Remove the water coil cover by removing the 3 screws. (Photo 8-2)
- (12) Pull out the plate heat exchanger assembly from the hydrobox by lifting it upward. (Photos 8-3 and 8-4)

## PHOTOS/ FIGURES

Photo 8-3(ERSC series)





Plate heat exchanger Strainer valve

Photo 8-4



## DISASSEMBLY PROCEDURE

### <EHSC series>

Procedure (1) to (6) is the same as <ERSC series>.

(7) Remove the G1" nut on the water inlet side of the strainer valve using 2 spanners: one to hold the strainer valve and the other to turn the G1" nut. (Photo 8-5)

- When reinstalling the G1" nut, use a new G1" gasket.

(8) Remove the TH2 thermistor from the thermistor holder. (Photo 13-2)

(9) Remove the flare nuts on the gas and liquid pipes under the hydrobox using 2 spanners: one to hold each flare joint and the other to turn each flare nut.

(10) Remove the water coil cover by removing the 3 screws. (Photo 8-5)

(11) Remove the 2 screws on the strainer valve stay. (Photo 8-6)

(12) Pull out the plate heat exchanger assembly with the strainer valve from the hydrobox by lifting it upward. (Photo 8-6)

(13) Remove the strainer valve from the plate heat exchanger assembly by detaching the quick connection. (Photos 8-4 and 8-6)

- When reinstalling the quick connection, use new O-ring.
- Refer to page 90 for how to attach and detach the quick connection.

## PHOTOS/ FIGURES

Photo 8-6(EHSC series)





Photo 8-5(EHSC series)



## DISASSEMBLY PROCEDURE

## PHOTOS/ FIGURES


### 8. How to remove the plate heat exchanger (continued)

Refer to the previous page for step (1) to (5). (Skip (4).)

#### <E\*SD series>

- (6) Remove the pipe (W.C.-W.P) and L joint (upper) together by detaching the quick connection for the L joint (upper) and the plate heat exchanger. (Photo 8-7)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (7) Remove the pipe (P.V.-B.H.) by detaching the quick connection. (Photo 8-7)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (8) Close the strainer valve. (Photo 8-7)
  - When the strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner. (Photo 8-5)
  - When opening or closing the strainer valve, ensure to do so fully, not halfway.
- (9) Remove the saddle band (upper the strainer) by removing the 2 screws. (Photo 8-7)
- (10) Detach the quick connection for the L joint (Lower) and the plate heat exchanger, and rotate forward the pipe (to W.C.) with the L joint (lower) by using the quick connection (upper the strainer) as a fulcrum.
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (11) Remove the TH2 thermistor from the thermistor holder. (Photo 8-7)

Photo 8-7(E\*SD series)



## DISASSEMBLY PROCEDURE

### 8. How to remove the plate heat exchanger(continued) <E\*SD series>

- (12) Remove the flare nuts on the gas and liquid pipes under the hydrobox using 2 spanners: one to hold each flare joint and the other to turn each flare nut.
- (13) Remove the plate heat exchanger with water coil cover by lifting it upward after removing the 2 screws on the water coil cover. (Photos 8-7 and 8-8)
- (14) Remove the water coil cover and the water coil base by removing the 6 screws. (Photo 8-9)

## PHOTOS/ FIGURES

Photo 8-8(E\*SD series)





Plate heat exchanger

Photo 8-9(E\*SD series)



## DISASSEMBLY PROCEDURE

### 9. How to remove the strainer


#### <ERS\* / EHS\* series>

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Swing the control box to the front. (Refer to Procedure 4.)
- (3) Close the strainer valve (OFF). (Photos 9-1 and 9-4)
  - When the strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner.
  - When opening or closing the strainer valve, ensure to do so fully, not halfway.
- (4) Remove the 2 screws on the strainer valve stay. (Photos 9-1 and 9-4)
- (5) Remove the G1" nut using 2 spanners: one to hold the strainer and the other to turn the G1" nut. (Photos 9-1 and 9-4)
  - When reinstalling the G1" nut, use new G1" gasket.
- (6) Detach the quick connection. (Photos 9-1 and 9-4)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
  - Reuse the removed strainer valve stay and the strainer valve stay fixing screws. (Photos 9-2 and 9-5)

#### <Removal of the strainer cover (debris recovery)>


- (4) Remove the cover with 2 spanners: one to hold the strainer valve and the other to turn the cover. (Photos 9-1 and 9-4)
  - Be sure to reattach the mesh after washing. (Photo 9-3)
  - When reinstalling the cover, use a new packing.

**Photo 9-3**




## PHOTOS/ FIGURES


**Photo 9-1(ERS\* series)**




**Photo 9-2(ERS\* series)**



**Photo 9-4(EHS\* series)**



**Photo 9-5(EHSC series)**



## DISASSEMBLY PROCEDURE

### 9. How to remove the strainer(continued)

#### <EHPX series>

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Swing the control box to the front. (Refer to Procedure 4.)
- (3) Close the strainer valve (OFF). (Photo 9-6)
  - When the strainer valve handle is stiff, turn the handle 90 degrees clockwise mainly by using a spanner.
  - When opening or closing the strainer valve, ensure to do so fully, not halfway.
- (4) Remove the 2 screws on the strainer valve stay. (Photos 9-1 and 9-4)
- (5) Remove the G1" nut using 2 spanners: one to hold the strainer and the other to turn the G1" nut. (Photo 9-6)
  - When reinstalling the G1" nut, use new G1" gasket
- (6) Detach the quick connection, then remove the strainer valve and L joint together by lifting them upward (Photo 9-6)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
- (7) Remove the L joint by detaching the quick connection and remove the strainer valve stay by removing the 2 screws. (Photo 9-7)
  - When reinstalling the quick connection, use new O-ring.
  - Refer to page 90 for how to attach and detach the quick connection.
  - Reuse the removed L joint, the strainer valve stay and the strainer valve stay fixing screws.

#### <Removal of the strainer cover (debris recovery)>

- (4) Remove the cover with 2 spanners: one to hold the strainer valve and the other to turn the cover.
  - Be sure to reattach the mesh after washing. (Photo 9-3)
  - When reinstalling the cover, use a new packing.

## PHOTOS/ FIGURES

Photo 9-6(EHPX series)





Photo 9-7(EHPX series)



## DISASSEMBLY PROCEDURE

### 10. How to remove the manometer / pressure relief valve / air vent (automatic)

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Swing the control box to the front. (Refer to Procedure 4.)

#### <Manometer>

- (3) Remove the screw on the manometer. (Photo 10-1)
- (4) Hold the sides of the manometer cover, disengage the claws, and remove the manometer with cover. (Photo 10-1)
- (5) Remove the G1/4" nut and feed the capillary tube throughout the hydrobox.
  - When reinstalling the G1/4" nut, use a new G1/4" gasket. (Photo 10-2)
- (6) Remove the manometer from the manometer cover while pressing on the claws. (Photo 10-3)
  - When reinstalling the manometer assembly on the hydrobox beware not to put strain on the root of the capillary tube as the capillary tube is easy to break at the root.

#### <Pressure relief valve> (3bar)

- (3) Remove the field piping from the pressure relief valve.
- (4) Remove the manometer by removing the G1/4" nut.
  - When reinstalling the G1/4" nut, use a new G1/4" gasket. (Photo 10-2)
- (5) Remove the pressure relief valve with a flare joint using 2 spanners: one to hold the flare joint and the other to turn the flare nut. (Photo 10-2)
- (6) Remove the pressure relief valve using 2 spanners: one to hold the flare joint and the other to turn the pressure relief valve. (Photo 10-4)
- (7) Eliminate loctite on the thread surfaces using remover. (Photo 10-4)
  - Before reinstallation, apply loctite over the thread surface on the pressure relief valve.
  - For more details about the loctite and the remover, refer to Page 91.
  - Suitable drain pipe work should be attached to pressure relief valve(3bar).
  - Make sure to carry out check (turn the cap) on pressure relief valve(3bar).

## PHOTOS/ FIGURES

Photo 10-1




Photo 10-2




Photo 10-3





Photo 10-4



## DISASSEMBLY PROCEDURE

### 10. How to remove the manometer / pressure relief valve / air vent (automatic) (Continued)


#### <Pressure relief valve(5bar)>

- (3) Remove the right side panel.
- (4) Remove the band at the base of the pressure relief valve(5bar).
- (5) Remove the pressure relief valve with a flare joint using 2 spanners: one to hold the flare joint and the other to turn the flare nut. (Photo 10-5)
- (6) Remove the pressure relief valve using 2 spanners: one to hold the flare joint and the other to turn the pressure relief valve. (Photo 10-4)
- (7) Eliminate loctite on the thread surfaces using remover. (Photo 10-4)
  - Before reinstallation, apply loctite over the thread surface on the pressure relief valve.
  - For more details about the loctite and the remover, refer to Page 91.
  - The outlet for the pressure relief valve (5bar) should be open ended and facing the rear panel.

#### <Air vent (automatic)>

- (3) Remove the air vent with a flare joint using 2 spanners: one to hold the flare joint and the other to turn the flare nut.
- (4) Remove the flare joint from the air vent. (Photo 10-7)

Photo 10-7



## PHOTOS/ FIGURES

Photo 10-5 (R3 model only)





Photo 10-6



### 11. How to remove the expansion vessel

- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Swing the control box to the front. (Refer to Procedure 4.)
- (3) Remove the flare nut using 2 spanners: one to hold the flare joint and the other to turn the flare nut. (Photo 11-1)
- (4) Remove the 2 screws on the metal support.
  - Note: To avoid dropping of the expansion vessel, hold the expansion vessel with the metal support by hand when removing the last screw.
- (5) Pull out the metal support. (Photo 11-1)
- (6) Pull out the expansion vessel. (Photo 11-1)
- (7) Remove the flare joint from the expansion vessel. (Photo 11-2)
  - When reinstalling the flare joint, use a new G3/8" gasket.

Note: To avoid dropping of the expansion vessel, hold it securely when removing it.

Photo 11-1





Photo 11-2






## DISASSEMBLY PROCEDURE

### 12. How to remove the drain cock (primary circuit)


- (1) Remove the front panel. (Refer to Procedure 1.)
- (2) Swing the control box to the front. (Refer to Procedure 4.)
- (3) Remove the drain cock (primary circuit).

**Photo 12-1 (E\*S\* series)**



## PHOTOS/ FIGURES


**Photo 12-2 (EHPX series)**




### 13. How to remove the thermistor <liquid refrigerant temp.> (TH2) / thermistor <flow water temp. & return water temp.> (THW1, THW2)

- (1) Remove the front panel. (Refer to Procedure 1.)
  - (2) Remove the control box cover. (Refer to Procedure 3.)
  - (3) Disconnect the following connectors on the control board.
    - TH2 (CN21)
    - THW1, THW2 (CNW12)
  - (4) Release the THW1, THW2 and TH2 lead wires from the cable clamp, the 2 cable straps and the coated clamp. Feed the lead wires out the control box without putting strain on their connectors.
  - (5) Swing the control box to the front. (Refer to Procedure 4.)
  - (6) Remove the thermistors from the thermistor holders.
- (Photos 13-2, 13-3 and 13-4)


**Photo 13-1**




**Photo 13-2(EHS\* series)**



**Photo 13-4(ERS\* series)**



**Photo 13-3(EHPX series)**



## DISASSEMBLY PROCEDURE

### 14. How to remove the drain pan (ERS\*series)

- (1) Remove the front panel.
- (2) Disconnect all the field piping.
- (3) Remove the saddle band and the rubber tube by removing the 2 screws. Then remove the 2 screws fixing the strainer valve stay. (Photos 14-1)
  - Reuse the removed saddle band, rubber tube and screws fixing the saddle band and rubber tube.
- (4) Remove the screw on the manometer cover, then remove the manometer claw. (Photo 14-1)
- (5) Remove 3 screws on the cover plate. (Photo 14-3)
- (6) Remove the cover plate. (Photo 14-4)
- (7) Remove 3 screws each on the side panel (L, R), and 2 screws on the underneath surface and base assy from the hydrobox. (Photo 14-5)
- (8) Remove 5 screws on the base assy. (Photo 14-6)
- (9) Remove the drain pan from the base. (Photo 14-7)
- (10) Remove the 2 screws fixing strainer valve holder, and remove the strainer valve holder. (Photo 14-2)
  - Reuse removed the strainer valve holder and the strainer valve holder fixing screws.

## PHOTOS/ FIGURES

Photo 14-1




Photo 14-2




Photo 14-3




Photo 14-4




Photo 14-5




Photo 14-6





Photo 14-7



## DISASSEMBLY PROCEDURE

### 15. How to detach and attach the quick joint

Refer to the following steps when detaching and attaching the quick connection.

- (1) Remove the clip. (Photos 15-1 and 15-2)
- (2) Separate the connected parts to remove the O-ring. (Photo 15-3)
  - Do not reuse the removed O-ring.
  - Wipe off if dirt or foreign matters are found on the sealing surface where the O-ring touches.
- (3) Apply grease on the O-ring using a plastic bag, etc. (Photo 15-4)
- (4) Attach the O-ring to the male part of quick connection. (Photo 15-5)
  - Keep the O-ring free from dirt or foreign matters.
- (5) Connect the male and female parts of the quick connection. (Photo 15-6)
- (6) Attach the clip. (Photo 15-7)
  - Ensure to attach the wider diameter of the clip to the female side. Failure to do so, it may cause water leak at the connected part. (Photo 15-8) (For the same diameter quick connection, following this note is not necessary.)

## PHOTOS/ FIGURES

Photo 15-1




Photo 15-2




Photo 15-3




Photo 15-4




Photo 15-5



Photo 15-6




Photo 15-7





Photo 15-8



## Notes on replacing the parts

Replacement of the parts listed below requires the following procedure.

After the parts are removed, eliminate loctite on threads by applying loctite remover, apply new loctite, and then install and tighten the parts to the specified tightening torques below. For details about recommended loctite and loctite remover, refer to Table 11-1, and for details about the replacement parts and their tightening torques, refer to Table 11-2.

**Table 11-1**

Recommended	Manufacturer	No.	Note
Loctite	Henkel	Loctite 5400	Apply loctite all over from the end of external thread to the second ridge. After installing the parts, fix the parts for at least 30 minutes
Loctite remover	Henkel	Loctite 7200 Gasket Remover	Spray loctite remover over sealant on the threads, let the sealant sit until soft, and then eliminate it with a wire brush.

Note: When using the products above, refer to the appropriate manuals that come with the individual products.

**Table 11-2**

Part name *1	Recommended tightening torque [Nm] *2
PRESSURE RELIEF VALVE (3bar)	15 ± 1
PRESSURE RELIEF VALVE (5bar)	15 ± 1

\*1 For more details about the listed parts, refer to the parts catalogue.

\*2 Undertightening and overtightening the parts affect water seal life. Tighten the parts to the appropriate tightening torques.

When installing the parts that are not listed above, observe the tightening torques in accordance with Table 11-3.

Always use a new O-ring or gasket.

**Table 11-3**

	Size [inch]	Recommended tightening torque [Nm]
Gasket	G1/4"	8 ± 1
	G3/8"	15 ± 1
	G1"	42 ± 2
Packing	Strainer cover	40 ± 2
O-ring	Flow sensor	30 ± 2
	Air vent (Automatic)	15 ± 1
Attached packing	Drain cock (primary circuit)	0.25 ± 0.05
Flare joint (for water circuit parts)		35 ± 2

After the procedure is complete, ensure that no water leaks.

### 12-1. Refrigerant collecting (pumpdown) for split model systems only

Refer to "Refrigerant collection" in the outdoor unit installation manual or service manual.

### 12-2. Back-up operation of boiler

Heating operation is backed up by boiler.

For more details, refer to the installation manual of PAC-TH011HT-E.

#### <Installation & System set up>

1. Set DIP-SW 1-1 to ON "With boiler" and SW2-6 to ON "With Mixing tank".
2. Install the thermistors THWB1 (Flow temp.) and THWB2 (Return temp.) \*1 on the boiler circuit.
3. Connect the output wire (OUT10: Boiler operation) to the signal input (room thermostat input) on the boiler. \*2
4. Install one of the following room temp. thermostats. \*3

- Wireless remote controller (option)
- Room temp. thermostat (local supply)
- Main remote controller (remote position)

\*1 The boiler temperature thermistor is an optional part.

\*2 OUT10 has no voltage across it.

\*3 Boiler heating is controlled on/off by the room temp. thermostat.

#### <Remote controller settings>

1. Go to Service menu > Heat source setting and choose "Boiler" or "Hybrid". \*4
2. Go to Service menu > Operation settings > Boiler settings to make detailed settings for "Hybrid" above .

\*4 The "Hybrid" automatically switches heat sources between Heat pump (and Electric heater) and boiler.

### 12-3. Multiple outdoor units control

To realize bigger systems by using multiple outdoor units, up to 6 units of the same model can be connected.

The hydrobox can be used as a slave unit for multiple outdoor unit control.

For more details, refer to the installation manual of PAC-IF061/062B-E.

PAC-IF051/052B-E cannot be connected to the hydrobox.

Check the model name of connecting master unit.

#### <DIP switch setting>

- Set DIP SW4-1 to ON "Active: multiple outdoor unit control".
- Keep DIP SW4-2 OFF (default setting) (master/slave setting: slave).
- Set DIP SW1-3 to ON when the hydrobox is connected to a DHW tank.

The main remote controller settings changed from the default settings are reset by replacing the controller board. To facilitate re-selecting settings on the main remote controller, it is recommended to write down the changes in the sheet below before replacement.

**13-1. Engineers Forms (1/2)**

Should settings be changed from default, please enter and record new setting in 'Field Setting' column. This will ease resetting in the future should the system use change or the circuit board need to be replaced.

**Commissioning/Field settings record sheet**

Main remote controller screen		Parameters	Default setting	Field setting	Notes	
<b>Main</b>	Zone1 heating room temp.	10–30°C	20°C			
	Zone2 heating room temp. *1	10–30°C	20°C			
	Zone1 heating flow temp.	25–60°C	45°C			
	Zone2 heating flow temp. *2	25–60°C	35°C			
	Zone1 cooling flow temp. *3	5–25°C	15°C			
	Zone2 cooling flow temp. *3	5–25°C	20°C			
	Zone1 heating compensation curve	–9–+9°C	0°C			
	Zone2 heating compensation curve *2	–9–+9°C	0°C			
	Holiday mode	Active/Non active/Set time	—			
<b>Option</b>	Forced DHW operation	ON/OFF	—			
	DHW	ON/OFF/Timer	ON			
	Heating/Cooling	ON/OFF/Timer	ON			
	Energy monitor	Consumed electrical energy/Delivered energy	—			
<b>Setting</b>	DHW *4	Operation mode	Normal/Eco *5	Normal		
		DHW max. temp.	40–60°C *6	50°C		
		DHW temp. drop	5–30°C	10°C		
		DHW max. operation time	30–120 min	60 min		
		DHW mode restriction	30–120 min	30 min		
		Legionella prevention *4	Active	Yes/No	Yes	
	Heating/ Cooling *3	Hot water temp.	60–70°C *6	65°C		
		Frequency	1–30 days	15 days		
		Start time	00.00–23.00	03.00		
		Max. operation time	1–5 hours	3 hours		
		Duration of maximum temp.	1–120 min	30 min		
		Compensation curve	Hi flow temp. set point	Zone1 outdoor ambient temp.	–30–+33°C *7	–15°C
Zone1 flow temp.	25–60°C			50°C		
Zone2 outdoor ambient temp. *2	–30–+33°C *7			–15°C		
Zone2 flow temp. *2	25–60°C			40°C		
Lo flow temp. set point	Zone1 outdoor ambient temp.			–28°C–+35°C *8	35°C	
	Zone1 flow temp.			25–60°C	25°C	
	Zone2 outdoor ambient temp. *2		–28–+35°C *8	35°C		
	Zone2 flow temp.		25–60°C	25°C		
	Adjust		Zone1 outdoor ambient temp.	–29–+34°C *9	—	
			Zone1 flow temp.	25–60°C	—	
Zone2 outdoor ambient temp. *2			–29–+34°C *9	—		
Zone2 flow temp. *2			25–60°C	—		
Holiday		DHW *5	Active/Non active	Non active		
		Heating/ Cooling *3	Active/Non active	Active		
	Zone1 heating room temp.	10–30°C	15°C			
	Zone2 heating room temp. *1	10–30°C	15°C			
	Zone1 heating flow temp.	25–60°C	35°C			
	Zone2 heating flow temp. *2	25–60°C	25°C			
	Zone1 cooling flow temp. *3	5–25°C	25°C			
	Zone2 cooling flow temp. *3	5–25°C	25°C			
	Initial settings	Language	EN/FR/DE/SV/ES/IT/DA/NL/FI/NO/PT/BG/PL/CZ/RU	EN		
		°C/°F	°C/°F	°C		
		Summer time	ON/OFF	OFF		
		Temp. display	Room/DHW tank/Room&DHW tank /OFF	OFF		
Time display		hh:mm/hh:mm AM/AM hh:mm	hh:mm			
Room sensor settings for Zone1		TH1/Main RC/Room RC1-8/"Time/Zone"	TH1			
Room sensor settings for Zone2 *2		TH1/Main RC/Room RC1-8/"Time/Zone"	TH1			
Room RC zone select *2		Zone1/Zone2	Zone1			
Service menu	Thermistor adjustment	THW1	–10–+10°C	0°C		
		THW2	–10–+10°C	0°C		
		THW5	–10–+10°C	0°C		
		THW6	–10–+10°C	0°C		
		THW7	–10–+10°C	0°C		
		THW8	–10–+10°C	0°C		
		THW9	–10–+10°C	0°C		
		THWB1	–10–+10°C	0°C		
		THWB2	–10–+10°C	0°C		
		Auxiliary settings	Economy settings for pump.	ON/OFF *10	ON	
	Delay (3–60 min)			10 min		
	Electric heater (Heating)		Space heating: ON (used)/OFF (not used)	ON		
	Electric heater (DHW) *4		Electric heater delay timer (5–180 min)	30 min		
	Booster heater		DHW: ON (used)/OFF (not used)	ON		
	Immersion heater		DHW: ON (used)/OFF (not used)	ON		
	Electric heater delay timer (15–30 min)			15 min		
	Mixing valve control		Running (10–240 sec)	120 sec		
	Interval (1–30 min)		2 min			
Flow sensor	Minimum (0–100 L/min)		5 L/min			
	Maximum (0–100 L/min)		100 L/min			

\*1 The settings related to Zone2 can be switched only when 2-zone temperature control or 2-zone valve ON/OFF control is active.

\*2 The settings related to Zone2 can be switched only when 2 Zone temperature control is enabled (when DIP SW2-6 and SW 2-7 are ON).

\*3 Cooling mode settings are available for ERS \* model only.

\*4 Only available if DHW tank present in system.

\*5 When the hydrobox is connected with a PUMY-P outdoor unit, the mode is fixed to "Normal".

## Engineers Forms (2/2)

Commissioning/Field settings record sheet (continued from the previous page)

Main remote controller screen			Parameters	Default setting	Field setting	Notes		
Service menu	Pump speed		Pump speed (1–5)	5				
	Heat source setting		Standard/Heater/Boiler/Hybrid *11	Standard				
	Operation settings	Heating operation *12	Flow temp.range *13	Min.temp. (25–45°C)	30°C			
				Max.temp. (35–60°C)	50°C			
			Room temp.control *14	Mode (Normal/Fast)	Normal			
				Interval (10–60 min)	10 min			
			Heat pump thermo diff.adjust	ON/OFF *10	ON			
		Lower limit (–9––1°C)		–5°C				
		Upper limit (+3–+5°C)		5°C				
		Freeze stat function *11		Outdoor ambient temp. (3–20°C)**	5°C			
		Simultaneous operation (DHW/Heating)		ON/OFF *10	OFF			
				Outdoor ambient temp. (–30–+10°C) *8	–15°C			
	Cold weather function		ON/OFF *10	OFF				
			Outdoor ambient temp. (–30–+10°C) *8	–15°C				
	Boiler operation		Hybrid settings	Outdoor ambient temp. (–30–+10°C) *8	–15°C			
				Priority mode (Ambient/ Cost/CO <sub>2</sub> ) *16	Ambient			
				Intelligent settings	Energy price *17	Electricity (0.001–999 */kWh)	0.5 */kWh	
			Boiler (0.001–999 */kWh)		0.5 */kWh			
			CO <sub>2</sub> emission	Electricity (0.001–999 kg-CO <sub>2</sub> /kWh)	0.5 kg-CO <sub>2</sub> /kWh			
				Boiler (0.001–999 kg-CO <sub>2</sub> /kWh)	0.5 kg-CO <sub>2</sub> /kWh			
			Heat source	Heat pump capacity (1–40 kW)	11.2 kW			
				Boiler efficiency (25–150%)	80%			
				Booster heater 1 capacity (0–30 kW)	2 kW			
			Floor dry up function		ON/OFF *10	OFF		
	Target temp.	Start&Finish (25–60°C)			30°C			
		Max. temp. (25–60°C)			45°C			
		Max. temp. period (1–20 days)			5 days			
	Flow temp. (Increase)	Temp. increase step (+1–+10°C)			+5°C			
		Increase interval (1–7 days)			2 days			
	Flow temp. (Decrease)	Temp. decrease step (–1––10°C)	–5°C					
		Decrease interval (1–7 days)	2 days					
	Energy monitor settings		Electric heater capacity	Booster heater 1 capacity	0–30 kW	2 kW		
				Booster heater 2 capacity	0–30 kW	4 kW		
Immersion heater capacity				0–30 kW	0 kW			
Delivered energy adjustment			–50–+50%	0%				
Water pump input		Pump 1	0–200 W or ***(factory fitted pump)	***				
		Pump 2	0–200 W	0 W				
		Pump 3	0–200 W	0 W				
Electric energy meter		0.1/1/10/100/1000 pulse/kWh	1 pulse/kWh					
Heat meter		0.1/1/10/100/1000 pulse/kWh	1 pulse/kWh					
External input settings		Demand control (IN4)	Heat source OFF/Boiler operation	Boiler operation				
		Outdoor thermostat (IN5)	Heater operation/Boiler operation	Boiler operation				

\*6 For the model without both booster and immersion heater, it may not reach the set temperature depending on the outside ambient temperature.

\*7 The lower limit is –15°C depending on the connected outdoor unit.

\*8 The lower limit is –13°C depending on the connected outdoor unit.

\*9 The lower limit is –14°C depending on the connected outdoor unit.

\*10 On: the function is active; Off: the function is inactive.

\*11 When DIP SW1-1 is set to OFF "WITHOUT Boiler" or SW2-6 is set to OFF "WITHOUT Mixing tank", neither Boiler nor Hybrid can be selected.

\*12 Valid only when operating in Room temp. control mode.

\*13 Valid only when operating in Heating room temperature.

\*14 When DIP SW5-2 is set to OFF, the function is active.

\*15 If asterisk (\*\*) is chosen freeze stat function is deactivated. (i.e. primary water freeze risk)

\*16 When the hydrobox is connected with a PUMY-P outdoor unit, the mode is fixed to "Ambient".

\*17 \*\*\* of \*\*/kWh represents currency unit (e.g. € or £ or the like)



### 13-2. Annual Maintenance Log Book

Contractor name		Engineer name	
Site name		Site number	

#### Hydrobox maintenance record sheet

Warranty number		Model number	
		Serial number	

No.	Mechanical	Frequency	Notes
1	Isolate and drain hydrobox, remove mesh from internal strainer clean and replace.		
2	Open the pressure relief valve, check for unrestricted discharge to the tundish and that the valve reseats correctly. Check there are no blockages in the tundish and associated pipe work.		
3	Drop the primary/heating system pressure to zero check and if necessary top up the expansion relief vessel (1 bar). Air valve of expansion vessel is TR-412.		
4	Check and if necessary top up the concentration of anti-freeze/inhibitor (if used in the system).		
5	Top up the primary/heating system using an appropriate filling loop and re-pressurise to 1 bar.		
6	Heat system and check pressure does not rise above 3 bar and no water is released from the safety valves.		
7	Release any air from the system.		

Refrigerant models only [EXCEPT EHPX]		Frequency	Notes
1	Refer to outdoor unit manual.		

Electrical		Frequency	Notes
1	Check condition of cables.		
2	Check rating and fuse fitted on the electricity supply.		

Controller		Frequency	Notes
1	Check field settings against factory recommendations.		
2	Check battery power of wireless thermostat and replace if necessary.		

#### Outdoor heat pump unit maintenance record sheet

Model number		Serial number	
--------------	--	---------------	--

	Mechanical	Frequency	Notes
1	Inspect grill, heat exchanger fins and air inlet for trapped debris/damage.		
2	Check condensate drain provision.		
3	Check integrity of water pipe work and insulation.		
4	Check all electrical connections.		
5	Check and record the operation voltage.		

All the above checks should be carried out once a year.

**Note:**

**Within the first couple of months of installation, remove and clean the hydrobox's strainer mesh plus any that are fitted external to the hydrobox. This is especially important when installing on an existing system.**

In addition to annual servicing it is necessary to replace or inspect some parts after a certain period of system operation. Please see tables below for detailed instructions. Replacement and inspection of parts should always be done by a competent person with relevant training and qualifications.

**Parts which require regular replacement**

Parts	Replace every	Possible failures
Pressure relief valve (PRV) Air vent (Auto/Manual) Drain cock (Primary circuit) Manometer	6 years	Water leakage

**Parts which require regular inspection**

Parts	Check every	Possible failures
Pressure relief valve (3bar)	1 year (turning the knob manually)	PRV would be fixed and expansion vessel would burst
Water circulation pump	20,000 hrs (3 years)	Water circulation pump failure

**Parts which must NOT be reused when servicing**

- \* O-ring
- \* Gasket

**Note:**

- Always replace the gasket for pump with a new one at each regular maintenance (every 20,000 hours of use or every 3 years).
- Make sure to carry out annual check (turn the cap) on 3bar PRV. This is not required for 5bar PRV.





# mitsubishi electric corporation

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

©Copyright 2018 MITSUBISHI ELECTRIC CORPORATION  
Issued: Dec. 2018 No. OCH571 REVISED EDITION-D  
Issued: Sep. 2016 No. OCH571 REVISED EDITION-C  
Issued: Aug. 2015 No. OCH571 REVISED EDITION-B  
Issued: Apr. 2015 No. OCH571 REVISED EDITION-A  
Published: Oct. 2014 No. OCH571  
Made in Japan

Specifications are subject to change without notice.