

TECHNICAL & SERVICE MANUAL

Series PLFY Ceiling Cassettes

Indoor unit

[Model Name]

[Service Ref.]

PLFY-WP32VBM-E

PLFY-WP32VBM-E.UK

PLFY-WP40VBM-E


PLFY-WP40VBM-E.UK

PLFY-WP50VBM-E

PLFY-WP50VBM-E.UK

Notes:

- This manual describes service data of the indoor units only.
- RoHS compliant products have <G> mark on the spec name plate.



INDOOR UNIT

CONTENTS

1. SAFETY PRECAUTION.....	2
2. PARTS NAMES AND FUNCTIONS.....	2
3. SPECIFICATIONS.....	7
4. 4-WAY AIR FLOW SYSTEM.....	10
5. OUTLINES AND DIMENSIONS.....	13
6. WIRING DIAGRAM.....	15
7. REFRIGERANT SYSTEM DIAGRAM.....	16
8. TROUBLESHOOTING.....	17
9. SPECIAL FUNCTION.....	24
10. DISASSEMBLY PROCEDURE.....	31

PARTS CATALOG (OCB586)

1

SAFETY PRECAUTION

Precautions for handling units for use with water

⚠ CAUTION

Do not use the existing water piping.

Store the piping materials indoors, and keep both ends of the pipes sealed until immediately before installation. Keep the joints wrapped in plastic bags. If dust or dirt enters the water circuit, it may damage the heat exchanger and cause water leakage.


Only use water.

Only use clean water as a refrigerant. The use of water outside the specification may damage the refrigerant circuit.


2

PARTS NAMES AND FUNCTIONS

2-1. INDOOR UNIT



2-2. WIRELESS REMOTE CONTROLLER




2-3. WIRED REMOTE CONTROLLER <PAR-30MAA><PAR-31MAA>

Wired remote controller function

The functions which can be used are restricted according to each model.


○ : Supported ✕ : Unsupported

Function		PAR-30MAA/PAR-31MAA	PAR-21MAA
Body	Product size H × W × D (mm)	120 × 120 × 19	120 × 130 × 19
	LCD	Full Dot LCD	Partial Dot LCD
	Backlight	○	✕
Energy-saving	Automatic return to the preset temperature	○	✕
Restriction	Setting the temperature range restriction	○	○
Function	Operation lock function	○	○
	Weekly timer	○	✕
	ON/OFF timer	○	○
	Manual vane angle	○	○



The functions of the function buttons change depending on the screen. Refer to the button function guide that appears at the bottom of the LCD for the functions they serve on a given screen.

When the system is centrally controlled, the button function guide that corresponds to the locked button will not appear.



① ON/OFF button

Press to turn ON/OFF the indoor unit.

② SELECT button

Press to save the setting.

③ RETURN button

Press to return to the previous screen.

④ MENU button

Press to bring up the Main menu.

⑤ Backlit LCD

Operation settings will appear.
When the backlight is off, pressing any button turns the backlight on and it will stay lit for a certain period of time depending on the screen.

When the backlight is off, pressing any button turns the backlight on and does not perform its function. (except for the (ON/OFF) button)

⑥ ON/OFF lamp

This lamp lights up in green while the unit is in operation. It blinks while the remote controller is starting up or when there is an error.

⑦ Function button **F1**

Main display : Press to change the operation mode.
Main menu : Press to move the cursor down.

⑧ Function button **F2**

Main display : Press to decrease temperature.
Main menu : Press to move the cursor up.

⑨ Function button **F3**

Main display : Press to increase temperature.
Main menu : Press to go to the previous page.


⑩ Function button **F4**

Main display : Press to change the fan speed.
Main menu : Press to go to the next page.


The main display can be displayed in two different modes: "Full" and "Basic".
The initial setting is "Full". To switch to the "Basic" mode, change the setting on the Main display setting.

<Full mode>

All icons are displayed for explanation.



<Basic mode>



① Operation mode

Indoor unit operation mode appears here.

② Preset temperature

Preset temperature appears here.

③ Clock (See the Installation Manual.)

Current time appears here.

④ Fan speed

Fan speed setting appears here.

⑤ Button function guide

Functions of the corresponding buttons appear here.



Appears when the ON/OFF operation is centrally controlled.



Appears when the operation mode is centrally controlled.



Appears when the preset temperature is centrally controlled.



Appears when the filter reset function is centrally controlled.



Appears when filter needs maintenance.

⑪ Room temperature (See the Installation Manual.)

Current room temperature appears here.



Appears when the buttons are locked.



Appears when the ON/OFF timer or Night setback function is enabled.



Appears when the Weekly timer is enabled.



Appears while the units are operated in the energy-save mode.



Appears when the built-in thermistor on the remote controller is activated to monitor the room temperature.

appears when the thermistor on the indoor unit is activated to monitor the room temperature.



Indicates the vane setting.



Indicates the louver setting.






Indicates the ventilation setting.



Appears when the preset temperature range is restricted.

Most settings (except ON/OFF, mode, fan speed, temperature) can be made from the Menu screen.

2-4. WIRED REMOTE CONTROLLER <PAR-21MAA>



Note:

- “PLEASE WAIT” message
This message is displayed for approximately 3 minutes when power is supplied to the indoor unit or when the unit is recovering from a power failure.
- “NOT AVAILABLE” message
This message is displayed if an invalid button is pressed (to operate a function that the indoor unit does not have).
If a single remote controller is used to operate multiple indoor units simultaneously that are different types, this message will not be displayed as far as any of the indoor units is equipped with the function.

3

SPECIFICATIONS

3-1. SPECIFICATIONS

Service Ref.		PLFY-WP32VBM-E.UK	PLFY-WP40VBM-E.UK	PLFY-WP50VBM-E.UK
Power source		1-Phase 220-240 V, 50/60 Hz		
Cooling capacity (Nominal)	*1 kW	3.6	4.5	5.6
	*1 kcal/h	3,100	3,100	3,100
	*1 BTU/h	12,300	12,300	12,300
	Power input kW	0.04	0.04	0.05
Current input A		0.35	0.35	0.45
Heating capacity (Nominal)	*1 kW	4.0	4.0	4.0
	*1 kcal/h	3,400	3,400	3,400
	*1 BTU/h	13,600	13,600	13,600
	Power input kW	0.03	0.03	0.04
Current input A		0.28	0.28	0.38
External finish		Galvanized steel sheet		
External dimension H × W × D		mm 258 × 840 × 840 in 10-3/16 × 33-1/8 × 33-1/8		
Net weight		kg [lb] 22 [10]		
Decoration panel		PLP-6BA	PLP-6BA	PLP-6BA
Model		MUNSELL (6.4Y 8.9/0.4)		
External finish		MUNSELL (6.4Y 8.9/0.4)		
Dimension H × W × D		mm 35 × 950 × 950 in 1-3/8 × 37-7/16 × 37-7/16		
Net weight		kg [lb] 13 [6]		
Heat exchanger		Cross fin (Aluminium fin and copper tube)		
FAN		Turbo fan × 1	Turbo fan × 1	Turbo fan × 1
Type × Quantity		Turbo fan × 1	Turbo fan × 1	Turbo fan × 1
Pa		0	0	0
mmH ₂ O		0	0	0
Motor type		DC motor		
Motor output kW		0.050	0.050	0.050
Driving mechanism		Direct drive		
Air flow rate (Low-Mid2-Mid1-High)		16 - 15 - 14 - 13 183 - 200 - 217 - 233 388 - 424 - 459 - 494	16 - 15 - 14 - 13 183 - 200 - 217 - 233 388 - 424 - 459 - 494	19 - 17 - 15 - 13 183 - 200 - 217 - 233 388 - 424 - 459 - 494
m ³ /min		16 - 15 - 14 - 13	16 - 15 - 14 - 13	19 - 17 - 15 - 13
L/s		183 - 200 - 217 - 233	183 - 200 - 217 - 233	183 - 200 - 217 - 233
cfm		388 - 424 - 459 - 494	388 - 424 - 459 - 494	388 - 424 - 459 - 494
Noise level (Low-Mid2-Mid1-High) (measure on anechoic room)		31 - 30 - 29 - 27	31 - 30 - 29 - 27	34 - 32 - 30 - 27
Insulation material		PS		
Air filter		PP honeycomb		
Protection device		Fuse		
Connectable outdoor unit		R410, CITY MULTI		
Diameter of refrigerant pipe		RC 3/4 screw		
Water inlet		RC 3/4 screw		
Water outlet		RC 3/4 screw		
Field drain pipe size		mm [in] O.D #32 (VP-25)		
Standard attachment		Document, accessory Installation Manual, Instruction Book		
Remark		Optional parts		
Decotation panel* ²		PLP-6BA	PLP-6BA	PLP-6BA
Air outlet shutter plate		PAC-SH51SP-E	PAC-SH51SP-E	PAC-SH51SP-E
High efficiency filter element * ³		PAC-SH59KF-E	PAC-SH59KF-E	PAC-SH59KF-E
Multi-function casement		PAC-SH53TM-E	PAC-SH53TM-E	PAC-SH53TM-E
Installation		* ² PLY-P-VBM-E should use together with PLP-6BA. * ³ PAC-SH53TM-E is necessary to use with filter PAC-SH59KF-E. Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.		
* ¹ <Cooling> Indoor temperature: 27°C D.B./19°C W.B. [81°F D.B./66°F W.B.] <Heating> Indoor temperature: 20°C D.B. [68°F D.B.]		Outdoor temperature: 35°C D.B. [95°F D.B.] Outdoor temperature: 7°C D.B./6°C D.B.[45°F D.B./43°F D.B.]		


3-2. ELECTRICAL PARTS SPECIFICATIONS

Parts name	Service Ref.	Symbol	PLFY-WP32VBM-E.UK	PLFY-WP40VBM-E.UK	PLFY-WP50VBM-E.UK
Room temperature detection thermistor		TH21	Resistance 0°C /15 kΩ, 10°C /9.6 kΩ, 20°C /6.3 kΩ, 25°C /5.4 kΩ, 30°C /4.3 kΩ, 40°C /3.0 kΩ		
Pipe temperature detection thermistor/ from HBC unit		TH22	Resistance 0°C /15 kΩ, 10°C /9.6 kΩ, 20°C /6.3 kΩ, 25°C /5.4 kΩ, 30°C /4.3 kΩ, 40°C /3.0 kΩ		
Pipe temperature detection thermistor/ to HBC unit		TH23	Resistance 0°C /15 kΩ, 10°C /9.6 kΩ, 20°C /6.3 kΩ, 25°C /5.4 kΩ, 30°C /4.3 kΩ, 40°C /3.0 kΩ		
Fuse (Indoor controller board)		FUSE	250 V 6.3 A		
Fan motor		MF	8-pole OUTPUT 50W		
Vane motor		MV	MSBPC20M04 12 V DC 300Ω/phase		
Drain pump		DP	PLD-12230ME-1 INPUT 12/10.8W 24 ℓ /Hr		
Drain float switch		FS	open/short detection		
Power supply terminal block		TB2	(L, N, ⊕) Rated to 330V 30A *		
Transmission terminal block		TB5	(M1, M2, S) Rated to 250V 20A *		
MA remote controller terminal block		TB15	(1, 2) Rated to 250V 10A *		

*Refer to WIRING DIAGRAM for the supplied voltage.

3-3. SOUND LEVEL

PLFY-WP-VBM-E



* Measured in anechoic room.


Sound level at anechoic room : Low-Mid2-Mid1-High

Service Ref.	Sound level dB (A)
PLFY-WP32VBM-E.UK	31 - 30 - 29 - 27
PLFY-WP40VBM-E.UK	
PLFY-WP50VBM-E.UK	34 - 32 - 30 - 27

3-4. NC CURVES


PLFY-WP32VBM-E.UK
PLFY-WP40VBM-E.UK

External static pressure : 0Pa
 Power source : 220,230,240V, 50Hz / 220V, 60Hz



PLFY-WP50VBM-E.UK

External static pressure : 0Pa
 Power source : 220,230,240V, 50Hz / 220V, 60Hz






4-1. PLACEMENT OF THE AIR OUTLETS

• For this grille, the blowout direction comes in 11 patterns.

Also, by setting the remote controller to the appropriate settings, you can adjust the airflow and speed. Select the settings from Table1 according to the location in which you want to install the unit.

1) Decide on the pattern of the airflow direction.


<Table 1>

	4-direction	3-direction	2-direction
Blowout direction pattern	<p>Pattern 1 Initial setting</p> 	<p>Pattern 4 1 air outlet fully closed</p> 	<p>Pattern 6 2 air outlet fully closed</p> 

Note1.
For 3 and 2-direction settings, please use the air outlet shutter plate (option).

2) According to the number of air outlets and height of the ceiling to install the unit, be sure to set up the switches (SWA, SWB) on the circuit board to the appropriate setting.

• Correspondence of ceiling heights to numbers of air outlets



PLFY-WP32/40/50VBM-E.UK

SWB	SWA	①	②	③
		Silent	Standard	High ceiling
④	4 direction	2.5 m	2.7 m	3.5 m
③	3 direction	2.7 m	3.0 m	3.5 m
②	2 direction	3.0 m	3.3 m	3.5 m

4-2. BRANCH DUCT HOLE AND FRESH AIR INTAKE HOLE

At the time of installation, use the duct holes (cut out) located at the positions shown in following diagram, as and when required.

- A fresh air intake hole for the optional multi function casement can also be made.


Note:

The figures marked with * in the drawing below represent the dimensions of the main unit excluding those of the optional multi function casement.

When installing the optional multi function casement, add 135 mm to the dimensions marked on the figure.

When installing the branch ducts, be sure to insulate adequately.

Otherwise, condensation and dripping may occur.



4-3. OPERATION IN CONJUNCTION WITH DUCT FAN (Booster fan)


- Whenever the indoor unit is operating, the duct fan also operates.

(1) Connect the optional multiple remote controller adapter (PAC-SA88HA-E) to the connector CN51 on the indoor controller board.

(2) Drive the relay after connecting the 12 V DC relay between the Yellow and Orange connector wires.

MB: Electromagnetic switch power relay for duct fan.


X: Auxiliary relay (For 12 V DC, coil rating: 1.0W or below)




4-4. FRESH AIR INTAKE AMOUNT & STATIC PRESSURE CHARACTERISTICS

1 PLFY-P32/40/50VBM-E.UK


Multi function casement + Standard filter




Multi function casement + High efficiency filter



Taking air into the unit










How to read curves



- Q...Planned amount of fresh air intake $\langle m^3/min \rangle$
- A...Static pressure loss of fresh air intake duct system with airflow amount Q $\langle Pa \rangle$
- B...Forced static pressure at air conditioner inlet with airflow amount Q $\langle Pa \rangle$
- C...Static pressure of booster fan with airflow amount Q $\langle Pa \rangle$
- D...Static pressure loss increase amount of fresh air intake duct system for airflow amount Q $\langle Pa \rangle$
- E...Static pressure of indoor unit with airflow amount Q $\langle Pa \rangle$
- Qa...Estimated amount of fresh air intake without D $\langle m^3/min \rangle$

PLFY-WP32VBM-E.UK PLFY-WP40VBM-E.UK PLFY-WP50VBM-E.UK
 <Standard Panel>



Unit: mm






- Note 1. Please choose the Grille from a standard grille, Auto-Grille.
- As for drain pipe, please use VP-25 (O.D. φ32 PVC TUBE). Drain pump inclusion. Raise is max 850mm from the ceiling.
 - As for suspension bolt, please use M10 or W3/8. (Procured at local site)
 - Electrical box may be removed for the service purpose. Make sure to slack the electrical wire little bit for control/power wires connection.
 - The height of the indoor unit is able to be adjusted with the grille attached.
 - For the installation of the optional high efficiency filter or optional multi-functional casement. (Reference of the 2nd sheet of detailed Figure)
 - Requires 400 mm or more space between transom and ceiling for the installation.
 - Add 135 mm to the dimensions * marked on the figure.
 - The optional high efficiency filter becomes optional multi-functional casement and concomitant use.
 - When installing the branch ducts, be sure to insulate adequately. Otherwise condensation and dripping may occur. (It becomes the cause of dew drops/Wear dew.)
 - As for necessary installation/service space, please refer to the under at figure.

PLFY-WP32VBM-E.UK PLFY-WP40VBM-E.UK PLFY-WP50VBM-E.UK
<Auto Descending Panel>

Unit: mm



Detail drawing of fresh air intake hole




In case of standard grille: PLP-6BA/PLP-6BAMD




In case of Auto-Grille: PLP-6BAJ

In case of wireless remote controller: PLP-6BALM

Emergency operation switch<Cooling> and Emergency Up/Down switch<Up>
 Emergency operation switch<Heating> and Emergency Up/Down switch<Down>




Auto-Grille Air intake grille Up/down distance



* In case of the optional parts Multi-functional casement and High-efficiency filter element


- Note 1. Please choose the Grille from a standard grille, Auto-Grille.
 2. As for drain pipe, please use VP-25(O.D. φ32 PVC TUBE.)
 Drain pump inclusion.
 Raise is max 850mm from the ceiling.
 3. As for suspension bolt, please use M10 or W3/8. (Procured at local site)
 4. Electrical box may be removed for the service purpose.
 Make sure to slack the electrical wire little bit for control/power wires connection.
 5. The height of the indoor unit is able to be adjusted with the grille attached.
 6. For the installation of the optional high efficiency filter or optional multi-functional casement. (Reference of the 2nd sheet of detailed Figure)
 1) Requires 400 mm or more space between transom and ceiling for the installation.
 2) The optional high efficiency filter becomes optional multi-functional casement and concomitant use.
 7. When installing the branch ducts, be sure to insulate adequately.
 Otherwise condensation and dripping may occur.
 (It becomes the cause of dew drops/Wear dew.)
 8. As for necessary installation/service space, please refer to the under at figure.



PLFY-WP32VBM-E.UK PLYF-WP40VBM-E.UK PLYF-WP50VBM-E.UK

[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
I.B.	INDOOR CONTROLLER BOARD	DP	DRAIN PUMP	A.B.	ADDRESS BOARD
CN27	CONNECTOR	FS	DRAIN FLOAT SWITCH	SWA	SWITCH
CN32		MF	FAN MOTOR	SWB	
CN51		MV	VANE MOTOR	SWC	
CN52		TB2	TERMINAL BLOCK	SW1	
CN105	IT TERMINAL	TB5	TERMINAL BLOCK	SW11	
FUSE	FUSE (T6.3A/250V)	TB15	TERMINAL BLOCK	SW12	
LED1	POWER SUPPLY (I.B.)	TH21	THERMISTOR	SW14	
LED2	POWER SUPPLY (I.B.)	TH22		OPTION PART	
SW2	SWITCH	TH23		W.B.	PCB FOR WIRELESS REMOTE CONTROLLER
SW3				BZ	BUZZER
SW4				LED1	LED (OPERATION INDICATION : GREEN)
SWE				LED2	LED (PREPARATION FOR HEATING : ORANGE)
X1	AUX. RELAY			RU	RECEIVING UNIT
				SW1	EMERGENCY OPERATION (HEAT/DOWN)
				SW2	EMERGENCY OPERATION (COOL/UP)



NOTES:

1. At servicing for outdoor unit, always follow the wiring diagram of outdoor unit.
2. In case of using MA-Remote controller, please connect to TB15. (Remote controller wire is non-polar.)
3. In case of using M-NET, please connect to TB5. (Transmission line is non-polar.)
4. Symbol [S] of TB5 is the shield wire connection.
5. Symbols used in wiring diagram above are, □□□ : terminal block, ○○○○ : connector.
6. The setting of the SW2 dip switches differs in the capacity. For the detail, refer to <Table 1>.


LED on indoor board for service

Mark	Meaning	Function
LED1	Main power supply	Main Power supply (Indoor unit:220-240V) power on → lamp is lit
LED2	Power supply for MA-Remote controller	Power supply for MA-Remote controller on → lamp is lit

7

REFRIGERANT SYSTEM DIAGRAM







PLFY-WP32VBM-E.UK PLYF-WP40VBM-E.UK PLYF-WP50VBM-E.UK



Item \ Capacity	PLFY-WP32/40/50VBM-E
Water inlet	RC 3/4 screw
Water outlet	RC 3/4 screw

8-1. HOW TO CHECK THE PARTS

PLFY-WP32VBM-E.UK PLYF-WP40VBM-E.UK PLYF-WP50VBM-E.UK

Parts name	Check points									
Room temp. detection thermistor (TH21) Pipe temp. detection thermistor/ from HBC unit (TH22) Pipe temp. detection thermistor/ to HBC unit (TH23)	Disconnect the connector then measure the resistance with a tester. (At the ambient temperature of 10 to 30°C) <table border="1"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>4.3 to 9.6 kΩ</td> <td>Open or short</td> </tr> </tbody> </table> (Refer to "8-1-1. Thermistor" .)	Normal	Abnormal	4.3 to 9.6 kΩ	Open or short					
Normal	Abnormal									
4.3 to 9.6 kΩ	Open or short									
Vane motor (MV) 	Measure the resistance between the terminals with a tester. (At the ambient temperature of 20 to 30°C) <table border="1"> <thead> <tr> <th>Connector</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>Red - Yellow (⑤-③, ⑩-⑧, ⑮-⑬, ⑳-⑱)</td> <td rowspan="4">300 Ω</td> <td rowspan="4">Open or short</td> </tr> <tr> <td>Red - Blue (⑤-①, ⑩-⑥, ⑮-⑪, ⑳-⑱)</td> </tr> <tr> <td>Red - Orange (⑤-④, ⑩-⑨, ⑮-⑭, ⑳-⑱)</td> </tr> <tr> <td>Red - White (⑤-②, ⑩-⑦, ⑮-⑫, ⑳-⑰)</td> </tr> </tbody> </table>	Connector	Normal	Abnormal	Red - Yellow (⑤-③, ⑩-⑧, ⑮-⑬, ⑳-⑱)	300 Ω	Open or short	Red - Blue (⑤-①, ⑩-⑥, ⑮-⑪, ⑳-⑱)	Red - Orange (⑤-④, ⑩-⑨, ⑮-⑭, ⑳-⑱)	Red - White (⑤-②, ⑩-⑦, ⑮-⑫, ⑳-⑰)
Connector	Normal	Abnormal								
Red - Yellow (⑤-③, ⑩-⑧, ⑮-⑬, ⑳-⑱)	300 Ω	Open or short								
Red - Blue (⑤-①, ⑩-⑥, ⑮-⑪, ⑳-⑱)										
Red - Orange (⑤-④, ⑩-⑨, ⑮-⑭, ⑳-⑱)										
Red - White (⑤-②, ⑩-⑦, ⑮-⑫, ⑳-⑰)										
Drain pump (DP) 	Measure the resistance between the terminals with a tester. (Winding temperature 20°C) <table border="1"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>290 Ω</td> <td>Open or short</td> </tr> </tbody> </table>	Normal	Abnormal	290 Ω	Open or short					
Normal	Abnormal									
290 Ω	Open or short									
Drain float switch (FS) 	Measure the resistance between the terminals with a tester. <table border="1"> <thead> <tr> <th>State of moving part</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>UP</td> <td>Short</td> <td>Other than short</td> </tr> <tr> <td>DOWN</td> <td>Open</td> <td>Other than open</td> </tr> </tbody> </table>	State of moving part	Normal	Abnormal	UP	Short	Other than short	DOWN	Open	Other than open
State of moving part	Normal	Abnormal								
UP	Short	Other than short								
DOWN	Open	Other than open								
i-see sensor (Option) 	Turn on the indoor unit with the black plastic tape on the outside of i-see sensor controller board. With electricity being turned on, measure the power voltage between connectors with tester. i-see sensor rotates and pull out the connector of motor for i-see sensor.  i-see sensor (At the ambient temperature of 10 to 40°C) <table border="1"> <thead> <tr> <th>i-see sensor connector</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>②(-)-④(+)</td> <td>1.857 to 3.132 V DC</td> <td>Other than the normal</td> </tr> <tr> <td>①(+)-②(-)</td> <td>0.939 to 1.506 V DC</td> <td>Other than the normal</td> </tr> </tbody> </table> NOTE : Be careful not to discharge static electricity into electronics.	i-see sensor connector	Normal	Abnormal	②(-)-④(+)	1.857 to 3.132 V DC	Other than the normal	①(+)-②(-)	0.939 to 1.506 V DC	Other than the normal
i-see sensor connector	Normal	Abnormal								
②(-)-④(+)	1.857 to 3.132 V DC	Other than the normal								
①(+)-②(-)	0.939 to 1.506 V DC	Other than the normal								
Vane motor for i-see sensor (Option) 	Measure the resistance between the terminals with a tester. (At the ambient temperature of 20 to 30°C) <table border="1"> <thead> <tr> <th>Connector</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>Red - Yellow</td> <td rowspan="4">250 Ω</td> <td rowspan="4">Open or short</td> </tr> <tr> <td>Red - Blue</td> </tr> <tr> <td>Red - Orange</td> </tr> <tr> <td>Red - White</td> </tr> </tbody> </table>	Connector	Normal	Abnormal	Red - Yellow	250 Ω	Open or short	Red - Blue	Red - Orange	Red - White
Connector	Normal	Abnormal								
Red - Yellow	250 Ω	Open or short								
Red - Blue										
Red - Orange										
Red - White										

8-1-1. Thermistor


<Thermistor characteristic graph>

Thermistor for lower temperature
 Room temperature detection thermistor (TH21)
 Pipe temperature detection thermistor/from HBC unit (TH22)
 Pipe temperature detection thermistor/to HBC unit (TH23)

Thermistor $R_0=15\text{ k}\Omega \pm 3\%$
 Fixed number of $B=3480 \pm 2\%$

$$R_t = 15 \exp \left\{ 3480 \left(\frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	15 kΩ
10°C	9.6 kΩ
20°C	6.3 kΩ
25°C	5.4 kΩ
30°C	4.3 kΩ
40°C	3.0 kΩ



8-1-2. DC an motor (fan motor/indoor controller board)


Check method of indoor fan motor (fan motor/indoor controller board)

① Notes

- High voltage is applied to the connector (CNMF) for the fan motor. Pay attention to the service.
- Do not pull out the connector (CNMF) for the motor with the power supply on.
 (It causes trouble of the indoor controller board and fan motor.)






② Self check

Conditions : The indoor fan cannot rotate.



8-2. FUNCTION OF DIP SWITCH

The black square (■) indicates a switch position.

Switch	Pole	Function	Operation by switch		Effective timing	Remarks
			ON	OFF		
SW1 Function setting	1	Thermistor <Room temperature detection> position	Built-in remote controller	Indoor unit	Under suspension	<div style="border: 1px solid black; padding: 2px;">Address board</div> <Initial setting> ON OFF 
	2	Filter clogging detection	Provided	Not provided		
	3	Filter cleaning	2,500 hr	100 hr		
	4	Fresh air intake	Effective	Not effective		
	5	Switching remote display	Thermo ON signal display	Indicating fan operation ON/OFF		
	6	Humidifier control	Always operated while the heat in ON *1	Operated depends on the condition *2		
	7	Airflow set in case of thermo OFF at heating mode	Low *3	Extra low *3		
	8	Auto restart function	Setting air flow *3	Depends on SW1-7		
	9	Power ON/OFF by breaker	Effective	Not effective		
	SW2 Capacity code setting	1-6	Capacity	SW2		
WP32			ON OFF 			
WP40			ON OFF 			
WP50			ON OFF 			
SW3 Function setting	1	Heat pump/Cooling only	Cooling only	Heat pump	Under suspension	<div style="border: 1px solid black; padding: 2px;">Indoor controller board</div> Set while the unit is off. <Initial setting> ON OFF 
	2	Louver/humidifier *5	Available	Not available		
	3	Vane	Available	Not available		
	4	Vane swing function in heating (wave-flow)	Available	Not available		
	5	Vane horizontal angle ①	Second setting *4	First setting *4		
	6	Vane horizontal angle ②	Third setting *4	Depends on SW3-5		
	7	—	—	—		
	8	Sensible temperature correction	Not effective	Effective		
	9	—	—	—		
	10	—	—	—		
SW4 Model Selection (Setting for PLFY series)	1-5	When replacing the indoor controller board, make sure to set the switch to the initial setting, which is shown below.		Before power supply ON	<div style="border: 1px solid black; padding: 2px;">Indoor controller board</div>	

*1 Fan operation at Heating mode

*2 Thermo ON operation at Heating mode

*3 Refer to the <Table A> below.

*4 Refer to the <Table B> below.

*5 SW3-2 setting. Only for PLFY-P-VBM, SW is used to change whether the humidifier functions or not. (Fixed the louver function less.)


<Table A>









SW1-7	SW1-8	
OFF	OFF	Extra low
ON	OFF	Low
OFF	ON	Setting air flow
ON	ON	Stop

<Table B>




SW3-5	SW3-6	Vane setting	Initial setting	Setting	Vane position
OFF	OFF	Set up ①		Standard	Standard
ON	OFF	Set up ②	●	Less draft *	Upward position than the standard
OFF	ON	Set up ③		Less smudging	Downward position than the standard
ON	ON	unused		—	—

* Be careful of smudge on ceiling.



Switch	Pole	Operation by switch	Effective timing	Remarks																														
SWA Ceiling height selector	1-3	<p>Ceiling height can be changed depends on SWB setting.</p> <p>(High ceiling) 3 (Standard) 2 (Silent) 1</p>  <table border="1"> <thead> <tr> <th colspan="2">PLFY-WP32/40/50VBM-E</th> <th>①</th> <th>②</th> <th>③</th> </tr> <tr> <th colspan="2">SWA</th> <th>Silent</th> <th>Standard</th> <th>High ceiling</th> </tr> </thead> <tbody> <tr> <th>SWB</th> <th></th> <th></th> <th></th> <th></th> </tr> <tr> <td>④</td> <td>4 direction</td> <td>2.5m</td> <td>2.7m</td> <td>3.5m</td> </tr> <tr> <td>③</td> <td>3 direction</td> <td>2.7m</td> <td>3.0m</td> <td>3.5m</td> </tr> <tr> <td>②</td> <td>2 direction</td> <td>3.0m</td> <td>3.3m</td> <td>3.5m</td> </tr> </tbody> </table>	PLFY-WP32/40/50VBM-E		①	②	③	SWA		Silent	Standard	High ceiling	SWB					④	4 direction	2.5m	2.7m	3.5m	③	3 direction	2.7m	3.0m	3.5m	②	2 direction	3.0m	3.3m	3.5m	Under operation or suspension	<p>Address board</p> <p><Initial setting></p> 
PLFY-WP32/40/50VBM-E		①	②	③																														
SWA		Silent	Standard	High ceiling																														
SWB																																		
④	4 direction	2.5m	2.7m	3.5m																														
③	3 direction	2.7m	3.0m	3.5m																														
②	2 direction	3.0m	3.3m	3.5m																														
SWC Option selector	2	<p>② オフ ① 標</p>  <p>When attaching the optional high performance filter elements (multi function casement) to the unit, be sure to attach it to ② in order to prevent the airflow reducing.</p>	<p>Address board</p> <p><Initial setting></p> <p>② オフ ① 標</p> 																															
SW11 1s digit address setting SW12 10s digit address setting	Rotary switch	<p>SW12 SW11</p>  <p>How to set addresses Example : If address is "3", remain SW12 (for over 10) at "0", and match SW11 (for 1 to 9) with "3".</p>	Before power supply ON	<p>Address board</p> <p><Initial setting></p> 																														
SW14 Branch No. Setting	Rotary switch	<p>SW14</p>  <p>How to set branch numbers SW14 (Series R2 only) Match the indoor unit's refrigerant pipe with the BC controller's end connection number. Remain other than series R2 at "0".</p>		<p>Address board</p> <p><Initial setting></p> <p>SW14</p> 																														


Continue to the next page

Switch	Pole	Operation by switch	Effective timing	Remarks																											
J41, J42 Wireless remote controller Pair No.	Jumper	<ul style="list-style-type: none"> To operate each indoor unit by each remote controller when installed 2 indoor units or more are near, Pair No. setting is necessary. <ol style="list-style-type: none"> Pair No. setting is available with the 4 patterns (Setting patters A to D). Make setting for J41, J42 of indoor controller board and the Pair No. of wireless remote controller. You may not set it when operating it by 1 remote controller. <ol style="list-style-type: none"> Setting for indoor unit Jumper wire J41, J42 on the indoor controller board are cut according to the table below. Wireless remote controller pair number: Setting operation <ol style="list-style-type: none"> Press the SET button (using a pointed implement). Check that the remote controller's display has stopped before continuing. MODEL SELECT flashes, and the model No. (3 digits) appears (steadily-lit). Press the MINUTE button twice. The pair number appears flashing. Press the temperature \odot \odot buttons to select the pair number to set. Press the SET button (using a pointed implement). The set pair number is displayed (steadily-lit) for 3 seconds, then disappears. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th rowspan="2">Setting pattern</th> <th colspan="2">Indoor controller Jumper wire</th> <th rowspan="2">Pair No. of wireless remote controller*</th> <th rowspan="2"></th> </tr> <tr> <th>J41</th> <th>J42</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>—</td> <td>—</td> <td>0</td> <td>Initial setting</td> </tr> <tr> <td>B</td> <td>Cut</td> <td>—</td> <td>1</td> <td>—</td> </tr> <tr> <td>C</td> <td>—</td> <td>Cut</td> <td>2</td> <td>—</td> </tr> <tr> <td>D</td> <td>Cut</td> <td>Cut</td> <td>3</td> <td>—</td> </tr> </tbody> </table> <p>*Pair No.4-9 of wireless remote controller is setting pattern D.</p>	Setting pattern	Indoor controller Jumper wire		Pair No. of wireless remote controller*		J41	J42	A	—	—	0	Initial setting	B	Cut	—	1	—	C	—	Cut	2	—	D	Cut	Cut	3	—	Under operation or suspension	<p><Initial setting> Pattern A</p> 
Setting pattern	Indoor controller Jumper wire			Pair No. of wireless remote controller*																											
	J41	J42																													
A	—	—	0	Initial setting																											
B	Cut	—	1	—																											
C	—	Cut	2	—																											
D	Cut	Cut	3	—																											
SWE Test run for Drain pump	Connector	<p>Drain pump and fan are activated simultaneously after the connector SWE is set to ON and turn ON the power.</p>  <p>The connector SWE is set to OFF after test run.</p>	Under operation	<p><Initial setting></p> 																											

8-3. TEST POINT DIAGRAM

8-3-1. Indoor controller board


PLFY-WP32VBM-E.UK PLYF-WP40VBM-E.UK PLYF-WP50VBM-E.UK



Note: The voltage range of 12 V DC in this page is between 11.5 to 13.7 V DC.

8-3-2. Address board

PLFY-WP32VBM-E.UK PLY-WP40VBM-E.UK PLY-WP50VBM-E.UK




9-1. HOW TO PERFORM THE UP/DOWN OPERATION OF THE AIR INTAKE GRILLE

9-1-1. Setting up the lowering distance of air intake grille


You can set up 8 different stages of lowering distance for the air intake grille according to the set up location if desired.

Note that as an initial setting, the decorative panel will automatically stop at 1.6 m from the ceiling level. The distance is a rough indication, check by actually lowering it.









- 1) Take the cover off the electric box of the decorative panel. (2 screws)
- 2) Set up the dip switches of SW22 or SW2 on the control board of the decorative panel as follows.



DIP SW 22




The black square (■) indicates a switch position.

Lowering distance (Rough indication of the ceiling height)	SW22 (Lowering distance)	Lowering distance (Rough indication of the ceiling height)	SW22 (Lowering distance)
1.2 m (up to 2.4 m)	ON OFF  1 2 3 4 5 6 7 8 9 10	1.6 m (2.4-2.8 m)	Initial setting ON OFF  1 2 3 4 5 6 7 8 9 10
2.0 m (2.8-3.2 m)	ON OFF  1 2 3 4 5 6 7 8 9 10	2.4 m (3.2-3.6 m)	ON OFF  1 2 3 4 5 6 7 8 9 10
2.8 m (3.6-4.0 m)	ON OFF  1 2 3 4 5 6 7 8 9 10	3.2 m (4.0-4.4 m)	ON OFF  1 2 3 4 5 6 7 8 9 10
3.6 m (4.4-4.8 m)	ON OFF  1 2 3 4 5 6 7 8 9 10	4.0 m (4.8-5.2 m)	ON OFF  1 2 3 4 5 6 7 8 9 10









Note: Airflow outreach distance is different depending on indoor units and air volume (ceiling height), so airflow may not reach the indicated ceiling height as shown in the above table.

- 3) Put the cover back on the electric box of the decorative panel.

DIP SW 2



The black square (■) indicates a switch position.

Lowering distance (Rough indication of the ceiling height)	SW2 (Lowering distance)	Lowering distance (Rough indication of the ceiling height)	SW2 (Lowering distance)
1.2 m (up to 2.4 m)	ON OFF  1 2 3 4 5 6	1.6 m (2.4-2.8 m)	Initial setting ON OFF  1 2 3 4 5 6
2.0 m (2.8-3.2 m)	ON OFF  1 2 3 4 5 6	2.4 m (3.2-3.6 m)	ON OFF  1 2 3 4 5 6
2.8 m (3.6-4.0 m)	ON OFF  1 2 3 4 5 6	3.2 m (4.0-4.4 m)	ON OFF  1 2 3 4 5 6
3.6 m (4.4-4.8 m)	ON OFF  1 2 3 4 5 6	4.0 m (4.8-5.2 m)	ON OFF  1 2 3 4 5 6

Note: Airflow outreach distance is different depending on indoor units and air volume (ceiling height), so airflow may not reach the indicated ceiling height as shown in the above table.

9-1-2. How to perform the up/down operation using wireless remote controller

Warning: Ensure that the air-conditioner is not running. • Otherwise, it may cause an injury or a failure.

- 1) Ensure that the air-conditioner is not running.
- 2) Press the "Down" button to lower the air intake grille.

By default, the air intake grille will automatically stop at a lowering distance of 1.6 m from the ceiling level. The distance can be changed to 1.2 m, 2.0 m, 2.4 m, 2.8 m, 3.2 m, 3.6 m and 4.0 m. These should be used only as a guide. You should lower the air intake grille yourself to check the exact distance.

When you want to stop the air intake grille while it is lowering, press the "Stop" or "Up" button on the remote controller to stop at that position.

- 3) Remove the filter or air intake grille and clean them.
- 4) Press the "Up" button on the remote controller to put the air intake grille in place.

If the air intake grille is not placed in the correct position at a time, the operation is automatically retried.


When you want to stop the air intake grille while it is rising, press the "Stop" or "Down" button on the remote controller to stop at that position.




Wireless remote controller for Automatic Filter Elevation Panel

9-1-3. How to perform the up/down operation using wired remote controller <PAR-30MAA><PAR-31MAA>


① Select "Maintenance" from the Main menu, and press the button.




Select "Auto descending panel" with the **F1** or **F2** button, and press the button.



② Move the cursor to "M-NET address" or "Operation" with the **F1** button to select.




Select the M-NET address for the units to lower the panel, with the **F2** or **F3** button, and press the button.



- M-NET address: M-NET address
- Operation: Down/Up

Press the **F4** button to confirm the unit.




<Confirmation of target unit>

If the unit being set is unknown, make the setting and then press the **F4** button to confirm.

The air conditioner which is blowing downward is the target air conditioner.

Navigating through the screens

- To return to the previous screen..... button



9-1-4. How to perform the up/down operation using wired remote controller (PAR-21MAA)

■ General Operation

Raise or lower all the air intake grilles managed by the remote controller at the same time.
Install the remote controller in a place where you can observe all the air-conditioners. Otherwise, the lowering grille may make contact with something and cause damage to it.

1) Ensure that the air-conditioner is not running.

The up/down operation mode is only available when the air-conditioner is "OFF".

Warning: Ensure that the air-conditioner is not running.
• Otherwise, it may cause an injury or a failure.

2) Press both the "FILTER" and "Ventilation" buttons simultaneously for 2 seconds or more to enter the up/down operation mode.

"Up/down operation mode" display



3) Press the TEMP. (▽) button. After a while, the air intake grille will begin lowering.

"Stand by for lowering" display



"Lowering" display (blinking)



"Stopped" display (when finished lowering)



[Note]

- You cannot stop the operation while the air intake grille is lowering. If you press the (△) button while the air intake grille is moving down, the air intake grille may stop lowering, but it will not stop immediately.
- By default, the air intake grille will automatically stop at the lowering distance of 1.6 m from the ceiling level. The distance can be changed to 1.2 m, 2.0 m, 2.4 m, 2.8 m, 3.2 m, 3.6 m, and 4.0 m. These should be used only as a guide. You should lower the air intake grille yourself to check the exact distance.

4) Remove the filter and/or air intake grille to clean them.

5) Press the TEMP. (△) button. After a while, the air intake grille will begin to rise and then be put back into place.

"Stand by for raising" display



"Raising" display (blinking)



"Stopped" display (when the air intake grille has been put back into place)




[Note]

- You cannot stop the operation while the air intake grille is rising. If you press the (▽) button while the air intake grille is moving up, the air intake grille may stop rising, but it will not stop immediately.

6) Exit the up/down mode either by pressing the "ON/OFF" button or by pressing both the "FILTER" and "Ventilation" buttons simultaneously for 2 seconds or more.

After exiting the up/down mode, wait for about 30 seconds to perform the next operation. The remote controller will not accept any operation for that period.



■ Up/down operation with the individual specified air-conditioner (when used in combination with Mr. SLIM model)
Raise or lower the air intake grille of the specific air-conditioner that you select from all that are managed by that remote controller.

1) Ensure that the air-conditioner is not running.


The up/down operation mode is only available when the air-conditioner is "OFF".

Warning: Ensure that the air-conditioner is not running.
• Otherwise, it may cause an injury or a failure.

2) Press both the "FILTER" and "Ventilation" buttons simultaneously for 2 seconds or more to enter the up/down operation mode.



3) Press the "Ventilation" button. After a while, it will switch to the "individually-specified up/down operation mode".



If the number of the target air-conditioner is unknown, go to 4).

In the upper right figure, the air-conditioner which the refrigerant address is "00" and the unit No. is "1" is currently selected.

If the number of the target air-conditioner is known, go to 5).

4) If you press the "FILTER" button when the "Unit No." or "Refrigerant address No." is blinking, the up/down airflow direction of the displayed air-conditioner will be switched downward after a while, and the airflow direction of the other vents will all be blocked.


- In Step 5) described below, identify the target air-conditioner by changing the "Unit No." and "Refrigerant address No." and by pressing the "FILTER" button to check the up/down airflow direction.

[Remarks]

- If "Err" is displayed when you press the "FILTER" button to check the target air-conditioner, the air-conditioner with that "Unit No." or "Refrigerant address" may not exist. Check and set that air-conditioner again.

5) Select the "Unit No." and "Refrigerant address No.".


- "Unit No." and "Refrigerant address No." can be changed by using the "TEMP." buttons (Δ) (▽) when the panel displays (a) or (b).
- Every time you press the "Mode selection" button, the target of operation will change as illustrated below.




[Remarks]

- Each pressing action changes the unit No. from "1 - 4" to "0". (Unit No. "0" means that all of 1 - 4 are targeted.)
- Each press changes the "Refrigerant address" from "0" to "15".

6) Continue to press the "Mode selection" button until "Waiting for up/down operation" is displayed.



The following steps are the same as steps 3) - 6) described in the "General Operation" section. Refer to that section.



9-2. OPERATION (AUTO DESCENDING PANEL: PLP-6BAJ)

(1) Normal operation

① UP/DOWN

Air intake grille is raised/lowered by commands of UP and DOWN.

Air intake grille does not move under the state of no-load detection or obstacle detection.

Air intake grille stops automatically at the set lowering distance from the ceiling level.

② STOP

It stops in the cases below :

- When it reaches at the set lowering distance from the ceiling level.

It automatically stops after a predetermined period of lowering.

- When it is stored in the panel.

The air intake grille is judged to be stored in the panel when the storage detection switch is pressed for 3 seconds continuously.


- When receiving commands of STOP, DOWN while moving up or UP while moving down.

The STOP button is only available on the automatic filter elevation panel remote controller.

When the wired remote controller is used, there will be a slight delay in stopping due to transmission speed.

- When both wire 1b and wire 2b are not loaded.

Only the wire b in each UP/DOWN Machine has a tension detection switch.



(2) Special operation

① Storage operation

Case : Obstruction of the raising grille before storage or malfunction of storage detection switch

Storage operation will be performed when the intake grille has been raised the set distance but the storage detection switch is not engaged.

In this case, the operation below will be repeated up to 4 times.

10 cm down → 30 cm up → ... → 10 cm down → 30 cm up

② No-load detection

Case : UP/DOWN commands with no grille suspended.

When both wire 1b and wire 2b are not loaded, the wires will not move.


③ Obstacle detection

Case : Making contact with something while lowering.


Should the loads on the wire 1b and wire 2b be removed due to the grille making contact with something while lowering, the lowering operation will stop. The grille will then be raised 10 cm and stop again.

[Emergency operation]

- When the wireless remote controller cannot be used (in the case of battery discharge, misplacing of the wireless remote controller, malfunctioning and so on), the emergency switch on the receiver can be used as an alternative. When doing this, particular caution must be taken not to fall.

To lower the air intake grille : Press the  button once.

(For emergency heating operation, press and hold this button.)



To raise the air intake grille : Press the  button once.

(For emergency cooling operation, press and hold this button.)

- To stop the air intake grille from moving, use the opposite buttons to those used to initiate movement. (To stop it from lowering, press the UP button; To stop it from rising, press the DOWN button.)
- If UP/DOWN machine is out of order, fix air intake grille temporarily and the indoor unit can be operated. For details, refer to installation manual for the attachment of grille.



9-3. ELECTRICAL CIRCUIT (Controller board and wiring diagram (Panel))

9-3-1. DIP SW 22 type



Symbol	Name	Symbol	Name
U.B	Auto grille controller board	W.B	Wireless remote controller board
FUSE	Fuse (3.15A)	BZ	Buzzer
SW22	Switch (Lowering distance set up)	RU	Receiver
UK1	Up/down machine	SW1	Emergency switch (heating/down)
MU1	Motor (Up/down)	SW2	Emergency switch (cooling/up)
LS21	Limit switch (tension detection)	LS1	Limit switch (storage detection)
I.B	Indoor controller board	R.B	Wired remote controller

9-3-2. DIP SW 2 type



[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
U.B	CONTROLLER BOARD	I.B	INDOOR UNIT CONTROLLER BOARD	UK1	UP/DOWN MACHINE
FUSE	FUSE (T3.15A/250V)	W.B	WIRELESS SIGNAL RECEIVER BOARD	M	MOTOR (FOR GRILLE UP/DOWN)
SW1	SWITCH (MODEL SELECTION)	BZ	BUZZER	LS21	LIMIT SWITCH (TENSION DETECTION)
SW2	SWITCH (LOWERING DISTANCE)	RU	RECEIVING UNIT	LS1	LIMIT SWITCH (STORAGE DETECTION)
SW3	SWITCH (SYSTEM SELECTION)	SW1	EMERGENCY HEATING LONG PRESS FOR OVER 2 SEC)	R.B	WIRED REMOTE CONTROLLER
LED1	LED RED (MICROCOMPUTER POWER)	SW2	EMERGENCY COOLING LONG PRESS FOR OVER 2 SEC)		
LED2	LED RED (GRILLE CONDITION)				

9-3-3. Check point of trouble

<LED (SW22 type) /LED2 (SW2 type) display>

- Turn OFF : No power supply
- Blink : Storage detection switch ON (short)
- One blink : Storage detection switch OFF (open)
- Two blinks : Tension detection switch OFF (open)

<controller board>

Check item	Check point	Normal	Remarks
Up/down controller P.C. board supply voltage	CN3A (between 3–5)	198–264 V AC	—
Up/down machine supply voltage	CN2B, CN2C	10–12 V DC	Check when instructing up/down with LED blinking once.

<Up/down machine>

Check item	Check point	Normal	Check contents
Storage detection switch	CN2E	open or short	Check if it is short when pressing push switch.
Tension detection switch	CN2F, CN2G	open or short	Check if it is short when wire b is tensioned.
Motor	CN2B, CN2C	5–20 Ω	Check if it is not open or short.
Entwining wires	Pull wire	Retension: about 2 kgf	Check if wire is drawn out by pulling with 3 kgf.




9-4. TROUBLESHOOTING

- Check the following points.

Problem	Possible Reason	Corrective Action
Air intake grille does not function with operation of the wireless remote controller.	Air-conditioner is running.	Stop running the air-conditioner and try again.
	Power failure	After recovering from power failure, try again.
	Batteries are not inserted into the wireless remote controller. Or battery power is running low.	Insert or replace the battery.
	There is something on the air intake grille. Or something is stuck in the air intake grille.	Remove the objects or obstacles from the air intake grille. Or, remove the stuck object.
Air intake grille cannot be fixed in place.	There is something on the air intake grille.	Remove the objects or obstacles from the air intake grille.
	Filter is not properly installed.	Lower the air intake grille again and check whether the filter is installed in the correct position.
	Air intake grille is not hung with all 4 hooks.	Lower the air intake grille again and hook on the air intake grille.
Air intake grille stops lowering. (Air intake grille would not lower any further.)	The air intake grille has finished lowering to the auto-stop position.	This is normal.
Noises are made during up/down operation. (While air intake grille is moving up/down.)	This is the noise made when the wire is wound and unwound.	This is normal.
Noises are made while putting the air intake grille into place.	This is the operational noise for putting the air intake grille into place.	
Air intake grille repeats rising and lowering several times while being put into place.	This is the operation for putting the air intake grille into place.	
Air intake grille leans toward one side during the up/down operation.	The speeds of winding/unwinding wires are slightly different for each wire.	

PLFY-WP32VBM-E.UK PLY-WP40VBM-E.UK PLY-WP50VBM-E.UK

Be careful when removing heavy parts.


OPERATING PROCEDURE	PHOTOS & ILLUSTRATIONS
<p>1. Removing the air intake grille</p> <p>(1) Slide the knob of air intake grille toward the arrow ① to open the air intake grille.</p> <p>(2) Remove drop prevention hook from the panel.</p> <p>(3) Slide the shaft in the hinge to the direction of the arrow ② and remove the air intake grille.</p>	<p>Figure 1</p>  <p>Air intake grille knob</p> <p>Air intake grille</p> <p>Grille</p> <p>Filter</p>
<p>2. Removing the room temperature detection thermistor (TH21)</p> <p>(1) Remove the air intake grille and the filter. (See Figure 1)</p> <p>(2) Remove the 2 screws from the electrical box cover.</p> <p>(3) Disconnect the connector CN20 (Red) from the indoor controller board.</p> <p>(4) Remove the room temperature detection thermistor.</p>	<p>Photo 1</p>  <p>MA remote controller terminal cover</p> <p>Address board cover fixing screw</p> <p>Address board</p> <p>Address board cover fixing screw</p> <p>Terminal cover fixing screw</p> <p>Electrical box cover fixing screws</p> <p>Electrical box cover</p>
<p>3. Removing the address board (A.B)</p> <p>(1) Remove the air intake grille and the filter. (See Figure 1)</p> <p>(2) Remove the 2 screws from the address board cover.</p> <p>(3) Disconnect the connectors CN43 (RED/4P) and CN82 (RED/8P).</p> <p>(4) Slide and remove the address board.</p>	<p>Photo 2</p>  <p>Room temp. detection thermistor (TH21)</p> <p>Bell mouth</p> <p>Turbo fan</p> <p>Nut</p> <p>Electrical box fixing screws</p> <p>Electrical box</p> <p>Indoor controller board</p> <p>Support for Indoor controller board</p> <p>Electrical box fixing screws</p>
<p>4. Removing the indoor controller board (I.B)</p> <p>(1) Remove the air intake grille and the filter. (See Figure 1)</p> <p>(2) Remove the 2 screws from the electrical box cover.</p> <p>(3) Disconnect the connectors :</p> <ul style="list-style-type: none"> CNMF (White/7P) for fan motor CN44 (White/4P) for thermistor (TH22/TH23) CNP (Blue/3P) for drain pump CN4F (White/4P) for float switch CN01 (Black/5P) for earth and TB2 CNV (White/20P) for vane motor CN81, CN42 (Red/8P,4P) for address board CN2M (Blue/2P) for TB5 <p>(4) Remove the 6 supports from indoor controller board.</p> <p>(5) Remove the indoor controller board.</p>	<p>5. Removing the electrical box</p> <p>(1) Remove the air intake grille and the filter. (See Figure 1)</p> <p>(2) Remove the 3 screws from the electrical box cover.</p> <p>(3) Disconnect the connectors. (Refer to procedure 4)</p> <p>(4) Remove 4 electrical box fixing screws and remove 2 hooks.</p> <p>(5) Pull the electrical box.</p> <p><Electrical parts in the electrical box></p> <ul style="list-style-type: none"> Indoor controller board Terminal block (TB2) (TB5)



OPERATING PROCEDURE

6. Removing the fan and fan motor (MF)

- (1) Remove the electrical box. (See Photo 2)
- (2) Remove the bell mouth (3 screws). (See Photo 2)
- (3) Remove the turbo fan nut.
- (4) Pull out the turbo fan.
- (5) Remove the wire cover (3 screws).
- (6) Remove 2 wiring clamps.
- (7) Disconnect the connector of the fan motor (CNMF).
- (8) Remove the 3 nuts and washers and rubber mounts of the fan motor.



7. Removing the panel


- (1) Remove the air intake grille and the filter. (See Figure 1)
- (2) Disconnect the connector CNV (White/20P).

Corner panel (See Figure 2)

- (3) Remove the corner screw.
- (4) Slide the corner panel to the direction of the arrow ①, and remove the corner panel.

Panel (See Photos 4, 5)

- (5) Remove the 2 screws from the panel which fix to the oval holes.
- (6) Rotate the panel a little to come to the bell shaped hole where the screw is large and remove the panel.




8. Removing the drain pan

- (1) Remove the air intake grille and the filter. (See Figure 1)
- (2) Remove the 2 screws from the electrical box cover.
- (3) Disconnect the connectors. (Refer to procedure 4)
- (4) Remove the panel. (See Photos 4, 5)
- (5) Remove the electrical wiring service panel (3 screws).
- (6) Remove the drain pump wire cover (1 screw).
- (7) Remove the electrical box. (See Photo 2)
- (8) Remove the bell mouth. (See Photo 2)
- (9) Remove the 4 screws and pull out the drain pan.


Notes:

1. Pull out the left and right of the pan gradually.
2. Be careful not to crack or damage the pan.



9. Removing the pipe temperature detection thermistor/from HBC unit (TH22) and pipe temperature detection thermistor/to HBC unit (TH23)

- (1) Remove the drain pan. (See Photo 6)
- (2) Remove the turbo fan. (See Photo 3)
- (3) Remove the 2 wiring clamps. (See Photo 3)
- (4) Remove the coil plate (2 screws).
- (5) Remove the thermistors which are inserted into the holders installed to the thin copper pipe.
- (6) Disconnect the 4-pin white connector (CN44).






OPERATING PROCEDURE


10 Removing the drain pump (DP) and float switch (FS)

- (1) Remove the drain pan. (See Photo 6)
- (2) Cut the hose band and remove the hose.
- (3) Remove the drain pump assembly (3 screws and 2 hooks).
- (4) Remove the drain pump (3 screws).
- (5) Remove the float switch (2 screws).



11. Removing the heat exchanger

- (1) Remove the drain pan. (See Photo 6)
- (2) Remove the 3 screws of the piping cover, and pull out piping cover.
- (3) Remove the 2 screws of coil plate.
- (4) Remove the 2 screws of the coil.
- (5) Remove the screw of the coil support.
- (6) Pull out the heat exchanger.



CITY MULTI

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU TOKYO 100-8310, JAPAN
