



*Changes for the Better*

AIR CONDITIONER

**2021**

**R32**

# Service Handbook

**Model**

**PURY-M200, M250, M300, M350, M400, M450, M500YNW-A1**

**PURY-EM200, EM250, EM300, EM350, EM400, EM450, EM500YNW-A1**

**CMB-WM350, 500F-AA**

**CMB-WM108, 1016V-BB**

# Safety Precautions

- Read and observe the safety precautions below and the instructions provided on the labels affixed to the unit.
- Retain this manual for future reference. Make sure that this manual is passed on to the end users.
- All refrigerant piping work, electrical work, air-tightness test, and brazing work must be performed by qualified personnel.
- Incorrect use may result in serious injury.



indicates a hazardous situation which, if not avoided, could result in death or serious injury.



indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

**CAUTION**

addresses practices not related to personal injury, such as product and/or property damage.

## General Precautions



**Do not use any refrigerant other than the type indicated in the manuals for the unit and on the nameplate.**

- Doing so will cause the unit or pipes to burst, or result in an explosion or fire during use, during repairs, or at the time of disposal of the unit.
- It may also be in violation of applicable laws.
- MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.

**Do not use the unit in an unusual environment.**

- If the unit is used in areas exposed to large amounts of oil, steam, organic solvents, or corrosive gases (such as ammonia, sulfuric compounds, or acids), or areas where acidic/alkaline solutions or special chemical sprays are used frequently, it may significantly reduce the performance and corrode the internal parts, resulting in refrigerant leakage, water leakage, injury, electric shock, malfunction, smoke, or fire.

**Do not change the settings of the safety or protection devices.**

- Forcing the unit to operate by disabling the safety devices, such as the pressure switch or the thermal switch, may result in bursting, fire, or explosion.
- Operating the unit with a safety device whose settings have been changed may result in bursting, fire, or explosion.
- Using safety devices other than those specified by Mitsubishi Electric may result in bursting, fire, or explosion.

**Do not alter or modify the unit.**

- Doing so will result in refrigerant leakage, water leakage, serious injury, electric shock, or fire.

**Do not wet the electrical parts.**

- Doing so may result in current leakage, electric shock, malfunction, or fire.

**Do not touch the electrical parts, switches, or buttons with wet fingers.**

- Doing so may result in electric shock, malfunction, or fire.

**Do not touch the refrigerant pipes and refrigerant line components with bare hands during and immediately after operation.**

- The refrigerant in the pipes will be very hot or very cold, resulting in frostbite or burns.

**Do not touch the electrical parts with bare hands during and immediately after operation.**

- Doing so may result in burns.

**Ventilate the room while servicing the unit.**

- If the refrigerant leaks, oxygen deficiency may result. If the leaked refrigerant comes in contact with a heat source, toxic gas will be generated.

**If you notice any abnormality (e.g., a burning smell), stop the operation, turn off the power switch, and consult your dealer.**

- Continuing the operation may result in electric shock, malfunction, or fire.

**Properly install all required covers and panels on the terminal box and the control box.**

- If dust or water enters the unit, this may result in electric shock or fire.

**Periodically check the unit base for damage.**

- If the damage is left uncorrected, the unit will fall and cause serious injury.

**Consult your dealer for the proper disposal of the unit.**

- The refrigerant oil and the refrigerant in the unit will pose a risk of environmental pollution, fire, or explosion.

**Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.**

**The unit shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.)**

**Do not pierce or burn.**

**Be aware that refrigerants may not contain an odour.**

**The unit shall be installed, operated and stored in a room with a floor area according to the following figure.**

## **! CAUTION**

**Children should be supervised to ensure that they do not play with the appliance.**

**Do not operate the unit with the panels and guards removed.**

- Rotating, hot, or high-voltage parts may cause injury, electric shock, or fire.

**Do not touch fans, heat exchanger fins, or the sharp edges of components with bare hands.**

- Doing so may result in injury.

## **Transportation and Installation**

## **! WARNING**

**When lifting the unit, pass the slings through the four designated sling holes.**


- Improper lifting will cause the unit to topple or fall, resulting in serious injury.

## **! CAUTION**

**Do not lift the unit with the PP bands that are used on some products.**

- Doing so may result in injury.

**When installing an HBC, take safety measures in accordance with the European Standard, based on the system refrigerant amount and the room volume as shown in the figure below. (The installation restrictions can be simply found by using the flow-chart provided on a separate sheet.)**



**The unit shall be properly stored to prevent mechanical damage.**

**Wear protective gloves when working on the unit.**

- Failure to do so may result in injury.
- High-pressure pipes poses a risk of burns if touched with bare hands while the unit is in operation.

**Check that markings of the unit are not illegible.**

- Illegible warning or caution markings may cause damage to the unit, resulting in injury.

**Observe the restrictions on the maximum weight that a person can lift, which is specified in local regulations.**

- Failure to do so may result in injury.

## Installation

### WARNING

**Do not install the unit where combustible gas may leak.**

- If combustible gas accumulates around the unit, fire or explosion may result.

**Do not allow children to play with the packing materials.**

- Suffocation or serious injury may result.

**Cut up the packing materials before disposal.**

**All installation work must be performed by qualified personnel in accordance with this manual.**

- Improper installation may result in refrigerant leakage, water leakage, serious injury, electric shock, or fire.

**If the air conditioner is installed in a small room, take measures to prevent the refrigerant concentration from exceeding the safety limit in the event of refrigerant leakage.**

- Consult your dealer regarding the appropriate measures to prevent the allowable concentration from being exceeded. If the refrigerant leaks and the allowable concentration is exceeded, hazards due to a lack of oxygen in the room will result.

**Install the unit in accordance with the instructions to minimize the risk of damage from earthquakes and strong winds.**

- Improper installation will cause the unit to topple, resulting in serious injury.

**The unit must be securely installed on a structure that can sustain its weight.**

- Failure to do so will cause the unit to fall, resulting in serious injury.

**Do not open the control box cover when charging refrigerant.**

- Doing so may cause sparks, resulting in fire.

### CAUTION

**Seal all openings around pipes and wires to keep out small animals, rainwater, or snow.**

- Failure to do so may result in current leakage, electric shock, or damage to the unit.

**Do not install the unit where corrosive gas may be generated.**

- Doing so can corrode the pipes, resulting in refrigerant leakage and fire.

## Piping Work

### WARNING

**Piping work shall be kept to a minimum.**

**The pipes shall be protected from physical damage.**

**Before heating the brazed sections, remove the gas and oil that are trapped in the pipes.**

- Failure to do so may generate fire, resulting in serious injury.

**Do not purge the air using refrigerant. Use a vacuum pump to evacuate the system.**

- Residual gas in the refrigerant lines will cause bursting of the pipes or an explosion.

**Do not use oxygen, flammable gas, or a refrigerant containing chlorine for air-tightness testing.**

- Doing so may result in an explosion. Chlorine will deteriorate the refrigerant oil.

**When installing or relocating the unit, do not allow air or any substance other than the specified refrigerant to enter the refrigerant lines.**

- Any substance other than the specified refrigerant may cause abnormally high pressure in the refrigerant lines, resulting in bursting of the pipes or an explosion.

**After the installation has been completed, check for refrigerant leaks.**

- If the refrigerant leaks, oxygen starvation may result. If the leaked refrigerant comes in contact with a heat source, toxic gas will be generated.

**Have a fire extinguisher nearby before brazing work.**

- If the refrigerant leaks while brazing work is being performed, fire may result.

**Provide no-smoking signs at the brazing workplace.**

- If the refrigerant leaks when an ignition source is present, fire may result.

**Pipes with outer diameter exceeding 33.4 mm are subject to the Pressure Equipment Directive (PED), and brazing of these pipes must be done by PED certified personnel.**

## Wiring Work

### **WARNING**

**Include some slack in the power cables.**

- Failure to do so may break or overheat the cables, resulting in smoke or fire.

**Connections must be made securely and without tension on the terminals.**

- Improperly connected cables may break, overheat, or cause smoke or fire.

**Tighten all terminal screws to the specified torque.**

- Loose screws and contact failure may result in smoke or fire.

**Electrical work must be performed by qualified personnel in accordance with local regulations and the instructions provided in this manual. Only use the specified cables and dedicated circuits.**

- Inadequate power source capacity or improper electrical work will result in electric shock, malfunction, or fire.

**Install an earth leakage breaker on the power supply of each unit.**

- Failure to do so may result in electric shock or fire.

**Only use properly rated breakers (an earth leakage breaker, local switch <a switch + fuse that meets local electrical codes>, or overcurrent breaker).**

- Failure to do so may result in electric shock, malfunction, smoke, or fire.

**Only use standard power cables of sufficient capacity.**

- Failure to do so may result in current leakage, overheating, smoke, or fire.

**Proper grounding must be provided by qualified personnel.**

- Improper grounding may result in electric shock, fire, explosion, or malfunction due to electrical noise. Do not connect the ground wire to gas or water pipes, lightning rods, or telephone ground wires.

### **CAUTION**

**After the wiring work has been completed, measure the insulation resistance, and make sure that it reads at least 1 MΩ.**

- Failure to do so may result in electric leakage, malfunction, or fire.

## Relocation and Repairs

### WARNING

**Only qualified personnel must relocate or repair the unit. Do not attempt to disassemble or alter the unit.**

- Failure to do so will result in refrigerant leakage, water leakage, serious injury, electric shock, or fire.

**Do not service the unit in the rain.**

- Doing so may result in electric leakage, electric shock, wire shorting, malfunction, smoke, or fire.

**Check for refrigerant leaks before service.**

- If the refrigerant leaks, fire may result.

**Do not open the control box cover when recovering, charging, or purging refrigerant.**

- Doing so may cause sparks, resulting in fire.

## Additional Precautions

### CAUTION

**Do not turn off the power immediately after stopping operation.**

- Wait for at least five minutes after the unit has stopped before turning off the power. Failure to do so may result in drain water leakage or the mechanical failure of sensitive parts.

**The unit must be periodically inspected by a dealer or qualified personnel.**

- If dust or dirt accumulates inside the unit, the drain pipes may become clogged, and water leakage from the pipes may wet the surroundings and generate odours.

**Turn on the power at least 12 hours before starting operation. Keep the power turned on throughout the operating season.**

- Insufficient energizing will result in malfunction.

**Do not use the air conditioner for special purposes (e.g. keeping food, animals, plants, precision devices, or art objects in a room).**

- Such items could be damaged or deteriorated.

**Collect the refrigerant and properly dispose of it in accordance with local regulations.**

**Do not install the unit on or over items that are subject to water damage.**

- When the room humidity exceeds 80% or if the drain pipe is clogged, condensation may collect and drip from the indoor unit onto the ceiling or floor.

**Drain piping must be installed by a dealer or qualified personnel to ensure proper drainage.**

- Improper drain piping may cause water leakage, resulting in damage to furniture and other surroundings.

**Take appropriate measures against electrical noise interference when installing the unit in hospitals or radio communication facilities.**

- Inverter, high-frequency medical, or wireless communication equipment as well as power generators may cause the air conditioning system to malfunction. The air conditioning system may also adversely affect the operation of these types of equipment by creating electrical noise.

**Insulate pipes to prevent condensation.**

- Condensation may collect and drip from the unit onto the ceiling or floor.

**Keep the service valves closed until refrigerant charging is completed.**

- Failure to do so will damage the unit.

**Place a wet towel on the service valves before brazing the pipes to keep the temperature of the valves from rising above 120°C (248°F).**

- Failure to do so may result in equipment damage.

**Keep the flame out of contact with the cables and metal sheet when brazing the pipes.**

- Failure to do so may result in burnout or malfunction.

**Use the following tools specifically designed for use with the specified refrigerant: Gauge manifold, charge hose, gas leak detector, check valve, refrigerant charge base, vacuum gauge, and refrigerant recovery equipment.**

- Gas leak detectors for conventional refrigerants will not react to a refrigerant that does not contain chlorine.
- If the specified refrigerant is mixed with water, refrigerant oil, or another refrigerant, the refrigerant oil will deteriorate and the compressor will malfunction.

**Use a vacuum pump with a check valve.**

- If the vacuum pump oil flows back into the refrigerant lines, the refrigerant oil may deteriorate and the compressor may malfunction.

**Keep tools clean.**

- If dust, dirt, or water accumulates on the charging hose or the flare processing tool, the refrigerant will deteriorate and the compressor will malfunction.

**Use refrigerant piping made of phosphorus deoxidized copper (copper and copper alloy seamless pipes) that meets local requirements. Pipe joints should also meet local requirements. Keep the inner and outer surfaces of the pipes clean and free of sulphur, oxides, dust/dirt, shaving particles, oils, moisture, or any other contaminants.**

- Contaminants on the inside of the refrigerant piping will cause the refrigerant oil to deteriorate and cause the compressor to malfunction.

**Store pipes indoors, and keep both ends of the pipes sealed until just before making a flare connection or brazing. (Store elbows and other joints in plastic bags.)**

- If dust, dirt, or water enters the refrigerant lines, the refrigerant oil will deteriorate and the compressor will malfunction.

**Braze the pipes with a nitrogen purge to avoid oxidation.**

- Oxidized flux inside the refrigerant pipes will cause the refrigerant oil to deteriorate and cause the compressor to malfunction.

**Do not use existing refrigerant piping.**

- The old refrigerant and refrigerant oil in the existing piping contain a large amount of chlorine, which will cause the refrigerant oil in the new unit to deteriorate and cause the compressor to malfunction.

**If a large electric current flows due to a malfunction or faulty wiring, earth-leakage breakers on the unit side and on the upstream side of the power supply system could both operate. Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.**

**This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.**

**This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

**Store the unit in a room large enough to allow clearance in the event of refrigerant leakage.**

**Refrigerant R32 is flammable. Do not use a naked-flame type detector.**

**Only qualified personnel may touch the USB port in the control box.**

# CONTENTS

---

## Chapter 1 Check Before Servicing

1-1	Preparation for Piping Work.....	1
1-2	Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil .....	3
1-3	Working with Refrigerant Piping.....	14
1-4	Precautions for Wiring .....	19
1-5	Cautionary notes on installation environment and maintenance.....	21

## Chapter 2 Restrictions

2-1	System Configurations .....	1
2-2	Types and Maximum Allowable Length of Cables .....	2
2-3	Switch Settings.....	3
2-4	M-NET Address Settings .....	4
2-5	Demand Control Overview .....	9
2-6	System Connection Example .....	10
2-7	Example System with an MA Remote Controller .....	11
2-8	Example System with an ME Remote Controller.....	24
2-9	Example System with an MA and an ME Remote Controller.....	26
2-10	Restrictions on Refrigerant Pipes .....	29

## Chapter 3 Major Components, Their Functions and Refrigerant Circuits

3-1	External Appearance and Refrigerant Circuit Components of Outdoor Unit .....	1
3-2	Outdoor Unit Refrigerant Circuit Diagrams .....	8
3-3	Functions of the Major Components of Outdoor Unit .....	14
3-4	Functions of the Major Components of Indoor Unit .....	16
3-5	External Appearance and Refrigerant Circuit Components of HBC.....	17
3-6	HBC Refrigerant Circuit Diagrams.....	22
3-7	Functions of the Major Components of HBC.....	24

## Chapter 4 Electrical Components and Wiring Diagrams

4-1	Outdoor Unit Circuit Board Arrangement .....	1
4-2	Outdoor Unit Circuit Board Components .....	6
4-3	Outdoor Unit Electrical Wiring Diagrams.....	17
4-4	Transmission Booster Electrical Wiring Diagrams .....	20
4-5	HBC Circuit Board Arrangement .....	21
4-6	HBC Circuit Board Components .....	22
4-7	HBC Electrical Wiring Diagrams .....	27

## Chapter 5 Control

5-1	Dipswitch Functions and Factory Settings.....	1
5-2	Outdoor Unit Control .....	11
5-3	HBC Control.....	22

## Chapter 6 Test Run

6-1	Read before Test Run .....	1
6-2	Operation Characteristics and Refrigerant Charge .....	2
6-3	Evaluating and Adjusting Refrigerant Charge.....	2
6-4	The Following Symptoms Are Normal .....	4



# CONTENTS

---

## Chapter 7 Troubleshooting Using Error Codes

7-1	Error Code and Preliminary Error Code Lists .....	1
7-2	Error Code Definitions and Solutions: Codes [0 - 999].....	8
7-3	Error Code Definitions and Solutions: Codes [1000 - 1999].....	11
7-4	Error Code Definitions and Solutions: Codes [2000 - 2999].....	15
7-5	Error Code Definitions and Solutions: Codes [3000 - 3999].....	24
7-6	Error Code Definitions and Solutions: Codes [4000 - 4999].....	26
7-7	Error Code Definitions and Solutions: Codes [5000 - 5999].....	48
7-8	Error Code Definitions and Solutions: Codes [6000 - 6999].....	61
7-9	Error Code Definitions and Solutions: Codes [7000 - 7999].....	81
7-10	Unit Error Code Definitions and Solutions: Codes [Er91 - Er99].....	90

## Chapter 8 Troubleshooting Based on Observed Symptoms

8-1	MA Remote Controller Problems .....	1
8-2	ME remote Controller Problems .....	5
8-3	Refrigerant Control Problems .....	10
8-4	Checking Transmission Waveform and for Electrical Noise Interference.....	15
8-5	Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems .....	18
8-6	Troubleshooting Solenoid Valve Problems .....	22
8-7	Troubleshooting Outdoor Unit Fan Problems .....	23
8-8	Troubleshooting LEV, FCV Problems .....	24
8-9	Troubleshooting Problems with Major Components on HBC.....	34
8-10	Troubleshooting Inverter Problems .....	40
8-11	Control Circuit .....	57
8-12	Measures for Refrigerant Leakage .....	66
8-13	Parts Replacement Instructions (Outdoor Unit).....	68
8-14	HBC Maintenance Instructions (Applicable to main and sub HBCs) .....	127
8-15	Main-HBC Maintenance Instructions .....	138
8-16	Sub-HBC Maintenance Instructions .....	177
8-17	Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit.....	182

## Chapter 9 USB Function

9-1	Service Overview.....	1
9-2	Operation Data Collection and Storage Functions (Outdoor unit) .....	4
9-3	Software Rewrite Function on the USB (Outdoor unit, HBC) .....	8
9-4	Maintenance LED Display and Troubleshooting .....	10

## Chapter 10 LED Status Indicators

10-1	LED Status Indicators (Outdoor unit) .....	1
10-2	LED Status Indicators (HBC).....	4
10-3	LED Status Indicators Table.....	6

---

## Chapter 1 Check Before Servicing

<b>1-1</b>	<b>Preparation for Piping Work</b> .....	<b>1</b>
1-1-1	Read before Servicing .....	1
1-1-2	Tool Preparation .....	2
<b>1-2</b>	<b>Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil</b> .....	<b>3</b>
1-2-1	Piping Materials .....	3
1-2-2	Storage of Piping Materials.....	4
1-2-3	Pipe Processing.....	4
1-2-4	Differences in Refrigerant Properties.....	5
1-2-5	Precautions for handling equipment using R32 .....	6
1-2-6	Refrigerant Oil.....	13
<b>1-3</b>	<b>Working with Refrigerant Piping</b> .....	<b>14</b>
1-3-1	Pipe Brazing.....	14
1-3-2	Air Tightness Test.....	15
1-3-3	Vacuum Drying .....	16
1-3-4	Refrigerant Charging.....	18
<b>1-4</b>	<b>Precautions for Wiring</b> .....	<b>19</b>
<b>1-5</b>	<b>Cautionary notes on installation environment and maintenance</b> .....	<b>21</b>



# 1-1 Preparation for Piping Work

## 1-1-1 Read before Servicing

### 1. Check the type of refrigerant used in the system to be serviced.

#### Refrigerant Type

Multi air conditioner for building application CITY MULTI:R32

### 2. Check the symptoms exhibited by the unit to be serviced.

Refer to this service handbook for symptoms relating to the refrigerant cycle.

### 3. Thoroughly read the safety precautions at the beginning of this manual.

### 4. Preparing necessary tools: Prepare a set of tools to be used exclusively with each type of refrigerant.

For information about the correct use of tools, refer to the following page(s). [1-1-2 Tool Preparation]

### 5. Verification of the connecting pipes: Verify the type of refrigerant used for the unit to be moved or replaced.

- Use refrigerant pipes made of phosphorus deoxidized copper. Keep the inner and outer surfaces of the pipes clean and free of such contaminants as sulfur, oxides, dust, dirt, shaving particles, oil, and water.
- These types of contaminants inside the refrigerant pipes may cause the refrigerant oil to deteriorate.

### 6. Toxic hydrofluoric acid gas will form or refrigerant will ignite if leaked refrigerant is exposed to an open flame. Be sure to keep the work area well ventilated.

#### CAUTION

- Install new pipes immediately after removing old ones to keep moisture out of the refrigerant circuit.
- The use of refrigerant that contains chloride, such as R22, will cause the refrigerating machine oil to deteriorate.

## 1-1-2 Tool Preparation

Prepare the following tools and materials necessary for installing and servicing the unit.

**Tools for use with R32 (Adaptability of tools that are for use with R410A, R22, or R407C)**

### 1. To be used exclusively with R32 (not to be used if used with R410A, R22, or R407C)

Tools/Materials	Use	Notes
Gauge Manifold	Evacuation and refrigerant charging	Higher than 5.09MPa[738psi] on the high-pressure side
Charging Hose	Evacuation and refrigerant charging	The hose diameter is larger than the conventional model.
Refrigerant Recovery Cylinder	Refrigerant recovery	
Refrigerant Cylinder	Refrigerant charging	The refrigerant type is indicated. The cylinder is light blue.
Charging Port on the Refrigerant Cylinder	Refrigerant charging	The charge port diameter is larger than that of the current port.

### 2. Tools and materials that may be used with R32 with some restrictions

Tools/Materials	Use	Notes
Gas Leak Detector	Gas leak detection	The ones for use with HFC refrigerant may be used.
Vacuum Pump	Vacuum drying	May be used if a check valve adapter is attached.
Refrigerant Recovery Equipment	Refrigerant recovery	May be used if compatible with R32.

### 3. Tools and materials that are used with R22, R407C, or R410A that may also be used with R32

Tools/Materials	Use	Notes
Vacuum Pump with a Check Valve	Vacuum drying	
Bender	Bending pipes	
Torque Wrench	Tightening flare nuts	Only the flare processing dimensions for pipes that have a diameter of $\varnothing 12.7$ (1/2") and $\varnothing 15.88$ (5/8") have been changed.
Pipe Cutter	Cutting pipes	
Welder and Nitrogen Cylinder	Welding pipes	
Refrigerant Charging Meter	Refrigerant charging	
Vacuum Gauge	Vacuum level check	

### 4. Tools and materials that must not be used with R32

Tools/Materials	Use	Notes
Charging Cylinder	Refrigerant charging	Prohibited to use
Tools containing abrasive materials	Pipe cutting, cut edge treatment	Prohibited to use

Tools for R32 must be handled with special care to keep moisture and dust from infiltrating the cycle.

# 1-2 Handling and Characteristics of Piping Materials, Refrigerant, and Refrigerant Oil

## 1-2-1 Piping Materials

**Do not use the existing piping!**

### 1. Copper pipe materials

O-material (Annealed)	Soft copper pipes (annealed copper pipes). They can easily be bent with hands.
1/2H-material (Drawn)	Hard copper pipes (straight pipes). They are stronger than the O-material (Annealed) at the same radial thickness.

- The distinction between O-materials (Annealed) and 1/2H-materials (Drawn) is made based on the strength of the pipes themselves.
- O-materials (Annealed) can easily be bent with hands.
- 1/2H-materials (Drawn) are considerably stronger than O-material (Annealed) at the same thickness.

### 2. Types of copper pipes

Maximum working pressure	Refrigerant type
3.45 MPa [500psi]	R22, R407C etc.
4.30 MPa [624psi]	R410A, R32 etc.

### 3. Piping materials/Radial thickness

Use refrigerant pipes made of phosphorus deoxidized copper.  
 The operation pressure of the units that use R32 is higher than that of the units that use R22.  
 Use pipes that have at least the radial thickness specified in the chart below.  
 (Pipes with a radial thickness of 0.7 mm or less may not be used.)

Pipe size (mm[in])	Radial thickness (mm)	Type
ø6.35 [1/4"]	0.8t	O-material (Annealed)
ø9.52 [3/8"]	0.8t	
ø12.7 [1/2"]	0.8t	
ø15.88 [5/8"]	1.0t	
ø19.05 [3/4"]	1.0t	1/2H-material, H-material (Drawn)
ø22.2 [7/8"]	1.0t	
ø25.4 [1"]	1.0t	
ø28.58 [1-1/8"]	1.0t	
ø31.75 [1-1/4"]	1.1t	
ø34.93 [1-3/8"]	1.2t	
ø41.28 [1-5/8"]	1.4t	

- Annealed pipes have been used for older model units when a diameter of the pipe is up to ø19.05 (3/4"). For a system that uses R410A or R32, use pipes that are made with 1/2H-material (Drawn). (Annealed pipes may be used for pipes with a diameter of ø19.05 (3/4") and a radial thickness of 1.2 t).
- The figures in the radial thickness column are based on the Japanese standards and provided only as a reference. Use pipes that meet the local standards.

### 4. Thickness and refrigerant type indicated on the piping materials

Ask the pipe manufacturer for the symbols indicated on the piping material for new refrigerant.


## 1-2-2 Storage of Piping Materials

### 1. Storage location



Store the pipes to be used indoors. (Warehouse at site or owner's warehouse)  
If they are left outdoors, dust, dirt, or moisture may infiltrate and contaminate the pipe.

### 2. Sealing the pipe ends



Both ends of the pipes should be sealed until just before brazing.  
Keep elbow pipes and T-joints in plastic bags.

Refrigerant oil is highly hygroscopic and is likely to degrade and cause compressor failure if moisture infiltrates into the system. Storage of piping materials requires stringent management.

## 1-2-3 Pipe Processing

Use a small amount of ester oil, ether oil, or alkylbenzene to coat flares and flanges.  
Prevent the particles that are generated during pipe cutting or cut edge treatment from entering the pipes. If abrasive materials contained in sandpaper or cutting tools enter the refrigerant circuit, they may cause the compressor, valves, or other refrigerant circuit components to fail.

#### Note

- Use a minimum amount of oil.
- Use only ester oil, ether oil, and alkylbenzene.
- To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

## 1-2-4 Differences in Refrigerant Properties

### 1. Chemical property

Refrigerant R32 is as low in toxicity and slightly flammable refrigerant. However, because the specific gravity of vapor refrigerant is greater than that of air, leaked refrigerant in a closed room will accumulate at the bottom of the room and may cause hypoxia. Because the refrigerant is slightly flammable, do not perform installation or service work in a confined area.

	HFC Refrigerant			HCFC Refrigerant
	R32	R410A	R407C	R22
	R32	R32/R125	R32/R125/R134a	R22
Composition (wt%)	(100)	(50/50)	(23/25/52)	(100)
Type of Refrigerant	Single Refrigerant	Pseudo-azeotropic Refrigerant	Non-azeotropic Refrigerant	Single Refrigerant
Chloride	Not included	Not included	Not included	Included
Safety Class	A2L	A1/A1	A1/A1	A1
Molecular Weight	52.0	72.6	86.2	86.5
Boiling Point (°C/°F)	-51.7/-61.0	-51.4/-60.5	-43.6/-46.4	-40.8/-41.4
Steam Pressure (25°C,MPa/77°F,psi) (gauge)	1.588/230	1.557/226	0.9177/133	0.94/136
Saturated Steam Density (25°C,kg/m <sup>3</sup> /77°F,psi)	47.4	64.0	42.5	44.4
Flammability	Slightly flammable	Nonflammable	Nonflammable	Nonflammable
Ozone Depletion Coefficient (ODP) <sup>*1</sup>	0	0	0	0.055
Global Warming Coefficient (GWP) <sup>*2</sup>	675	2088	1774	1810
Refrigerant Charging Method	Refrigerant charging in the liquid state/refrigerant charging in the gaseous state	Refrigerant charging in the liquid state	Refrigerant charging in the liquid state	Refrigerant charging in the gaseous state
Replenishment of Refrigerant after a Refrigerant Leak	Available	Available	Available	Available

\*1 When CFC11 is used as a reference

\*2 When CO<sub>2</sub> is used as a reference

### 2. Refrigerant composition

R32 is a single refrigerant and can be handled in a similar manner as with other single refrigerants, such as R22. If the refrigerant leaks out, it may be replenished.

### 3. Pressure characteristics

The pressure in the system using R32 is 1.6 times as great as that in the system using R22.

Temperature (°C/°F)	Pressure (gauge)			
	R32	R410A	R407C	R22
	MPa/psi	MPa/psi	MPa/psi	MPa/psi
-20/-4	0.30/44	0.30/44	0.18/26	0.14/20
0/32	0.71/103	0.70/102	0.47/68	0.40/58
20/68	1.37/199	1.34/194	0.94/136	0.81/117
40/104	2.38/345	2.31/335	1.44/209	1.44/209
60/140	3.83/555	3.73/541	2.44/354	2.33/338
65/149	4.28/621	4.17/605	2.75/399	2.60/377



## 1-2-5 Precautions for handling equipment using R32

When handling the units that use R32 refrigerant, observe the following notes. (The notes are based on the precautions regarding R32 refrigerant contained in IEC 60335-2-40.)

### 1. Transportation

- 1) Additional transportation regulations may exist with respect to equipment containing slightly flammable gas. The maximum number of pieces of equipment or the configuration of the equipment, permitted to be transported together will be determined by the applicable transport regulations.

### 2. Disposal

- 1) Follow the local regulations on proper disposal of equipment using R32.

### 3. Storage

- 1) Store the unit in a sufficiently large space so that leaked refrigerant will not stagnate in a small confined area.
- 2) The maximum number of pieces of equipment permitted to be stored together will be determined local regulations.

### 4. Servicing information

- 1) Checks to the area  
Prior to beginning work on systems containing slightly flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised. For repair to the refrigerating system, 3) to 7) shall be completed prior to conducting work on the system.
- 2) Work procedure  
Work shall be undertaken under a controlled procedure so as to minimise the risk of a slightly flammable gas being present while the work is being performed.
- 3) General work area  
All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.
- 4) Checking for presence of refrigerant  
The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially slightly flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants.
- 5) Presence of fire extinguisher  
If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO<sub>2</sub> fire extinguisher adjacent to the charging area.
- 6) No ignition sources  
No person carrying out work, such as brazing, in relation to a refrigeration system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed in a conspicuous place in the work area.

7) Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before replacing parts or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

8) Checks to the refrigeration equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the MITSUBISHI ELECTRIC's Installation Manual and Service Handbook shall be followed. If in doubt, consult the dealer's technical department for assistance.

The following checks shall be applied to installations using slightly flammable refrigerants:

- the amount of refrigerant charge depends on the size of the area in which products containing refrigerant are to be installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected being so corroded.

9) Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

10) Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

## 5. Repairing sealed components

- 1) During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- 2) Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- 3) Ensure that the apparatus is mounted securely.
- 4) Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the MITSUBISHI ELECTRIC's specifications.
- 5) The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

## 6. Refrigerant leakage detection

The following leak detection methods are deemed acceptable for all refrigerant systems.

- 1) Electronic leak detectors may be used to detect refrigerant leaks but, in the case of slightly flammable refrigerants, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- 2) If a leak is suspected, all naked flames shall be removed/extinguished.
- 3) If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Because R32 is slightly flammable, oxygen free nitrogen (OFN) shall be poured through the system both before and during the brazing process to purge R32.

## 7. Refrigerant removal and vacuum drying for service

- 1) R32 is slightly flammable. Follow the procedures below to reduce the risk of R32 from catching fire:
  1. Remove refrigerant;
  2. Purge the circuit with inert gas;
  3. Evacuate;
  4. Purge again with inert gas;
  5. Open the circuit by cutting or brazing.
- 2) The charged refrigerant shall be recovered into the recovery cylinders designated for use with R32. For appliances containing slightly flammable refrigerants, the system shall be "flushed" with OFN to render the unit safe. This process may need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.
- 3) Because R32 is slightly flammable, flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place.
- 4) Ensure that the outlet for the vacuum pump is not close to any ignition sources and that ventilation is available.

## 8. Decommissioning

- 1) Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.
- 2) Become familiar with the equipment and its operation.
- 3) Isolate system electrically.
- 4) Before attempting the procedure, ensure that:
  - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
  - all personal protective equipment is available and being used correctly;
  - the recovery process is supervised at all times by a competent person;
  - recovery equipment and cylinders conform to the appropriate standards.
- 5) Pump down refrigerant system, if possible.
- 6) Make sure that cylinder is situated on the scales before recovery takes place.
- 7) Start the recovery machine and operate in accordance with MITSUBISHI ELECTRIC's instructions.
- 8) Do not overfill cylinders. (No more than 80% volume liquid charge)
- 9) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- 10) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- 11) Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

## 9. Labelling

- 1) Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Because R32 is slightly flammable, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

## 10. Appropriate refrigerant recovery method

- 1) When removing refrigerant from a system, either for repairing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- 2) When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available. All cylinders to be used are designated for recovering refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery starts.
- 3) The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, slightly flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult dealer if in doubt.
- 4) The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants with different properties in recovery units and especially not in cylinders.
- 5) If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that slightly flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

## 11. Competence of service personnel

### (1) General

Special training additional to usual refrigerating equipment repair procedures is required when equipment with slightly flammable refrigerants is affected.

### (2) Training

The training should include the substance of the following:

Information about the explosion potential of slightly flammable refrigerants to show that flammables may be dangerous when handled without care.

### (3) Information about the correct working procedures

#### Commissioning

- 1) Ensure that the floor area is sufficient for the refrigerant charge or that the ventilation duct is assembled in a correct manner.
- 2) Connect the pipes and carry out a leak test before charging with refrigerant.
- 3) Check safety equipment before putting into service.

#### Maintenance

- 1) Portable equipment shall be repaired outside or in a workshop specially equipped for servicing units with slightly flammable refrigerants.
- 2) Ensure sufficient ventilation at the repair place.
- 3) Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 4) Discharge capacitors in a way that won't cause any spark. The standard procedure to short circuit the capacitor terminals usually creates sparks.
- 5) Reassemble sealed enclosures accurately. If seals are worn, replace them.
- 6) Check safety equipment before putting into operation.
- 7) Carry a portable refrigerant-leak sensor when entering a space with a risk of refrigerant leakage.

Repair

- 1) Portable equipment shall be repaired outside or in a workshop specially equipped for servicing units with slightly flammable refrigerants.
- 2) Ensure sufficient ventilation at the repair place.
- 3) Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 4) Discharge capacitors in a way that won't cause any spark.
- 5) When brazing is required, the following procedures shall be carried out in the right order:
  1. Remove the refrigerant. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
  2. Evacuate the refrigerant circuit.
  3. Purge the refrigerant circuit with nitrogen for 5 min.
  4. Evacuate again.
  5. Remove parts to be replaced by cutting, not by flame.
  6. Purge the braze point with nitrogen during the brazing procedure.
  7. Carry out a leak test before charging with refrigerant.
- 6) Reassemble sealed enclosures accurately. If seals are worn, replace them.
- 7) Check safety equipment before putting into operation.

Decommissioning

- 1) If the safety is affected when the equipment is putted out of service, the charged refrigerant shall be removed before decommissioning.
- 2) Ensure sufficient ventilation at the equipment location.
- 3) Be aware that malfunction of the equipment may be caused by refrigerant loss and a refrigerant leak is possible.
- 4) Discharge capacitors in a way that won't cause any spark.
- 5) Remove the refrigerant. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
- 6) Evacuate the refrigerant circuit.
- 7) Purge the refrigerant circuit with nitrogen for 5 min.
- 8) Evacuate again.
- 9) Fill with nitrogen up to atmospheric pressure.
- 10) Put a label on the equipment that the refrigerant is removed.

Disposal


- 1) Ensure sufficient ventilation at the working place.
- 2) Remove the refrigerant. If the recovery is not required by national regulations, drain the refrigerant to the outside. Take care that the drained refrigerant will not cause any danger. In doubt, one person should guard the outlet. Take special care that drained refrigerant will not float back into the building.
- 3) Evacuate the refrigerant circuit.
- 4) Purge the refrigerant circuit with nitrogen for 5 min.
- 5) Evacuate again.
- 6) Cut out the compressor and drain the oil.

## 12. Installation restrictions for outdoor units

### Do not install the unit where combustible gas may leak.

- If combustible gas accumulates around the unit, fire or explosion may result.

- Provide sufficient space around the unit for effective operation, efficient air movement, and ease of access for maintenance.
- Note that refrigerant gas is heavier than air and will therefore tend to collect in low spots such as basements.
- When an indoor unit that draws in outside air exits near the outdoor unit, be careful not to affect the normal operation of the indoor unit.
- When the amount of drain water is excessive, drain water comes out of the outdoor unit along the panel during heating operation. Provide sufficient space around the unit.
- R32 is heavier than air—as well as other refrigerants—so tends to accumulate at the base (in the vicinity of the floor). If R32 accumulates around the base, it may reach a flammable concentration in case the room is small. To avoid ignition, maintain a safe work environment by ensuring appropriate ventilation. If the refrigerant leaks in a room or an area that has insufficient ventilation, refrain from using flames until the work environment is improved by ensuring appropriate ventilation.
- Do not install the outdoor unit in a basement or machinery room, where the refrigerant stagnates.
- Install the outdoor unit in a place where at least one of the four sides is open.




- If the unit needs to be installed in a space where all four sides are blocked, confirm that one of these situations (A, B, or C) is satisfied.


A: Secure sufficient installation space (minimum installation area:  $A_{min}$ ).

Install the unit in a space with an installation area of  $A_{min}$  or more, corresponding to the refrigerant amount (M). (M = factory-charged refrigerant + refrigerant to be added on site)

M (kg)	$A_{min}$ (m <sup>2</sup> )
10	112
20	223
30	334
40	445
50	556
60	667




B: Install the unit in a space with a wall height of  $\leq 0.125$  m.



C: Create an appropriate ventilation open area.

Good




Opening:

- Must occupy 80% of the longitudinal side of a space.
- Must have an opening ratio of 75% or higher.

(Example: space with a louver)

NG



(Example: basement)

### 13. Installation restrictions for HBC

Observe the following restrictions that apply to the installation of HBC.


[Restrictions for HBC installation]

#### **! WARNING**

- Do not place an ignition source in a space where a HBC is installed or adjacent spaces not shielded by firewalls.  
Examples: Lighters, combustion heaters, combustion boilers, and combustion cookers
- Figure 2 shows the minimum floor areas required for given amounts of refrigerant in various refrigerant systems. Make sure the installation conditions meet the requirements shown in the figure. Take appropriate safety measures in accordance with the instructions provided in Figure 2.
- All of the above-mentioned restrictions apply not only to new installations but also to relocations and layout changes.

Figure 2

In addition to what is listed below, floor-standing units will require an agitator.



## 1-2-6 Refrigerant Oil

### 1. Refrigerating machine oil in the HFC refrigerant system

HFC type refrigerants use a refrigerating machine oil different from that used in the R22 system. Note that the ester oil used in the system has properties that are different from commercially available ester oil. Different types of oil are used for R407C/R410A and for R32. When charging the units with refrigerant oil, be sure to use the tools for designated use with refrigerant oil for R32.

Refrigerant	Refrigerating machine oil
R22	Mineral oil
R407C	Ester oil
R410A	Ester oil
R32	Ester oil

### 2. Effects of contaminants\*1

Refrigerating machine oil used in the HFC system must be handled with special care to keep contaminants out. The table below shows the effect of contaminants in the refrigerating machine oil on the refrigeration cycle.

### 3. The effects of contaminants in the refrigerating machine oil on the refrigeration cycle.

Cause		Symptoms	Effects on the refrigerant cycle
Water infiltration		Frozen expansion valve and capillary tubes	Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat Motor insulation failure Burnt motor Coppering of the orbiting parts Burn-in on the orbiting parts
		Hydrolysis	
Air infiltration		Oxidization	
Infiltration of contaminants	Dust, dirt	Adhesion to expansion valve and capillary tubes	Clogged expansion valve, capillary tubes, and drier Poor cooling performance Compressor overheat
		Infiltration of contaminants into the compressor	Burn-in on the orbiting parts
	Mineral oil etc.	Sludge formation and adhesion	Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat
		Oil degradation	Burn-in on the orbiting parts

\*1. Contaminants is defined as moisture, air, processing oil, dust/dirt, wrong types of refrigerant, and refrigerating machine oil.




## 1-3 Working with Refrigerant Piping

### 1-3-1 Pipe Brazing


Perform brazing with special care to keep foreign objects (such as oxide scale, copper powder, water, and dust) out of the refrigerant system.

Example: Inside the brazed connection

Use of no inert gas during brazing



Use of inert gas during brazing



#### 1. Items to be strictly observed

- Do not conduct refrigerant piping work outdoors if raining.
- Use inert gas during brazing.
- Use a brazing material (BCuP-3) that requires no flux when brazing between copper pipes or between a copper pipe and copper coupling.
- If installed refrigerant pipes are not immediately connected to the equipment, then braze and seal both ends.

#### 2. Reasons


- Refrigerant oil is highly hygroscopic and is likely to cause unit failure if moisture infiltrates into the system.
- Residual flux in the refrigerant circuit will cause sludge to form.

#### 3. Notes


Do not use commercially available antioxidants because they may cause the pipes to corrode or refrigerating machine oil to deteriorate.

## 1-3-2 Air Tightness Test

No changes have been made in the detection method. Note that a refrigerant leak detector for R22 will not detect an R32 leak.



Halide torch



R22 leakage detector

### 1. Items to be strictly observed

- Pressurize the equipment with nitrogen up to the design pressure (4.15MPa[601psi]), and then judge the equipment's air tightness, taking temperature variations into account.

### 2. Reasons

- Oxygen, if used for an air tightness test, poses a risk of explosion. (Only use nitrogen to check air tightness.)

### 3. Notes

Procure a leak detector that is specifically designed to detect an HFC leak. A leak detector for R22 will not detect an HFC(R32) leak.

### 1-3-3 Vacuum Drying



(Photo1) 15010H



(Photo2) 14010

Recommended vacuum gauge:  
ROBINAIR 14010 Thermistor Vacuum Gauge

#### 1. Vacuum pump with a reverse-flow check valve (Photo1)

To prevent the vacuum pump oil from flowing into the refrigerant circuit during power OFF or power failure, use a vacuum pump with a reverse-flow check valve. A reverse-flow check valve may also be added to the vacuum pump currently in use.

#### 2. Standard of vacuum degree (Photo 2)

Use a vacuum pump that attains 0.5Torr(65Pa) or lower degree of vacuum after 5 minutes of operation, and connect it directly to the vacuum gauge. Use a pump well-maintained with an appropriate lubricant. A poorly maintained vacuum pump may not be able to attain the desired degree of vacuum.

#### 3. Required precision of vacuum gauge

Use a vacuum gauge that registers a vacuum degree of 5Torr(650Pa) and measures at intervals of 1Torr(130Pa). (A recommended vacuum gauge is shown in Photo2.) Do not use a commonly used gauge manifold because it cannot register a vacuum degree of 5Torr(650Pa).

#### 4. Evacuation time

•After the degree of vacuum has reached 5Torr(650Pa), evacuate for an additional 1 hour. (A thorough vacuum drying removes moisture in the pipes.) When the outside temperature drops below 1°C (or when the saturation pressure drops below 656 Pa), continue vacuum drying for another 1 hour after the vacuum degree has reached the saturated vapor pressure of the water (ice) at the outside temperature. When performing vacuum drying at a low outside temperature, use a vacuum gauge appropriate for the temperature range.

Degree of vacuum (reference)

Outdoor temp.	-20°C (-4°F)	-15°C (5°F)	-10°C (14°F)	-5°C (23°F)	0°C (32°F)
Degree of vacuum	0.77 Torr (103 Pa)	1.24 Torr (165 Pa)	1.95 Torr (260 Pa)	3.01 Torr (402 Pa)	4.58 Torr (611 Pa)

\* Degrees of vacuum shown above are obtained based on the saturated vapor pressure of ice.

\* In a system using water heat exchangers, circulate water to prevent the water in the heat exchangers from freezing during vacuum drying.

•Verify that the vacuum degree has not risen by more than 1Torr(130Pa) 1hour after evacuation. A rise by less than 1Torr(130Pa) is acceptable.

•If the vacuum is lost by more than 1Torr(130Pa), conduct evacuation, following the instructions in section 6. Special vacuum drying.

#### 5. Procedures for stopping vacuum pump

To prevent the reverse flow of vacuum pump oil, open the relief valve on the vacuum pump side, or draw in air by loosening the charge hose, and then stop the operation.

The same procedures should be followed when stopping a vacuum pump with a reverse-flow check valve.

## 6. Special vacuum drying

- When 5Torr(650Pa) or lower degree of vacuum cannot be attained after 3 hours of evacuation, it is likely that water has penetrated the system or that there is a leak.
- If water infiltrates the system, break the vacuum with nitrogen. Pressurize the system with nitrogen gas to 0.5kgf/cm<sup>2</sup>G(0.05MPa) and evacuate again. Repeat this cycle of pressurizing and evacuation either until the degree of vacuum below 5Torr(650Pa) is attained or until the pressure stops rising.
- Only use nitrogen gas for vacuum breaking. (The use of oxygen may result in an explosion.)

## 7. Notes

- To evacuate air from the entire system

Applying a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) is not enough to attain the desired vacuum pressure.

Be sure to apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2) and also through the check joints on the high and low pressure sides (CJ1 and 2).

- To evacuate air only from the outdoor units

Apply a vacuum through the check joints on the high and low pressure sides (CJ1, and 2).

- To evacuate air from the HBC and extension pipes


Apply a vacuum through the check joints at the refrigerant service valve on the high and low pressure sides (BV1 and 2).

- When performing the maintenance work, such as vacuum drying, pumping down, or refrigerant recovery, on the outdoor unit or the heat-source unit, set SW001-1 first and then SW002-5 on the HBC board to ON to operate the water circuit pump and circulate the water to prevent the water side of the heat exchanger within the HBC from freezing.

\* When vacuum drying, pumping down or refrigerant recovery has been completed, set SW002-5 first and then SW001-1 to OFF.


### 1-3-4 Refrigerant Charging

Cylinder with a siphon





Cylinder color R32 is light blue.

Cylinder without a siphon



Refrigerant charging in the liquid state



#### 1. Reasons

R32 is a single refrigerant with a boiling point of -52°C (-62°F) and can be handled in a similar manner as with other single refrigerants, such as R22.

#### 2. Notes

When using a cylinder with a siphon, refrigerant is charged in the liquid state without the need for turning it upside down. Check the type of the cylinder on the label before use.

If the refrigerant leaks out, it may be replenished. The entire refrigerant does not need to be replaced. (Charge refrigerant in the liquid state.)

Refer to the following page(s).[8-12 Measures for Refrigerant Leakage]

# 1-4 Precautions for Wiring

- Control boxes house high-voltage and high-temperature electrical parts.
- They may still remain energized or hot after the power is turned off.
- When opening or closing the front cover of the control box, keep out of contact with the internal parts.  
 Before inspecting the inside of the control box, turn off the power, leave the unit turned off for at least 10 minutes, and check that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less.  
 It will take approximately 10 minutes until the voltage is discharged after power off.
- Disconnect the relay connector (RYFAN 1, RYFAN 2) on the outdoor unit fan before performing maintenance work.  
 Before connecting or disconnecting the connector, check that the outdoor unit fan is stopped and that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less.  
 If the outdoor unit fan is rotated by external forces such as strong winds, the main circuit capacitor can be charged and cause an electric shock.  
 Refer to the wiring nameplate for details.  
 Reconnect the relay connector (RYFAN 1, RYFAN 2) after completion of maintenance work.
- Before turning on the power, make sure the power-supply wire is properly connected. Also, perform a voltage check at the power-supply terminal block. (Refer to item (6) in section [6-1 Read before Test Run])
- When the power is on, the compressor is energized even while the compressor is stopped.  
 It is energized to evaporate the liquid refrigerant that has accumulated in the compressor.
- Before connecting wiring to TB7, check that the voltage has dropped below 20 VDC.
- When a system controller is connected to the centralized control transmission cable to which power is supplied from the outdoor unit (power jumper on the outdoor unit is connected to CN40), be aware that power can be supplied to the centralized control transmission and the system controller may detect an error and send an error notice if the outdoor unit fan is rotated by external forces, such as strong winds, even when power to the outdoor unit is turned off.
- Do not keep turning on and off the power in a short period.
- Turn on the power after the power-supply voltage and frequency have stabilized.
- Distortion in the power supply voltage waveform can cause a malfunction.
- When replacing the internal electrical components of the control box, tighten the screws to the recommended tightening torque as specified below.

Recommended tightening torque for the internal electrical components of the control box

Screw	Recommended tightening torque (N·m)
M3	0.69
M4	1.47
M5	2.55
M6	2.75
M8	6.20


\*1 When replacing semiconductor modules (e.g., INV board, fan board), apply heatsink silicone evenly to the semiconductor module on the back of the circuit board. Next, tighten the screws holding the semiconductor module to one-third of the specified torque, and then tighten the screws to the specified torque.

\*2 Deviating from the recommended tightening torque may cause damage to the unit or its parts.

Take the following steps to ensure that the screws are properly tightened.

- 1) Ensure that the spring washers are parallel to the terminal block.

Even if the tightening torque is observed, if the washers are not parallel to the terminal block, then the semiconductor module is not installed properly.




2) Check the wires are securely fastened to the screw terminals.

• **Screw the screws straight down so as not to damage the screw threads.**

Hold the two round terminals back to back to ensure that the screw will screw down straight.

• **After tightening the screw, mark a line through the screw head, washer, and terminals with a permanent marker.**

Example



Poor contact caused by loose screws may result in overheating and fire.  
Continued use of the damaged circuit board may cause overheating and fire.

---

## 1-5 Cautionary notes on installation environment and maintenance

---

**Salt-resistant unit is resistant to salt corrosion, but not salt-proof. Please note the following when installing and maintaining outdoor units in marine atmosphere.**

- 1) Install the salt-resistant unit out of direct exposure to sea breeze, and minimize the exposure to salt water mist.
- 2) Avoid installing a sun shade over the outdoor unit, so that rain will wash away salt deposits off the unit.
- 3) Install the unit horizontally to ensure proper water drainage from the base of the unit. Accumulation of water in the base of the outdoor unit will significantly accelerate corrosion.
- 4) Periodically wash salt deposits off the unit, especially when the unit is installed in a coastal area.
- 5) Repair all noticeable scratches after installation and during maintenance.
- 6) Periodically check the unit, and apply anti-rust agent and replace corroded parts as necessary.





---

## Chapter 2 Restrictions

<b>2-1</b>	<b>System Configurations</b> .....	<b>1</b>
<b>2-2</b>	<b>Types and Maximum Allowable Length of Cables</b> .....	<b>2</b>
<b>2-3</b>	<b>Switch Settings</b> .....	<b>3</b>
<b>2-4</b>	<b>M-NET Address Settings</b> .....	<b>4</b>
2-4-1	Address Settings List .....	4
2-4-2	Outdoor Unit Power Jumper Connector Connection.....	5
2-4-3	Outdoor Unit Centralized Controller Switch Setting .....	5
2-4-4	Room Temperature Detection Position Selection .....	6
2-4-5	Start/Stop Control of Indoor Units .....	6
2-4-6	Miscellaneous Settings .....	6
2-4-7	Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit .....	7
<b>2-5</b>	<b>Demand Control Overview</b> .....	<b>9</b>
<b>2-6</b>	<b>System Connection Example</b> .....	<b>10</b>
<b>2-7</b>	<b>Example System with an MA Remote Controller</b> .....	<b>11</b>
2-7-1	Single Refrigerant System (Automatic Indoor/Outdoor Address Startup).....	11
2-7-2	Single Refrigerant System .....	13
2-7-3	Grouped Operation of Units in Separate Refrigerant Circuits.....	15
2-7-4	System with a Connection of System Controller to Centralized Control Transmission Line.....	17
2-7-5	System with a Connection of System Controller to Indoor-Outdoor Transmission Line .....	19
2-7-6	System with Multiple HBCs.....	21
<b>2-8</b>	<b>Example System with an ME Remote Controller</b> .....	<b>24</b>
2-8-1	System with a Connection of System Controller to Centralized Control Transmission Line.....	24
<b>2-9</b>	<b>Example System with an MA and an ME Remote Controller</b> .....	<b>26</b>
2-9-1	System with a Connection of System Controller to Centralized Control Transmission Line.....	26
<b>2-10</b>	<b>Restrictions on Refrigerant Pipes</b> .....	<b>29</b>
2-10-1	Restrictions on Refrigerant Pipe Length .....	29
2-10-2	Restrictions on Refrigerant Pipe and Water Pipe Size .....	30
2-10-3	HBC Connection Method .....	31



# 2-1 System Configurations

## 1. Table of compatible indoor units

The table below summarizes the types of indoor units that are compatible with different types of outdoor units.

### (1) Standard combinations

Outdoor units	HBC	Number of connectable HBC	Sub-HBC	Maximum number of connectable Sub-HBC	Maximum total capacity of connectable indoor units	Maximum number of connectable indoor units	Types of connectable indoor units
M200YNW-A1	CMB- WM350F-AA	1	CMB- WM108V-BB CMB- WM1016V-BB	3	100 - 300	30	W/WP/WL10 - W/WP/WL125 models R32 series indoor units
M250YNW-A1					125 - 375	37	
M300YNW-A1					150 - 450	45	
M350YNW-A1					175 - 525	50	
M400YNW-A1	CMB- WM500F-AA	1	200 - 600	50			
M450YNW-A1			225 - 675	50			
M500YNW-A1			250 - 750	50			

**Note**

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given outdoor unit exceeds the capacity of the outdoor unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the outdoor unit whenever possible.
- 3) Only either P\*\*Y-W model indoor units (equipped with a flow control valve) or P\*\*Y-WP/WL model indoor units (without a flow control valve) can be connected to the HBC. (Combining different models of indoor units will cause a connection error.)
- 4) The following models of indoor units can be used as indoor units equipped with a flow control valve when used with the optional valve kit (PAC-SK04VK-E).

<Applicable indoor units>

P\*\*Y-WL\*\*

\* The optional valve kit (PAC-SK04VK-E) cannot be installed on P\*\*Y-WP\*\* models.

### (2) High COP combinations

Outdoor units	HBC	Number of connectable HBC	Sub-HBC	Maximum number of connectable Sub-HBC	Maximum total capacity of connectable indoor units	Maximum number of connectable indoor units	Types of connectable indoor units
EM200YNW-A1	CMB- WM350F-AA	1	CMB- WM108V-BB CMB- WM1016V-BB	3	100 - 300	30	W/WP/WL10 - W/WP/WL125 models R32 series indoor units
EM250YNW-A1					125 - 375	37	
EM300YNW-A1					150 - 450	45	
EM350YNW-A1					175 - 525	50	
EM400YNW-A1	CMB- WM500F-AA	1	200 - 600	50			
EM450YNW-A1			225 - 675	50			
EM500YNW-A1			250 - 750	50			

**Note**

- 1) "Maximum total capacity of connectable indoor units" refers to the sum of the numeric values in the indoor unit model names.
- 2) If the total capacity of the indoor units that are connected to a given outdoor unit exceeds the capacity of the outdoor unit, the indoor units will not be able to perform at the rated capacity when they are operated simultaneously. Select a combination of units so that the total capacity of the connected indoor units is at or below the capacity of the outdoor unit whenever possible.
- 3) Only either P\*\*Y-W model indoor units (equipped with a flow control valve) or P\*\*Y-WP/WL model indoor units (without a flow control valve) can be connected to the HBC. (Combining different models of indoor units will cause a connection error.)
- 4) The following models of indoor units can be used as indoor units equipped with a flow control valve when used with the optional valve kit (PAC-SK04VK-E).

<Applicable indoor units>

P\*\*Y-WL\*\*

\* The optional valve kit (PAC-SK04VK-E) cannot be installed on P\*\*Y-WP\*\* models.


## 2-2 Types and Maximum Allowable Length of Cables

### 1. Wiring work

#### (1) Notes

- 1) Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual.
- 2) Install external transmission cables at least 5cm [1-31/32"] away from the power supply cable to avoid noise interference. (Do not put the control cable and power supply cable in the same conduit tube.)
- 3) Provide grounding for the outdoor unit as required.
- 4) Run the cable from the electric box of the indoor or outdoor unit in such way that the box is accessible for servicing.
- 5) Do not connect power supply wiring to the terminal block for transmission line. Doing so will damage the electronic components on the terminal block.
- 6) Use 2-core shielded cables as transmission cables.

Do not use a single multiple-core cable to connect indoor units that belong to different refrigerant systems. Doing so may result in signal transmission errors and malfunctions.



TB3: Terminal block for indoor-outdoor transmission line TB7: Terminal block for centralized control

- 7) When extending the transmission cable, be sure to extend the shield wire.

#### (2) Control wiring

Different types of control wiring are used for different systems. Before performing wiring work, refer to the following page(s).

[2-7 Example System with an MA Remote Controller]

[2-8 Example System with an ME Remote Controller]

[2-9 Example System with an MA and an ME Remote Controller]

##### Types and maximum allowable length of cables

Control lines are categorized into 2 types: transmission line and remote controller line.

Use the appropriate type of cables and observe the maximum allowable length specified for a given system. If a given system has a long transmission line or if a noise source is located near the unit, place the unit away from the noise source to reduce noise interference.

- 1) M-NET transmission line

Cable type	Facility type	All facility types
	Type	Shielded cable CVVS, CPEVS, MVVS
	Number of cores	2-core cable
	Cable size	Larger than 1.25mm <sup>2</sup> [AWG16]
Maximum transmission line distance between the outdoor unit and the farthest indoor unit		200 m [656ft] max. Maximum wiring length between outdoor unit and main HBC: 150 m [492 ft]
Maximum transmission line distance for centralized control and Indoor/outdoor transmission line (Maximum line distance via outdoor unit)		1000 m [3280ft] (500 m [1640ft]) max. *1 *The maximum overall line length from the power supply unit on the transmission lines for centralized control to each outdoor unit or to the system controller is 200m [656ft] max. *1 If a given system includes one or more unit or remote controller that does not support the maximum allowable cable distance of 1000 m [3280 ft], the maximum allowable cable distance in the system will be 500 m [1640 ft]. Refer to the latest catalog for information on which units and remote controllers support the maximum allowable cable distance of 1000 m [3280 ft].

2) Remote controller wiring

		MA remote controller* <sup>1</sup>	ME remote controller* <sup>2</sup>
Cable type	Type	VCTF, VCTFK, CVV, CVS, VVR, VVF, VCT	Shielded cables CVVS, CPEVS, and MVVS
	Number of cores	2-core cable	2-core cable
	Cable size	0.3 to 1.25mm <sup>2</sup> * <sup>3</sup> * <sup>5</sup> [AWG22 to 16]	0.3 to 1.25mm <sup>2</sup> * <sup>3</sup> [AWG22 to 16] (0.75 to 1.25mm <sup>2</sup> ) * <sup>4</sup> [AWG18 to 16]
Maximum overall line length		200 m [656ft] max.	The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-outdoor transmission line distance.

- \*1 MA remote controller refers to MA remote controller (PAR-31/32/33MAA, PAR-21MAA), MA simple remote controller, and wireless remote controller.
- \*2 ME remote controller refers to ME remote controller, Compact ME remote controller, and LOSSNAY remote controller.
- \*3 The use of cables that are smaller than 0.75mm<sup>2</sup> (AWG18) is recommended for easy handling.
- \*4 When connected to the terminal block on the Simple remote controller, use cables that meet the cable size specifications shown in the parenthesis.
- \*5 When connecting PAR-31MAA or MA Simple remote controller, use sheathed cables with a minimum thickness of 0.3 mm<sup>2</sup>.

## 2-3 Switch Settings

### 1. Switch setting

The necessary switch settings depend on system configuration. Before performing wiring work, refer to the following page(s).  
 [2-7 Example System with an MA Remote Controller]  
 [2-8 Example System with an ME Remote Controller]  
 [2-9 Example System with an MA and an ME Remote Controller]  
 If the switch settings are changed while the unit is being powered, those changes will not take effect, and the unit will not function properly.

Units on which to set the switches		Symbol	Units to which the power must be shut off
CITY MULTI indoor unit	Main/sub unit	IC	Outdoor units and Indoor units
LOSSNAY * <sup>1</sup>		LC	Outdoor units and LOSSNAY
ME remote controller	Main/sub remote controller	RC	Outdoor units
MA remote controller	Main/sub remote controller	MA	Indoor units
CITY MULTI outdoor unit		OC	Outdoor units
HBC	Main	HB	Outdoor units and HBC
	Sub1 - 3	HS1 - 3	Outdoor units* <sup>2</sup> and HBC

- \*1. Applicable when LOSSNAY units are connected to the indoor-outdoor transmission line.
- \*2. When setting the switch SW4 of the control board, set it with the outdoor unit power on. Refer to the following page(s).  
 [5-1-1 Outdoor Unit Switch Functions and Factory Settings]

## 2-4 M-NET Address Settings

### 2-4-1 Address Settings List

#### 1. M-NET Address settings

##### (1) Address settings table

The need for address settings and the range of address setting depend on the configuration of the system.

Unit or controller		Sym- bol	Address setting range	Setting method	Factory address setting
CITY MULTI indoor unit	Main/sub unit	IC	0, 01 to 50 <sup>*1*4*5</sup>	<ul style="list-style-type: none"> <li>Assign the smallest address to the main indoor unit in the group, and assign sequential address numbers to the rest of the indoor units in the same group.</li> <li>In a system with two or more HBCs, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul> </li> </ul> Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii) < (iv)" is true.	00
M-NET adapter					
M-NET control interface					
Free Plan adapter					
LOSSNAY		LC	0, 01 to 50 <sup>*1*4*5</sup>	Assign an arbitrary but unique address to each of these units after assigning an address to all indoor units.	00
ME remote controller	Main remote controller	RC	101 to 150	Add 100 to the smallest address of all the indoor units in the same group.	101
	Sub remote controller	RC	151 to 200 <sup>*3</sup>	Add 150 to the smallest address of all the indoor units in the same group.	
MA remote controller		MA	No address settings required. (The main/sub setting must be made if 2 remote controllers are connected to the system.)		Main
CITY MULTI outdoor unit		OC	0, 51 to 100 <sup>*1*2*5</sup>	Assign an address that equals the lowest address of the indoor units in the same refrigerant circuit plus 50.	00
Auxiliary outdoor unit	HBC (main)	HB	0, 51 to 100 <sup>*1*2*5</sup>	<ul style="list-style-type: none"> <li>Assign an address that equals the address of the outdoor unit in the same refrigerant system plus 1.</li> <li>If a given address overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> </ul>	00
	HBC (sub)	HS1 HS2 HS3	51 to 100 <sup>*2</sup>	<ul style="list-style-type: none"> <li>Assign an address to both the sub HBC that equals the lowest address of the indoor units that are connected to each of them plus 50.</li> <li>If a sub HBC is connected, the automatic startup function is not available.</li> </ul>	

- \*1. If a given address overlaps any of the addresses that are assigned to other units, use a different, unused address within the setting range.
- \*2. To set the outdoor unit address or the auxiliary outdoor unit address to "100," set the rotary switches to "50."
- \*3. To set the ME remote controller address to "200," set the rotary switches to "00."
- \*4. Some models of indoor units have two or three control boards.  
Assign an address to the No.1, No. 2, and No. 3 control boards so that the No. 2 control board address equals the No. 1 control board address plus 1, and that the No. 3 control board address equals the No. 1 control board address plus 2.
- \*5. No address settings are required for units in a system with a single outdoor unit (with some exceptions).  
Address setting is required if a sub HBC are connected.

Unit or controller		Sym- bol	Address setting range	Setting method	Factory address setting
System con- troller	Group remote control- ler	GR SC	201 to 250	Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	201
	System remote control- ler	SR SC		Assign an arbitrary but unique address within the range listed on the left to each unit.	
	ON/OFF remote control- ler	AN SC		Assign an address that equals the sum of the smallest group number of the group to be controlled and 200.	
	Schedule timer (com- patible with M-NET)	ST SC		Assign an arbitrary but unique address within the range listed on the left to each unit.	202
	Central controller AE-200 AG-150A GB-50ADA G(B)-50A	TR SC	0, 201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit. The address must be set to "0" to control the K-control unit.	000
	LM adapter	SC	201 to 250	Assign an arbitrary but unique address within the range listed on the left to each unit.	247

### 2-4-2 Outdoor Unit Power Jumper Connector Connection

There are limitations on the total number of units that are connectable to each refrigerant system. Refer to the DATABOOK for details.

System configuration	Connection to the system controller	Power supply unit for transmission lines	Group operation of units in a system with multiple outdoor units	Power supply switch connector connection
System with one outdoor unit	–	–	–	CN41 (Factory setting)
System with multiple outdoor units	Not connected	–	Not grouped	Disconnect the male connector from the female power supply switch connector (CN41) and connect it to the female power supply switch connector (CN40) on only one of the outdoor units.*2  *Connect the S (shielded) terminal on the terminal block (TB7) on the outdoor unit whose CN41 was replaced with CN40 to the ground terminal (↗) on the electric box.
		Not required	Grouped	
	With connection to the indoor unit system	Not required	Grouped/not grouped	
		Not required*1 (Powered from the outdoor unit)	Grouped/not grouped	
With connection to the centralized control system	Required*1	Grouped/not grouped	CN41 (Factory setting)	

\*1 The need for a power supply unit for transmission lines depends on the system configuration. Some controllers, such as GB-50ADA, have a function to supply power to the transmission lines.

\*2 The replacement of the power jumper connector from CN41 to CN40 must be performed on only one outdoor unit in the system.

### 2-4-3 Outdoor Unit Centralized Controller Switch Setting

System configuration	Centralized control switch (SW5-1) settings *1
Connection to the system controller Not connected	OFF (Factory setting)
Connection to the system controller Connected *2	ON

\*1 Set SW5-1 on all outdoor units in the same refrigerant circuit to the same setting.

\*2 When only the LM adapter is connected, leave SW5-1 to OFF (as it is).



### 2-4-4 Room Temperature Detection Position Selection

To stop the fan during heating Thermo-OFF (SW1-7 and 1-8 on the indoor units to be set to ON), use the built-in thermistor on the remote controller or an optional thermistor.

- 1) To use the built-in sensor on the remote controller, set the SW1-1 to ON.  
(Factory setting: SW1-1 set to "OFF".)
  - Some models of remote controllers are not equipped with a built-in temperature sensor. Use the built-in temperature sensor on the indoor unit instead.
  - When using the built-in sensor on the remote controller, install the remote controller where room temperature can be detected. (Note) Factory setting for SW1-1 on the indoor unit of the All-Fresh Models is ON.
- 2) When an optional temperature sensor is used, set SW1-1 to OFF, and set SW3-8 to ON.
  - When using an optional temperature sensor, install it where room temperature can be detected.

### 2-4-5 Start/Stop Control of Indoor Units

Each indoor unit (or group of indoor units) can be controlled individually by setting SW 1-9 and 1-10.

Function	Operation of the indoor unit when the operation is resumed after the unit was stopped	Setting (SW1) <sup>*4 *5</sup>	
		9	10
Power ON/OFF by the plug <sup>*1,*2,*3</sup>	Indoor unit will go into operation regardless of its operation status before power off (power failure). (In approx. 5 minutes)	OFF	ON
Automatic restoration after power failure	Indoor unit will go into operation if it was in operation when the power was turned off (or cut off due to power failure). (In approx. 5 minutes)	ON	OFF
	Indoor unit will remain stopped regardless of its operation status before power off (power failure).	OFF	OFF

- \*1. Do not shut off power to the outdoor units. Doing so will cut off the power supply to the compressors and the heater on the outdoor units and may result in compressor malfunction when operation is restored after a power failure.
- \*2. Not applicable to units with a built-in drain pump or humidifier.
- \*3. Models with a built-in drain pump cannot be turned on/off by the plug individually. All the units in the same refrigerant circuits will be turned on or off by the plug.
- \*4. Requires that the dipswitch settings for all the units in the group be made.
- \*5. To control the external input to and output from the air conditioners with the PLC software for general equipment via the AE-200, set SW1-9 and SW1-10 to ON. With these settings made, the power start-stop function becomes disabled. To use the auto recovery function after power failure while these settings are made, set SW1-5 to ON.

### 2-4-6 Miscellaneous Settings

Cooling-only setting for the indoor unit: Cooling only model (Factory setting: SW3-1 "OFF.")  
When using indoor unit as a cooling-only unit, set SW3-1 to ON.

## 2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit

### (1) Various connection options

Type	Usage	Function	Terminal to be used <sup>*1</sup>	Option
Input	Prohibiting cooling/heating operation (thermo OFF) by an external input to the outdoor unit. *It can be used as the DEMAND control device for each system.	DEMAND (level)	CN3D <sup>*2</sup>	Adapter for external input (PAC-SC36NA-E)
	Performs a low level noise operation of the outdoor unit by an external input to the outdoor unit. * It can be used as the silent operation device for each refrigerant system.	Low-noise mode (level) <sup>*3*4</sup>		
	Forces the outdoor unit to perform a fan operation by receiving signals from the snow sensor. <sup>*5</sup>	Snow sensor signal input (level)	CN3S	
	The operation mode of the unit can be changed from normal cooling operation (performance priority) to energy-saving cooling mode by an external signal input.	Energy-saving mode	CN3K	
Output	How to extract signals from the outdoor unit *It can be used as an operation status display device. *It can be used for an interlock operation with external devices.	Operation status of the compressor <sup>*5</sup>	CN51	Adapter for external output (PAC-SC37SA-E)
		Error status <sup>*6</sup>		

\*1 For details, refer to section (2) Example of wiring connection.

\*2 For details, refer to section (2) Example of wiring connection and other relevant sections in the manual. [2-5 Demand Control Overview]

\*3 Low-noise mode is valid when Dip SW6-8 on the outdoor unit is set to OFF. When DIP SW6-8 is set to ON, 4 levels of on-DEMAND are possible, using different configurations of low-noise mode input and DEMAND input settings.

\*4. By setting Dip SW6-7, the Low-noise mode can be switched between the Capacity priority mode and the Low-noise priority mode.

When SW6-7 is set to ON: The low-noise mode always remains effective.

When SW6-7 is set to OFF: The low noise mode is cancelled when certain outside temperature or pressure criteria are met, and the unit goes into normal operation (capacity priority mode).

Low-noise mode is effective.		Capacity priority mode becomes effective.	
Cooling	Heating	Cooling	Heating
TH7<30°C[86°F] and 63HS1<32kg/cm <sup>2</sup>	TH7>3°C[37°F] and 63LS>4.6kg/cm <sup>2</sup>	TH7>35°C[95°F] or 63HS1>35kg/cm <sup>2</sup>	TH7<0°C[32°F] or 63LS<3.9kg/cm <sup>2</sup>






\*5 If the formula TH7>5 holds true, the fan will not go into operation when the contact receives signal input.

\*6 When using a base heater, change the setting using SW4. When using a base heater, error output will not be available.

**(2) Example of wiring connection**

**⚠ CAUTION**

- 1) Wiring should be covered by insulation tube with supplementary insulation.
- 2) Use relays or switches with IEC or equivalent standard.
- 3) The electric strength between accessible parts and control circuit should have 2750V or more.



## 2-5 Demand Control Overview

### (1) General outline of control

Demand control is performed by using the external signal input to the 1-2 and 1-3 pins of CN3D on the outdoor unit (OC). Between 2 and 4 steps of demand control is possible by setting Dip SW6-8 on the outdoor unit (OC).

No	Demand control switch	Dip SW6-8	Input to CN3D*2
		OC	
1	2 steps (0-100%)	OFF	OC
2	4 steps (0-50-75-100%)	ON	OC

- \*1 Available demand functions  
M200 - M500YNW-A1, EM200 - EM500YNW-A1 models (single-outdoor-unit system) : 2 and 4 steps shown in the rows 1 and 2 in the table above only.
- \*2 Signal is input to CN3D on the outdoor unit whose SW6-8 is set to ON. When SW6-8 is set to OFF on all outdoor units, the signal is input to the CN3D on the OC.  
Outdoor units whose SW6-8 is set to ON are selectable in a single refrigerant system.
- \*3 If wrong sequence of steps are taken, the units may go into the Thermo-OFF (compressor stop) mode.  
Ex) When switching from 100% to 50%  
(Incorrect) 100%→0%→50% The units may go into the Thermo-OFF mode.  
(Correct) 100%→75%→50%
- \*4 The percentage of the demand listed in the table above is an approximate value based on the compressor volume and does not necessarily correspond with the actual capacity.
- \*5 Notes on using demand control in combination with the low-noise mode  
To enable the low-noise mode, it is necessary to short-circuit 1-2 pin of CN3D on the outdoor unit whose SW6-8 is set to OFF. When SW6-8 is set to ON on all outdoor units, the following operations cannot be performed.  
•Performing 4-step demand in combination with the low-noise operation in a single-outdoor-unit system.

#### 1) Contact input and control content

##### 2-step demand control

The same control as the Thermo-OFF is performed by closing 1-3 pin of CN3D.

CN3D	
1-3	
Open	100%
Close	0%

##### 4-step demand control (When SW6-8 is set to ON on an outdoor unit)

Demand capacity is shown below.

CN3D	1-2P	
1-3P	Open	Close
Open	100%	75%
Close	0%	50%

## 2-6 System Connection Example

Examples of typical system connection are shown below.  
 Refer to the Installation Manual that came with each device or controller for details.

### (1) An example of a system to which an MA remote controller is connected

	System configuration	Connection to the system controller	Address start up for indoor and outdoor units	Notes
1	Single refrigerant system	NO	Automatic address setup	
2	Single refrigerant system	NO	Manual address setup	
3	Grouping of units in different refrigerant systems	NO	Manual address setup	
4	Single refrigerant system	With connection to transmission line for centralized control	Manual address setup	
5	Single refrigerant system	With connection to indoor-outdoor transmission line	Manual address setup	
6	Single refrigerant system	With connection to transmission line for centralized control	Manual address setup	

### (2) An example of a system to which an ME remote controller is connected

	System configuration	Connection to the system controller	Address start up for indoor and outdoor units	Notes
1	Single refrigerant system	With connection to transmission line for centralized control	Manual address setup	

### (3) An example of a system to which both MA remote controller and ME remote controller are connected


	System configuration	Connection to the system controller	Address start up for indoor and outdoor units	Notes
1	Single refrigerant system	With connection to transmission line for centralized control	Manual address setup	

\*MA remote controller and ME remote controller cannot both be connected to the same group.

# 2-7 Example System with an MA Remote Controller

## 2-7-1 Single Refrigerant System (Automatic Indoor/Outdoor Address Startup)

### (1) Sample control wiring



### (2) Cautions

- 1) ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
- 3) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required. To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- The table above shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- 4) Automatic address setup is not available if start-stop input (CN32, CN51, CN41) is used for a group operation of indoor units or when multiple indoor units with different functions

are grouped in the same group. Refer to the following page(s). [2-7-2 Single Refrigerant System]

### (3) Maximum allowable length

- 1) Indoor/outdoor transmission line  
 Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)  
 $L1 + L2 + L3 + L4 \leq 200m$  [656ft]  
 $L1 + L2 + L11 + L12 + L13 \leq 200m$  [656ft]  
 $L1 \leq 150m$  [492ft]
- 2) Transmission line for centralized control  
 No connection is required.
- 3) MA remote controller wiring  
 Maximum overall line length (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16])  
 $m1 \leq 200m$  [656ft]  
 $m2 + m3 \leq 200m$  [656ft]  
 $m4 + m5 \leq 200m$  [656ft]  
 \*When connecting PAR-31MAA or MA Simple remote controller, use sheathed cables with a minimum thickness of 0.3 mm<sup>2</sup>.

**(4) Wiring method**

- 1) Indoor/outdoor transmission line  
 Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor unit (OC), of the terminal block for indoor-outdoor transmission line (TB3) on the main HBC (HB), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

•Only use shielded cables.

**Shielded cable connection**

Daisy-chain the ground terminal (  $\text{G}$  ) on the outdoor unit (OC), the S terminal of the terminal block (TB3) on the HBC (HB), and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

- 2) Transmission line for centralized control  
 No connection is required.
- 3) MA remote controller wiring  
 Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (IC) to the terminal block on the MA remote controller (MA). (Non-polarized two-wire)

**When 2 remote controllers are connected to the system**

**(5) Address setting method**

When 2 remote controllers are connected to the system, connect terminals 1 and 2 of the terminal block (TB15) on the indoor unit (IC) to the terminal block on the two MA remote controllers.

•Set one of the MA remote controllers as a sub controller. (Refer to the Instruction Manual for the MA remote controller for the setting method.)

**Group operation of indoor units**

To perform a group operation of indoor units (IC), daisy-chain terminals 1 and 2 on the terminal block (TB15) on all indoor units (IC) in the same group, and then connect terminals 1 and 2 on the terminal block (TB15) on the indoor unit on one end to the terminal block on the MA remote controller. (Non-polarized two-wire)


•When performing a group operation of indoor units that have different functions, "Automatic indoor/outdoor address setup" is not available.

- 4) Switch setting  
 No address settings required.
- 5) When replacing the control board on only some of the outdoor units, delete all connection information. (Refer to [5-1-1 Outdoor Unit Switch Functions and Factory Settings] for information on switch functions.)

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	No settings required.	-	Port number setting is required For information about how to perform a group operation of indoor units that feature different functions, refer to the following page(s). [2-7-2 Single Refrigerant System]	00
		Sub unit	IC				
2	MA remote controller	Main remote controller	MA	No settings required.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit		OC	No settings required.	-		00
4	Auxiliary outdoor unit	HBC	HB	No settings required.	-		00

## 2-7-2 Single Refrigerant System

### (1) Sample control wiring



\* If the HB address overlaps any of the addresses that are assigned to either the OC or HS, use a different, unused address.  
 OC and HB addresses (lowest indoor unit address in the group plus +50) have higher priority than the HS address.

### (2) Cautions

- 1) ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
- 3) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.  
 To connect two transmission boosters, connect them in parallel.  
 (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- The table above shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.

### (3) Maximum allowable length

- 1) Indoor/outdoor transmission line  
 Same as 2-7-1
- 2) Transmission line for centralized control  
 No connection is required.
- 3) MA remote controller wiring  
 Same as 2-7-1



**(4) Wiring method**

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor unit (OC), of the terminal block for indoor-outdoor transmission line (TB3) on the main and sub HBCs (HB and HS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

•Only use shielded cables.

**Shielded cable connection**

Daisy-chain the ground terminal (  $\text{G}$  ) on the outdoor unit (OC), the S terminal of the terminal block (TB3) on HB

- and HS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.
- 2) Transmission line for centralized control  
No connection is required.
- 3) MA remote controller wiring  
Same as 2-7-1

**When 2 remote controllers are connected to the system**

Same as 2-7-1

**Group operation of indoor units**

Same as 2-7-1

4) Switch setting


Address setting is required as follows.

**(5) Address setting method**

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>•Assign the smallest address to the main unit in the group.</li> <li>•In a system with two or more HBCs make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul> </li> <li>Make the settings for the indoor units in the way that the formula "(i) &lt; (ii) &lt; (iii) &lt; (iv)" is true.</li> </ul>	<ul style="list-style-type: none"> <li>•Port number setting is required</li> <li>•To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> </ul>	00
		Sub unit					
2	MA remote controller	Main remote controller	MA	No settings required.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit		OC	51 to 100	<ul style="list-style-type: none"> <li>• Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."</li> </ul>	<ul style="list-style-type: none"> <li>•To set the address to 100, set the rotary switches to 50.</li> <li>•If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>•The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
4	Auxiliary outdoor unit	HBC (Main)	HB	51 to 100	OC +1		
		HBC (Sub)	HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-7-3 Grouped Operation of Units in Separate Refrigerant Circuits

### (1) Sample control wiring



### (2) Cautions

- 1) ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
- 3) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 4) Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 5) Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor units.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.  
To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- ◆The left table shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- ◆Refer to the DATABOOK for further information about how many booster units are required for a given system.

### (3) Maximum allowable length

- 1) Indoor/outdoor transmission line  
Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)  
L12 ≤ 200m [656ft]  
L22 ≤ 200m [656ft]  
◆The maximum piping length between OC and HB is 150 m.
- 2) Transmission line for centralized control  
L31 ≤ 200m [656ft]
- 3) MA remote controller wiring  
Same as 2-7-1
- 4) Maximum line distance via outdoor unit (1.25mm<sup>2</sup> [AWG16] or larger)  
L12+L31+L22 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>

<sup>\*1</sup> If a given system includes one or more unit or remote controller that does not support the maximum allowable cable distance of 1000 m [3280 ft], the maximum allowable cable distance in the system will be 500 m [1640 ft]. Refer to the latest catalog for information on which units and remote controllers support the maximum allowable cable distance of 1000 m [3280 ft].

**(4) Wiring method**

1) Indoor/outdoor transmission line

Same as 2-7-2

**Shielded cable connection**

Same as 2-7-2

2) Transmission line for centralized control

Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuit and on the OC in the same refrigerant circuit.

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

•Only use shielded cables.

**Shielded cable connection**

Daisy-chain the S terminal on the terminal block (TB7) on the outdoor unit (OC) with the shield wire of the shielded cable. Short-circuit the earth terminal (E) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as 2-7-1

**When 2 remote controllers are connected to the system**

Same as 2-7-1

**Group operation of indoor units**

Same as 2-7-1

4) Switch setting

Address setting is required as follows.

**Note**

a) When connecting TB7, only commence after checking that the voltage is below 20 VDC.


**(5) Address setting method**

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>Assign the smallest address to the main unit in the group.</li> <li>In a system with two or more HBCs, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul> </li> <li>Make the settings for the indoor units in the way that the formula "(i) &lt; (ii) &lt; (iii) &lt; (iv)" is true.</li> </ul>	<ul style="list-style-type: none"> <li>Port number setting is required</li> <li>To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> </ul>	00
		Sub unit					
2	MA remote controller	Main remote controller	MA	No settings required.	-		Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit		OC	51 to 100	<ul style="list-style-type: none"> <li>Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50." (If the address is already used, set to a different address within the specified range.)</li> </ul>	<ul style="list-style-type: none"> <li>To set the address to 100, set the rotary switches to 50.</li> <li>If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
4	Auxiliary outdoor unit	HBC (Main)	HB	51 to 100	OC + 1		
		HBC (Sub)	HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-7-4 System with a Connection of System Controller to Centralized Control Transmission Line

### (1) Sample control wiring

An example of a system in which a system controller is connected to the transmission cable for the centralized control system and the power is supplied from the outdoor unit



### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units (not required if power to the transmission line for centralized control is supplied from a controller with a power supply function, such as GB-50ADA).
- Short-circuit the shield terminal (S terminal) and the earth terminal (E) on the terminal block for transmission line for centralized control (TB7) on the outdoor unit whose power jumper connector is mated with CN40.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.  
To connect two transmission boosters, connect them in parallel.  
(Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- The left table shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

### (3) Maximum allowable length

- Indoor/outdoor transmission line  
Same as 2-7-3
- Transmission line for centralized control  
 $L31+L32 \leq 200\text{m}$  [656ft]
- MA remote controller wiring  
Same as 2-7-1
- Maximum line distance via outdoor unit  
(1.25mm<sup>2</sup> [AWG16] or larger)  
 $L32+L31+L12 \leq 1000\text{m}$  [3280ft] (500 m [1640ft])<sup>\*1</sup>  
 $L32+L22 \leq 1000\text{m}$  [3280ft] (500 m [1640ft])<sup>\*1</sup>  
 $L12+L31+L22 \leq 1000\text{m}$  [3280ft] (500 m [1640ft])<sup>\*1</sup>

<sup>\*1</sup> If a given system includes one or more unit or remote controller that does not support the maximum allowable cable distance of 1000 m [3280 ft], the maximum allowable cable distance in the system will be 500 m [1640 ft]. Refer to the latest catalog for information on which units and remote controllers support the maximum allowable cable distance of 1000 m [3280 ft].

**(4) Wiring method**

- 1) Indoor/outdoor transmission line  
Same as 2-7-2  
Only use shielded cables.  
**Shielded cable connection**  
Same as 2-7-2
- 2) Transmission line for centralized control  
Daisy-chain terminals A and B on the system controller, terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuits and on the outdoor unit (OC) in the same refrigerant circuit.  
If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.  
If a system controller is connected, set the central control switch (SW5-1) on the control board of all outdoor units to "ON."

**Note**


- a) When connecting TB7, only commence after checking that the voltage is below 20 VDC.  
•Only use shielded cables.  
**Shielded cable connection**  
Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC with the shield of the shielded cable. Short-circuit the earth terminal (  $\perp$  ) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.
- 3) MA remote controller wiring  
Same as 2-7-1  
**When 2 remote controllers are connected to the system**  
Same as 2-7-1  
**Group operation of indoor units**  
Same as 2-7-1
- 4) Switch setting  
Address setting is required as follows.

**(5) Address setting method**

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>•Assign the smallest address to the main unit in the group.</li> <li>•In a system with two or more HBCs, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul>                             Make the settings for the indoor units in the way that the formula "(i) &lt; (ii) &lt; (iii) &lt; (iv)" is true.                         </li> </ul>	<ul style="list-style-type: none"> <li>•Port number setting is required</li> <li>•To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> </ul>	00
		Sub unit					
2	MA remote controller	Main remote controller	MA	No settings required.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller.	Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit (Note)		OC	51 to 100	<ul style="list-style-type: none"> <li>• Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."</li> </ul>	<ul style="list-style-type: none"> <li>•To set the address to 100, set the rotary switches to 50.</li> <li>•If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>•The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
4	Auxiliary outdoor unit	HBC (Main)	HB	51 to 100	OC +1		
		HBC (Sub)	HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-7-5 System with a Connection of System Controller to Indoor-Outdoor Transmission Line

### (1) Sample control wiring



Note1 LM adapters cannot be connected to the indoor-outdoor transmission line.

### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 MA remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- Provide grounding to S terminal on the terminal block for transmission line for centralized control (TB7) on only one of the outdoor units.
- A maximum of three system controllers can be connected to the indoor-outdoor transmission line. (AE-200, AG-150A, GB-50ADA, or G(B)-50A are not connectable.)
- When the total number of indoor units exceeds 20 (12 if one or more indoor units of the 200 model or above is connected), it may not be possible to connect a system controller to the indoor-outdoor transmission line.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.  
To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- The left table shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.

### (3) Maximum allowable length

- Indoor/outdoor transmission line  
Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)  
L12 ≤ 200m [656ft]  
L22 ≤ 200m [656ft]  
L25 ≤ 200m [656ft]
- The maximum piping length between OC and HB is 150 m.
- Transmission line for centralized control  
L31 ≤ 200m [656ft]
- MA remote controller wiring  
Same as 2-7-1  
Maximum line distance via outdoor unit (1.25mm<sup>2</sup> [AWG16] or larger)  
L25+L31+L12 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>  
L12+L31+L22 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>

\*1 If a given system includes one or more unit or remote controller that does not support the maximum allowable cable distance of 1000 m [3280 ft], the maximum allowable cable distance in the system will be 500 m [1640 ft]. Refer to the latest catalog for information on which units and remote controllers support the maximum allowable cable distance of 1000 m [3280 ft].

**(4) Wiring method**

- 1) Indoor/outdoor transmission line  
 Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor unit (OC), of the terminal block for indoor-outdoor transmission line (TB3) on the main and sub HBCs (HB and HS), of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC), and the S terminal of the system controller. (Non-polarized two-wire)  
 •Only use shielded cables.  
**Shielded cable connection**  
 Daisy-chain the ground terminal (  $\perp$  ) on the outdoor unit (OC), the S terminal of the terminal block (TB3) on the HB and HS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.
- 2) Transmission line for centralized control  
 Daisy-chain terminals M1 and M2 on the terminal block for transmission line for centralized control (TB7) on the outdoor units (OC) in different refrigerant circuit and on the OC in the same refrigerant circuit.  
 If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on only one of the outdoor units.

Set the central control switch (SW5-1) on the control board of all outdoor units to "ON."

**Note**


- a) When connecting TB7, only commence after checking that the voltage is below 20 VDC.  
 •Only use shielded cables.  
**Shielded cable connection**  
 Daisy-chain the S terminal on the terminal block (TB7) on the outdoor units (OC, OS) with the shield wire of the shielded cable. Short-circuit the earth terminal (  $\perp$  ) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.
- 3) MA remote controller wiring  
 Same as 2-7-1  
**When 2 remote controllers are connected to the system**  
 Same as 2-7-1  
**Group operation of indoor units**  
 Same as 2-7-1
- 4) Switch setting  
 Address setting is required as follows.

**(5) Address setting method**

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	•Assign the smallest address to the main unit in the group. •In a system with two or more HBCs, make the settings for the indoor units in the following order. (i) Indoor unit to be connected to the main HBC (ii) Indoor unit to be connected to the sub HBC 1 (iii) Indoor unit to be connected to the sub HBC 2 (iv) Indoor unit to be connected to the sub HBC 3 Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii) < (iv)" is true.	•Port number setting is required •To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.	00
		Sub unit					
2	MA remote controller	Main remote controller	MA	No settings required.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller.	Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit		OC	51 to 100	• Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."	•To set the address to 100, set the rotary switches to 50. •If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range. •The use of a sub HBC requires the connection of a main HBC.	00
4	Auxiliary outdoor unit	HBC (Main)	HB	51 to 100	OC +1		
		HBC (Sub)	HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-7-6 System with Multiple HBCs

### (1) Sample control wiring



### (2) Cautions

- 1) ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 2) No more than 2 MA remote controllers can be connected to a group of indoor units.
- 3) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 4) Replacement of male power jumper connector (CN41) must be performed only on one of the outdoor units.
- 5) Short-circuit the S (shield) terminal of the terminal block for the central control unit (TB7) and the ground terminal (⌈) on the outdoor unit whose power jumper was moved from CN41 to CN40.
- 6) When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.

To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required	
	1 unit	2 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	25 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	19 - 37 units	38 - 50 units

- The table above shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
- Refer to the DATABOOK for further information about how many booster units are required for a given system.

- 7) When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

### (3) Maximum allowable length

- 1) Indoor/outdoor transmission line  
 Maximum distance (1.25mm<sup>2</sup> [AWG16] or larger)  
 L12 ≤ 200m [656ft]  
 L22 ≤ 200m [656ft]
  - ♦The maximum piping length between OC and HB is 150 m.
- 2) Transmission line for centralized control  
 L31+L32 ≤ 200m [656ft]
- 3) MA remote controller wiring  
 Maximum overall line length  
 (0.3 to 1.25mm<sup>2</sup> [AWG22 to 16])  
 m1 ≤ 200m [656ft]  
 m2+m3 ≤ 200m [656ft]
- 4) Maximum line distance via outdoor unit  
 (1.25mm<sup>2</sup> [AWG16] or larger)  
 L32+L31+L12 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>  
 L32+L22 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>  
 L12+L31+L22 ≤ 1000 m [3280ft] (500 m [1640ft])<sup>\*1</sup>

<sup>\*1</sup> If a given system includes one or more unit or remote controller that does not support the maximum allowable cable distance of 1000 m [3280 ft], the maximum allowable cable distance in the system will be 500 m [1640 ft]. Refer to the latest catalog for information on which units and remote controllers support the maximum allowable cable distance of 1000 m [3280 ft].



**(4) Wiring method**

1) Indoor/outdoor transmission line

Daisy-chain terminals M1 and M2 of the terminal block for indoor-outdoor transmission line (TB3) on the outdoor unit (OC), of the terminal block for indoor-outdoor transmission line (TB3) on the main and sub HBCs (HB and HS), and of the terminal block for indoor-outdoor transmission line (TB5) on each indoor unit (IC). (Non-polarized two-wire)

•Only use shielded cables.

**Shielded cable connection**

Daisy-chain the ground terminal (GND) on the outdoor unit (OC), the S terminal of the terminal block (TB3) on the HB and HS, and the S terminal of the terminal block (TB5) on the indoor unit (IC) with the shield of the shielded cable.

2) Transmission line for centralized control

Daisy-chain terminals A and B of the system controller, M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor units (OC) in different refrigerant systems, and M1 and M2 terminals of TB7 (terminal block for centralized control system connection) on the outdoor unit (OC) in the same refrigerant circuit.

If a power supply unit is not connected to the transmission line for centralized control, replace the power jumper connector on the control board from CN41 to CN40 on

only one of the outdoor units.

When connecting a system controller, set the centralized control switch (SW5-1) on the control board of all indoor units to "ON."

**Note**

a) When connecting TB7, only commence after checking that the voltage is below 20 VDC.

•Only use shielded cables.

**Shielded cable connection**

Daisy-chain the S terminal of the terminal block (TB7) on the system controller, OC with the shield of the shielded cable. Short-circuit the earth terminal (GND) and the S terminal on the terminal block (TB7) on the outdoor unit whose power jumper connector is mated with CN40.

3) MA remote controller wiring

Same as 2-7-1

**When 2 remote controllers are connected to the system**

Same as 2-7-1

**Group operation of indoor units**

Same as 2-7-1

4) Switch setting

Address setting is required as follows.


**(5) Address setting method**

Pro-ced-ur-es	Unit or controller			Address setting range	Setting method	Notes	Fac-tory set-ting
1	Indoor unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>Assign the smallest address to the main unit in the group.</li> <li>In a system with a sub HBC, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul>                             Make the settings for the indoor units in the way that the formula "(i) &lt; (ii) &lt; (iii) &lt; (iv)" is true.                         </li> </ul>	<ul style="list-style-type: none"> <li>Port number setting is required</li> <li>To perform a group operation of indoor units that feature different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> </ul>	00
		Sub unit					
2	MA remote controller	Main remote controller	MA	No settings required.	-	Make the same indoor unit group settings with the system controller as the ones that were made with the MA remote controller.	Main
		Sub remote controller	MA	Sub remote controller	Settings to be made with the Sub/Main switch		
3	Outdoor unit		OC	51 to 100	<ul style="list-style-type: none"> <li>Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."</li> </ul>	<ul style="list-style-type: none"> <li>To set the address to 100, set the rotary switches to 50.</li> </ul>	00
4	Auxiliary unit	HBC (Main)	HB	51 to 100	OC +1	<ul style="list-style-type: none"> <li>To set the address to 100, set the rotary switches to 50.</li> <li>If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
		HBC (Sub)	HS	51 to 100	Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-8 Example System with an ME Remote Controller

### 2-8-1 System with a Connection of System Controller to Centralized Control Transmission Line

#### (1) Sample control wiring



#### (2) Cautions

- ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- No more than 2 ME remote controllers can be connected to a group of indoor units.
- Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units.
- When the number of the connected indoor units is as shown in the table below, one or more transmission boosters (sold separately) are required.  
To connect two transmission boosters, connect them in parallel. (Observe the maximum number of connectable indoor units that are listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required		
	1 unit	2 units	3 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	13 - 32 units	33 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	9 - 24 units	25 - 40 units	41 - 50 units

- The left table shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
  - Refer to the DATABOOK for further information about how many booster units are required for a given system.
- When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

#### (3) Maximum allowable length

- Indoor/outdoor transmission line  
Same as 2-7-3
- Transmission line for centralized control  
Same as 2-7-4
- ME remote controller wiring  
Maximum overall line length  
(0.3 to 1.25mm<sup>2</sup> [AWG22 to 16])  
m1 ≤ 10m [32ft]  
m2+m3 ≤ 10m [32ft]  
If the standard-supplied cable must be extended, use a cable with a diameter of 1.25mm<sup>2</sup> [AWG16]. The section of the cable that exceeds 10m [32ft] must be included in the maximum indoor-outdoor transmission line distance described in 1).  
When connected to the terminal block on the Simple remote controller, use cables that meet the following cable size specifications: 0.75 - 1.25 mm<sup>2</sup> [AWG18-16].
- Maximum line distance via outdoor unit  
(1.25 mm<sup>2</sup> [AWG16] or large)  
Same as 2-7-4

**(4) Wiring method**

- 1) Indoor/outdoor transmission line  
Same as 2-7-2  
**Shielded cable connection**  
Same as 2-7-2
- 2) Transmission line for centralized control  
Same as 2-7-4  
**Shielded cable connection**  
Same as 2-7-4
- 3) ME remote controller wiring  
ME remote controller is connectable anywhere on the indoor-outdoor transmission line.

**When 2 remote controllers are connected to the system**

- Refer to the section on Switch Setting.
- Performing a group operation (including the group operation of units in different refrigerant circuits).**  
Refer to the section on Switch Setting.
- 4) Switch setting  
Address setting is required as follows.


**(5) Address setting method**

Procedures	Unit or controller			Address setting range	Setting method	Notes	Factory setting
1	Indoor unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>♦Assign the smallest address to the main unit in the group.</li> <li>♦In a system with two or more HBCs, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul> </li> <li>Make the settings for the indoor units in the way that the formula "(i) &lt; (ii) &lt; (iii) &lt; (iv)" is true.</li> </ul>	<ul style="list-style-type: none"> <li>♦Port number setting is required</li> <li>♦To perform a group operation of indoor units that have different functions, set the indoor unit in the group with the greatest number of functions as the main unit.</li> </ul>	00
		Sub unit					
2	ME remote controller	Main remote controller	RC	101 to 150	Add 100 to the main unit address in the group	<ul style="list-style-type: none"> <li>♦It is not necessary to set the 100s digit.</li> <li>♦To set the address to 200, set the rotary switches to 00.</li> </ul>	101
		Sub remote controller	RC	151 to 200	Add 150 to the main unit address in the group		
3	Outdoor unit		OC	51 to 100	<ul style="list-style-type: none"> <li>♦ Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."</li> </ul>	<ul style="list-style-type: none"> <li>♦To set the address to 100, set the rotary switches to 50.</li> <li>♦If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>♦The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
4	Auxiliary outdoor unit	HBC (Main)	HB	51 to 100	OC +1		
		HBC (Sub)	HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

## 2-9 Example System with an MA and an ME Remote Controller

### 2-9-1 System with a Connection of System Controller to Centralized Control Transmission Line

#### (1) Sample control wiring



2 Restrictions

#### (2) Cautions

- 1) Be sure to connect a system controller.
- 2) ME remote controller and MA remote controller cannot both be connected to the same group of indoor units.
- 3) Assign to the indoor units connected to the MA remote controller addresses that are smaller than those of the indoor units that are connected to the ME remote controller.
- 4) No more than 2 ME remote controllers can be connected to a group of indoor units.
- 5) No more than 2 MA remote controllers can be connected to a group of indoor units.
- 6) Do not connect the terminal blocks (TB5) on the indoor units that are connected to different outdoor units with each other.
- 7) Replace the power jumper connector of the control board from CN41 to CN40 on only one of the outdoor units.
- 8) Provide an electrical path to ground for the S terminal on the terminal block for centralized control on only one of the outdoor units.
- 9) When the number of the connected indoor units is as shown in the right table, one or more transmission boosters (sold separately) are required.  
 To connect two transmission boosters, connect them in parallel.  
 (Observe the maximum number of connectable indoor units that are

listed in the specifications for each outdoor unit.)

	Number of transmission booster (sold separately) required		
	1 unit	2 units	3 units
When the W/WP/WL200 and W/WP/WL250 models are not included in the connected indoor units	13 - 32 units	33 - 50 units	-
When the W/WP/WL200 and W/WP/WL250 models are included in the connected indoor units	9 - 24 units	25 - 40 units	41 - 50 units

- ♦The above table shows the number of transmission boosters that is required by the system with four HBCs. For each HBC added or subtracted, subtract or add two indoor units.
  - ♦Refer to the DATABOOK for further information about how many booster units are required for a given system.
- 10) When a power supply unit is connected to the transmission line for centralized control, leave the power jumper connector on CN41 as it is (factory setting).

**(3) Maximum allowable length**

- 1) Indoor/outdoor transmission line  
Same as 2-7-3
- 2) Transmission line for centralized control  
Same as 2-7-4
- 3) MA remote controller wiring  
Same as 2-7-1
- 4) ME remote controller wiring  
Same as 2-8-1
- 5) Maximum line distance via outdoor unit  
(1.25 mm<sup>2</sup> [AWG16] or larger)  
Same as 2-7-4

**(4) Wiring method**

- 1) Indoor/outdoor transmission line  
Same as 2-7-2

**Shielded cable connection**

- Same as 2-7-2
- 2) Transmission line for centralized control  
Same as 2-7-4

**Shielded cable connection**

- Same as 2-7-4
- 3) MA remote controller wiring  
(When 2 remote controllers are connected to the system,  
Group operation of indoor units)  
Same as 2-7-1
- 4) ME remote controller wiring  
(When 2 remote controllers are connected to the system,  
Group operation of indoor units)  
Same as 2-8-1
- 5) Switch setting  
Address setting is required as follows.

**(5) Address setting method**

Pro- ce- dures	Unit or controller				Ad- dress setting range	Setting method	Notes	Fac- tory set- ting
1	Opera- tion with the MA re- mote controller	In- door unit	Main unit	IC	01 to 50	<ul style="list-style-type: none"> <li>Assign the smallest address to the main unit in the group.</li> <li>In a system with two or more HBCs, make the settings for the indoor units in the following order.                             <ul style="list-style-type: none"> <li>(i) Indoor unit to be connected to the main HBC</li> <li>(ii) Indoor unit to be connected to the sub HBC 1</li> <li>(iii) Indoor unit to be connected to the sub HBC 2</li> <li>(iv) Indoor unit to be connected to the sub HBC 3</li> </ul> </li> </ul> Make the settings for the indoor units in the way that the formula "(i) < (ii) < (iii) < (iv)" is true.	<ul style="list-style-type: none"> <li>Assign an address smaller than that of the indoor unit that is connected to the ME remote controller.</li> <li>Enter the same indoor unit group settings on the system controller as the ones that were entered on the MA remote controller.</li> <li>To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> <li>Port number setting is required.</li> </ul>	00
			Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
	MA re- mote con- troller	Main re- mote con- troller	MA	No settings re- quired.	-		Main	
		Sub remote con- troller	MA	Sub remote con- troller	Settings to be made according to the remote controller function selection			
2	Opera- tion with the ME re- mote controller	In- door unit	Main unit	IC	01 to 50	Assign the smallest address to the main unit in the group.	<ul style="list-style-type: none"> <li>Assign an address higher than those of the indoor units that are connected to the MA remote controller.</li> <li>Make the initial settings for the indoor unit group settings via the system controller.</li> <li>To perform a group operation of indoor units that have different functions, designate the indoor unit in the group with the greatest number of functions as the main unit.</li> <li>Port number setting is required.</li> <li>Addresses that are assigned to the indoor units that are connected to the sub HBC should be higher than the addresses that are assigned to the indoor units that are connected to the main HBC.</li> </ul>	00
			Sub unit	IC	01 to 50	Assign sequential numbers starting with the address of the main unit in the same group +1. (Main unit address +1, main unit address +2, main unit address +3, etc.)		
	ME re- mote con- troller	Main re- mote con- troller	RC	101 to 150	Add 100 to the main unit address in the group.	<ul style="list-style-type: none"> <li>It is not necessary to set the 100s digit.</li> <li>To set the address to 200, set it to 00.</li> </ul>	101	
		Sub remote con- troller	RC	151 to 200	Add 150 to the main unit address in the group.			
3	Outdoor unit			OC	51 to 100	<ul style="list-style-type: none"> <li>Set the address to "the smallest indoor unit address in the same refrigerant circuit system + 50."</li> </ul>	<ul style="list-style-type: none"> <li>To set the address to 100, set it to 50.</li> <li>If the addresses that is assigned to the main HBC overlaps any of the addresses that are assigned to the outdoor units or to the sub HBC, use a different, unused address within the setting range.</li> <li>The use of a sub HBC requires the connection of a main HBC.</li> </ul>	00
4	Auxiliary outdoor unit	HBC (Main)		HB	51 to 100	OC +1	<ul style="list-style-type: none"> <li>The use of a sub HBC requires the connection of a main HBC.</li> </ul>	
		HBC (Sub)		HS		Assign an address that equals the sum of the smallest address of the indoor units that are connected to the sub HBC and 50.		

# 2-10 Restrictions on Refrigerant Pipes

## 2-10-1 Restrictions on Refrigerant Pipe Length





Fig. 1

(Unit: m)

	Item	Piping portion	Allowable value
Pipe lengths	Between outdoor unit and HBC (refrigerant pipework)	A	110 or less
	Water pipework between indoor units and HBC	f + g + h + k	60 or less
Height difference	Between HBC and outdoor units	Outdoor unit above HBC	H
		Outdoor unit below HBC	H'
Height difference	Between indoor units and HBC	h1	15(10) or less*3
	Between indoor units	h2	15(10) or less*3

\*1. 90 m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.  
 \*2. 60 m is available depending on the model and installation conditions. For more detailed information, contact your local distributor.  
 \*3. Values in ( ) are applied when indoor total capacity exceeds 130% of outdoor unit capacity



## 2-10-2 Restrictions on Refrigerant Pipe and Water Pipe Size

### (1) Refrigerant pipe between outdoor unit and HBC (Part A)

Unit model		HBC		
		Model name	High pressure side	Low pressure side
Outdoor unit side	PURY-(E)M200	(HBC) CMB-WM350F-AA	ø15.88 (Brazing)	ø19.05 (Brazing)
	PURY-(E)M250		ø15.88 (Brazing)	ø22.2 (Brazing)
	PURY-(E)M300		ø15.88 (Brazing)	ø22.2 (Brazing)
	PURY-(E)M350		ø15.88 (Brazing)	ø28.58 (Brazing)
	PURY-(E)M400	(HBC) CMB-WM500F-AA	ø19.05 (Brazing)	ø28.58 (Brazing)
	PURY-(E)M450		ø19.05 (Brazing)	ø28.58 (Brazing)
	PURY-(E)M500		ø19.05 (Brazing)	ø28.58 (Brazing)

### (2) Water pipe (Sections a, b, c, d, e, f, g, h and k)





Total down-stream indoor unit capacity	Pipe size between Main-HBC and Sub-HBC <sup>*1</sup> Pipe size between Main-HBC and indoor unit <sup>*1</sup> Pipe size between Sub-HBC and indoor unit <sup>*1</sup>		
	Max 20 m <sup>*2</sup>	Max 40 m <sup>*2</sup>	Max 60 m <sup>*2</sup>
W/WP/WL10	I.D. ≥ 12 mm	I.D. ≥ 12 mm	I.D. ≥ 12 mm
W/WP/WL11 - W/WP/WL15	I.D. ≥ 12 mm	I.D. ≥ 12 mm	I.D. ≥ 15.5 mm
W/WP/WL16 - W/WP/WL25	I.D. ≥ 15.5 mm	I.D. ≥ 15.5 mm	I.D. ≥ 15.5 mm
W/WP/WL26 - W/WP/WL32	I.D. ≥ 15.5 mm	I.D. ≥ 19.9 mm	I.D. ≥ 19.9 mm
W/WP/WL33 - W/WP/WL50	I.D. ≥ 19.9 mm	I.D. ≥ 19.9 mm	I.D. ≥ 19.9 mm
W/WP/WL51 - W/WP/WL63	I.D. ≥ 19.9 mm	I.D. ≥ 25.2 mm	I.D. ≥ 25.2 mm
W/WP/WL64 - W/WP/WL80	I.D. ≥ 25.2 mm	I.D. ≥ 25.2 mm	I.D. ≥ 25.2 mm
W/WP/WL81 - W/WP/WL100	I.D. ≥ 25.2 mm	I.D. ≥ 25.2 mm	I.D. ≥ 32.6 mm
W/WP/WL101 - W/WP/WL150	I.D. ≥ 32.6 mm	I.D. ≥ 32.6 mm	I.D. ≥ 32.6 mm
W/WP/WL151 - W/WP/WL250	I.D. ≥ 32.6 mm	I.D. ≥ 32.6 mm	I.D. ≥ 39.6 mm
W/WP/WL251 - W/WP/WL300	I.D. ≥ 39.6 mm	I.D. ≥ 39.6 mm	I.D. ≥ 50.8 mm
W/WP/WL301 - W/WP/WL750	I.D. ≥ 50.8 mm	I.D. ≥ 50.8 mm	I.D. ≥ 50.8 mm

\*1. When connecting CMB-WM108/1016V-AA and CMB-WM108/1016V-BB, refer to the installation manual for CMB-WM108/1016V-AA about pipe size.

\*2. Piping length from Main-HBC to the farthest indoor unit

## 2-10-3 HBC Connection Method

### (1) Size of the pipe that fits the standard HBC ports



**Note: 1**

**To connect multiple indoor units to a port**

- Maximum total capacity of connected indoor units: W/WP/WL80
- Maximum number of connectable indoor units: 3 units
- Branch joints are field-supplied.
- All the indoor units that are connected to the same port must be in the same group and perform the Thermo-ON/OFF operation simultaneously.
- The room temperatures of all the indoor units in the group need to be monitored via the connected remote controller.
- When connecting a W/WP/WL71 through 125 model indoor unit to an HBC, the pipes that connect the unit to the same set of HBC ports cannot be branched out to connect additional units.
- Selection of water piping  
 Select the size according to the total capacity of indoor units to be installed downstream.
- Do not connect multiple indoor units to the same port when operating each of them in different modes (cooling, heating, stop, and thermo-OFF). The indoor units connected to the same port must be set to operate in the same mode. Set them to the same group to make them run/stop in the same mode all together. Alternatively, enable the thermo setting on the remote controller, or set the common thermostat (optional) to run/stop the units in the same mode based on the representative temperature.
- When multiple indoor units are connected to a single port, install a pressure control valve in the pipe to equalize the pressure of all indoor units.
- Pressure control valves are required for the “WP-type” and “WL-type without the optional valve kit” indoor units only, and not for the “W-type” and “WL-type with the optional valve kit” indoor units.

**Note: 2**

**Connecting W/WP/WL100 or 125 indoor units to an HBC**

- ♦When connecting W/WP/WL100 or 125 indoor units to an HBC, connect each unit to two sets of two ports on the HBC, using two junction pipes (Y-joints).
- ♦Connect an increaser (20A-to-32A) to the merged side of each junction pipe.
- ♦When the junction pipes are connected to Main-HBC, the branched sides of the junction pipes cannot be connected to the ports "3 and 4" at the same time. (See Fig. 1.)
- ♦When the junction pipes are connected to 16 Sub-HBC ports, the branched sides of the junction pipes cannot be connected to the ports "4 and 5," "8 and 9," or "12 and 13" at the same time. (See Fig. 2.)
- ♦When the junction pipes are connected to 8 Sub-HBC ports, the branched sides of the junction pipes cannot be connected to the ports "4 and 5" at the same time. (See Fig. 3.)
- ♦When a W/WP/WL100 or a 125 model indoor unit is connected to an HBC, the pipes that connect the unit to the same set of HBC ports cannot be branched out to connect additional units.

**Note: 3**

**Selecting the port for indoor unit connection**

- ♦The table below shows the ports for connecting the units that belong to Group 1 and Group 2.

	Group 1	Group 2
CMB-WM350/500F-AA	Ports from 1 to 3	Ports from 4 to 6
CMB-WM108V-BB	Ports from 1 to 4	Ports from 5 to 8
CMB-WM1016V-BB	Ports from 1 to 4	Ports from 5 to 8
	Ports from 9 to 12	Ports from 13 to 16

---

## Chapter 3 Major Components, Their Functions and Refrigerant Circuits


<b>3-1</b>	<b>External Appearance and Refrigerant Circuit Components of Outdoor Unit.....</b>	<b>1</b>
3-1-1	External Appearance of Outdoor Unit.....	1
3-1-2	Outdoor Unit Refrigerant Circuits.....	4
<b>3-2</b>	<b>Outdoor Unit Refrigerant Circuit Diagrams.....</b>	<b>8</b>
<b>3-3</b>	<b>Functions of the Major Components of Outdoor Unit.....</b>	<b>14</b>
<b>3-4</b>	<b>Functions of the Major Components of Indoor Unit.....</b>	<b>16</b>
<b>3-5</b>	<b>External Appearance and Refrigerant Circuit Components of HBC.....</b>	<b>17</b>
3-5-1	Main HBC.....	17
3-5-2	Sub HBC.....	20
<b>3-6</b>	<b>HBC Refrigerant Circuit Diagrams.....</b>	<b>22</b>
<b>3-7</b>	<b>Functions of the Major Components of HBC.....</b>	<b>24</b>



# 3-1 External Appearance and Refrigerant Circuit Components of Outdoor Unit


## 3-1-1 External Appearance of Outdoor Unit

(1) PURY-M200, M250, M300YNW-A1  
PURY-EM200, EM250, EM300YNW-A1




**(2) PURY-M350, M400, M450YNW-A1  
PURY-EM350, EM400, EM450YNW-A1**

3 Major Components, Their Functions and Refrigerant Circuits



**(3) PURY-M500YNW-A1  
PURY-EM500YNW-A1**







### 3-1-2 Outdoor Unit Refrigerant Circuits

(1) PURY-M200, M250, M300YNW-A1  
 PURY-EM200, EM250, EM300YNW-A1

3 Major Components, Their Functions and Refrigerant Circuits




**(2) PURY-M350, M400, M450YNW-A1  
PURY-EM350YNW-A1**




**(3) PURY-EM400, EM450YNW-A1**

**3 Major Components, Their Functions and Refrigerant Circuits**




**(4) PURY-M500YNW-A1  
PURY-EM500YNW-A1**




# 3-2 Outdoor Unit Refrigerant Circuit Diagrams

## (1) PURY-M200 - M300YNW-A1




(2) PURY-EM200 - EM300YNW-A1




### (3) PURY-M350 - M450YNW-A1

## 3 Major Components, Their Functions and Refrigerant Circuits



**(4) PURY-EM350 - EM450YNW-A1**






**(5) PURY-M500YNW-A1**


**3 Major Components, Their Functions and Refrigerant Circuits**

Products manufactured in August 2020 and earlier are equipped with Cv1b.



**(6) PURY-EM500YNW-A1**


Products manufactured in August 2020 and earlier are equipped with Cv1b.



### 3-3 Functions of the Major Components of Outdoor Unit

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Compressor	MC1 (Comp1)		Adjusts the amount of circulating refrigerant by adjusting the operating frequency based on the operating pressure data	(E)M200 - (E)M350 models Low-pressure shell scroll compressor wirewound resistance 20°C [68°F] : 0.192Ω (E)M400 - (E)M500 models Low-pressure shell scroll compressor wirewound resistance 20°C [68°F] : 0.219Ω	
High pressure sensor	63HS1		<ol style="list-style-type: none"> <li>1) Detects high pressure</li> <li>2) Regulates frequency and provides high-pressure protection</li> </ol>	<p>63HS1</p> <p>Pressure 0~4.15 MPa [601psi] Vout 0.5~3.5V 0.071V/0.098 MPa [14psi] Pressure [MPa] =1.38 x Vout [V]-0.69 Pressure [psi] =(1.38 x Vout [V] - 0.69) x 145</p> <p>1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
Low pressure sensor	63LS		<ol style="list-style-type: none"> <li>1) Detects low pressure</li> <li>2) Provides low-pressure protection</li> </ol>	<p>63LS</p> <p>Pressure 0~1.7 MPa [247psi] Vout 0.5~3.5V 0.173V/0.098 MPa [14psi] Pressure [MPa] =-0.566 x Vout [V] - 0.283 Pressure [psi] =(-0.566 x Vout [V] - 0.283) x 145</p> <p>1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
Pressure switch	63H1		<ol style="list-style-type: none"> <li>1) Detects high pressure</li> <li>2) Provides high-pressure protection</li> </ol>	4.15MPa[601psi] OFF setting	
Thermistor	TH4 (Discharge temperature)		<ol style="list-style-type: none"> <li>1) Detects discharge air temperature</li> <li>2) Provides high-pressure protection</li> </ol>	<p>Degrees Celsius</p> $R_{120} = 7.465k\Omega$ $R_{25/120} = 4057$ $R_t = 7.465 \exp\{4057(\frac{1}{273+t} - \frac{1}{393})\}$	Resistance check
			<ol style="list-style-type: none"> <li>0°C[32°F] : 698 kΩ</li> <li>10°C[50°F] : 413 kΩ</li> <li>20°C[68°F] : 250 kΩ</li> <li>30°C[86°F] : 160 kΩ</li> <li>40°C[104°F] : 104 kΩ</li> <li>50°C[122°F] : 70 kΩ</li> <li>60°C[140°F] : 48 kΩ</li> <li>70°C[158°F] : 34 kΩ</li> <li>80°C[176°F] : 24 kΩ</li> <li>90°C[194°F] : 17.5 kΩ</li> <li>100°C[212°F] : 13.0 kΩ</li> <li>110°C[230°F] : 9.8 kΩ</li> </ol>		

[3-3 Functions of the Major Components of Outdoor Unit ]

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Thermistor	TH3 (Pipe temperature)		Controls defrosting during heating operation	Degrees Celsius $R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_t = 15 \exp\{3460 (\frac{1}{273+t} - \frac{1}{273})\}$  0°C[32°F] :15 kΩ 10°C[50°F] :9.7 kΩ 20°C[68°F] :6.4 kΩ 25°C[77°F] :5.3 kΩ 30°C[86°F] :4.3 kΩ 40°C[104°F] :3.1 kΩ	Resistance check
	TH7 (Outdoor temperature)		1) Detects outdoor air temperature 2) Controls fan operation		
	TH5 (Pipe temperature)		Fan operated on the 63LS and TH5 values.		
	TH15 (Compressor shell bottom temperature)		Detects compressor shell bottom temperature		
	THHS Inverter heat sink temperature		Inverter overheating protection	Degrees Celsius $R_{50} = 17k\Omega$ $R_{25/120} = 4016$ $R_t = 17 \exp\{4016 (\frac{1}{273+t} - \frac{1}{323})\}$  0°C[32°F] :161 kΩ 10°C[50°F] :97 kΩ 20°C[68°F] :60 kΩ 25°C[77°F] :48 kΩ 30°C[86°F] :39 kΩ 40°C[104°F] :25 kΩ	
Solenoid valve	SV1a Discharge-suction bypass		1) High/low pressure bypass at start-up and stopping, and capacity control during low-load operation 2) High-pressure-rise prevention	AC220 - 240V Open while being powered/ closed while not being powered	Continuity check with a tester
	SV2		Prevention of low-pressure drop Refrigerant equalization control	AC220 - 240V Open while being powered/ closed while not being powered	
LEV	LEV2a, 2b, 2c	LEV2c is only on the (E)M500 models.	(During cooling) Heat exchanger capacity control (During heating) Refrigerant equalization control	DC12V Opening of stepping motor driving valve 0-3000 pulses (LEV2a, 2b) 0-3000 pulses (LEV2d, (E)M200-300) 0-6000 pulses (LEV2d, (E)M350-500)	Continuity Test with a Tester. Continuity between white and orange. Continuity between yellow, brown, and blue 
	LEV2d		Heat exchanger capacity control		
	LEV4		Injection amount control	DC12V Opening of stepping motor driving valve 0-480 pulses (direct driven type)	
	LEV9		Refrigerant cooling control		
4-way valve	21S4a, b		Changeover between heating and cooling	AC220 - 240V Dead: cooling cycle Live: heating cycle	Continuity check with a tester
	21S4c	(E)M500 models only			
Fan motor	FAN motor 1, 2	FAN motor 2 is only on the (E)M350 - (E)M500 models.	Regulates the heat exchanger capacity by adjusting the operating frequency and operating the propeller fan based on the operating pressure.	(E)M200 - (E)M300, (E)M500 AC380 - 460V, 920W (E)M350 - (E)M450 AC380 - 460V, 460W	

### 3-4 Functions of the Major Components of Indoor Unit

Part Name	Symbol (functions)	Notes	Usage	Specification	Check method
Flow control valve	FCV		Controls the rate of water flow to the indoor unit.	DC12V Opening of stepping motor driving valve 85-(770) pulses	Refer to the section [8-8-4 General Overview on FCV Operation (Indoor unit)].
Thermistor	TH1 (Suction air temperature)		Indoor unit control (Thermo)	$R_0=15k\Omega$ $R_{0/80}=3460$ $R_t = 15 \exp\{3460(\frac{1}{273+t} - \frac{1}{273})\}$ 0°C [32°F]: 15 kΩ 10°C [50°F]: 9.7 kΩ 20°C [68°F]: 6.4 kΩ 25°C [77°F]: 5.3 kΩ 30°C [86°F]: 4.3 kΩ 40°C [104°F]: 3.1 kΩ	Resistance check
	TH2 (Inlet pipe temperature)		Indoor unit control (Hot adjust)		
	TH3 (Outlet pipe temperature)		Indoor unit control (Error detection)		
	TH4 Outdoor air temperature)		Indoor unit control (Thermo)		
	Temperature sensor (Indoor air temperature)		Indoor unit control (Thermo)		
Pressure sensor (inner water)	PS1		1) Detects inner water pressure 2) Check flow rate	<p>PS1                      Pressure 0~1.0 MPa [145psi]                      Vout 0.5~4.5V                      0.392V/0.098 MPa [14psi]                      Pressure [MPa] = 0.25 x Vout [V] - 0.125                      Pressure [psi] = (0.25 x Vout [V] - 0.125) x 145                      1 GND (Black)                      2 Vout (White)                      3 Vcc (DC5V) (Red)</p>	
Pressure sensor (outlet water)	PS2		1) Detects outlet water pressure 2) Check flow rate	<p>PS1                      Pressure 0~1.0 MPa [145psi]                      Vout 0.5~4.5V                      0.392V/0.098 MPa [14psi]                      Pressure [MPa] = 0.25 x Vout [V] - 0.125                      Pressure [psi] = (0.25 x Vout [V] - 0.125) x 145                      1 GND (Black)                      2 Vout (White)                      3 Vcc (DC5V) (Red)</p>	

**Note**

Some parts are not built in, depending on the connected indoor units.


Component	Sym-bol	
Room temperature thermistor	TH21	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ
Water inlet pipe thermistor	TH22	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ
Water outlet pipe thermistor	TH23	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ

# 3-5 External Appearance and Refrigerant Circuit Components of HBC


## 3-5-1 Main HBC

### 1. External view


#### (1) CMB-WM350,500F-AA




2. Front side




3. Rear side



#### 4. Front side (bottom)



#### 5. Front side (top)







### 3-5-2 Sub HBC

#### 1. Front


##### (1) CMB-WM1016V-BB



##### (2) CMB-WM108V-BB




#### 2. Rear right side




### 3. Top side

#### (1) CMB-WM1016V-BB



Valve block  
(VB3f)

#### (2) CMB-WM108V-BB




Valve block  
(VB3e)

# 3-6 HBC Refrigerant Circuit Diagrams


## 1. HBC

### (1) CMB-WM350, 500F-AA




2. Sub-HBC

(1) CMB-WM108V-BB




(2) CMB-WM1016V-BB



### 3-7 Functions of the Major Components of HBC

#### (1) HBC

Part name	Symbols	Notes	Usage	Specifications	Check method
Solenoid valve	SV1	Refrigerant side	Opens during the cooling mode and defrost cycle	AC220-240V Open when energized/ closed when de-energized	Continuity check with a tester
4-way valve	21S4Ma,b	Refrigerant side	Switches between heating and cooling	AC220-240V Open when energized/ closed when de-energized	Continuity check with a tester
LEV	LEV1	Refrigerant side	Supplies refrigerant to Heating-main heat exchanger	DC12V Opening of a valve driven by a stepping motor 0~3000 pulses	Continuity check with a tester. Continuity between white, red, and orange. Continuity between yellow, brown, and blue. 
	LEV2	Refrigerant side	Supplies refrigerant to Cooling-main heat exchanger		
	LEV3	Refrigerant side	Subcool control		
Thermistor	TH11,12, T13,14	Refrigerant side	Compressor frequency control LEV opening adjustment	$R_0 = 15k\Omega$ $R_{0/80} = 3460$ $R_t = 15 \exp\{3460 (\frac{1}{273+t} - \frac{1}{273})\}$  0°C[32°F] :15kΩ 10°C[50°F] :9.7kΩ 20°C[68°F] :6.4kΩ 25°C[77°F] :5.3kΩ 30°C[86°F] :4.3kΩ 40°C[104°F] :3.1kΩ	
	TH15,16		Bypass superheat amount adjustment		
	TH31a~f	Water side	Indoor unit circulating water control		
	TH32,33		Indoor unit circulating water control		
	TH34,35		Water pump error detection		

Part name	Symbols	Notes	Usage	Specifications	Check method
Pressure sensor	PS1 (high pressure side)	Refrigerant side	1) Detects high pressure 2) LEV control	<p>Pressure 0~4.15 MPa [601psi] Vout 0.5~3.5V 0.071V/0.098 MPa [14psi] Pressure [MPa] =1.38 x Vout [V]-0.69 Pressure [psi] =(1.38 x Vout [V] - 0.69) x 145</p> <p>1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
	PS3 (medium pressure side)		1) Detects medium pressure 2) LEV control		
Pw1 (Pump1 inlet pressure)		Water side	1) Detects pump1 water inlet pressure 2) Water flow control	<p>Pressure 0~1.0 MPa [145psi] Vout 0.5~4.5V 0.392V/0.098 MPa [14psi] Pressure [MPa] =0.25 x Vout [V]-0.125 Pressure [psi] =(0.25 x Vout [V] - 0.125) x 145</p> <p>1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
Pw2 (Pump1 outlet pressure)	Water side	1) Detects pump1 water outlet pressure 2) Water flow control			
Pw3 (Pump2 inlet pressure)	Water side	1) Detects pump2 water inlet pressure 2) Water flow control			
Pw4 (Pump2 outlet pressure)	Water side	1) Detects pump2 water outlet pressure 2) Water flow control			
Valve block	VB3a~f <sup>*1</sup>	Water side	1) Switches the water flow path depending on the operation mode 2) Temperature difference control (Water flow to each indoor unit is controlled.)		
Pump	PUMP1,2	Water side	Temperature difference control (Water flow to each indoor unit is controlled.)	Rated voltage DC268V Specified voltage DC0-6V	
Water pressure protection valve	CPV1	Water side	Trips when the internal pressure in the water circuit rises	Operating pressure: 560 kPa	
3-way valve	MV1	Water side	Supplies water to the Pump 1 side or the Pump 2 side	DC12V Opening of a valve driven by a stepping motor <sup>*3</sup>	

\*1. The names of port "a" through "f" are corresponding to port 1 through 6.

\*2. For the degree of valve opening, "85" or "1600" indicates fully open and "800" indicates fully closed.

\*3. Valve opening: 800 = connection to both pump 1 and pump 2; 1600 = connection to pump 1; 85 = connection to pump 2

**(2) Sub-HBC**

Part name	Symbols	Notes	Usage	Specifications	Check method
Thermistor	TH31a~p <sup>*1</sup> , TH32, 33	Water side	Indoor unit circulating water control	Same as the table above	
Valve block	VB3a~p <sup>*1</sup>	Water side	1) Switches the water flow path depending on the operation mode 2) Temperature difference control (Water flow to each indoor unit is controlled.)	DC12V Opening of a valve driven by a stepping motor <sup>*2</sup>	

\*1. The names of port "a" through "p" are corresponding to port 1 through 16.

\*2. For the degree of valve opening, "0" or "1600" indicates fully open and "800" indicates fully closed.

---

## Chapter 4 Electrical Components and Wiring Diagrams

<b>4-1</b>	<b>Outdoor Unit Circuit Board Arrangement</b> .....	<b>1</b>
4-1-1	Outdoor Unit Control Box.....	1
<b>4-2</b>	<b>Outdoor Unit Circuit Board Components</b> .....	<b>6</b>
4-2-1	Control Board.....	6
4-2-2	Power-supply board (PS Board) .....	7
4-2-3	Inverter Board (INV Board) .....	9
4-2-4	Fan Board .....	12
4-2-5	Noise Filter .....	13
4-2-6	Filter Board .....	15
4-2-7	Capacitor Board (CAP Board).....	16
<b>4-3</b>	<b>Outdoor Unit Electrical Wiring Diagrams</b> .....	<b>17</b>
<b>4-4</b>	<b>Transmission Booster Electrical Wiring Diagrams</b> .....	<b>20</b>
<b>4-5</b>	<b>HBC Circuit Board Arrangement</b> .....	<b>21</b>
4-5-1	HBC and Sub-HBC Control Box .....	21
<b>4-6</b>	<b>HBC Circuit Board Components</b> .....	<b>22</b>
4-6-1	HBC and Sub-HBC Circuit Board .....	22
<b>4-7</b>	<b>HBC Electrical Wiring Diagrams</b> .....	<b>27</b>
4-7-1	HBC and Sub-HBC Electrical Wiring Diagrams .....	27






## 4-1 Outdoor Unit Circuit Board Arrangement


### 4-1-1 Outdoor Unit Control Box

#### <HIGH VOLTAGE WARNING>



- Control box houses high-voltage parts.
- When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.
- Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage of the capacitor in the main circuit has dropped to 20 VDC or less.


#### (1) PURY-(E)M200, (E)M250, (E)M300YNW-A1



#### Note

- 1) Exercise caution not to damage the front panel of the control box. Damage to this part affect the waterproof and dust proof properties of the control box and may result in damage to its internal components.
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) **Perform the service after disconnecting the relay connector in the INV box (RYFAN1). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 5) To connect wiring to TB7 in the MAIN BOX, check that the voltage is 20 VDC or below.
- 6) After servicing, reconnect the relay connector (RYFAN1) in the INV box as it was.
- 7) When opening or closing the front panel of the control box, do not touch any of the internal components. Before inspecting inside the control box, turn off the power to the unit, leave it turned off for at least 10 minutes, and check that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 8) When the power is on, the compressor is energized even while it is stopped. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. It is energized to evaporate the liquid refrigerant that has accumulated in the compressor.


MAIN BOX



**Note**

- 1) Leave the grounding connected during maintenance.


INV BOX



**Note**

- 1) Refrigerant pipes are connected to the back of the INV box. Do not forcibly pull out the INV box. Doing so may result in deformation of the pipe.
- 2) A Faston terminal on the inrush current resistor has a locking function. Check that the terminal is securely locked in place. Press the tab in the middle of the terminal to remove it.
- 3) Leave the grounding connected during maintenance.
- 4) Connecting the RYRS2 cable to the RYPN terminal will damage the FAN board.

**(2) PURY-(E)M350, (E)M400, (E)M450YNW-A1**




\*The figure above shows the unit seen from the left after the front panel and the left side panel were removed.

**Note**

- 1) Refrigerant pipes are connected to the back of the control box. Do not forcibly pull out the control box. Doing so may result in deformation of the pipe.
- 2) Exercise caution not to damage the front panel of the control box. Damage to this part affect the waterproof and dust proof properties of the control box and may result in damage to its internal components.
- 3) A Faston terminal on the inrush current resistor has a locking function. Check that the terminal is securely locked in place. Press the tab in the middle of the terminal to remove it.
- 4) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 5) **Perform the service after disconnecting the relay connector in the INV box (RYFAN1 and RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 6) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 7) After servicing, reconnect the relay connector (RYFAN1 and RYFAN2) in the INV box as it was.
- 8) When opening or closing the front panel of the control box, do not touch any of the internal components. Before inspecting inside the control box, turn off the power to the unit, leave it turned off for at least 10 minutes, and check that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 9) When the power is on, the compressor is energized even while it is stopped. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. It is energized to evaporate the liquid refrigerant that has accumulated in the compressor.
- 10) Connecting the RYRS2 cable to the RYPN terminal will damage the FAN board.

### (3) PURY-(E)M500YNW-A1




**Note**

- 1) Refrigerant pipes are connected to the back of the control box. Do not forcibly pull out the control box. Doing so may result in deformation of the pipe.
- 2) Exercise caution not to damage the front panel of the control box. Damage to this part affect the waterproof and dust proof properties of the control box and may result in damage to its internal components.
- 3) A Faston terminal on the inrush current resistor has a locking function. Check that the terminal is securely locked in place. Press the tab in the middle of the terminal to remove it.
- 4) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 5) **Perform the service after disconnecting the relay connector in the INV box (RYFAN1 and RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 6) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 7) After servicing, reconnect the relay connector (RYFAN1 and RYFAN2) in the INV box as it was.
- 8) When opening or closing the front panel of the control box, do not touch any of the internal components. Before inspecting inside the control box, turn off the power to the unit, leave it turned off for at least 10 minutes, and check that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN in the INV box is 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 9) When the power is on, the compressor is energized even while it is stopped. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. It is energized to evaporate the liquid refrigerant that has accumulated in the compressor.
- 10) Connecting the RYRS2 cable to the RYPN terminal will damage the FAN board.

# 4-2 Outdoor Unit Circuit Board Components


## 4-2-1 Control Board



\*For information about the display of SW4 function settings, refer to the following page(s). [5-1-1 Outdoor Unit Switch Functions and Factory Settings]


## 4-2-2 Power-supply board (PS Board)

### (1) PURY-(E)M200, (E)M250, (E)M300YNW-A1






**(2) PURY-(E)M350, (E)M400, (E)M500YNW-A1**



### 4-2-3 Inverter Board (INV Board)


#### (1) PURY-(E)M200, (E)M250, (E)M300YNW-A1



**Note**

- When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- A Faston terminal on the inrush current resistor has a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- Control box houses high temperature parts. Be well careful even after turning off the power source.
- Perform the service after disconnecting the relay connector (RYFAN1). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across pins 1 and 5 of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.**
- After servicing, reconnect the relay connector (RYFAN1) of the fan as it was.
- When the power is turned on, the compressor is energized even while it is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. The liquid refrigerant in the compressor will evaporate by energizing the compressor.


## (2) PURY-(E)M350, (E)M400, (E)M450YNW-A1



### Note

- 1) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 2) A Faston terminal on the inrush current resistor has a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) **Perform the service after disconnecting the relay connector (RYFAN1, RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across pins 1 and 5 of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 5) After servicing, reconnect the relay connector (RYFAN1, RYFAN2) of the fan as it was.
- 6) When the power is on, the compressor or heater is energized even while the compressor is stopped. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. It is energized to evaporate the liquid refrigerant that has accumulated in the compressor.


**(3) PURY-(E)M500YNW-A1**



**Note**

- 1) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 2) A Faston terminal on the inrush current resistor has a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) **Perform the service after disconnecting the relay connector (RYFAN1, RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across pins 1 and 5 of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 5) After servicing, reconnect the relay connector (RYFAN1, RYFAN2) of the fan as it was.
- 6) When the power is turned on, the compressor is energized even while it is not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. The liquid refrigerant in the compressor will evaporate by energizing the compressor.

### 4-2-4 Fan Board




**Note**


- 1) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the capacitor voltage (inverter main circuit) has dropped to 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 2) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 3) **Perform the service after disconnecting the relay connector (RYFAN1, RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across pins 1 and 5 of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 4) To connect wiring to TB7, check that the voltage is 20 VDC or below.
- 5) After servicing, reconnect the relay connector (RYFAN1, RYFAN2) of the fan as it was.

### 4-2-5 Noise Filter

#### (1) PURY-(E)M200, (E)M250, (E)M300, (E)M350, (E)M400, (E)M450YNW-A1




(2) PURY-(E)M500YNW-A1



### 4-2-6 Filter Board


#### (1) PURY-(E)M500YNW-A1





### 4-2-7 Capacitor Board (CAP Board)

#### (1) PURY-(E)M350, (E)M400, (E)M450YNW-A1




**Note**

- 1) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the capacitor voltage (inverter main circuit) has dropped to 20 VDC or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.
- 2) A Faston terminal on the inrush current resistor has a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.
- 3) Control box houses high temperature parts. Be well careful even after turning off the power source.
- 4) **Perform the service after disconnecting the relay connector (RYFAN1, RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across pins 1 and 5 of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions.** Refer to the wiring nameplate for details.
- 5) After servicing, reconnect the relay connector (RYFAN1, RYFAN2) of the fan as it was.

# 4-3 Outdoor Unit Electrical Wiring Diagrams

## (1) PURY-(E)M200, (E)M250, (E)M300YNW-A1



- \*1. Single-dotted lines indicate wiring not supplied with the unit.
- \*2. Dot-dash lines indicate the control box boundaries.
- \*3. Refer to the Data book for connecting input/output signal connectors.
- \*4. Daisy-chain terminals (TB3) on the outdoor units in the same refrigerant system together.
- \*5. Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion. Press the tab on the terminals to removed them.
- \*6. Control box houses high-voltage parts. Before inspecting the inside of the MAIN BOX or INV BOX, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage of the connector RYPN on INV BOX has dropped to DC20V or less.
- \*7. Control board LED display.
  - LED2 Normal operation (LED on/blink)
  - LED3 SW6-10 is OFF and in operation (LED in stop/Unit)
  - LED4 SW4-1-10 are OFF and in operation (LED in stop/Unit)
  - LED5 SW6-10 is ON and in operation (LED in stop/Unit)
  - LED101 Normal operation (LED on/blink)
  - LED102 Function setting by SW4 (LED on/blink)
  - LED103 Error (LED on/blink)

- \*8. Difference of appliance.
 

Model name	Appliance
PURY	'8 exist
PURY	'9 do not exist
- \*9. Difference of appliance.
 

Model name	Appliance
PURY	LEDV9
PURY	LEDV9
- \*10. Difference of appliance.
 

Model name	Appliance
PURY	LEDV9
PURY	LEDV9
- \*11. Difference of appliance.
 


Model name	Appliance
PURY-AM	'11 do not exist
PURY-EM	'11 exist

<Symbol explanation>

Symbol	Explanation
Z1S4B	Coil/gating switching
Z1S4D	Coil/gating capacity control (only PURY model)
63H1	Pressure
63HS1	High pressure protection for the coil/exchanger for inverter
63LS	Discharge pressure
ACC1/ACC2	Current sensor (AC)
C700 C701, C705 C706	Capacitor (inverter main circuit)
DCL	Diode con (for high frequency noise reduction)
LEV1 *10	Pressure sensor
LEV2a,b	Pressure control, Refrigerant flow rate control
LEV2a *9	Pressure control, Refrigerant flow rate control (discharge pipe temperature)
LEV4	Heat exchanger for inverter
LEV9 *9,10	Heat exchanger for inverter
RT.5	Resistor
RS401/02/03	For current detection
SV1a	Solenoid valve
SV2	valve
SV9 *8	For opening/closing the discharge circuit bypass
SV10 *8	For opening/closing the bypass circuit
SV14,15 *11	For continuous heating
TB1	Terminal
TB3	Terminal block
TB2 *8	Thermistor
TH4	Discharge pipe temperature
TH5	ACC inlet pipe temperature
TH6 *8	Subcooled liquid refrigerant temperature
TH7	O.A temperature
TH15	Compressor shell bottom temperature
TH15	IPM temperature
TH15/02	Magnetic relay (inverter main circuit)
Z22,Z24,Z25	Function setting connector

**(2) PURY-(E)M350, (E)M400, (E)M450YNW-A1**

**4 Electrical Components and Wiring Diagrams**



- \*1 Single-dotted lines indicate wiring not supplied with the unit.
- \*2 Dot-dash lines indicate the control box boundaries.
- \*3 Refer to the Data book for connecting input/output signal connectors.
- \*4 Daisy-chain terminals (TB3) on the outdoor units in the same refrigerant system together.
- \*5 Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion. Press the tab on the terminals to removed them.
- \*6 Control box houses high-voltage parts. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage of the connector RYPN has dropped to DC20V or less.
- \*7 Control board LED display.

LED3	Normal operation LED (Error/OK)
LED3	SW45-10 is OFF and SW46-10 is ON (In operation/LED in stop/Unit)
LED3	SW45-10 is ON and SW46-10 is OFF (Error/LED disabled/Unit)
LED101	Normal operation LED (Error/OK)

**\*8. Difference of appliance.**

Model name	Appliance
PURY	'3' exist
PURY	LEV9
PURY	LEV9

**\*9. Difference of appliance.**

Model name	Appliance
PURY	LEV9
PURY	LEV20

**\*10. Difference of appliance.**

Model name	Appliance
PURY	LEV9
PURY	LEV9


**\*11. Difference of appliance.**

Model name	Appliance
PURY	LEV9
PURY	LEV9

**<Symbol explanation>**

Symbol	Explanation
Z1S4a	4-way valve
Z1S4b	Coil/Heating switching
63H1	Pressure switch
63H1	Pressure switch
63S1	Pressure sensor
63S1	Pressure sensor
ACC1, ACC2	Capacitor (inverter main circuit)
DC	DC reactor
DC	Choke coil (for high frequency noise reduction)
LEV1*10	Linear expansion valve
LEV2a/b	Pressure control/Refrigerant flow rate control
LEV2a'9	Pressure control/Refrigerant flow rate control
LEV9'9, 10	Heat exchanger for inverter
RF1	Fan motor (for cooling in control box)
RF1	Resistor
RF1	For inverter speed prevention
RF1	For opening/closing the bypass circuit under the OSE
RF1	For opening/closing the discharge suction bypass
SV9'9	For opening/closing the bypass circuit
SV10'8	For continuous heating
SV14, 15'11	For changing refrigerant flow (cooling/heating)
TB1	Terminal block
TB3	Indoor/outdoor transmission line
TB2'3	Indoor control transmission line
TB3	Five terminal
TH4	Discharge pipe temperature
TH5	ACC inlet pipe temperature
TH6'9	Sub-cooled liquid refrigerant temperature
TH7	Oil temperature
TH15	Compressor shell bottom temperature
TH15	IPM temperature
X901, X202	Magnetic relay/inverter main circuit
Z2Z1, Z23	Function setting connector

**(3) PURY-(E)M500YNW-A1**



- \*1. Single-dotted lines indicate wiring not supplied with the unit.
- \*2. Dot-dash lines indicate the control box boundaries.
- \*3. Refer to the Data book for connecting input/output signal connectors.
- \*4. Daisy-chain terminals (TB3) on the outdoor units in the same refrigerant system together.
- \*5. Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion. Press the tab on the terminals to removed them.
- \*6. Control box houses high-voltage parts. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage of the connector RYPN has dropped to DC20V or less.
- \*7. Control board LED display.
 

LED2	Normal operation(LED/Normal)
LED3	SW4-10 is OFF and in operation(LED/In stop/Unlk)
LED3	SW4-10 is ON
LED101	Function setting by SW4
LED101	SW4-10 is OFF
LED101	Normal operation(LED/VC Error/Unlk)

- \*8. Difference of appliance.
 

Model name	Appliance
PURY	3-axis
PURY	3-axis
- \*9. Difference of appliance.
 


Model name	Appliance
PURY	LEV9
PURY	LEV9
- \*10. Difference of appliance.
 

Model name	Appliance
PURY	LEV9
PURY	LEV9

**<Symbol explanation>**

Symbol	Explanation
21SAa	Cooling/heating switching
21SAa.c	Heat exchanger capacity control(only PURY model)
63H	High pressure switching
63HS1	Pressure sensor
63LS	Low pressure
ACC1/ACC2	Current sensor(ACC)
C100-C109	Capacitor (inverter main circuit)
DCL	DC reactor
LEV1 *10	Choke coil (for high frequency noise reduction)
LEV2a,b,c	Linear expansion valve
LEV2d *9	Pressure control/Refrigerant flow rate control
LEV4	Pressure control/Refrigerant flow rate control
LEV9-9,10	For opening/closing the injection circuit
MF1,2	Heat exchanger for inverter
R1,5	Fan motor(for cooling in control box)
RS1010/203	Resistor
SV1a	For inrush current prevention
SV2	For opening/closing the bypass circuit under the O/S
SV2	For opening/closing the discharge suction bypass
SV9 *8	For opening/closing the bypass circuit
SV10,11 *8	For continuous heating
TB3	Power supply transmission line
TB7	Central control transmission line
TH2 *8	Subcool bypass outlet temperature
TH3	Pipe temperature
TH4	Discharge pipe temperature
TH5	ACC inlet pipe temperature
TH6 *8	Subcooled liquid refrigerant temperature
TH7	QA temperature
TH5	Compressor shell bottom temperature
TH15	IPM temperature
X101-X103	Magnetic relay(inverter main circuit)
ZZ2,Z1,Z5	Function setting connector


# 4-4 Transmission Booster Electrical Wiring Diagrams




## 4-5 HBC Circuit Board Arrangement

### 4-5-1 HBC and Sub-HBC Control Box

#### 1. CMB-WM350, 500F-AA




#### 2. CMB-WM108V, 1016V-BB



# 4-6 HBC Circuit Board Components


## 4-6-1 HBC and Sub-HBC Circuit Board

### 1. Control board



## 2. PS board

LED 01  
Lit: Microcomputer is energized  
Unlit: Microcomputer is not energized  
LED 02  
Lit: Converter operation  
Blinking: Converter error







### 3. INV board

LED01  
Lit: Inverter operation  
Blinking: Inverter error  
LED04  
Lit: Microcomputer in operation

SW001  
Address switch




### 4. VB board



CN991  
Battery box




### 5. SUB PS board



# 4-7 HBC Electrical Wiring Diagrams

## 4-7-1 HBC and Sub-HBC Electrical Wiring Diagrams


### (1) CMB-WM350, 500F-AA



(Symbol explanation)


Symbol	Name
Z1SMA, 21S4Nb	4 way valve
ACL	AC reactor
C150, C153-C155	Capacitor
C156, C158, C170, C171	Capacitor
DS405	Diode
DS401	Diode
F001-F011	Fuse AC50V/8A
F101, F110	Fuse AC50V/15A
F121, F122	Fuse AC250V/6.3A
F131, F132	Fuse AC250V/3.15A
LV1-LV3	Expansion Valve
MV1	3 way valve
NR001-NR003	Relay
PS1-PS3, PM1-PW4	Pressure Sensor
SV1	Solenoid Valve
SW1, SW2, SW003, SW011, SW1P-SW1P03, SW011, SW012	Switch(Device Setting)
TB1	Terminal Block (for power source)
TB3	Terminal Block (for Transmission)
TH11-TH16, TH32-TH35	Thermister
TH31P-TH31T	Sensor
WP1, WP2	Valve Block
X01-X03, X52	Pump
Z1ZZ	Auxiliary Relay
	Function setting connector

NOTE:1. TB3 is transmission terminal block.  
 Never connect power line to it.  
 2. The initial set values of switch on Control Board are as follows.  
 SWU01-0  
 SWU02-0  
 3. The wirings to TB1 and TB3 shown in dotted line are field work.




(2) CMB-WM108V-BB model

4 Electrical Components and Wiring Diagrams



X (See next paper for the details)

**(3) CMB-WM108V-BB model (Detail of X section)**




(Symbol explanation)

Symbol	Name
FS	Float switch
F01	Fuse AC250V 6.3A F
TB	Terminal block (for power source)
TB3	Terminal block (for Transmission)
TH31a-h, TH32-33	Thermister sensor
VB3a-h	Valve block
Z1, Z2	Function setting connector

- NOTE: 1. TB3 is transmission terminal block.  
 Never connect power line to it.  
 2. The initial set values of switch on Control Board are as follows.  
 SWU01:0  
 SWU02:0  
 3. The wirings to TB and TB3 shown in dotted line are field work.

**(4) CMB-WM1016V-BB model**


**4 Electrical Components and Wiring Diagrams**



X (See next paper for the details)

Y (See next paper for the details)

**(5) CMB-WM1016V-BB model (Detail of X, Y section)**



(Symbol explanation)

Symbol	Name
FS	Float switch
F01	Fuse AC250V 6.3A F
TB	Terminal block (for power source)
TB3	Terminal block (for Transmission)
TH31a~p, TH32~33	Thermister sensor
VB3a~p	Valve block
Z1,Z2	Function setting connector

- NOTE: 1. TB3 is transmission terminal block.  
 Never connect power line to it.  
 2. The initial set values of switch on Control Board are as follows.  
 SWU01:0  
 SWU02:0  
 3. The wirings to TB and TB3 shown in dotted line are field work.





---

## Chapter 5 Control

<b>5-1</b>	<b>Dipswitch Functions and Factory Settings</b> .....	<b>1</b>
5-1-1	Outdoor Unit Switch Functions and Factory Settings .....	1
5-1-2	Indoor Unit Switch Functions and Factory Settings .....	6
5-1-3	Remote Controller Switch Functions and Factory Settings .....	7
5-1-4	Switch Functions <HBC> .....	9
<b>5-2</b>	<b>Outdoor Unit Control</b> .....	<b>11</b>
5-2-1	Overview .....	11
5-2-2	Initial Control .....	11
5-2-3	Startup Control .....	11
5-2-4	Refrigerant Bypass Control .....	12
5-2-5	Frequency Control .....	13
5-2-6	Defrost Operation Control .....	14
5-2-7	Refrigerant Recovery Control .....	17
5-2-8	Outdoor Unit Fan Control .....	18
5-2-9	Expansion valve control (LEV2a, LEV2b, LEV2c, and LEV2d).....	19
5-2-10	Control of Controller Cooling Function (Electronic Expansion Valve <LEV9>).....	19
5-2-11	Injection Control (Linear Expansion Valve <LEV4>).....	19
5-2-12	Control at Initial Startup .....	19
5-2-13	Operation Mode .....	20
5-2-14	Demand Control.....	21
5-2-15	Control of IH energization without the compressor in operation .....	21
<b>5-3</b>	<b>HBC Control</b> .....	<b>22</b>
5-3-1	Water Pump Control .....	22
5-3-2	4-Way Valve Control .....	23
5-3-3	Valve Block (VB3) Water Flow Rate Adjustment .....	24
5-3-4	Valve Block (VB3) Water Flow Path Switching Control .....	25
5-3-5	Bypass Control.....	26
5-3-6	Plate Heat Exchanger Control .....	26
5-3-7	Defrost Operation Control .....	27
5-3-8	Refrigerant Recovery Control .....	31
5-3-9	Backup Control .....	31
5-3-10	Water Pump Protection Control .....	32



# 5-1 Dipswitch Functions and Factory Settings

## 5-1-1 Outdoor Unit Switch Functions and Factory Settings

### (1) Control board


Switch		Function	Function according to switch setting		Switch setting timing	
			OFF	ON		
SWU	1-2	Unit address setting	Set to 00 or 51-100 with the dial switch		Before power on	
SW5	1	Centralized control switch	Without connection to the centralized controller	With connection to the centralized controller	Before power on	
	2	Deletion of connection information	Normal control	Deletion	Before power on	
	3	-	Preset before shipment			
	4	-				
	5	-				
	6	-				
	7	-				
	8	-				
	9	-				
	10	-	-	-	-	-
SW6	1	-	-	-	-	-
	2	-	-	-	-	-
	3	-	-	-	-	-
	4	Model setting (outdoor unit/high static pressure setting)	High static pressure (Note 4)		Before power on	
	5	Model setting (outdoor unit/high static pressure setting)			Before power on	
	7	Performance-priority/low-noise mode setting	Performance-priority mode (Note 2)	Quiet-priority mode	Anytime after power on	
	8	Low-noise mode/step demand switching	Low-noise mode (Note 3)	Step demand mode	Before power on	
	9	Self-diagnosis monitor display / SW4 function setting mode switching	Note 7	Note 7	Anytime after power on	
	10					

Switch		Function	Function according to switch setting		Switch setting timing
			OFF	ON	
SW7	1	Enables or disables the detection of the following types of inverter compressor errors ACCT, DCCT sensor error(5301 Detail code 115, 116) ACCT, DCCT sensor circuit error(5301 Detail code 117, 118) IPM open-phase/CNCT2 connection error(5301 Detail code 119) Wiring connection error(5301 Detail code 120)	Error detection enabled	Error detection disabled (no-load operation allowed)	Any time after power on
	2	Enables or disables no-load operation of the fan inverter The unit continues no-load operation for 30 seconds and comes to an error stop. See the relevant pages for details: [8-10-9 Checking the Fan Board for Damage at No Load]	No-load operation disabled	No-load operation enabled	Any time after power on
	3	-	-	-	-
	4	-	-	-	-
	5	-	-	-	-
	6	-	-	-	-
	7	-	-	-	-
	8	-	-	-	-
	9	Switches between the normal startup mode and the USB writer rewrite mode	Normal startup mode	USB writer rewrite mode	Before power on
	10	-	-	-	-

**Note**

- 1) Unless otherwise specified, leave the switch to OFF where indicated by "-" or where the cells are blank, which may be set to OFF for a reason.
- 2) When set to the performance-priority mode, the low-noise mode will be terminated, and the units will operate in the normal mode.  
Cooling: Ambient temperature or the high pressure is high.  
Heating: When the outside air temperature is low or when the low pressure is low. Refer to the following page(s). [2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit]
- 3) Operation noise is reduced by controlling the compressor frequencies and the rotation speed of the outdoor unit fans. CN3D needs to be set. Refer to the following page(s). [2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit]
- 4) Selectable with the function switches SW6-4 and SW6-5.

		SW6-5	
		ON	OFF
SW6-4	ON	80 Pa	60 Pa
	OFF	30 Pa	0 Pa

- 5) Keep SW7-1, and -2 set to OFF during normal operation. Leaving these switches to ON will disable the error-detection function and can lead to equipment damage.
- 6) Shaded areas (  ) indicate factory settings.

7) Selectable with the function switches SW6-9 and SW6-10.

		SW6-10	
		ON	OFF
SW6-9	ON	Self-diagnosis monitor display (round type LED) No. 0 to 1023	Self-diagnosis monitor display (7seg LED) No. 1024 to 2047
	OFF	SW4 function setting mode No. 0 to 1023	Self-diagnosis monitor display (7seg LED) No. 0 to 1023

Switch		Function		Function according to switch setting		Switch setting timing	
				OFF (LED3 Unlit)	ON (LED3 Lit)		
SW4 SW6-10: OFF	1-10 1:ON, 0:OFF	Self-diagnosis/operation monitor		Refer to the following page(s). [10 LED Status Indicators]		Anytime after power on	
SW4 1-10 [0:OFF, 1:ON] (Note 1) SW6-10:ON	No.769	1000000011	Test run mode: ON/OFF		Stops all ICs	Sends a test-run signal to all IC	Anytime after power on
	No.817	1000110011	Starts up drive recorder		Enabled	Disabled	Anytime after power on
	No.818	0100110011	Data collection during an error		Disabled	Enabled	Anytime after power on
	No.832	0000001011	Cumulative compressor operation time deletion		Retained	Cleared	Anytime after power on (OFF → ON)
	No.848	0000101011	Continuous heating cycle function		Disabled	Enabled	After being energized and while the compressor is stopped
	No.876	0011011011	High-pressure over-rise backup setting		SV2 is used.	LEV9 is used.	After being energized and while the compressor is stopped
	No.885	1010111011	Fan speed setting at low outside temperature heating		Refer to Note 8).		After being energized and while the compressor is stopped
	No.886	0110111011					After being energized and while the compressor is stopped
	No.891	1101111011	Smooth auto-shift startup mode		Disabled	Enabled	After being energized and while the compressor is stopped
	No.896	0000000111	Clearance of error history SW	OC	Retained (IC/OC)	Deleted (IC/OC)	Anytime after power on (OFF → ON)
	No.897	1000000111	High sensible heat operation setting		Depends on the combined setting with No. 900 (Note 7)		Anytime after power on (OFF → ON)
	No.900	0010000111	High sensible heat operation setting		Depends on the combined setting with No. 897 (Note 7)		Anytime after power on (OFF → ON)
	No.912	0000100111	Pump down function		Normal control	Pump down operation	After being energized and while the compressor is stopped
	No.913	1000100111	Forced defrost (Note 2)		Normal control	Forced defrost starts	10 minutes after the completion of defrost operation (OFF → ON) or 10 minutes after compressor start-up (OFF → ON)
	No.915	1100100111	Defrost start temperature (Note 2)		(E)P200, (E)P250: -10°C [14°F] (E)P300 ~ (E)P500: -8°C [18°F]	-5°C [23°F]	Anytime after power on
	No.916	0010100111	Defrost end temperature (Note 2)		7°C [45°F]	12°C [54°F]	Anytime after power on
	No.918	0110100111	Changes the defrost timer setting (Note 2)		50 minutes	90 minutes	Anytime after power on (OFF → ON)
	No.921	1001100111	Temperature unit display		°C	°F	Anytime after power on
	No.922	0101100111	Refrigerant amount adjustment		Normal control	Refrigerant amount adjust mode	Anytime after power on (except during initial startup/becomes ineffective 90 minutes after compressor started up.)
	No.933	1010010111	Snow sensor setting		Effective only when TH7 ≤ 5 is true or the snow sensor contact input is on.	Effective when TH7 ≤ 5 is true	Anytime after power on
No.934	0110010111	Snow sensor setting		Continuous fan operation (FAN=50%)	Intermittent fan operation (100% for 5 minutes ↔ 0% for 30 minutes)	Anytime after power on	
No.935	1110010111	High heating power (at low outside temperature)		Effective	Ineffective	Anytime after power on	
No.956	0111011110	SV2 control time setting after recovery from defrost		Always ON	5 minutes	After being energized and while the compressor is stopped	
No.958	0111110111	Clear the history of completing initial control		Retained	Cleared	After being energized and while the compressor is stopped * Effective only OFF to ON	
No.982	0110101111	Target evaporation temperature setting		Refer to Note 3).		Anytime after power on	
No.997	1010011111	Multiple-stage low-noise setting		Depends on the combined setting with No. 1006 (Note 6)		After being energized and while the compressor is stopped	
No.1006	0111011111			Depends on the combined setting with 997 (Note 7)		After being energized and while the compressor is stopped	

**Note**

- 1) To change the settings, set SW6-10 to ON, set SW4, and press and hold SWP3 for 2 seconds or longer (OFF ↔ ON). LED3 will light up when the switch setting is ON, and lights off when OFF. Use the LED3 display to confirm that the settings are properly made. The settings will need to be set again when the control board is replaced. Write down the settings on the electrical wiring drawing label.
- 2) For details, refer to the following page(s).[5-2-6 Defrost Operation Control]
- 3) The table below shows how the target evaporation temperature is set with SW4 (982).

SW4(982)	OFF → ON → OFF → ON → OFF → ON
Target evaporating temperature	0°C → -2°C → 0°C → -4°C → 0°C → -6°C [32°F] [28°F] [32°F] [25°F] [32°F] [21°F]

\*SW4 (982) setting will not automatically be restored after the control board is replaced. (The function of SW4 is explained in Note 5.) When using the function of SW4, write down the SW4 (982) setting on the control board panel, and manually reset the setting after the control board is replaced.

- 4) Unless otherwise specified, leave the switch to OFF where indicated by "-" or where the cells are blank, which may be set to OFF for a reason.
- 5) The settings that are configured with SW4 (SW6-10: ON) will automatically be stored on the indoor units that support the new function\*. The stored settings will automatically be restored when the outdoor unit control board is replaced. Not applicable to SW4 (982).

If none of the connected indoor units supports the new function, no configuration information will be saved. If this is the case, manually record the settings configuration on the control box panel.

\*The new function is supported on most units that are manufactured in December of 2012 and later. Depending on the model, this function may be added on later date. Ask your dealer for further details.

- 6) The table below shows the modes selectable with the function switches SW (997) and SW4 (1006).

Switch		SW4(1006)	
		OFF	ON
SW4(997)	OFF	50% mode	60% mode
	ON	85% mode	70% mode

- 7) The table below shows the combinations of the settings for items No. 897 and No. 900 and the target evaporating temperature setting that corresponds to each combination.

Switch		No.900	
		OFF	ON
No.897	OFF	0°C [32°F]	9°C [48°F]
	ON	6°C [43°F]	14°C [57°F]

- 8) The table below shows the combinations of the settings for items No.885 and No.886 and the ratio of outdoor unit fan speed at low outside temperature heating setting that corresponds to each combination.

Switch		No.886	
		OFF	ON
No.885	OFF	Max	Middle
	ON	High	Low

- 9) Shaded areas (  ) indicate factory settings.

**(2) Fan board**

Switch		Function	Function according to switch setting		Switch setting timing
			OFF	ON	
SW1	1	Enabling/Disabling no-load operation No-load operation will continue for approximately 30 seconds, and then the unit will come to an abnormal stop. For details, refer to the following page(s). [8-10-9 Checking the Fan Board for Damage at No Load]	No-load operation disabled	No-load operation enabled	Anytime after power on
	2	-	-	-	-
	3	Address setting. See the notes below.	0	5	Before power on
	4		0	6	Before power on

**Note**

- Only the addresses are preset before shipment (All other switches are set to OFF.) Unless otherwise specified, leave the switch to OFF where indicated by "-", which may be set to OFF for a reason.
- To set the address for a unit with one fan, only set SW1-3 to ON (= address 5). To set the addresses for a unit with two fans, set SW1-3 on the fan board on the right side (when seen from the front of the control box) to ON (= address 5) and set SW1-4 on the left fan board to ON (= address 6).
- Leave SW1-1 to OFF during normal operation. Setting this switch to ON will disable the error detection function and may result in equipment damage.



## 5-1-2 Indoor Unit Switch Functions and Factory Settings

### (1) Dipswitches

1) SW1,3

Switch	Function	Function according to switch setting		Switch setting timing	Notes	
		OFF	ON			
SW1	1	Room temperature detection position	Indoor unit inlet	Built-in sensor on the remote controller		
	2	Clogged filter detection	Not available	Available		
	3	Filter check reminder time setting	100h	2500h		
	4	Outside air intake	Disabled	Enabled		
	5	Remote display option	Fan output	Thermo-ON signal		
	6	Humidifier control	During heating operation	Always on while in the heating mode		
	7	Fan speed setting for Heating Thermo-OFF	Very Low	Low		
		-	-	-		
	8	Fan speed setting for Heating Thermo-OFF	According to the SW1-7 setting	Preset speed		
		-	-	-		
9	Self-recovery after power failure	Disabled	Enabled	While the unit is stopped (Remote controller OFF)		
10	Power source start-stop	Disabled	Enabled			
SW3	1	Unit model selection	Heat pump		Cooling only	
	2	Louver	Not available		Available	PLFY-WP-VBM model only
	3	Vane	Not available		Available	PLFY-WP-VBM model only
	4	Vane swing function	Not available		Available	PLFY-WP-VBM model only
		Setting i-See sensor installation position	Setting pattern①*1		Setting pattern③*1	PLFY-WP-VFM model only
	5	Vane horizontal angle①*1	First setting*2		Second setting*2	PLFY-WP-VBM, PLYF-WP-VFM model only
	6	Vane horizontal angle②*1	Depends on SW3-5		Third setting*2	PLFY-WP-VBM model only
	7	-	-		-	
	8	Heating 4°C [7.2°F] up	Enabled	Disabled	Set to OFF on floor-standing (PFFY) type units	
	9	-	-	-	The setting depends on the model and type.	
10	-	-	-			

Note 1. Settings in the shaded areas are factory settings.

Note 2. If both SW1-7 and SW1-8 are set to ON, the fan remains stopped during heating Thermo-OFF.

To prevent incorrect temperature detection due to a build-up of warm air around the indoor unit, use the built-in temperature sensor on the remote controller (SW1-1) instead of the one on the indoor unit inlet thermistor.


\*1. Refer to the Installation Manual.

SW3-5	SW3-6	Vane setting	Initial setting	Setting	Vane position
OFF	OFF	Set up①*1		Standard	Standard
ON	OFF	Set up②*1	●	Less draft*3	Upward position than the standard
OFF	ON	Set up③*1		Less smudging	Downward position than the standard
ON	ON	unused		-	-

\*3. Be careful of smudge on ceiling.

2) SW2

Model	W/WP/WL10	W/WP/WL15	W/WP/WL20	W/WP/WL25	W/WP/WL32	W/WP/WL40	W/WP/WL50	W/WP/WL63
Capacity (model) code	2	3	4	5	6	8	10	13
SW2 setting								
Model	W/WP/WL71	W/WP/WL80	W/WP/WL100	W/WP/WL125				
Capacity (model) code	14	16	20	25				
SW2 setting								



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

**Note**

The setting timing for SW2 is before power is turned on.

**(2) Address switch**

Actual indoor unit address setting varies in different systems. Refer to the installation manual for the outdoor unit for details on how to make the address setting.

Each address is set with a combination of the settings for the 10's digit and 1's digit.

(Example)



When setting the address to "3", set the 1's digit to 3, and the 10's digit to 0.

When setting the address to "25", set the 1's digit to 5, and the 10's digit to 2.

**5-1-3 Remote Controller Switch Functions and Factory Settings**

**(1) MA simple remote controller (PAC-YT52CRA)**

There are switches on the back of the top case. Remote controller Main/Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW1. (The factory settings are ON for SW1, 2, and 3 and OFF for SW4.)



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.


SW No.	SW contents Main	ON	OFF	Comment	Switch setting timing
1	Remote controller Main/Sub setting	Main	Sub	Set one of the two remote controllers at one group to "ON".	Before power on
2	Temperature display units setting	Celsius	Fahrenheit	When the temperature is displayed in [Fahrenheit], set to "OFF".	Before power on
3	Cooling/heating display in AUTO mode	Yes	No	When you do not want to display "Cooling" and "Heating" in the AUTO mode, set to "OFF".	Before power on
4	Indoor temperature display	Yes	No	When you want to display the indoor temperature, set to "ON".	Before power on

**Note**

The MA remote controllers (PAR-31/32/33MAA, PAR-21MAA) do not have the switches listed above. Refer to the installation manual for the function setting.

**(2) ME remote controller (PAR-F27MEA)**

Set the address of the remote controller with the rotary switch.



Example: In case of address 108

	Address setting range	Setting method
Main remote controller	101-150	Add 100 to the smallest address of all the indoor units in the same group.
Sub remote controller	151-200	Add 150 to the smallest address of all the indoor units in the same group.
Setting of rotary switch	Address No.	
01-99 <sup>*1</sup>	101-199 with the 100's digit automatically being set to 1 <sup>*2</sup>	
00	200	

\*1. At factory shipment, the rotary switch is set to 01.

\*2. The address range that can be set with the ME remote controller is between 101 and 200. When the dials are set to a number between 01 and 99, the 100's digit is automatically set to [1]. When the dials are set to 00, the 100's digit is automatically set to [2].

**Note**

To set addresses, use a precision slotted screw driver [(-), 2.0 mm [0.08 in] (w)], and do not apply than 19.6N. The use of any other tool or applying too much load may damage the switch.

**Note**

The ME remote controllers (PAR-U02MEDA) do not have the switches listed above. Refer to the installation manual for the function setting.

### 5-1-4 Switch Functions <HBC>

(1) Control board

Switch	Function	Function according to switch setting		Switch setting timing	
		OFF	ON		
SW001	1	Water supply SW	Not available	Available: VB=0 or 1600	Any time after being energized
	2	Air vent SW	Not available	Available	Any time after being energized
	3	-	-	-	-
	4	-	-	-	-
	5	-	-	-	-
	6	-	-	-	-
	7	-	-	-	-
	8	-	-	-	-
	9	Heat recovery defrost	Available	Not available	Before being energized
	10	-	-	-	-
SW002	1	Debris removal run mode	Not available	Available	Any time after being energized
	2	-	-	-	-
	3	Test run air vent mode after strainer processing	Not available	Available	Any time after being energized
	4	Forced termination of a test run	Not available	Available	Any time after being energized
	5	Water tightness check	Not available (When the switch is set from ON to OFF, set the VB3 to the specified opening for stop-page.)	Available Two water pumps ON (output 30%) one minute after setting VB3 to 0 or 1600.	Any time after being energized (only when the control mode is stopped)
	6	Operation function 1 of the valve block	Not available	VB3=800	Any time after being energized
	7	Compatible with antifreeze-liquid 1	Refer to the Databook.		
	8	Compatible with antifreeze-liquid 2			
	9	Switches between the normal startup mode and the USB writer rewrite mode	Normal startup mode	USB writer rewrite mode	Before being energized
	10	-	-	-	-
SW011	1	-	-	-	-
	2	-	-	-	-
	3	-	-	-	-
	4	-	-	-	-
	5	-	-	-	-
	6	-	-	-	-
	7	-	-	-	-
	8	-	-	-	-

(2) Pump INV board

Switch		Function	Function according to switch setting		Switch setting timing
			OFF	ON	
SW1	1	-	-	-	-
	2	-	-	-	-
	3	Address setting. See the notes below.	0	5	Before power on
	4		0	6	Before power on


**Note**


- Only the addresses are preset before shipment (All other switches are set to OFF.) Unless otherwise specified, leave the switch to OFF where indicated by "-", which may be set to OFF for a reason.
- Set SW1-3 to ON to set the address to 5 (left pump INV board). Set SW1-4 to ON to set the address to 6 (right pump INV board)

## 5-2 Outdoor Unit Control

### 5-2-1 Overview

- The outdoor units are designated as OC in the order of capacity from large to small (if two or more units have the same capacity, in the order of address from small to large).
- The setting of outdoor unit can be verified by using the self-diagnosis switch (SW4).

SW4 (SW6-10:OFF)	Display
	<ul style="list-style-type: none"> <li>•The unit is designated as the OC: "OC" appears on the display.</li> </ul>



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- The OC determines the operation mode and the control mode, and it also communicates with the indoor units.

### 5-2-2 Initial Control

- When the power is turned on, the initial processing of the microcomputer is given top priority.
- During the initial processing, control processing of the operation signal is suspended. (The control processing is resumed after the initial processing is completed. Initial processing involves data processing in the microcomputer and initial setting of each of the LEV opening. This process will take up to 5 minutes.)
- During the initial processing, the LED monitor on the outdoor unit's control board displays S/W version → refrigerant type → Model and capacity → and communication address in turn every second.

### 5-2-3 Startup Control

- The upper limit of frequency during the first 3 minutes of the operation is 50 Hz.
- When the power is turned on, normal operation will start after the initial start-up mode (to be described later) has been completed (with a restriction on the frequency).
- In the Heating-Only or Heating-Main operation, the unit will not start when TH7 > 25°C. In the test run mode, the unit will start when TH7 > 25°C.

## 5-2-4 Refrigerant Bypass Control

Bypass solenoid valves, which bypass the high- and low- pressure sides, perform the following functions.

### (1) Bypass solenoid valve (SV1a) (ON = Open)

Operation	SV1a	
	ON	OFF
When starting-up the compressor of each outdoor unit	ON for 4 minutes.	
After the restoration of thermo or 3 minutes after restart	ON for 4 minutes.	
During cooling or heating operation with the compressor stopped	Always ON. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less	
After the operation has stopped	ON for 3 minutes. Exception: OFF when 63HS1-63LS is 0.2MPa[29psi] or less	
During defrost operation	ON	
While the compressor is operating at the minimum frequency and when the low pressure (63LS) drops (3 or more minutes after compressor startup)	When the low pressure (63LS) drops below 0.23 Mpa [33 psi] during cooling-only or cooling-main operation.	When the low pressure (63LS) drops below 0.38 Mpa [55 psi] during cooling-only or cooling-main operation.
When high pressure (63HS1) rises	When 63HS1 exceeds 3.62MPa[525psi]	When 63HS1 is 3.43MPa [497 psi] or below in 30 seconds

### (2) Bypass solenoid valve (SV2) (ON = Open)

Operation	SV2	
	ON	OFF
When high pressure (63HS1) rises during heating operation	While the compressor is operating at the minimum frequency and when 63HS1 exceeds 3.43 MPa [497 psi] during heating-only or heating-main operation	When 63HS is 2.65 MPa [384 psi] or below
When low pressure (63LS) drops during heating operation	When 63HS is below 1.47 MPa [213 psi] and 63LS is below 0.25 MPa [36 psi]	When 63HS is above 1.72 MPa [249 psi] or 63LS is above 0.39 MPa [56 psi]
When the defrost operation is completed	SW4(956)=OFF Always ON SW4(956)=ON ON for 5 minutes	
Others	Always OFF (Closed)	

### (3) Bypass LEV (LEV9)

Operation	LEV9	
	480 pulses	Normal control
When high pressure (63HS1) rises during heating operation •SW(876) = ON	While the compressor is operating at the minimum frequency and when 63HS1 exceeds 3.43 MPa [497 psi] during heating-only or heating-main operation	When 63HS is 2.65 MPa [384 psi] or below

## 5-2-5 Frequency Control

- Depending on the capacity required, the frequency of the compressor is controlled to keep constant evaporation temperature (0°C [32°F] = 0.71 MPa [103 psi]) during cooling operation, and condensing temperature (49°C [120°F] = 2.88 MPa [418 psi]) during heating operation.
- The table below summarizes the operating frequency ranges of the inverter compressor during normal operation.

Model	Frequency/cooling		Frequency/heating	
	Max	Min	Max	Min
M200	52Hz	18Hz	58Hz	18Hz
M250	65Hz	18Hz	74Hz	18Hz
M300	74Hz	18Hz	92Hz	18Hz
M350	95Hz	18Hz	107Hz	18Hz
M400	97Hz	37Hz	113Hz	37Hz
M450	111Hz	37Hz	124Hz	37Hz
M500	120Hz	37Hz	140Hz	37Hz
EM200	52Hz	18Hz	58Hz	18Hz
EM250	65Hz	18Hz	74Hz	18Hz
EM300	74Hz	18Hz	92Hz	18Hz
EM350	95Hz	18Hz	107Hz	18Hz
EM400	97Hz	37Hz	113Hz	37Hz
EM450	111Hz	37Hz	124Hz	37Hz
EM500	120Hz	37Hz	140Hz	37Hz

**Note**

The maximum frequency during heating operation depends on the outside air temperature and the dipswitch settings.

### (1) Pressure limit

The upper limit of high pressure (63HS1) is preset, and when it exceeds the upper limit, the frequency is decreased every 15 seconds.

- The actuation pressure is when the high-pressure reading on 63HS1 is 3.58MPa[519psi].

### (2) Discharge temperature limit

Discharge temperature (TH4) of the compressor in operation is monitored, and when it exceeds the upper limit, the frequency is decreased every minute.

- Operating temperature is 110°C [230°F].

### (3) Periodic frequency control

Frequency control other than the ones performed at start-up, upon status change, and for protection is called periodic frequency control (convergent control) and is performed in the following manner.

**Periodic control cycle**

Periodic control is performed after the following time has passed

- 30 seconds after either compressor start-up or the completion of defrost operation
- 30 seconds after frequency control based on discharge temperature or pressure limit

**The amount of frequency change**

The amount of frequency change is controlled to approximate the target value based on the evaporation temperature (Te) and condensing temperature (Tc).



## 5-2-6 Defrost Operation Control

### (1) Starting the defrost operation

•The defrost cycle will start when all of the three conditions (outside temperature, cumulative compressor operation time, and pipe temperature) under <Condition 1>, <Condition 2>, or <Condition 3> are met.

	Condition 1	Condition 2	Condition 3
Outside temperature (TH7)	-5°C [23°F] or above	-5°C [23°F] or below	
Cumulative compressor operation time	50 minutes or more 90 minutes or more if the defrost prohibit timer is set to 90.		250 minutes or more
Pipe temperature (TH3)	The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes.	((E)M200-(E)M500) The pipe temperature has stayed below the value obtained from the formula "Outside temperature (TH7) - 5°C [23°F]" for three minutes, or the 63LS reading has stayed below the value obtained from the formula "1.5 + 0.02 x (20+TH7)" for three minutes.	The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes

**Note**

1) Pipe temperature(TH3)

	M200	M250	M300	M350	M400	M450	M500
SW4 (915) OFF	-8°C	-8°C	-8°C	-10°C	-10°C	-8°C	-8°C
SW4 (915) ON	-5°C	-5°C	-5°C	-5°C	-5°C	-5°C	-5°C

	EM200	EM250	EM300	EM350	EM400	EM450	EM500
SW4 (915) OFF	-8°C	-8°C	-8°C	-10°C	-10°C	-8°C	-8°C
SW4 (915) ON	-5°C	-5°C	-5°C	-5°C	-5°C	-5°C	-5°C

- The defrost cycle will not start until a minimum of 10 minutes have passed since the completion of the last defrost cycle.
- If 10 minutes have passed since compressor startup or since the completion of a defrost cycle, a forced defrost cycle can be started by setting DIP SW4 (913) to ON.
- Even if the defrost-prohibit timer is set to 90 minutes, the actual defrost-prohibit time for the next defrost cycle is 50 minutes if the last defrost cycle took 12 minutes.

**(2) Defrost operation**

Outdoor unit	Compressor frequency	Model	Compressor frequency
		(E)M200, (E)M250, (E)M300 models	79Hz
		(E)M350, (E)M400 models	107Hz
		(E)M450 models	121Hz
		(E)M500 models	147Hz
	Outdoor unit fan	Stopped	
	SV1a	ON (open)	
	LEV2a, 2b, 2c	3000	
	LEV2d	(E)M200 - (E)M300: 41, (E)M350 - (E)M500: 20	
	LEV4	0	
	LEV9	480	
	21S4a, 21S4b, 21S4c	OFF	
	SV2	ON (open)	

			Heat recovery defrost	Bypass defrost
HBC	Dip switch setting		SW1-9 OFF	SW1-9 ON
	LEV1		3000	41
	LEV2		3000	41
			41	41
	LEV3		3000	3000
	SV1		OFF (close)	ON (open)
	21S4Ma		OFF	OFF
	21S4Mb		ON	ON
	Pump1		Command value 100%	Scheduled control
	Pump2		Command value 100%	Scheduled control
		Scheduled control	Scheduled control	
HBC or Sub HBC	VB3	Heating Thermo-ON	C800 or H800	Scheduled control
		Heating Thermo-OFF	0	0
		Cooling Thermo-ON	Scheduled control	Scheduled control
		Cooling Thermo-OFF	0	0

- \* The compressor frequency is fixed at 60Hz for 3 minutes after the start of the defrost operation.
- \* The compressor frequency is fixed at 60Hz when the shell bottom SH (TH15 - Te) ≤ 10°C [18°F].

**(3) Stopping the defrost operation**

- The defrost cycle ends when 12 minutes have passed <sup>\*1</sup>since the beginning of the cycle, or when the pipe temperatures (TH3) have been continuously detected for 4 minutes (when SW4 (916) is set to OFF) or 2 minutes (when SW4 (916) is set to ON) that exceeds the values in the table below.
- The defrost cycle will not end for two minutes once started unless one of the following conditions is met: Pipe temperature reaches 25°C [77°F] and SW4 (916) is set to OFF OR  $\alpha^{*2} = 25^{\circ}\text{C} + \text{TH}7^{\circ}\text{C}$  [77°F+TH7°F] and SW4 (916) is set to ON.
- \*1 The compressor frequency is fixed at 60Hz when the compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]. And the defrost mode may continue even after 12 minutes.
- \*2 (5°C [41°F] ≤ α ≤ 25°C [77°F]).

Model	TH3	
	SW4 (916) OFF	SW4 (916) ON
(E)M200 model	7°C [45°F]	12°C [54°F]
(E)M250 model	7°C [45°F]	12°C [54°F]
(E)M300 model	7°C [45°F]	12°C [54°F]
(E)M350 model	7°C [45°F]	12°C [54°F]
(E)M400 model	7°C [45°F]	12°C [54°F]
(E)M450 model	7°C [45°F]	12°C [54°F]
(E)M500 model	7°C [45°F]	12°C [54°F]

**(4) Problems during defrost operation**

- If a problem is detected during defrost operation, the operation will be stopped, and the defrost prohibition time based on the integrated compressor operation time will be set to 20 minutes.
- The unit will stop after the defrost operation when the total time of “compressor bottom SH (TH15 – Te) ≤ 10°C [18°F]” reaches 3 minutes.

**(5) Change in the number of operating indoor units during defrost operation**

- Even when there is a change in the number of operating indoor units during defrost operation, the operation will continue, and an adjustment will be made after the completion of the defrost operation.
- Defrost operation will be continued, even if the indoor units stop or under the Thermo-OFF conditions until it has run its course.

## 5-2-7 Refrigerant Recovery Control

---

The refrigerant recovery control function controls the refrigerant flow at the HBC during heating operation to keep the refrigerant from collecting inside the HBC.

It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the outdoor heat exchanger.

### **Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)**

The refrigerant recovery mode starts when all of the following conditions are met:

- 1) When 5 minutes have passed in the Heating-only or Heating-main mode or 30 seconds have passed in the Cooling-only or Cooling-main mode since the completion of the previous refrigerant recovery cycle AND the when following conditions are met.

Outdoor unit TH4 > 105°C [221°F]

- 2) When the port is not in the 4-minute restart delay mode

### **Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)**

The opening of LEV1 and LEV2 on the HBC is increased.

## 5-2-8 Outdoor Unit Fan Control

### (1) Control method

- Depending on the capacity required, the rotation speed of the outdoor fan is controlled by the inverter to keep a constant condensing temperature (outside temperature + 10°C [50°F]) during cooling operation and a constant evaporation temperature (0°C [32°F] = 0.71 MPa [103 psi]) during heating operation.

### (2) Control

- Outdoor unit fan stops while the compressor is stopped (except in the presence of input from snow sensor).
- The fan operates at full speed for 5 seconds after start-up. (Only when TH7 < 0°C [32°F])
- The outdoor unit fan stops during defrost operation.
- Both fans operate on the (E)M350, (E)M400, (E)M450, and (E)M500 models of outdoor units.

### (3) Outdoor heat exchanger capacity control pattern

- Outdoor fan rotation control is supported.
- As the operation pattern number increases, the refrigerant bypassing the outdoor heat exchanger increases. As the operation pattern number increases, the capacity difference becomes smaller between cooling operation and heating operation.
- In each mode, the four-way valve and the expansion valve operate as shown in the table below. The expansion valve may open or close during the refrigerant equalization control or the evaporation temperature control. See [5-2-9 Expansion valve control (LEV2a, LEV2b, LEV2c, and LEV2d)]

Model	Operation mode	Operation patterns	Four-way valve			LEV				
			21S4a	21S4b	21S4c	LEV2a	LEV2b	LEV2c	LEV2d	LEV4
(E)M200, (E)M250, (E)M300 models	Cooling-only Cooling-main	1	OFF	OFF	-	3000	3000	-	41	*Injection controlled
		2	OFF	ON	-	3000	41	-	1000	
		3	OFF	ON	-	500	41	-	3000	
		4	OFF	ON	-	300	41	-	3000	
	Heating-only	1	ON	ON	-	3000	3000	-	41	
	Heating-main	1	ON	ON	-	3000	3000	-	41	
		2	ON	ON	-	3000	3000	-	1250	
	Defrost	1	OFF	OFF	-	3000	3000	-	41	
(E)M350, (E)M400, (E)M450 models	Cooling-only Cooling-main	1	OFF	OFF	-	3000	3000	-	20	
		2	OFF	ON	-	3000	41	-	800	
		3	OFF	ON	-	3000	41	-	6000	
		4	OFF	ON	-	1000	41	-	6000	
	Heating-only	1	ON	ON	-	3000	3000	-	20	
	Heating-main	1	ON	ON	-	3000	3000	-	20	
		2	ON	ON	-	3000	3000	-	1000	
	Defrost	1	OFF	OFF	-	3000	3000	-	20	
(E)M500 models	Cooling-only Cooling-main	1	OFF	OFF	OFF	3000	3000	3000	20	
		2	OFF	ON	ON	3000	41	41	800	
		3	OFF	ON	ON	3000	41	41	6000	
		4	OFF	ON	ON	1000	41	41	6000	
	Heating-only	1	ON	ON	ON	3000	3000	3000	20	
	Heating-main	1	ON	ON	ON	3000	3000	3000	20	
		2	ON	ON	ON	3000	3000	3000	1000	
	Defrost	1	OFF	OFF	OFF	3000	3000	3000	20	

### (4) Evaporation temperature control (Expansion valves LEV2a, LEV2b, LEV2c, and LEV2d)

- LEV is controlled every 30 seconds so that the minimum temperature of the liquid refrigerant (TH12) of the Cooling-main heat exchanger and of the bypass inlet (TH15) of the HBC are in a constant range during Heating-only or Heating-main operation.

### 5-2-9 Expansion valve control (LEV2a, LEV2b, LEV2c, and LEV2d)

The default opening levels of the expansion valves LEV2a, LEV2b, LEV2c, and LEV2d are shown in Section [5-2-8 Outdoor Unit Fan Control]. When the following control (1) is performed during heating-only or heating-main operation, the valves open or close.

#### (1) Evaporation temperature control

- LEV is controlled every 30 seconds so that the minimum temperature of the liquid refrigerant (TH12) of the Cooling-main heat exchanger and of the bypass inlet (TH15) of the HBC are in a constant range during Heating-only or Heating-main operation.

### 5-2-10 Control of Controller Cooling Function (Electronic Expansion Valve <LEV9>)

- Control of controller cooling function is performed individually for OC.
- The opening of LEV9 is adjusted every three seconds to keep the controller heatsink temperature (THHS) below the threshold value, which is determined by the setting of the outside temperature (TH7).


### 5-2-11 Injection Control (Linear Expansion Valve <LEV4>)

- LEV4 opening is adjusted every 30 seconds to keep the discharge temperature (TH4) within the predetermined range.

### 5-2-12 Control at Initial Startup

- When started up for the first time before 12 hours have elapsed after power on, the unit goes into the initial startup mode.
- They will go into the normal control mode.

#### (1) Single-outdoor-unit system



## 5-2-13 Operation Mode

### (1) Indoor unit operation mode

The operation mode can be selected from the following 6 modes using the remote controller.

1	Cooling mode
2	Heating mode
3	Dry mode
4	Automatic cooling/heating mode
5	Fan mode
6	Stopping mode

### (2) Outdoor unit operation mode


1	Cooling only mode	All indoor units in operation are in cooling mode.
2	Heating only mode	All indoor units in operation are in heating mode.
3	Cooling main mode	Coexistence of units in cooling and heating modes.
4	Heating main mode	Coexistence of units in cooling and heating modes.
5	Stopping mode	All indoor units are in fan mode or stopping mode.

**Note**


When units in cooling and heating coexist, the operation mode (cooling main mode or heating main mode) will be determined, based on the refrigerant pressure in the R2 refrigerant circuit and speed variation data.

### (3) Operation pattern for automatic cooling/heating mode

When the automatic cooling/heating mode is selected from remote controller functions, the indoor temperature will be detected in pattern as shown in the figure below, and the operation mode (cooling or heating) will automatically be selected.



### (4) Relationship between the operation mode and the load capacity (kW) (within a system)



## **5-2-14      Demand Control**

---

Cooling/heating operation can be prohibited (Thermo-OFF) by an external input to the indoor units.

### **Note**

When DIP SW6-8 is set to ON, the 4-step DEMAND control is enabled.

For details, refer to the following page(s). [2-4-7 Various Control Methods Using the Signal Input/Output Connector on Outdoor Unit]

## **5-2-15      Control of IH energization without the compressor in operation**

---

IH is used to heat the compressor motor on the stopped outdoor unit to make liquid refrigerant in the compressor evaporate or to keep liquid refrigerant from flooding the compressor.


- Initial power on after power is turned on: Stays on for 12 hours, and then transitions to the operation that is performed while the compressor is stopped
- When the compressor is stopped: Stays on for 30 minutes after the compressor stopped, and then repeats the off-on cycle at 30-minute intervals
- Lit LED1 on the INV board indicates that the INV board is energized by an IH.



## 5-3 HBC Control

### 5-3-1 Water Pump Control

Depending on the capacity required, temperature difference on the indoor units is controlled so as to be within a certain range. During normal operation, the changes in specified voltage of the water pump corresponding to the capacity of connectable indoor units are shown in the graph below.



**Note**

The specified voltage changes with the load on the indoor unit side. (A sample is shown in the graph above.)


#### (1) Periodic specified voltage control

- 1) Periodic control cycle  
Specified voltage control is performed after the following times have elapsed.
  - Thirty seconds after either compressor startup or the completion of the defrost cycle
- 2) The amount of frequency change  
The amount of specified voltage change is controlled to approximate the target value based on the target temperature difference.

### 5-3-2 4-Way Valve Control

4-way valves (21S4M (a, b)) turn on or off according to the operation mode.  
 For 21S4Ma, ON indicates switching to the cooling side and OFF indicates switching to the heating side. For 21S4Mb, ON indicates switching to the heating side and OFF indicates switching to the cooling side. For 21S4Ma, ON indicates switching to the cooling side and OFF indicates switching to the heating side. For 21S4Mb, ON indicates switching to the heating side and OFF indicates switching to the cooling side. When energized: ON; When de-energized: OFF

No.	Operation mode	4-way valve control mode	4-way valve	
			21S4Ma	21S4Mb
1	Cooling-only	Cooling	ON	OFF
2		Mild-cooling	OFF	OFF
3	Cooling-main	Cooling-main	OFF	OFF
4	Heating-main	Heating-main	OFF	OFF
5	Heating-only	Mild-heating	OFF	OFF
6		Heating	OFF	ON
7	Defrost	Defrost	The status before defrosting maintained	The status before defrosting maintained
8	Stopped	Stopped	OFF	OFF



**Note**

- Select the installation site carefully, as some noise may be produced when the 4-way valve is switched. Install the unit in a place where the noise from the unit will not be problem. (Install the indoor units and HBC at least 5m [16-6/16ft] away from each other when installing in a space with low background noise, e.g., hotel rooms.) Install the unit in the ceiling of an area that are not always occupied by people, e.g., hallway, office kitchen, restrooms. (Do not install the unit in the middle of a room.)
- The elapsed time is used to reduce the switching frequency of the control modes between No. 1 or No. 6 AND No. 3 or No. 4.
- Capacity control is determined depending on the opening of VB3 that adjusts the water flow rate.

### 5-3-3 Valve Block (VB3) Water Flow Rate Adjustment

---

• Depending on the capacity required, periodic control is performed every one minute to keep the temperature difference between the heat exchanger outlet pipe temperature and indoor unit port pipe temperature and the opening is controlled in the range between 85 and 700 (cooling) or 900 and 1600 (Heating) pulses.

For the degree of valve opening, C800 or H800 indicate fully open and 0 indicates fully closed.

• When the P\*\*Y-W models of indoor units (\*1) are connected to the HBC, the flow is controlled by the flow control valve (FCV) on the indoor units, not by the valve block.

(\*1) Only either P\*\*Y-W model indoor units (equipped with a flow control valve) or P\*\*Y-WP/WL model indoor units (without a flow control valve) can be connected to the HBC. (Combining different models of indoor units will cause a connection error.)

(\*2) The following models of indoor units can be used as indoor units equipped with a flow control valve when used with the optional valve kit (PAC-SK04VK-E).

<Applicable indoor units>

P\*\*Y-WL\*\*

\* The optional valve kit (PAC-SK04VK-E) cannot be installed on P\*\*Y-WP\*\* models.

### 5-3-4 Valve Block (VB3) Water Flow Path Switching Control

•The following table shows the control pattern of the valve block in different operation modes to switch the water flow.

**(1) Cooling-only Thermo-ON, Cooling-only Thermo-OFF, Cooling-only test run, Heating-only Thermo ON, and Heating-only Thermo OFF**

Outdoor unit operation mode	Connected indoor unit operation mode	VB3 command value for opening
Cooling-only Thermo-ON Heating-only Thermo ON	Stop	1
	Fan	1
	Thermo-ON	2 or 3
	Thermo-OFF	1
Cooling-only Thermo-OFF Heating-only Thermo OFF	Stop	1
	Fan	1
	Thermo-OFF	1
Cooling-only test run	Stop	1
	Fan	1
	Thermo-ON	2 or 3
	Thermo-OFF	1

**(2) Heating-main Thermo-ON, Heating-main Thermo-OFF, Cooling-main Thermo-ON, and Cooling-main Thermo-OFF**

Outdoor unit operation mode	Connected indoor unit operation mode	VB3 command value for opening
Heating-main Thermo-ON Cooling-main Thermo-ON	Stop	1
	Fan	1
	Cooling Thermo-ON	2
	Cooling Thermo-OFF	1
	Heating Thermo-ON	3
	Heating Thermo-OFF	1
Heating-main Thermo-OFF Cooling-main Thermo-OFF	Stop	1
	Fan	1
	Cooling Thermo-OFF	1
	Heating Thermo-OFF	1

<Designated degree of valve opening>

- 1: 800 pulse
- 2: 85~700 pulses
- 3: 900~1600 pulses

### 5-3-5 Bypass Control

Solenoid valves have two types: (SV1) that bypass the high- and low- pressure sides; LEV (LEV3). They perform the following functions.

#### (1) Bypass solenoid valve (SV1) (ON: open)

Operation mode	SV1	
Cooling-only Thermo-ON	Always ON	
Cooling-main Thermo-ON	Always OFF	
Heating-only Thermo-ON	Always OFF	
Heating-main Thermo-ON	Always OFF	
Defrost	Always ON during heat recovery defrost	OFF except to perform heat recovery defrost
Stop	Always OFF	
Cooling-only Thermo-OFF	Always ON	
Thermo-OFF (Heating-only, Mixture of units in cooling and heating)	Always OFF	
Cooling-only test run	Always ON	
Test run for stop	Always ON	

5 Control

### 5-3-6 Plate Heat Exchanger Control

#### (1) Cooling-only Thermo-ON and Cooling-only test run

•When three minutes have passed after the LEV operates with initial opening, the LEV opening is adjusted every 1 minute to keep the amount of superheat before and after the plate heat exchanger constant.

#### (2) Heating-only Thermo-ON

•When three minutes have passed after the LEV operates with initial opening, the LEV opening is adjusted every 1 minute to keep the amount of subcool before and after the plate heat exchanger constant.

#### (3) Cooling-main/Heating-main Thermo-ON and Cooling-main/Heating-main refrigerant recovery

- 1) Periodic control for LEV1  
The LEV opening is adjusted the same way as described in (2) Heating-only Thermo-ON and Heating-only refrigerant recovery.
- 2) Periodic control for LEV2  
To be fully open (3000)


## 5-3-7 Defrost Operation Control

### (1) Defrost cycle type

•The defrost cycle has following two types: Bypass defrost that is the same method as that used in a CITY MULTI series system and heat recovery defrost (default) that the heat is collected from the water circuit and the defrost cycle ends early.

The following figure shows the refrigerant flow for the heat recovery defrost. In the heat recovery defrost method, LEV1 and LEV2 are fully opened and the heat is exchanged between the refrigerant and water. In the heat recovery defrost method, the defrost cycle ends early because the heat is caught from the water. In the bypass defrost method, LEV1 and LEV2 are closed and the heat is not exchanged between the refrigerant and water.

The basic defrost method is the heat recovery defrost with the dip switch 001-9 on the HBC turned OFF (default). The bypass defrost may be performed depending on the water temperature. Setting the dip switch 001-9 to ON performs the bypass defrost.



**(2) Starting the defrost operation**

•The defrost cycle will start when all of the three conditions (outside temperature, cumulative compressor operation time, and pipe temperature) under <Condition 1>, <Condition 2>, or <Condition 3> are met.

	Condition 1	Condition 2	Condition 3
Outside temperature (TH7)	-5°C [23°F] or above	-5°C [23°F] or below	
Cumulative compressor operation time	50 minutes or more 90 minutes or more if the defrost prohibit timer is set to 90.		250 minutes or more
Pipe temperature (TH6)	The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes.	The pipe temperature (TH6) has stayed at or below the value obtained from the formula "Outside temperature (TH7) - 10°C [18°F]" for three minutes. or the 63LS reading has stayed below the value obtained from the formula "1.5 + 0.02 x (20+TH7)" for three minutes.	The pipe temperature has stayed below the temperatures in the table below (Note1) for three minutes

**Note**

1) Outdoor unit pipe temperature (TH6)

SW3-3 OFF	-8°C
SW3-3 ON	-5°C

- If 10 minutes have passed since compressor startup or since the completion of a defrost cycle, a forced defrost cycle can be started by setting DIP SW002-7 to ON.
- Even if the defrost-prohibit timer is set to 90 minutes (or 150 minutes for "Condition 3" to be met), the actual defrost-prohibit time for the next defrost cycle is 50 minutes if the last defrost cycle took 12 minutes.

**(3) Defrost cycle**

Outdoor unit	Compressor frequency	model	Compressor frequency
		(E)M200, (E)M250, (E)M300	79Hz
		(E)M350, (E)M400	107Hz
		(E)M450	121Hz
		(E)M500	147Hz
	outdoor fan	Stop	
	SV1a	ON (open)	
	LEV2a, 2b, 2c	3000	
	LEV2d	(E)M200-(E)M300: 41, (E)M350-(E)M500: 20	
	LEV4	0	
	LEV9	480	
	21S4a, 21S4b	OFF	
	SV2	OFF (close)	


		Heat recovery defrost	Bypass defrost	
HBC	Dip switch setting	SW1-9 OFF	SW1-9 ON	
	LEV1	3000	41	
	LEV2		3000	41
			41	41
	LEV3	3000	3000	
	SV1	OFF (close)	ON (open)	
	21S4Ma	OFF	OFF	
	21S4Mb	ON	ON	
	Pump1	Command value 100%	Scheduled control	
	Pump2		Command value 100%	Scheduled control
			Scheduled control	Scheduled control
HBC or Sub HBC	VB3	Heating Thermo-ON	C800 or H800	Scheduled control
		Heating Thermo-OFF	0	0
		Cooling Thermo-ON	Scheduled control	Scheduled control
		Cooling Thermo-OFF	0	0

\*The indoor unit fan will stop during defrost.



**(4) Recovering from Defrost**

•The setting of the dip switch 001-9 determines the defrost method (bypass defrost or heat recovery defrost).  
 As shown in the following flow chart, the bypass defrost may be performed during the heat recovery defrost depending on the operation status.



### 5-3-8 Refrigerant Recovery Control

The refrigerant recovery control function controls the refrigerant flow at the HBC during heating operation to keep the refrigerant from collecting inside the HBC.

It is also performed during cooling operation to prevent an excessive amount of refrigerant from accumulating in the outdoor heat exchanger.

**Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)**

The refrigerant recovery mode starts when all of the following conditions are met:

- 1) When 5 minutes have passed in the Heating-only or Heating-main mode or 30 seconds have passed in the Cooling-only or Cooling-main mode since the completion of the previous refrigerant recovery cycle AND the when following conditions are met.  
Outdoor unit TH4 > 105°C [221°F]
- 2) When the port is not in the 4-minute restart delay mode

**Starting criteria for the refrigerant recovery cycle (during Cooling-only, Cooling-main, Heating-only, or Heating-main mode)**

The opening of LEV1 and LEV2 on the HBC is increased.

### 5-3-9 Backup Control

The following backup control is started on the HBC as necessary.

**(1) Backup mode for plate heat exchanger protection**

•The following control is performed depending on the outlet pipe temperature of the plate heat exchanger for freeze-up protection.

[Cooling-main/Heating-main operation]

- 1) Outdoor unit  
Cooling-main operation: Continued; Heating-main operation: Continued
- 2) HBC

		Control mode	
		Cooling-main/Heating-main	Cooling-only
Outdoor unit	Operation mode	Continues the current operation	Cooling-only Thermo-OFF
HBC	21S4Ma	Heating side: open (de-energized)	Cooling side: open (energized)
	21S4Mb	Cooling side: open (de-energized)	Cooling side: open (de-energized)
	LEV1	Maintains the opening that was used in the previous operation mode	Opening during Cooling-only Thermo-OFF
	LEV2	41 pulses: fully closed	Opening during Cooling-only Thermo-OFF
	LEV3	3000 pulses: fully open	Opening during Cooling-only Thermo-OFF
	SV1	Closed	Open
	PUMP1	Continues the heating operation	Continues the cooling-only operation
	PUMP2	Continues the cooling operation	Continues the cooling-only operation
	VB3a~p	The opening depending on the indoor unit operation mode	The opening depending on the indoor unit operation mode

**(2) Heating water temperature backup mode**

•When the heating operation can be continued without receiving heat from the refrigerant due to water temperature rise during heating operation (the outlet pipe temperature of the plate heat exchanger is 70°C or above), the outdoor unit goes into the Thermo-OFF mode, and the heating operation is performed only by circulating the hot water by the water pump. When the water temperature decreases to a certain level (the outlet temperature of the plate heat exchanger is 45°C or below), the outdoor unit starts up.

## **5-3-10 Water Pump Protection Control**

---

When the circuit is clogged or air enters the water circuit, the protection control starts on the HBC to protect the water pump and the system is stopped depending on the situation.

### **(1) When the internal temperature of the water pump increases**

•When the detection temperature of the water pump outlet pipe is above a certain level, the water pump is stopped to protect it from the heat.

### **(2) When the revolutions of the water pump increases**

•When the revolutions of the water pump is above a certain level (The value changes depending on the specified voltage.), the water pump is stopped to reduce the risk of air infiltration and water leaks.

### **(3) When the water pressure on the discharge or suction side of the pump dropped and when the differential between the discharge and the suction sides of the pump dropped.**

•When the discharge or suction pressure drops below a certain level, the pump is stopped to reduce the risk of water leakage resulting from air entrainment.

•When the differential between the discharge and suction sides of the pump drops below a certain level, the pump is stopped to reduce the risk of water leakage resulting from air entrainment.

---

## Chapter 6 Test Run

<b>6-1</b>	<b>Read before Test Run</b> .....	<b>1</b>
<b>6-2</b>	<b>Operation Characteristics and Refrigerant Charge</b> .....	<b>2</b>
<b>6-3</b>	<b>Evaluating and Adjusting Refrigerant Charge</b> .....	<b>2</b>
6-3-1	Refrigerant Overcharge and undercharge .....	2
6-3-2	Checking the Refrigerant Charge during Operation.....	2
6-3-3	Maximum refrigerant charge .....	3
6-3-4	Refrigerant Charge Adjustment Mode .....	3
<b>6-4</b>	<b>The Following Symptoms Are Normal</b> .....	<b>4</b>



## 6-1 Read before Test Run

### (1) Check for refrigerant leak and loose cables and connectors.

### (2) When opening or closing the front panel of the control box, do not let it come into contact with any of the internal components.

**Note**

- Before inspecting the inside of the control box, turn off the power, leave the unit turned off for at least 10 minutes, and check that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less. (It takes approximately 10 minutes to discharge electricity after the power is turned off.)
- Control box houses high temperature parts. Be well careful even after turning off the power source.
- Disconnect the relay connector (RYFAN 1, RYFAN 2) on the outdoor unit fan before performing maintenance work. (Before connecting or disconnecting the connector, check that the outdoor unit fan is stopped and that the voltage across pins 1 and 5 of connector RYPN has dropped to 20 VDC or less. If the outdoor unit fan is turned by strong winds, the main circuit capacitor will be energized and poses an electric shock hazard. Refer to the wiring diagram name plate for details.
- To connect wiring to TB7, check that the voltage is 20 VDC or below.
- Reconnect the relay connector (RYFAN 1, RYFAN 2) on the outdoor unit fan after completion of maintenance work.

### (3) Measure the insulation resistance between the power supply terminal block and the ground with a 500V megger and make sure it reads at least 1.0Mohm.

**Note**

- Do not operate the unit if the insulation resistance is below 1.0Mohm.
- Do not apply megger voltage to the terminal block for transmission line. Doing so will damage the controller board.
- The insulation resistance between the power supply terminal block and the ground could go down to close to 1Mohm immediately after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor.
- If insulation resistance reads at least 1 MΩ, by turning on the main power and keeping it on for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- Do not measure the insulation resistance of the terminal block for transmission line for the unit remote controller.

### (4) When the power is turned on, the compressor is energized even while it is not operating.

**Note**

- Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor.
- Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor and turn on the power to the outdoor unit. (The liquid refrigerant in the compressor will evaporate by energizing the compressor.)

### (5) Make sure the valves on both the high-pressure and low-pressure sides are fully open.

**Note**

Securely tighten the cap.

### (6) Check the phase sequence and the voltage of the power supply.

When the voltage is out of the  $\pm 10\%$  range, or when the phase voltage difference is more than 2%, please discuss the counter-measure with the customer.

### (7) [When a transmission booster is connected]

Turn on the transmission booster before turning on the outdoor units.

**Note**

- If the outdoor units are turned on first, the connection information for the refrigerant circuit may not be properly recognized.
- In case the outdoor units are turned on before the transmission booster is turned on, perform a power reset on the outdoor units after turning on the power booster.

### (8) Turn on the main power at least 12 hours before test run.

**Note**

Insufficient powering time may result in compressor damage.

### (9) When a power supply unit is connected to the transmission line for centralized control(\*), perform a test run with the power supply unit being energized. Leave the power jumper connector on CN41 as it is (factory setting).

\*Includes the cases where power is supplied to the transmission line from a system controller with a power-supply function

## 6-2 Operation Characteristics and Refrigerant Charge

It is important to have a clear understanding of the characteristics of refrigerant and the operating characteristics of air conditioners before attempting to adjust the refrigerant amount in a given system.

The following shows items of particular importance.

- 1) During cooling operation, the amount of refrigerant in the accumulator is the smallest when all indoor units are in operation.
- 2) During heating operation, the amount of refrigerant in the accumulator is the largest when all indoor units are in operation.
- 3) General tendency of discharge temperature
  - Discharge temperature tends to rise when the system is short on refrigerant.
  - Changing the amount of refrigerant in the system while there is refrigerant in the accumulator has little effect on the discharge temperature.
  - The higher the pressure, the more likely it is for the discharge temperature to rise.
  - The lower the pressure, the more likely it is for the discharge temperature to rise.
- 4) When the amount of refrigerant in the system is adequate, the compressor shell temperature is 10 to 60°C [18 to 108°F] higher than the low pressure saturation temperature (Te).
  - If the temperature difference between the compressor shell temperature and low pressure saturation temperature (Te) is smaller than 5°C [9°F], an overcharging of refrigerant is suspected.

## 6-3 Evaluating and Adjusting Refrigerant Charge

### 6-3-1 Refrigerant Overcharge and undercharge

Overcharging or undercharging of refrigerant can cause the following symptoms:

Before attempting to adjust the amount of refrigerant in the system, thoroughly check the operating conditions of the system. Then, adjust the refrigerant amount by running the unit in the refrigerant amount adjust mode.

The system comes to an abnormal stop, displaying 1500 (overcharged refrigerant) on the controller.	Overcharged refrigerant
The operating frequency does not reach the set frequency, and there is a problem with performance.	Insufficient refrigerant amount
The system comes to an abnormal stop, displaying 1102 (abnormal discharge temperature) on the controller.	

6 Test Run

### 6-3-2 Checking the Refrigerant Charge during Operation

Operate all indoor units in either cooling-only or heating-only mode, and check such items as discharge temperature, subcooling, low pressure, suction temperature, and shell bottom temperature to estimate the amount of refrigerant in the system.

Symptoms	Conclusion
Discharge temperature is high. (Normal discharge temperature is below 100°C [212°F].) *	Slightly undercharged refrigerant
Low pressure is unusually low.	
Suction superheat is large. (Normal suction superheat is less than 20°C [36°F].)	
Compressor shell bottom temperature is high. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is greater than 60°C [108°F].)	Slightly overcharged refrigerant
Discharge superheat is small. (Normal discharge superheat is greater than 10°C [18°F].)	
Compressor shell bottom temperature is low. (The difference between the compressor shell bottom temperature and low pressure saturation temperature (Te) is less than 5°C [9°F].)	

\*Evaluate the refrigerant amount using other criteria during the injection control.

•Proper judgment cannot always be made based on the standards above.

### 6-3-3 Maximum refrigerant charge

There is a limit to the amount of refrigerant that can be charged into a unit. Observe the maximum refrigerant charge in the table below.

♦M200-500YNW-A1

Total index of the outdoor units	M200	M250	M300	M350	M400	M450	M500
Factory charge (kg)	5.2	5.2	5.2	8.0	8.0	10.8	10.8
Maximum additional refrigerant charge on site (kg)	13.5	13.5	15.5	15.5	19.5	19.5	19.5
Maximum refrigerant charge (kg)	18.7	18.7	20.7	23.5	27.5	30.3	30.3

♦EM200-500YNW-A1

Total index of the outdoor units	EM200	EM250	EM300	EM350	EM400	EM450	EM500
Factory charge (kg)	5.2	5.2	5.2	8.0	8.0	10.8	10.8
Maximum additional refrigerant charge on site (kg)	13.5	13.5	15.5	15.5	19.5	19.5	19.5
Maximum refrigerant charge (kg)	18.7	18.7	20.7	23.5	27.5	30.3	30.3

### 6-3-4 Refrigerant Charge Adjustment Mode

On the model of unit described in this document, the refrigerant charge cannot be adjusted.



## 6-4 The Following Symptoms Are Normal

Symptoms	Remote controller display	Cause
The auto vane adjusts its position by itself.	Normal display	After an hour of cooling operation with the auto vane in the vertical position, the vane may automatically move into the horizontal position. Louver blades will automatically move into the horizontal position while the unit is in the defrost mode, pre-heating stand-by mode, or when the thermostat triggers unit off.
The fan speed changes during heating.	Normal display	Very Low fan speed when "Thermo-OFF." Changes from Very Low to pre-set fan speed when "Thermo-ON" depending on pipe temperature.
The fan stops during heating operation.	Defrost	The fan remains stopped during defrost operation.
The fan keeps running after the unit has stopped.	Unlit	When the auxiliary heater is turned on, the fan operates for one minute after stopping to dissipate heat.
The fan speed does not reach the set speed when operation switch is turned on.	STAND BY	The fan operates at extra low speed for 5 minutes after it is turned on or until the pipe temperature reaches 35°C[95°F], then it operates at low speed for 2 minutes, and finally it operates at the set speed. (Pre-heating stand-by)
When the main power is turned on, the display shown on the right appears on the indoor unit remote controller for 5 minutes.	"HO" or "PLEASE WAIT" icons blink on the display.	The system is starting up. Wait until the blinking display of "HO" or "PLEASE WAIT" go off.
The drain pump keeps running after the unit has stopped.	Unlit	The drain pump stays in operation for three minutes after the unit in the cooling mode is stopped.
The drain pump is running while the unit is stopped.	Unlit	When drain water is detected, the drain pump goes into operation even while the unit is stopped.
HBCs may make noise during cooling/heating changeover.	Normal display	This noise is made when the water circuit is reversed and is normal.
The sound of water flow is sometimes heard from the indoor unit immediately after the unit went into operation.	Normal display	This noise is caused by transient instability of water flow and is normal.
The check valve clacks.	Normal display	When the refrigerant flow is small, the valve vibrates and clacks. This is not a malfunction.
In a short while after the outdoor unit stops, the unit makes a clicking sound.	No display	After the unit stops and before the unit performs pressure equalization, the pressure difference temporarily becomes small and the check valve may vibrate and make a sound. This is temporary and does not imply a problem.

---

## Chapter 7 Troubleshooting Using Error Codes

<b>7-1</b>	<b>Error Code and Preliminary Error Code Lists</b> .....	<b>1</b>
<b>7-2</b>	<b>Error Code Definitions and Solutions: Codes [0 - 999]</b> .....	<b>8</b>
7-2-1	Error Code [0403] .....	8
7-2-2	Error Code [0404] .....	10
<b>7-3</b>	<b>Error Code Definitions and Solutions: Codes [1000 - 1999]</b> .....	<b>11</b>
7-3-1	Error Code [1102] .....	11
7-3-2	Error Code [1301] .....	12
7-3-3	Error Code [1302] (during operation) .....	13
7-3-4	Error Code [1302] (at startup) .....	14
7-3-5	Error Code [1500] .....	14
<b>7-4</b>	<b>Error Code Definitions and Solutions: Codes [2000 - 2999]</b> .....	<b>15</b>
7-4-1	Error Code [2500] (Models with a drain sensor) .....	15
7-4-2	Error Code [2500] (Models with a float switch) .....	16
7-4-3	Error Code [2501] (Water pump fault) .....	17
7-4-4	Error Code [2502] (Models with a drain sensor) .....	18
7-4-5	Error Code [2502] (Models with a float switch) .....	19
7-4-6	Error Code [2503] .....	20
7-4-7	Error Code [2512] (Control valve failure) (Indoor unit) .....	21
7-4-8	Error Code [2512] (Control valve failure) (HBC) .....	21
7-4-9	Error Code [2519] .....	22
7-4-10	Error Code [2520] .....	22
7-4-11	Error Code [2600] .....	23
7-4-12	Error Code [2601] .....	23
<b>7-5</b>	<b>Error Code Definitions and Solutions: Codes [3000 - 3999]</b> .....	<b>24</b>
7-5-1	Error Code [3121] .....	24
7-5-2	Error Code [3511] .....	25
<b>7-6</b>	<b>Error Code Definitions and Solutions: Codes [4000 - 4999]</b> .....	<b>26</b>
7-6-1	Error Code [4102] .....	26
7-6-2	Error Code [4106] .....	27
7-6-3	Error Code [4109] .....	27
7-6-4	Error Code [4114] .....	28
7-6-5	Error Code [4115] Detail Code 101, 102 .....	28
7-6-6	Error Code [4116] .....	29
7-6-7	Error Code [4121] .....	29
7-6-8	Error Code [4124] .....	30
7-6-9	Error Code [4129] Detail Code 101 .....	31
7-6-10	Error Code [4129] Detail Code 102 .....	31
7-6-11	Error Code [4129] Detail Code 103 .....	32
7-6-12	Error Code [4130] .....	33
7-6-13	Error Code [4131] (When indoor units with FCV are connected) .....	34
7-6-14	Error Code [4220, 4225, 4226] Detail Code 108 .....	35
7-6-15	Error Code [4220, 4225, 4226] Detail Code 109 .....	36
7-6-16	Error Code [4220] Detail Code 110 .....	37
7-6-17	Error Code [4220, 4225, 4226] Detail Code 111, 112 .....	37
7-6-18	Error Code [4220] Detail Code 123 .....	38
7-6-19	Error Code [4220] Detail Code 129 .....	38
7-6-20	Error Code [4220, 4225, 4226] Detail Code 131 .....	39

7-6-21	Error Code [4228] Detail Code 101.....	39
7-6-22	Error Code [4230] Detail Code 126.....	39
7-6-23	Error Code [4235, 4236] Detail Code 125.....	40
7-6-24	Error Code [4240, 4245, 4246] .....	41
7-6-25	Error Code [4250, 4255, 4256] Detail Code 101.....	42
7-6-26	Error Code [4250, 4255, 4256] Detail Code 104.....	43
7-6-27	Error Code [4250, 4255, 4256] Detail Code 105.....	44
7-6-28	Error Code [4250, 4255, 4256] Detail Code 106 and 107.....	45
7-6-29	Error Code [4250] Detail Code 121, 128, and 122.....	46
7-6-30	Error Code [4255, 4256] Detail Code 137.....	47
7-6-31	Error Code [4260] .....	47
<b>7-7</b>	<b>Error Code Definitions and Solutions: Codes [5000 - 5999] .....</b>	<b>48</b>
7-7-1	Error Code [5102] (Indoor unit).....	48
7-7-2	Error Code [5104] .....	49
7-7-3	Error Code [5103,5104,5105,5107,5115] .....	50
7-7-4	Error Code [5110] .....	51
7-7-5	Error Code [5111-5178] .....	52
7-7-6	Error Code [5201] .....	53
7-7-7	Error Code [5201] .....	53
7-7-8	Error Code [5201, 5203] .....	54
7-7-9	Error Code [5202] .....	54
7-7-10	Error Code [5211-5214] .....	55
7-7-11	Error Code [5301] Detail Code 115.....	55
7-7-12	Error Code [5301] Detail Code 117.....	56
7-7-13	Error Code [5301, 5305, 5306] Detail Code 119.....	57
7-7-14	Error Code [5301, 5305, 5306] Detail Code 120.....	58
7-7-15	Error Code [5305, 5306] Detail Code 135.....	59
7-7-16	Error Code [5305, 5306] Detail Code 136.....	60
7-7-17	Error Code [5701] .....	60
<b>7-8</b>	<b>Error Code Definitions and Solutions: Codes [6000 - 6999] .....</b>	<b>61</b>
7-8-1	Error Code [6201] .....	61
7-8-2	Error Code [6202] .....	61
7-8-3	Error Code [6600] .....	62
7-8-4	Error Code [6601] .....	62
7-8-5	Error Code [6602] .....	63
7-8-6	Error Code [6603] .....	64
7-8-7	Error Code [6606] .....	64
7-8-8	Error Code [6607] Error Source Address = Outdoor Unit (OC).....	65
7-8-9	Error Code [6607] Error Source Address = HBC (HB).....	65
7-8-10	Error Code [6607] Error Source Address = Indoor Unit (IC) .....	66
7-8-11	Error Code [6607] Error Source Address = ME Remote Controller .....	68
7-8-12	Error Code [6607] Error Source Address = System Controller .....	69
7-8-13	Error Code [6607] All Error Source Addresses .....	70
7-8-14	Error Code [6607] No Error Source Address .....	71
7-8-15	Error Code [6608] .....	72
7-8-16	Error Code [6831] .....	73
7-8-17	Error Code [6832] .....	74
7-8-18	Error Code [6833] .....	75
7-8-19	Error Code [6834] .....	76

---

7-8-20	Error Code [6840]	77
7-8-21	Error Code [6841]	77
7-8-22	Error Code [6842]	78
7-8-23	Error Code [6843]	79
7-8-24	Error Code [6846]	80
<b>7-9</b>	<b>Error Code Definitions and Solutions: Codes [7000 - 7999]</b>	<b>81</b>
7-9-1	Error Code [7100]	81
7-9-2	Error Code [7101]	82
7-9-3	Error Code [7102]	83
7-9-4	Error Code [7107]	84
7-9-5	Error Code [7110]	86
7-9-6	Error Code [7111]	86
7-9-7	Error Code [7113]	87
7-9-8	Error Code [7117]	88
7-9-9	Error Code [7130]	89
<b>7-10</b>	<b>Unit Error Code Definitions and Solutions: Codes [Er91 - Er99]</b>	<b>90</b>
7-10-1	Error Code [Er91]	90



## 7-1 Error Code and Preliminary Error Code Lists

Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition	Searched unit					Notes
				Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
0403	4300 4305 4306	01, 05, 06	Serial communication error/Panel communication error	O	O	O			(page 8)
	4308 4501 4502 4504	08, XY (X=0, 2, 3, 4, 5) (Y=1, 2, 4)				O			(page 8)
0404	-	-	Indoor unit EEPROM abnormality		O				(page 10)
1102	1202	-	Discharge temperature fault	O					(page 11)
1301	-	-	Low pressure fault	O					(page 12)
1302	1402	-	High pressure fault	O					(page 13)
1500	1600	-	Refrigerant overcharge	O					(page 14)
-	1605	-	Preliminary suction pressure fault	O					
2500	-	-	Drain sensor submergence		O				(page 15)
2501	-	-	Water pump fault			O			(page 17)
2502	-	-	Drain pump fault		O	O			(page 18)
2503	-	-	Drain sensor (Thd) fault		O		O		(page 20)
2512	-	01, 02, 100	Control valve failure		O	O			(page 21)
2519	2619	[201] - [204]	Abnormal water pressure drop			O			(page 22)
2520	2620		Abnormal water pressure rise			O			(page 22)
2600	-	-	Water leakage				O		(page 23)
2601	-	-	Water supply cutoff				O		(page 23)
3121	-	-	Out-of-range outside air temperature	O					(page 24)
3511	3611	-	Refrigerant overcooling	O					(page 25)
4102	4152	-	Open phase	O					(page 26)
4106	-	-	Transmission power supply fault	O					(page 27)
4109	-	-	Indoor unit fan operation error		O				(page 27)
4114	-	-	Indoor unit fan motor error		O				(page 28)
4115	4165	[101]	Power supply signal sync error			O			(page 28)
		[102]				O			(page 28)
4116	-	-	RPM error/Motor error		O		O		(page 29)
4121	4171	-	Function setting error	O					(page 29)
4124	-	-	Electric system not operate due to damper abnormality		O				(page 30)
4129	4179	[101]	Converter error			O			(page 31)
		[102]	Power supply signal sync error			O			(page 31)
		[103]	Signal wire fault			O			(page 32)

Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition	Searched unit					Notes
				Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
4130	-	-	Control power supply error			O			(page 33)
4131	-	[101]- [150]	Slightly open indoor unit valve during power cut			O			(page 34)
4220 4225 4226 (Note)	4320 4325 4326 (Note)	[0]	Backup operation	O					
		[108]	Abnormal bus voltage drop	O		O			(page 35)
		[109]	Abnormal bus voltage rise	O		O			(page 36)
		[110]	BUS voltage error	O					(page 37)
		[111]	Logic error	O		O			(page 37)
		[112]	Logic error	O					(page 37)
		[123]	Voltage boost control error	O					(page 38)
		[129]	Control power-supply fault	O					(page 38)
		[131]	Low bus voltage at startup	O					(page 39)
4228	4328	[101]	BUS voltage error (Software detection)			O			(page 39)
4230	4330	[126]	DCL temperature fault	O					(page 39)
4235 4236	4335 4336	[125]	Heatsink overheat protection	O		O			(page 40)
4240 4245 4246	4340 4345 4346	-	Overload protection	O		O			(page 41)
4250 4255 4256 (Note)	4350 4355 4356 (Note)	[0]	Backup operation	O					
		[101]	IPM error	O		O			(page 42)
		[104]	Short-circuited IPM/Ground fault	O		O			(page 43)
		[105]	Overcurrent error due to short-circuited motor	O		O			(page 44)
		[106]	Instantaneous overcurrent (S/W detection)	O		O			(page 45)
		[107]	Overcurrent (effective value) (S/W detection)	O		O			(page 45)
4250	4350	[121]	DCL overcurrent error (H/W)	O					(page 46)
		[128]	DCL overcurrent error (H/W)	O					(page 46)
		[122]	DCL overcurrent error (S/W)	O					(page 46)
4255 4256	4355 4356	[137]	Step-out fault	O		O			(page 47)
4260	-	-	Heatsink overheat protection at startup	O					(page 47)
5102	-	-	Incorrect pipe connection		O				(page 48)
5103	1205	00	Temperature sensor fault	O					(page 50)
5104	1202	-	Temperature sensor fault	OA processing unit intake air temperature (TH1)			O		(page 49)
				Outside temperature (TH24)		O			(page 49) Detectable only by the All-Fresh type indoor units
				Outdoor unit discharge temperature (TH4)	O				(page 50)

Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition		Searched unit					Notes
					Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
5105	1204	-	Temperature sensor fault	Accumulator inlet temperature (TH5)	O					(page 50)
5107	1221	-	Temperature sensor fault	Outside temperature (TH7)	O					(page 50)
5115	1203	-	Temperature sensor fault (Outdoor unit)	Compressor shell bottom temperature (TH15)	O					(page 50)
5110	1214	[0]	Backup operation		O					
		01, 05, 06	Temperature sensor fault	Heatsink temperature (THHS)	O		O			(page 51)
5111	-	-	Temperature sensor fault (HBC)	Liquid-side refrigerant temp. of Heating-main heat exchanger (TH11)			O			(page 52)
5112	-	-		Liquid-side refrigerant temp. of Cooling-main heat exchanger (TH12)			O			(page 52)
5113	-	-		Gas-side refrigerant temp. of Heating-main heat exchanger (TH13)			O			(page 52)
5114	-	-		Gas-side refrigerant temp. of Cooling-main heat exchanger (TH14)			O			(page 52)
5115	-	-		Bypass inlet temperature (TH15)			O			(page 52)
5116	-	-		Bypass outlet temperature (TH16)			O			(page 52)
5120	1248	[0]		Backup operation		O				
5132	-	-	Temperature sensor fault (HBC)	Water-side outlet temp. of Heating-main heat exchanger (TH32)			O			(page 52)
5133	-	-		Water-side outlet temp. of Cooling-main heat exchanger (TH33)			O			(page 52)
5134	-	-		Water pump WP2 outlet temperature (TH34)			O			(page 52)
5135	-	-		Water pump WP1 outlet temperature (TH35)			O			(page 52)
5141	-	-	Temperature sensor fault (HBC)	1st port returned water temp. (TH31a)			O			(page 52)
5142	-	-		2nd port returned water temp. (TH31b)			O			(page 52)
5143	-	-		3rd port returned water temp. (TH31c)			O			(page 52)
5144	-	-		4th port returned water temp. (TH31d)			O			(page 52)
5145	-	-		5th port returned water temp. (TH31e)			O			(page 52)
5146	-	-		6th port returned water temp. (TH31f)			O			(page 52)



Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition	Searched unit					Notes
				Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
5161	-	-	Temperature sensor fault (Sub-HBC)			O			(page 52)
5162	-	-				O			(page 52)
5163	-	-				O			(page 52)
5164	-	-				O			(page 52)
5165	-	-				O			(page 52)
5166	-	-				O			(page 52)
5167	-	-				O			(page 52)
5168	-	-				O			(page 52)
5169	-	-				O			(page 52)
5170	-	-				O			(page 52)
5171	-	-				O			(page 52)
5172	-	-				O			(page 52)
5173	-	-				O			(page 52)
5174	-	-				O			(page 52)
5175	-	-				O			(page 52)
5176	-	-				O			(page 52)
5177	-	-				O			(page 52)
5178	-	-				O			(page 52)
5201	1402	-	High-pressure sensor fault (63HS1)	O					(page 53)
5201	-	-	High-pressure sensor fault (HBC PS1)			O			(page 54)
5201	-	-	Water pressure sensor fault (indoor unit)		O				(page 53)
5202	-	-	Water pressure sensor fault (indoor unit)		O				(page 54)
5203	-	-	Intermediate pressure sensor fault (HBC PS3)			O			(page 54)
5211	-	-	Water pressure sensor fault (HBC Pw1)			O			(page 55)
5212	-	-	Water pressure sensor fault (HBC Pw2)			O			(page 55)
5213	-	-	Water pressure sensor fault (HBC Pw3)			O			(page 55)

Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition	Searched unit					Notes
				Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
5214	-	-	Water pressure sensor fault (HBC Pw4)			O			(page 55)
5301	4300	[0]	Backup operation	O					
		[115]	ACCT sensor fault	O					(page 55)
		[117]	ACCT sensor circuit fault	O					(page 56)
5301 5305 5306	4300 4305 4306	[0]	Backup operation	O					
		[119]	Open-circuited IPM/Loose ACCT connector	O		O			(page 57)
		[120]	Faulty ACCT wiring	O		O			(page 58)
5305 5306	4305 4306	[0]	Backup operation	O					
		[135]	Position detection error at startup	O		O			(page 59)
		[136]	Position detection error during operation	O		O			(page 60)
5701	-	-	Loose float switch connector		O	O			(page 60)
6201	-	-	Remote controller board fault (nonvolatile memory error)					O	(page 61)
6202	-	-	Remote controller board fault (clock IC error)					O	(page 61)
6600	-	[001]	Detection of overlapped address in centralized control system	O	O	O	O	O	(page 62)
		[002]	Detection of overlapped address in indoor unit system	O	O	O	O	O	(page 62)
6601	-	[001]	Detection of polarity setting error in centralized control system				O	O	(page 62)
		[002]	Detection of polarity setting error in indoor unit system				O	O	(page 62)
6602	-	[001]	Transmission processor hardware error in centralized control system	O	O	O	O	O	(page 63)
		[002]	Transmission processor hardware error in indoor unit system	O	O	O	O	O	(page 63)
6603	-	[001]	Transmission Bus-Busy error in centralized control system	O	O	O	O	O	(page 64)
		[002]	Transmission Bus-Busy error in indoor unit system	O	O	O	O	O	(page 64)
6606	-	[003]	Communication error between device processor on circuit board and M-NET processor	O	O	O	O	O	(page 64)
6607	-	-	No ACK error	O	O	O	O	O	(page 65)
6608	-	-	No response error	O	O	O	O	O	(page 72)
6831	-	-	MA controller signal reception error (No signal reception)		O			O	(page 73)
6832	-	-	MA remote controller signal transmission error (Synchronization error)		O			O	(page 74)
6833	-	-	MA remote controller signal transmission error (H/W error)		O			O	(page 75)
6834	-	-	MA controller signal reception error (Start bit detection error)		O			O	(page 76)
6840	-	-	A control communication reception error		O			O	(page 77)
6841	-	-	A control communication synchronism not recover		O			O	(page 77)

Error Code	Preliminary error code	Error (preliminary) detail code	Error code definition	Searched unit					Notes
				Outdoor unit	Indoor unit	HBC	LOSSNAY	Remote controller	
6842	-	-	A control communication transmission/reception hardware trouble		O			O	(page 78)
6843	-	-	A control communication start bit detection error		O			O	(page 79)
6846	-	-	Start-up time over		O			O	(page 80)
7100	-	-	Total capacity error	O					(page 81)
7101	-	-	Capacity code setting error	O	O	O	O		(page 82)
7102	-	-	Wrong number of connected units	O		O			(page 83)
7107	-	-	Port setting error			O			(page 84)
7110	-	-	Connection information signal transmission/reception error	O					(page 86)
7111	-	-	Remote controller sensor fault		O		O		(page 86)
7113	-	-	Function setting error (improper connection of CN-TYP)	O		O			(page 87)
7117	-	-	Model setting error	O		O			(page 88)
7130	-	-	Incompatible unit combination	O		O			(page 89)
Er91	-	-	Firmware update error	O					(page 90)

**[Outdoor unit]**

**Note**

The last digit in the check error codes in the 4000's and 5000's and two-digit detail codes indicate if the codes apply to inverter on fan inverter.

Example

Code 4225 (detail code 108): Bus voltage drop in the fan inverter system

Code 4230 : Heatsink overheat protection in the inverter system

The last digit	Inverter system
0 or 1	Compressor inverter system
5 or 6	Fan inverter system

<Compressor inverter>

INV board	Outdoor units	Overload protection I <sub>max</sub> (Arms)	Current effective value error (Arms)	Current peak value error (A <sub>peak</sub> )	Temperature protection TOL (°C)
INV35Y	(E)M200	19	23	56	95
	(E)M250				
	(E)M300				
INV42Y	(E)M350	27	33		
	(E)M400				
	(E)M450				
INV37YC	(E)M500				

<Fan inverter>

INV board	Outdoor units	Overload protection I <sub>max</sub> (Arms)	Current effective value error (Arms)	Current peak value error (A <sub>peak</sub> )	Temperature protection TOL (°C)
INVS/19Y	(E)M200	3.9	Off	7.0	Off
	(E)M250				
	(E)M300				
	(E)M350	4.5		8.5	
	(E)M400				
	(E)M450				
	(E)M500	3.9		7.0	

[HBC]

Note

The HBC controller has a pump inverter, power-supply board, and valve-block board. The last digit of the error codes in the 4000's and the 5000's and of the two-digit detail code distinguishes which item the error applies to.

Example

4305 (Detail 05)

4308 (Detail 08)

4501 (Detail X1)

Serial communication error → Pump inverter

Serial communication error → Power-supply board

Serial communication error → Valve-block board

The last digit	Inverter system
0 or 1 or 4	Valve-block board
5 or 6	Pump inverter
8	Power-supply board

<Pump inverter>

INV board	HBC	Overload protection I <sub>max</sub> (Arms)	Current effective value error (Arms)	Current peak value error (A <sub>peak</sub> )	Temperature protection TOL (°C)
INV/S20	CMB-WM350F-AA CMB-WM500F-AA	5.0	On	8.0	90

## 7-2 Error Code Definitions and Solutions: Codes [0 - 999]

### 7-2-1 Error Code [0403]

#### 1. Error code definition

Serial communication error

#### 2. Error definition and error detection method

##### [Outdoor unit]

Serial communication error between the control board and the INV board on the compressor, and between the control board and the Fan board

Detail code 1: Between the control board and the INV board

Detail code 5, 6: Between the control board and the Fan board

##### [HBC]

Serial communication error between the control board and the pump INV board, between the control board and the power-supply board, and between the control board and the valve block board

Detail code 05, 06: Between the control board and the pump INV board

Detail code 08: Between the control board and the power-supply board

Detail code X1, X2, X4: Between the control board and the valve block board (X=0, 2, 3, 4, 5)

#### 3. Cause, check method and remedy

##### [Outdoor unit]

##### (1) Faulty wiring

Check the following wiring connections.

- 1) Between Control board and Fan board

Control board	FAN board
CN4A	CN80
CN4B	CN80

- 2) Between control board and INV board

Control board	INV board
CN4	CN2

- 3) Between power-supply board and INV board

Power-supply board	INV board
CNINV	CN19V

- 4) Between power-supply board and Fan board

Power-supply board	FAN board
CNFAN1	CN81
CNFAN2	CN81

##### (2) PS board failure

Replace the PS board if the LED on the INV board, Fan board, or control board is not lit.

Using the detail codes, check the status of the LEDs on the circuit boards below.

Detail code 1: LED on the INV board

Detail code 5: LED on the right Fan board

Detail code 6: LED on the left Fan board

\*When the power-supply board is normal, all LEDs will be lit.

##### (3) INV board failure, Fan board failure and Control board failure

If the problem persists after a power reset, replace the INV board, FAN board, or control board.

**(4) Incorrect DIPSW setting on the Fan board**

Make sure the DIPSW on the Fan board are set as follows.

- Models with a single fan  
 DIPSW 1-3: ON  
 (All other switches: OFF)
- Models with two fans  
 DIPSW 1-3 on the right Fan board: ON (All other switches: OFF)  
 DIPSW 1-4 on the left Fan board: ON (All other switches: OFF)

**[HBC]**

**(1) Faulty wiring**

Check the following wiring connections.

- 1) Between the control board and the pump INV board (Detail code 5, 6)

Control board	Inverter board	Power-supply board
CN4A	CN80	-
CN4B	CN80	-
CN302	-	CNRST
-	CN81	CN17V1
-	CN81	CN17V2

- 2) Between the control board and the power-supply board (Detail code 8)

Control board	Power-supply board
CN901	CN001
CN902	CN002

- 3) Between the control board and the valve block board (Detail code X1, X2, X4)

Control board	Valve block board
CNV1	CNVS1
CNV2	CNVS1
CN702	CNDC1
-	CNDC1 ↔ CNDC2

**(2) Power-Supply board failure**

Replace the power-supply board if any of the LEDs on the following is unlit: Inverter board, control board, power-supply board, or valve block board.

**(3) Inverter board fault, control board fault, and valve block board fault**

If the problem persists after a power reset, replace the INV board, FAN board, control board, or valve block board.

**(4) Incorrect DIPSW setting on the pump INV board**

Make sure the DIPSW on the pump INV board are set as follows.

- DIPSW 1-3 on the left pump INV board: ON (All other switches: OFF)
- DIPSW 1-4 on the right pump INV board: ON (All other switches: OFF)

**(5) Incorrect address setting for the valve block board**

Check that CNADR of the valve block board is as follows.

- 6/8-branch model: No connector connection to CNADR
- 16-branch model: Connect the connector to the CNADR of the left valve block board.

## 7-2-2 **Error Code [0404]**

---

### 1. Error code definition

Indoor unit control-related errors

### 2. Error definition and error detection method

Indoor controller board

Abnormal if data cannot be read normally from the nonvolatile memory of the indoor controller board.

### 3. Cause, check method and remedy

Cause	Check method and remedy
Defective indoor controller board	Replace indoor controller board.

Note: Refer also to the Service Handbook for the indoor units.

## 7-3 Error Code Definitions and Solutions: Codes [1000 - 1999]

### 7-3-1 Error Code [1102]

#### 1. Error code definition

Discharge temperature fault

#### 2. Error definition and error detection method

- 1) If the discharge temperature of 120 °C [248°F] or more is detected during the operation (the first detection), the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the discharge temperature of 120° C [248°F] or more is detected again (the second detection) within 30 minutes after the second stop of the outdoor unit described above, the mode will be changed to 3 - minute restart mode, then the outdoor unit will restart in 3 minutes.
- 3) If the discharge temperature of 120°C [248°F] or more is detected (the third detection) within 30 minutes after the stop of the outdoor unit described above (regardless of the first or the second stop), the outdoor unit will make an error stop, and the error code "1102" will be displayed.
- 4) If the discharge temperature of 120°C [248°F] or more is detected more than 30 minutes after the previous stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop (the first stop or the second stop) of the outdoor unit, preliminary errors will be displayed on the LED display.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Gas leak, gas shortage	Refer to the following page(s). [6-3 Evaluating and Adjusting Refrigerant Charge]
(2) Overload operation	Check operating conditions and operation status of indoor/ outdoor units.
(3) HBC LEV malfunction Cooling only: LEV1, 2, and 3 Cooling main: LEV1, 2, and 3 Heating only or heating main: LEV1, 2, and 3 Defrost: LEV1, 2, and 3	Perform a heating operation and check the operation. Cooling: HBC LEV1, 2, and 3 SV1 21S4Ma and 21S4Mb Heating: HBC LEV1, 2, and 3 SV1 21S4Ma and 21S4Mb
(4) HBC SV1, 21S4Ma, and 21S4Mb malfunction → Cooling only or defrost	Refer to the following page(s). [8-8 Troubleshooting LEV, FCV Problems]
(5) HBC SV1, 21S4Ma, and 21S4Mb malfunction → Cooling only or cooling main	
(6) HBC SV1, 21S4Ma, and 21S4Mb malfunction → Heating only or heating main	
(7) Actuation failure in the four-way valve (21S4a or 21S4b) or the expansion valve (LEV2a or LEV2b) →heating only, heating main	
(8) Port address setting error.	Confirm the port address of the indoor unit.
(9) Refrigerant service valve actuation failure	Confirm that the refrigerant service valve is fully open.
(10) Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction Rise in discharge temp. by low pressure drawing for (3) - (11).	Check the fan on the outdoor unit. Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems]
(11) Gas leak between low and high pressures (4-way valve failure, Compressor failure, Solenoid valve (SV1a) failure)	Perform a cooling or heating operation and check the operation.
(12) Thermistor failure (TH4)	Refer to the following page(s). [7-7-3 Error Code [5103,5104,5105,5107,5115]]
(13) Input circuit failure on the controller board thermistor	Check the inlet air temperature on the LED monitor.
(14) Outdoor unit LEV4 valve actuation failure	Refer to the following page(s). [8-8 Troubleshooting LEV, FCV Problems]



## 7-3-2 Error Code [1301]

### 1. Error code definition

Low pressure fault

### 2. Error definition and error detection method

When starting the compressor from Stop Mode for the first time if low pressure reads 0.098MPa [14psi] immediately before start-up, the operation immediately stops.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Inner pressure drop due to a leakage.	Refer to the following page(s). [8-5-3 Comparing the Low-Pressure Sensor Measurement and Gauge Pressure]
(2) Low pressure sensor failure	
(3) Short-circuited pressure sensor cable due to torn outer rubber	
(4) A pin on the male connector is missing.	
(5) Disconnected wire	
(6) Failure of the low pressure input circuit on the controller board	

**Note**

When a shut-off valve is installed as a safety measure, closing of the valve may cause this error.

### 7-3-3 Error Code [1302] (during operation)

#### 1. Error code definition

High pressure fault 1 (Outdoor unit)

#### 2. Error definition and error detection method

- 1) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor during operation (the first detection), the outdoor stops once, turns to antirestart mode for 3 minutes, and restarts after 3 minutes automatically.
- 2) If the pressure of 3.78MPa [548psi] or higher is detected by the pressure sensor again (the second detection) within 30 minutes after the first stop of the outdoor unit, the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes automatically.
- 3) If the pressure of 3.87MPa [561psi] or higher is detected by the pressure sensor (the 15th detection) within 30 minutes of the 14th stop of the outdoor unit, the outdoor unit will make an error stop, and the error code "1302" will be displayed.
- 4) If the pressure of 3.78MPa [548psi] or higher is detected more than 30 minutes after the stop of the outdoor unit, the detection is regarded as the first detection, and the operation described in step 1 above will start.
- 5) For 30 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.
- 6) The outdoor unit makes an error stop immediately when not only the pressure sensor but also the pressure switch detects  $4.15^{+0,-0.15}$  MPa [ $601^{+0,-22}$  psi]

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) HBC LEV malfunction Heating only or heating main: LEV1, 2, and 3 Defrost: LEV1, 2, and 3	Perform a heating operation and check the operation. Cooling: Four-way valves (21S4a, 21S4b, and 21S4c) on the outdoor unit Expansion valves (LEV2a, 2b, 2c, and 2d) HBC SV1, 21S4Ma, and 21S4Mb  Heating: HBC SV1, 21S4Ma, and 21S4Mb Refer to the following page(s). [8-8 Troubleshooting LEV, FCV Problems]
(2) HBC SV1, 21S4Ma, and 21S4Mb malfunction →Cooling only or defrost	
(3) HBC SV1, 21S4Ma, and 21S4Mb malfunction →Cooling only or cooling main	
(4) HBC SV1, 21S4Ma, and 21S4Mb malfunction →Heating only or heating main HBC SV1, 21S4Ma, and 21S4Mb malfunction →Cooling only or cooling main	
(5) Actuation failure in the four-way valve (21S4a, 21S4b or 21S4c) or the expansion valve (LEV2a, LEV2b, LEV2c, or LEV2d) →Cooling-only or cooling-main	
(6) Port address setting error.	Confirm the port address of the indoor unit.
(7) Refrigerant service valve actuation failure	Confirm that the refrigerant service valve is fully open.
(8) Short cycle on the outdoor unit	Check the outdoor units for problems and correct them, if any.
(9) Dirty heat exchanger of the outdoor unit	
(10) Outdoor fan (including fan parts) failure, motor failure, or fan controller malfunction Items (8) through (10) above reduce the condensing capability of the unit, resulting in high-pressure rise during cooling operation.	
(11) Solenoid valve (SV1a) malfunction The by-pass valve (SV1a) can not control rise in high pressure.	Refer to the following page(s). [8-6 Troubleshooting Solenoid Valve Problems]
(12) Thermistor failure (TH3, TH7)	Refer to the following page(s). [7-7-3 Error Code [5103,5104,5105,5107,5115]]
(13) Pressure sensor failure	Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]
(14) Failure of the thermistor input circuit and pressure sensor input circuit on the controller board	Check the sensor temperature/pressure on the LED monitor.
(15) Thermistor mounting problem (TH3, TH7)	
(16) Disconnected male connector on the pressure switch (63H1) or disconnected wire	
(17) Open phase in the power-supply due to improper power-supply wiring	Refer to item (6) in section [6-1 Read before Test Run].

### 7-3-4 Error Code [1302] (at startup)

**1. Error code definition**

High pressure fault 2 (Outdoor unit)

**2. Error definition and error detection method**

If the pressure of 0.098MPa [14psi] or lower is registered on the pressure sensor immediately before start-up, it will trigger an abnormal stop, and error code "1302" will be displayed.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Inner pressure drop due to a leakage.	Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]
(2) Pressure sensor failure	
(3) Shorted-circuited pressure sensor cable due to torn outer rubber	
(4) A pin on the male connector on the pressure sensor is missing or contact failure	
(5) Disconnected pressure sensor cable	
(6) Failure of the pressure sensor input circuit on the controller board	
(7) Open phase in the power-supply due to improper power-supply wiring	Refer to item (6) in section [6-1 Read before Test Run].

### 7-3-5 Error Code [1500]

**1. Error code definition**

Refrigerant overcharge

**2. Error definition and error detection method**

An error can be detected by the shell bottom superheat (TH15 - Te).

- 1) If the formula "compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]" is satisfied during operation (first detection), the outdoor unit stops, goes into the 3-minute restart mode, and starts up in three minutes.
- 2) If the formula "compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]" is satisfied again within 40 minutes of the first stoppage of the outdoor unit (second detection), the unit comes to an abnormal stop, and the error code "1500" appears.
- 3) If the formula "compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]" is satisfied 40 minutes or more after the first stoppage of the outdoor unit, the same sequence as Item 1) above (first detection) is followed.
- 4) For 40 minutes after the stop of the outdoor unit, preliminary errors will be displayed on the LED display.
- 5) If the formula "compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]" is satisfied during the defrost operation and if the formula "compressor bottom SH (TH15 - Te) ≤ 10°C [18°F]" is also satisfied after the defrost operation, the same sequence as Item 1) above (first detection) is followed.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Overcharged refrigerant	Refer to the following page(s). [6-3 Evaluating and Adjusting Refrigerant Charge]
(2) Thermistor input circuit failure on the control board	Check the temperature and pressure readings on the sensor that are displayed on the LED monitor.
(3) Faulty mounting of thermistor (TH4, TH15)	Check the temperature and pressure readings on the thermistor that are displayed on the LED monitor.

## 7-4 Error Code Definitions and Solutions: Codes [2000 - 2999]

### 7-4-1 Error Code [2500] (Models with a drain sensor)

#### 1. Error code definition

Drain sensor submergence

#### 2. Error definition and error detection method

- 1) If an immersion of the drain sensor in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.
- 2) If the immersion of the sensor in the water is detected four consecutive times at an hour interval, this is considered water leakage, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
  - ♦One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
  - ♦The operation mode is changed to Cool/Dry.
  - ♦The liquid pipe temperature minus the inlet temperature is  $-10^{\circ}\text{C}$  [ $-18^{\circ}\text{F}$ ] or less.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Drain water drainage problem ♦Clogged drain pump ♦Clogged drain piping ♦Backflow of drain water from other units	Check for proper drainage.
(2) Adhesion of water drops to the drain sensor ♦Trickling of water along the lead wire ♦Rippling of drain water caused by filter clogging	1) Check for proper lead wire installation. 2) Check for clogged filter.
(3) Failure of the relay circuit for the solenoid valve	Replace the relay.
(4) Indoor unit control board failure ♦Drain sensor circuit failure	If the above item checks out OK, replace the indoor unit control board.

## 7-4-2 Error Code [2500] (Models with a float switch)

### 1. Error code definition

Drain sensor submergence


### 2. Error definition and error detection method

- 1) If an immersion of the float switch in the water is detected while the unit is in any mode other than the Cool/Dry mode and when the drain pump goes from OFF to ON, this condition is considered preliminary water leakage. While this error is being detected, humidifier output cannot be turned on.
- 2) If the drain pump turns on within one hour after preliminary water leakage is detected and the above-mentioned condition is detected two consecutive times, water leakage error water leakage is detected, and "2500" appears on the monitor.
- 3) Detection of water leakage is also performed while the unit is stopped.
- 4) Preliminary water leakage is cancelled when the following conditions are met:
  - One hour after the preliminary water leakage was detected, it is not detected that the drain pump goes from OFF to ON.
  - The operation mode is changed to Cool/Dry.
  - The liquid pipe temperature minus the inlet temperature is - 10°C [-18°F] or less.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Drain water drainage problem •Clogged drain pump •Clogged drain piping •Backflow of drain water from other units	Check for proper drainage.
(2) Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(3) Float switch failure	Check the resistance with the float switch turned on and turned off.

<Reference>



### 7-4-3 **Error Code [2501] (Water pump fault)**

**1. Error code definition**

**Pump water supply cutoff**

**2. Error definition and error detection method**

- 1) The pressure differential of less than 10 kPa as obtained from the pressures taken before and after Pump 1 (Pw2-Pw1) was detected three times in a row while Pump 1 is in operation.
- 2) The pressure differential of less than 10 kPa as obtained from the pressures taken before and after Pump 2 (Pw4-Pw3) was detected three times in a row while Pump 2 is in operation.
- 3) Pump 1 outlet water temperature (TH35) of 70°C or above was detected three times in a row.
- 4) Pump 2 outlet water temperature (TH34) of 70°C or above was detected three times in a row.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Pump operation failure	Refer to [8-9-4 Water Pump Control]
(2) Air-vent failure	1) Make sure the air vent valves are located in appropriate locations. Refer to [8-14-3 Instructions for the Air Vent Operation].
	2) Vent the air again in accordance with the procedures explained in [8-14-3 Instructions for the Air Vent Operation].



## 7-4-4 Error Code [2502] (Models with a drain sensor)

### 1. Error code definition

Drain pump fault

### 2. Error definition and error detection method

- 1) Make the drain sensor thermistor self-heat by passing current through it. If the temperature rise is small, it is interpreted that the sensor is immersed in water. This condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- 2) If another episode of the above condition is detected during the preliminary error, this is considered a drain pump error, and "2502" appears on the monitor.
- 3) This error is always detected while the drain pump is in operation.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
  - \*"Liquid pipe temperature-inlet temperature  $\leq -10^{\circ}\text{C}$  [ $-18^{\circ}\text{F}$ ]" has been detected for 30 minutes.
  - \*The immersion of drain sensor is detected 10 consecutive times.
  - \*The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop. "2502" appears on the monitor of the units that came to an error stop.
- 6) Forced stoppage of the outdoor unit  
 Detection timing: The error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit  
 Power reset the indoor unit that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.  
 Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.  
 (Note) Items 1) - 3) and 4) - 7) are detected independently from each other.

**Note**

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Drain pump failure	Check for proper functioning of the drain pump.
(2) Drain water drainage problem <ul style="list-style-type: none"> <li>•Clogged drain pump</li> <li>•Clogged drain piping</li> </ul>	Check for proper drainage.
(3) Adhesion of water drops to the drain sensor <ul style="list-style-type: none"> <li>•Trickling of water along the lead wire</li> <li>•Rippling of drain water caused by filter clogging</li> </ul>	1) Check for proper lead wire installation. 2) Check for clogged filter.
(4) Indoor unit control board failure <ul style="list-style-type: none"> <li>•Drain pump drive circuit failure</li> <li>•Drain heater output circuit failure</li> </ul>	If the above item checks out OK, replace the indoor unit control board.
(5) Wrong dipswitch setting on the indoor unit controller board <ul style="list-style-type: none"> <li>•Dipswitch for the new indoor unit controller board was wrongly set to "unit model without drain pump" instead of "unit model with drain pump" when the board was replaced.</li> </ul>	Check for proper dipswitch model setting on the indoor unit controller board.

## 7-4-5 Error Code [2502] (Models with a float switch)

### 1. Error code definition

#### Drain pump fault

### 2. Error definition and error detection method

- 1) The immersion of sensor tip in water is detected by the ON/OFF signal from the float switch.
  - \*Submergence of the sensor  
When it is detected that the float switch has been ON for 15 seconds, it is interpreted that the sensor tip is immersed in water.
  - \*Sensor in the air  
When it is detected that the float switch has been OFF for 15 seconds, it is interpreted that the sensor tip is not immersed in water.
- 2) If it is detected that the float switch has been ON for 3 minutes after the immersion of the sensor tip was detected, this is considered a drain pump failure, and "2502" appears on the monitor.
  - \*The total time it takes for this error to be detected is 3 minutes and 15 seconds, including the time it takes for the first immersion of the sensor tip to be detected.
- 3) Detection of drain pump failure is performed while the unit is stopped.
- 4) The following criteria are met when the criteria for the forced stoppage of outdoor unit (system stoppage) are met.
  - \*"Liquid pipe temperature-inlet temperature  $\leq -10^{\circ}\text{C}$  [ $-18^{\circ}\text{F}$ ]" has been detected for 30 minutes.
  - \*It is detected by the float switch that the sensor tip has been immersed in water for 15 minutes or more.
  - \*The conditions that are listed under items 1) through 3) above are always met before the criteria for the forced stoppage of the outdoor unit.
- 5) The indoor unit and the HBC that detected the conditions that are listed in item 4) above brings the outdoor unit in the same refrigerant circuit to an error stop (compressor operation prohibited), and the outdoor unit brings all the indoor units and the HBCs in the same refrigerant circuit that are in any mode other than Fan or Stop to an error stop. "2502" appears on the monitor of the units that came to an error stop.
- 6) Forced stoppage of the outdoor unit  
Detection timing: The error is detected whether the unit is in operation or stopped.
- 7) Ending criteria for the forced stoppage of outdoor unit  
Power reset the indoor unit and the HBC that was identified as the error source and the outdoor unit that is connected to the same refrigerant circuit.  
Forced stoppage of the outdoor unit cannot be cancelled by stopping the unit via the remote controller.  
(Note) Items 1) - 3) and 4) - 7) are detected independently from each other.

#### Note

The address and attribute that appear on the remote controller are those of the indoor unit (or OA processing unit) that caused the error.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Drain pump failure	Check for proper functioning of the drain pump mechanism
(2)	Drain water drainage problem •Clogged drain pump •Clogged drain piping	Check for proper drainage.
(3)	Stuck float switch Check for slime in the moving parts of the float switch.	Check for normal operation of the float switch.
(4)	Float switch failure	Check the resistance with the float switch turned on and turned off.
(5)	Indoor unit/Sub-HBC control board failure •Drain pump drive circuit failure •Float switch input circuit failure	Replace indoor unit/Sub-HBC control board.
(6)	Wrong dipswitch setting on the indoor unit controller board •Dipswitch for the new indoor unit controller board was wrongly set to "unit model without drain pump" instead of "unit model with drain pump" when the board was replaced.	Check for proper dipswitch model setting on the indoor unit controller board.
(7)	Items (1) through (5) above and an indoor unit electronic valve closure failure (leaky valve) occurred simultaneously.	Check the solenoid valves on the indoor unit for leaks.
(8)	Untightened manual air vent valve	Visual/Manual inspection

•During water supply or air vent operation, set the Dip SW 001-2 from OFF to ON. (This error is ignored for nine hours.)



## 7-4-6 Error Code [2503]

### 1. Error code definition

Drain sensor (Thd) fault

### 2. Error definition and error detection method

- If the open or short circuit of the thermistor has been detected for 30 seconds, this condition is considered to be a preliminary error, and the unit goes into the 3-minute restart delay mode.
- If another episode of the above condition is detected during the preliminary error, this is considered a drain sensor error.(If the short or open circuit of the thermistor is no longer detected, normal operation will be restored in 3 minutes.)
- This error is detected when one of the following conditions are met.
  - \*During Cool/Dry operation
  - \*Liquid pipe temperature minus inlet temperature is equal to or smaller than -10°C [-18°F] (except during the defrost cycle)
  - \*When the liquid temperature thermistor or suction temperature thermistor or short or open circuited.
  - \*Drain pump is in operation.
  - \*One hour has elapsed since the drain sensor went off.
    - Short: 90°C [194 °F] or above
    - Open: - 20°C [-4 °F] or below

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Faulty connector (CN31) insertion.	1) Check for connector connection failure. Reinsert the connector, restart the operation, and check for proper operation.
(2) Broken or semi-broken thermistor wire	2) Check for a broken thermistor wire.
(3) Thermistor failure	3) Check the resistance of the thermistor. 0°C[32 °F]:6.0 kΩ 10°C[50 °F]:3.9 kΩ 20°C[68°F]:2.6 kΩ 30°C[86°F]:1.8 kΩ 40°C[104 °F]:1.3 kΩ
(4) Indoor unit control board (error detection circuit) failure	4) Replace the indoor unit control board if the problem recurs when the unit is operated with the No.-1 and No.-2 pins on the drain sensor connector (CN31) being short-circuited. If the above item checks out OK, there are no problems with the drain sensor. Turn off the power and turn it back on.

### 7-4-7 **Error Code [2512] (Control valve failure) (Indoor unit)**

**1. Error code definition**

Flow control valve fault (indoor unit)

**2. Error definition and error detection method**

•Limit signal that is output from flow control valve is not detected or is not reset after it is detected.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Loose connectors, wiring fault	Check that the flow control valve wiring is properly connected to CN8A, and check the connectors for loose contact. If these are not the cause of the problem, replace the flow control valve.
(2) Flow control valve fault	
(3) Control board fault	If no problems are found with the above items, replace the control board.

### 7-4-8 **Error Code [2512] (Control valve failure) (HBC)**

**1. Error code definition**

Valve block fault (HBC)

**2. Error definition and error detection method**

•Limit signal that is output from valve block is not detected or is not reset after it is detected.

Detail code 01: VB3a-VB3h

Detail code 02: VB3i-VB3p

Detail code 100: MV1

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Loose connectors, wiring fault	When the LEDs on the control board (LD501) or VB board (LDV01-LDV08) are lit, check the valve block whose LED is lit for loose connectors, wiring fault, and proper operation. When the LEDs described above are not lit, check all the valve block for proper operation.
(2) Valve block fault	
(3) Control board failure/VB board failure	If the above items check out OK, replace the following boards. •Detail code 01: Replace VB board 1. *1 •Detail code 02: Replace VB board 2. *2 •Detail code 100: Replace the control board.

\*1. VB board 1: The VB board connected to VB3a-VB3h. The one on the right when facing the control box.

\*2. VB board 2: The VB board connected to VB3i-VB3p. The one on the left when facing the control box.

## 7-4-9 Error Code [2519]

### 1. Error code definition

**Water pressure drop**

### 2. Error definition and error detection method

- 1) If the reading of the pressure sensor Pw1 or Pw2 is below 10 kPa while Pump 1 is in operation, or the reading of the pressure sensor Pw3 or Pw4 is below 10 kPa while Pump 2 is in operation (first detection), the outdoor units and the pumps will stop, go into the 3-minute restart delay mode, and then restart.
- 2) If the pressure reading goes down below 10 kPa again within 10 minutes of the stoppage of the pump and within 2 minutes after the pump restarted (second detection), the outdoor units and the pumps will stop again, go into the 3-minute restart delay mode, and then restart.
- 3) If the pressure reading goes down below 10 kPa again within 10 minutes of the stoppage of the pump and within 2 minutes after the pump restarted (third detection), the units and the pumps will come to an abnormal stop, and the error code 2519 will appear.

\*Detail codes: 201(Pw1), 202(Pw2), 203(Pw3), 204(Pw4)

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Clogged strainer	Check the strainer for clogging.
(2) Insufficient supply-water pressure	Check that the supply-water pressure is in the range between 0.1 and 0.16 MPa.
(3) Air-vent failure	<ol style="list-style-type: none"> <li>1) Make sure the air vent valves are located in appropriate locations. Refer to [8-14-3 Instructions for the Air Vent Operation].</li> <li>2) Vent the air again in accordance with the procedures explained in [8-14-3 Instructions for the Air Vent Operation].</li> </ol>

## 7-4-10 Error Code [2520]

### 1. Error code definition

**Water pressure rise**

### 2. Error definition and error detection method

- 1) If the reading of the pressure sensor Pw1 or Pw2 exceeds 900 kPa while Pump 1 is in operation, or the reading of the pressure sensor Pw3 or Pw4 exceeds 900 kPa while Pump 2 is in operation (first detection), the outdoor units and the pumps will stop, go into the 3-minute restart delay mode, and then restart.
- 2) If the pressure reading exceeds 900 kPa again within 10 minutes of the stoppage of the pump and within 2 minutes after the pump restarted (second detection), the outdoor units and the pumps will stop again, go into the 3-minute restart delay mode, and then restart.
- 3) If the pressure reading exceeds 900 kPa again within 10 minutes of the stoppage of the pump and within 2 minutes after the pump restarted (third detection), the units and the pumps will come to an abnormal stop, and the error code 2520 will appear.

\*Detail codes: 201(Pw1), 202(Pw2), 203(Pw3), 204(Pw4)

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Valve block fault	When the LEDs on the control board (VB3a-VB3p) are lit, check the valve block whose LED is lit for loose connectors, wiring fault, and proper operation. When the LEDs described above are not lit, check all the valve block for proper operation.
(2) Port address setting error	Check the indoor unit port address settings.
(3) Deformed water pipe on site	Check the water pipes on site for deformation.
(4) Pressure sensor fault	Refer to [8-9-1 Pressure Sensor].

### 7-4-11 **Error Code [2600]**

---

#### 1. Error code definition

Water leakage

#### 2. Cause, check method and remedy

Check that water does not leak from the pipes in such as the humidifier.

### 7-4-12 **Error Code [2601]**

---

#### 1. Error code definition

Water supply cutoff

#### 2. Cause, check method and remedy

Cause		Check method and remedy
(1)	The water tank of the humidifier is empty.	Check the amount of supply water. Check for the solenoid valve and for the connection.
(2)	The solenoid valve for humidification is OFF.	Check the connector.
(3)	Disconnected float switch	Check the connecting part.
(4)	Poor operation of float switch	Check for the float switch.
(5)	Frozen water tank	Turn off the power source of the water tank to defrost, and turn it on again.

## 7-5 Error Code Definitions and Solutions: Codes [3000 - 3999]

### 7-5-1 Error Code [3121]

#### 1. Error code definition

Out-of-range outside air temperature

#### 2. Error definition and error detection method

- When the thermistor temperature of -28°C[-18°F] or below has continuously been detected for 3 minutes during heating operation (during compressor operation), the unit makes an error stop and "3121" appears on the display. (Use the OC thermistor temperature to determine when two outdoor units are in operation.)
- The compressor restarts when the thermistor temperature is -26°C[-15°F] or above (both OC and OS) during error stop. (The error display needs to be canceled by setting the remote controller.)
- Outdoor temperature error is canceled if the units stop during error stop. (The error display needs to be canceled by setting the remote controller.)

#### 3. Cause, check method and remedy

Check the following factors if an error is detected, without drop in the outdoor temperature.

Cause	Check method and remedy
(1) Thermistor failure	Check thermistor resistance.
(2) Pinched lead wire	Check for pinched lead wire.
(3) Torn wire coating	Check for wire coating.
(4) A pin on the male connector is missing or contact failure	Check connector.
(5) Disconnected wire	Check for wire.
(6) Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.

<Reference>

Short detection
Open detection  
 TH7 110 °C [230 °F ] and above (0.4 kΩ)    -40 °C [-40 °F ] and below (130 kΩ)

## 7-5-2 Error Code [3511]

### 1. Error code definition

Refrigerant overcooling

### 2. Error definition and error detection method

- 1) If the condition "THHS ≤ A\*1 °C remains true for continuous 6 minutes and 30 seconds" is met (for the first time) during operation, the outdoor unit will stop, go into the three-minute restart delay mode, and then automatically resume operation after three minutes have passed.
- 2) If the condition "THHS ≤ A\*1 °C remains true for continuous 6 minutes and 30 seconds" is met again (for the second time) within 30 minutes of the first stoppage of the outdoor unit explained above, the outdoor unit will stop, go into the three-minute restart delay mode, and then automatically resume operation after three minutes have passed.
- 3) If the condition "THHS ≤ A\*1 °C remains true for continuous 6 minutes and 30 seconds" is met again (for the third time) within 30 minutes of the second stoppage of the outdoor unit explained above and before the condition "THHS > A\*1 °C remains true for continuous 2 minutes" has been met, the unit will come to an abnormal stop, and this error will be indicated as "3511."
- 4) If the condition "THHS ≤ A\*1 °C remains true for continuous 6 minutes and 30 seconds" is met (regardless of the first or second time) after 30 minutes of the first occurrence or after the condition "THHS > A\*1 °C remains true for continuous 2 minutes" has been met, it is considered as the first occurrence, and the unit will follow the same behavior as the one described in item 1) above.
- 5) For 30 minutes after the stoppage of the outdoor unit, or the period up to the time when the condition "THHS > A\*1 °C remains true for continuous 2 minutes" has been met is considered as a preliminary error, and this state will be indicated on the LED.

\*1 During cooling: A = Outside temperature TH7; During heating: A = Evaporation temperature Te

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Outdoor unit LEV9 malfunction	Check the operation of unit in the Cooling or in the Heating mode. LEV9 Refer to [8-8 Troubleshooting LEV, FCV Problems].
(2) THHS failure	1) Check the IGBT on the INV board for proper mounting. 2) Check the THHS sensor reading on the LED. → Replace the INV board if the THHS value is abnormal.
(3) Thermistor failure (TH7)	Resistance value of the thermistor
(4) Low-pressure sensor fault	Refer to [8-5 Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems]

## 7-6 Error Code Definitions and Solutions: Codes [4000 - 4999]

### 7-6-1 Error Code [4102]

#### 1. Error code definition

Open phase

#### 2. Error definition and error detection method

- An open phase of the power supply (L1 phase, N phase) was detected at power on.
- The L3 phase current is outside of the specified range.
- When an open phase is detected (L3-phase or N-phase in the power supply) is detected at the start of operation.

**Note**

The open phase of the power supply may not always be detected if a power voltage from another circuit is applied.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Power supply problem •Open phase voltage of the power supply •Power supply voltage drop	•Check the input voltage to the power supply terminal block TB1. •Possible open phase in the power-supply due to improper power-supply wiring. (Refer to item (6) in section [6-1 Read before Test Run].)
(2) Noise filter problem •Coil problem •Circuit board failure	•Check the coil connections. •Check for coil burnout.
(3) Wiring failure	Check the wiring between CN5 on the noise filter and CNAC on the control board. Check the wiring between CN3 on the noise filter and CN110 on the control board.
(4) Blown fuse	Check for a blown fuse (F001) on the control board. →If a blown fuse is found, check for a short-circuiting or earth fault of the actuator. Check for a blown fuse (F3) on the noise filter. →If a blown fuse is found, check for a short-circuiting or earth fault of the actuator.
(5) Control board failure	Replace the control board if none of the above is causing the problem.

## 7-6-2 Error Code [4106]

### 1. Error code definition

<Transmission power supply fault Error detail code FF (Outdoor unit)>

### 2. Error definition and error detection method

Transmission power output failure

### 3. Cause

- 1) Wiring failure
- 2) Transmission power supply cannot output voltage because overcurrent was detected.
- 3) Voltage cannot be output due to transmission power supply problem.
- 4) Transmission voltage detection circuit failure

### 4. Check method and remedy

Check the transmission power supply circuit on all outdoor units in a given refrigerant circuit for problems. [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit]

## 7-6-3 Error Code [4109]

### 1. Error code definition

Indoor unit fan operation error

### 2. Error definition and error detection method

- 1) Connector CN28 has remained open-circuited for 100 consecutive seconds during operation.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Auxiliary relay fault	The coil or the wiring of the auxiliary relay connected to CN28 is faulty.
(2) Connector (CN28) is disconnected.	Check the connector for proper connection.
(3) Blown fuse	Check the fuse on the control circuit board.
(4) Motor error (thermistor error inside the motor)	Check the unit fan for proper operation in the test run mode. If no problems are found with items 1 through 3 above and the fan does not operate, replace the motor.



## 7-6-4 Error Code [4114]

### 1. Error code definition

Indoor unit fan motor error

### 2. Error definition and error detection method

When the fan motor output from the indoor unit circuit board is ON and when the rotation speed input from the fan motor cannot be detected for 30 seconds or more

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Fan motor connector contact failure	Check the fan motor connector CNMF for proper connection.
(2) Indoor unit circuit board failure	Remove the fan motor connector CNMF and check the voltage at the indoor unit circuit board. Testing point    1. 280 VDC (Between CNMF1 (+) and CNMF4 (-)) 2. 15 VDC (Between CNMF5 (+) and CNMF4 (-)) Replace the indoor unit circuit board if the voltage is abnormal. If the 4114 error persists after the indoor unit circuit board is replaced, replace the fan motor as well.
(3) Fan motor fault	Replace the fan motor if the voltage is normal in step (2) above. If the 4114 error persists after the fan motor is replaced, replace the indoor unit circuit board as well.

## 7-6-5 Error Code [4115] Detail Code 101, 102

### 1. Error code definition

Power supply signal sync error

### 2. Error definition and error detection method

The frequency cannot be determined when the power is switched on.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Power supply error	<ul style="list-style-type: none"> <li>•Check for an occurrence of a(n) (instantaneous) power failure at the time of error detection.</li> <li>•Check that the power-supply voltage is 198 V or above (TB01).</li> <li>•Check to see if the power-supply frequency is in the range between 45 and 54 Hz (55 and 64 Hz) (TB01).</li> <li>•Check the power supply voltage waveform for distortion.</li> </ul>
(2) Coil problem	Check for coil burnout. (L101 and L102 mounted on the PS board)
(3) Faulty wiring	Check fuse F111, F121 (PS board)
(4) Wiring failure Between TB01 and PS board CNAC	Confirm that the voltage at the PS board connector CNAC (2-4 pin) is 198 V or above.
(5) PS board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the PS board.

## 7-6-6 Error Code [4116]

### 1. Error code definition

RPM error/Motor error

### 2. Error definition and error detection method

♦LOSSNAY

\*The motor keep running even if the power is OFF.

\*The thermal overload relay is ON. (Only for the three-phase model)

♦Indoor unit

If detected less than 180rpm or more than 2000rpm, the indoor unit will restart and keep running for 3 minutes.If detected again, the display will appear.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Board failure	Replace the board.
(2)	Motor malfunction	Check for the motor and the solenoid switch.
(3)	Solenoid switch malfunction	

## 7-6-7 Error Code [4121]

### 1. Error code definition

Function setting error

### 2. Error source, cause, check method and remedy

Error source	Cause	Check method and remedy
Outdoor unit	(1) Dip switch setting error on the control board	Check the SW6-1 setting on the control board
	(2) Connector connection error on the control board	Check that nothing is connected to the connector CNAF on the control board.
	(3) Control board failure	Replace the control board if no problems are found with the two items above.

## 7-6-8 Error Code [4124]

### 1. Error code definition

Electric system not operate due to damper abnormality

### 2. Error definition and error detection method

When the damper is not located at the designated position.

### 3. Cause, check method and remedy

When the damper is not located at the designated position.


- 1) Check there is something that interferes the opening or closing movement of the damper.
- 2) If damper does not open or close, turn OFF the power supply and measure the resistance of the damper lock motors (ML1, ML2) and the damper motor (MV2).

The resistance value is normal each. →Replace the indoor electronic control P.C. board.

The resistance value is not normal each. →Replace the motor that indicates the abnormal value.

Part name	Check method and criteria	Figure				
Damper lock motor Right(ML1)	Measure the resistance between the terminals with a tester. (Part temperature: 10°C ~ 30°C)					
Damper lock motor Left(ML2)	<table border="1"> <tr> <td>Color of the lead wire</td> <td>Normal</td> </tr> <tr> <td>BRN-other one</td> <td>235Ω~255Ω</td> </tr> </table>		Color of the lead wire	Normal	BRN-other one	235Ω~255Ω
Color of the lead wire	Normal					
BRN-other one	235Ω~255Ω					
Damper motor (MV2)	Measure the resistance between the terminals with a tester. (Part temperature: 10°C ~ 30°C)					
	<table border="1"> <tr> <td>Color of the lead wire</td> <td>Normal</td> </tr> <tr> <td>BRN-other one</td> <td>282Ω~306Ω</td> </tr> </table>	Color of the lead wire	Normal	BRN-other one	282Ω~306Ω	
Color of the lead wire	Normal					
BRN-other one	282Ω~306Ω					

- 3) If damper opens or closes, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper open by pressing VANE CONTROL button.  
There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)  
There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)
- 4) If damper opens or closes and voltages in 3) are normal, measure the voltage between CN1X1 (+) and (-) and the voltage between CN1Y1 (+) and (-) during the damper close by pressing VANE CONTROL button.  
There is not 5V DC between CN1X1 (+) and (-). →Replace the damper limit switch (open)  
There is not 0V DC between CN1X1 (+) and (-). →Replace the damper limit switch (close)  
There is 5V DC between CN1X1 (+) and (-) and 0V DC between CN1X1 (+) and (-). →Replace the indoor electronic control P.C. board.



Note: Refer also to the Service Handbook for the indoor units.

## 7-6-9 Error Code [4129] Detail Code 101

### 1. Error code definition

Converter error (Detail code 101)

### 2. Error definition and error detection method

Vdc ≥ 420 V or an overcurrent through the converter was detected during inverter operation.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Power-supply environment	<ul style="list-style-type: none"> <li>•Check for an occurrence of a(n) (instantaneous) power failure at the time of error detection.</li> <li>•Check that the power-supply voltage is between 198 V and 264 V (TB01).</li> <li>•Check the power supply voltage waveform for distortion.</li> </ul>
(2) Wiring problem	Between FT001, FT002 (Terminal mounted on PS board), and AC reactor (ACL)
(3) Power-supply board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the PS board.

## 7-6-10 Error Code [4129] Detail Code 102

### 1. Error code definition

Power supply signal sync error

### 2. Error definition and error detection method

Power supply sync signal cannot be detected during inverter operation.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Power supply error	<ul style="list-style-type: none"> <li>•Check for an occurrence of a(n) (instantaneous) power failure at the time of error detection.</li> <li>•Check that the power-supply voltage is 198 V or above (TB01).</li> <li>•Check to see if the power-supply frequency is in the range between 45 and 54 Hz (55 and 64 Hz) (TB01).</li> <li>•Check the power supply voltage waveform for distortion.</li> </ul>
(2) Coil problem	Check for coil burnout. (L101 and L102 mounted on the PS board)
(3) Faulty wiring	Check fuse F111, F121
(4) Wiring failure Between TB01 and PS board CNAC	Confirm that the voltage at the PS board connector CNAC (2-4 pin) is 198 V or above.
(5) PS board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the PS board.

## 7-6-11 **Error Code [4129] Detail Code 103**

### 1. Error code definition

Signal wire fault

### 2. Error definition and error detection method

Power supply signal not detected by control board.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Wiring fault	Check the wiring between the following: •Between CN901 (MAIN board) and CN001 (PS board) •Between CN902 (MAIN board) and CN002 (PS board)
(2) PS board failure	If none of the items described above is applicable, and if the trouble reappears even after the power is switched on again, replace the PS board.

## 7-6-12 Error Code [4130]


### 1. Error code definition

Control power supply error

### 2. Error definition and error detection method

No power is supplied to the control board from the power board.

### 3. Cause, check method and remedy



## 7-6-13 **Error Code [4131] (When indoor units with FCV are connected)**

### 1. Error code definition

Slightly open indoor unit valve during power cut

### 2. Error definition and error detection method

On the indoor units to which no power is supplied, when a temperature difference of 10°C or greater is detected between the return air temperature (TH1) and the inlet water temperature (TH2) continuously for 5 minutes during cooling operation, the error code [4131] will be displayed, and the system will come to an abnormal stop.

\*The detail code indicates the address of the indoor unit in error. (Detail code: Indoor unit address + 100)

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Slightly open indoor unit flow control valve due to power cut	Turn on the power supply.
(2)	Thermistor failure	Check the thermistor value on the LED.
(3)	Failure in the indoor unit flow control valve	Check the operation of the flow rate control valve. See [8-8-4 General Overview on FCV Operation (Indoor unit)] for the valve operation.

## 7-6-14 Error Code [4220, 4225, 4226] Detail Code 108

### 1. Error code definition

Abnormal bus voltage drop (Detail code 108)

### 2. Error definition and error detection method

#### [Outdoor unit]

If Vdc 289V or less is detected during Inverter operation. (S/W detection)

#### [HBC]

If Vdc 150V or less is detected during Inverter operation. (S/W detection)

### 3. Cause, check method and remedy

#### [Outdoor unit]

#### (1) Power supply environment

Check the power-supply wiring for an open phase. Refer to item (6) in section [6-1 Read before Test Run].

Find out if there was a (momentary) power failure.

Check whether the power voltage (Between L1 and L2, L2 and L3, and L1 and L3) is 342V or less across all phases.

#### (2) Voltage drop detected

##### 4220

INV35Y, INV42Y, and INV37YC

•Check the voltage at relay connector RYPN while the inverter is stopped.

If the voltage is 420 V or above, check the following items.

- 1) Check the LED monitor to see if the bus voltage is above 289 V, and replace the inverter board if it is 289 V or below.
- 2) Check the coil (L) connections and for broken wiring.
- 3) Check the wiring connections between noise filter board and INV board.
- 4) If the problem persists after reboot, replace the INV board.

If the voltage is below 420 V, check the following items.

- 1) Check the coil (L) connections and for broken wiring.
- 2) Check the wiring connections between noise filter board and INV board and between INV board and R1 through R5.
- 3) Check the in-rush current resistor. Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components]
- 4) If the problem persists after reboot, replace the INV board.

##### 4225, 4226

•Check the voltage at relay connector RYPN while the inverter is stopped. If the voltage is below 420 V, check the following items.

- 1) Check for proper connections of noise filter coil and DC reactor, and for broken wiring.
- 2) Check the wiring connections between INV board and FAN board.
- 3) Check item for 4220

Replace the FAN board if no problems are found.

•Check the voltage at connector RYPN while the inverter is stopped. If the voltage is 420 V or above, check the following items.

- 1) Check the state of the wiring connections between the INV board and the Fan board.
- 2) Check contents 4220

Replace the Fan board if no problems are found.

#### (3) Control board failure

Check that 12VDC is applied to connector CN72 on the control board while the inverter is operating. If voltage is absent or the wrong voltage is applied, check the fuse F01. Replace the control board if no problems are found with the fuse.



**[HBC]**

**(1) Power supply environment**

Find out if there was a (momentary) power failure.  
Check that the power-supply voltage between L and N is 198 V or greater.  
Check the power supply voltage waveform for distortion.

**(2) Voltage drop**

- Measure the voltage across TBP and TBN on the power-supply board while the inverter is stopped. Check the following if the voltage is below 239 V.
  - 1) Check the wiring between FT001/FT002 (power-supply board) and ACL for proper connection.  
Make sure the short-circuit pin of CN003 (power-supply board) is properly connected.
  - 2) Turn the power back on, and if the problem persists, replace the power-supply board.
- Measure the voltage across TBP and TBN on the power-supply board while the inverter is stopped. Check the following if the voltage is 239 V or above.
  - 1) Check the wiring between the power-supply board and the pump inverter board for proper connection.
  - 2) Check that F001 on the pump inverter board is not blown.
  - 3) Turn the power back on, and if the problem persists, replace the pump inverter board.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

**7-6-15 Error Code [4220, 4225, 4226] Detail Code 109**

**1. Error code definition**

**Abnormal bus voltage rise (Detail code 109)**

**2. Error definition and error detection method**

**[Outdoor unit]**

If  $V_{dc} \geq 830V$  is detected during inverter operation.

**[HBC]**

If  $V_{dc} \geq 407V$  is detected during inverter operation.

**3. Cause, check method and remedy**

**[Outdoor unit]**

**(1) Different voltage connection**

Check the power supply voltage on the power supply terminal block (TB1).

**(2) INV board failure**

If the problem recurs, replace the INV board or fan board.  
In the case of 4220: INV board  
In the case of 4225 and 4226: Fan board

**[HBC]**

**(1) Different voltage connection**

Check the power supply voltage on the power supply terminal block (TB1).

**(2) INV board failure**

If the problem recurs, replace the pump INV board.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-16 Error Code [4220] Detail Code 110

### 1. Error code definition

VDC error (Detail code 110)

### 2. Error definition and error detection method

BUS voltage error When Vdc is equal to or greater than 814 volts (hardware detection)

### 3. Cause, check method and remedy

Details of 4220 error: See No. 108 and 109.

Also see error details No. 129 of 4220 error (applicable to INV37YC only).

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-17 Error Code [4220, 4225, 4226] Detail Code 111, 112

### 1. Error code definition

Logic error (Detail code 111, 112)

### 2. Error definition and error detection method

Hardware error

If only the hardware error logic circuit operates, and no identifiable error is detected.

### 3. Cause, Check method and remedy

**[Outdoor unit]**

**In the case of 4220**

Cause	Check method and remedy
(1) External noise	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit]
(2) INV board failure	

**In the case of 4225 and 4226**

Cause	Check method and remedy
(1) External noise	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]
(2) Fan board failure	

**[HBC]**

Cause	Check method and remedy
(1) External noise	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(2) Pump INV board failure	

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-18 Error Code [4220] Detail Code 123

### 1. Error code definition

Voltage boost control error (Detail code 123)(outdoor unit)

### 2. Error definition and error detection method

When a drop in power supply voltage or a malfunction in the booster circuit is detected

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Inverter-output-related items	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit] Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems] Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load] Refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation] Refer to the following page(s). [8-10-15 Checking the Installation Conditions]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-19 Error Code [4220] Detail Code 129

### 1. Error code definition

Control power supply error (Detail code 129)(outdoor unit)

### 2. Error definition and error detection method

INV35Y and INV42Y  
 Detection of insufficient drive voltage for relays on INV board

INV37YC  
 Detection of insufficient drive voltage for relays on INV board or for IGBT

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Contact failure	<INV35Y and INV42Y> Check the connectors CNRY on INV board and CNRYA on MAIN board for proper connections. <INV37YC> Check the connectors CNRY on INV board and CNRYA on MAIN board for proper connections. Check the connectors CN200 on INV board and CN300 on PS board for proper connections.
(2) Voltage check	Disconnect the connector CNRYA from the control board and check the voltage at the connector CNRYA. If a voltage of 13 V is not output, replace the control board and the PS board.
(3) Inverter board failure	If the problem persists after reboot, replace the INV board.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

**7-6-20 Error Code [4220, 4225, 4226] Detail Code 131**

**1. Error code definition**

Low bus voltage at startup (Detail code 131)

**2. Error definition and error detection method**

When  $V_{dc} \leq 289$  V is detected just before the inverter operation.

**3. Cause, check method and remedy**

**(1) Inverter main circuit failure**

Same as detail code 108 of 4220 error

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

**7-6-21 Error Code [4228] Detail Code 101**

**1. Error code definition**

BUS voltage error (Software detection)

**2. Error definition and error detection method**

" $V_{dc} \geq 425$ V" or " $V_{dc} \leq 150$ V" was detected during inverter operation.

**3. Cause, check method and remedy**

**(1) Power-supply environment**

Find out if there was a (momentary) power failure.  
 Check that the voltage across L and N is between 198 and 264 VAC.  
 Check the power-supply voltage waveform for distortion.

**(2) Power-supply board failure**

- Measure the voltage across TBP and TBN on the power-supply board while the inverter is stopped. Check the following if the voltage is below 239 V.
  - 1) Check the wiring between FT001/FT002 (power-supply board) and ACL for proper connection.  
 Make sure the short-circuit pin of CN003 (power-supply board) is properly connected.
  - 2) Turn the power back on, and if the problem persists, replace the power-supply board.
- Measure the voltage across TBP and TBN on the power-supply board while the inverter is stopped. Check the following if the voltage is 239 V or above.
  - 1) Turn the power back on, and if the problem persists, replace the power-supply board.

**7-6-22 Error Code [4230] Detail Code 126**

**1. Error code definition**

DCL temperature fault (Detail code 126)(outdoor unit)

**2. Error definition and error detection method**

When DCL temperature that equals or exceeds 150°C is detected (applicable to INV37YC only)

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Contact failure	Check the connector CNTH on the INV board for proper connection.
(2) DCL temperature sensor fault	Disconnect the connector (CNTH), and measure the resistance of the DCL temperature sensor. Replace the DCL temperature sensor if the value is abnormal. Refer to [3-3 Functions of the Major Components of Outdoor Unit].
(3) INV board failure	Replace the INV board if the problem persists after the operation is resumed.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-23 Error Code [4235, 4236] Detail Code 125

### 1. Error code definition

Heatsink overheat protection (Detail code 125)

### 2. Error definition and error detection method

#### [Outdoor unit]

Detection of fan INV heatsink temperature (THHS)  $\geq 100^{\circ}\text{C}$

#### [HBC]

Detection of pump INV heatsink temperature (THHS)  $\geq 100^{\circ}\text{C}$

### 3. Cause, check method and remedy

#### [Outdoor unit]

Cause	Check method and remedy
(1) FAN board fault	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]
(2) Outdoor unit fan failure	1) Check the outdoor unit fan for proper operation. Check the fan motor if problems are found with the operation of the fan. Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(3) Air passage blockage	1) Check the heatsink and the duct for blockage. Refer to the following page(s). [8-10-20 Checking the Fan Inverter Heatsink for Clogging]
(4) THHS failure	1) Check the IGBT heatsink for proper mounting. 2) Check the THHS sensor reading on the LED. → Replace the INV board if the THHS value is abnormal.

#### [HBC]

Cause	Check method and remedy
(1) Pump INV board fault	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(2) THHS failure	1) Check the IGBT heatsink for proper mounting. 2) Check the THHS sensor reading on the LED. → Replace the INV board if the THHS value is abnormal.

#### Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-24 Error Code [4240, 4245, 4246]

### 1. Error code definition

Overload protection

### 2. Error definition and error detection method

If the output current of "(Iac) > I<sub>max</sub> (Arms)" or "THHS > TOL" is continuously detected for 10 minutes during inverter operation. Refer to the following page(s). [7-1 Error Code and Preliminary Error Code Lists]

### 3. Cause, check method and remedy

[Outdoor unit]

Cause	Check method and remedy
(1) IPM contact failure	Check the IPM and cooling plate for proper contact. (Remove the inverter board, and check the IPM heatsink grease.)
(2) Air passage blockage	Check that the heat sink cooling air passage is not blocked
(3) Power supply environment	Power supply voltage is 342 V or above.
(4) Inverter, FAN board failure	Refer to the following page(s). [8-10 Troubleshooting Inverter Problems]
(5) Compressor failure	Check that the compressor has not overheated during operation. → Check the refrigerant circuit (oil return section). Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]
(6) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly.	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board). For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]]

[HBC]

Cause	Check method and remedy
(1) IPM contact failure	Check the IPM and cooling plate for proper contact. (Remove the inverter board, and check the IPM heatsink grease.)
(2) Power supply environment	Power supply voltage is 198 V or above.
(3) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(4) Pump failure	Check that the pump has not overheated during operation. → Check the refrigerant circuit (oil return section). Refer to the following page(s). [8-9-4 Water Pump Control] [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-25 Error Code [4250, 4255, 4256] Detail Code 101

### 1. Error code definition

IPM error (Detail code 101)

### 2. Error definition and error detection method

#### [Outdoor unit]

**In the case of 4250**

If an overcurrent is detected by the overcurrent detection circuit CT003 (R127 when INV37YC) on the INV board.

**In the case of 4255 and 4256**

IPM error signal is detected.

#### [HBC]

Detection of an IPM error signal.

### 3. Cause, check method and remedy

#### [Outdoor unit]

**In the case of 4250**

Cause	Check method and remedy
(1) Inverter output related	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit] [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems] [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation] [8-10-15 Checking the Installation Conditions] Check the IGBT module resistance value of the INV board, if no problems are found. [8-10-19 Troubleshooting Problems with IGBT Module]
(2) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly.	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board). For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]]
(3) Open phase in the power-supply due to improper power-supply wiring.	Refer to item (6) in section [6-1 Read before Test Run].

**In the case of 4255 and 4256**

Cause	Check method and remedy
(1) Fan motor abnormality	Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(2) Fan board failure	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]

#### [HBC]

Cause	Check method and remedy
(1) Pump motor abnormality	Refer to the following page(s). [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]
(2) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]

#### Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-26 Error Code [4250, 4255, 4256] Detail Code 104

### 1. Error code definition

Short-circuited IPM/Ground fault (Detail code 104)

### 2. Error definition and error detection method

When IPM/IGBT short damage or grounding on the load side is detected just before starting the inverter.

### 3. Cause, check method and remedy

[Outdoor unit]

In the case of 4250

Cause	Check method and remedy
(1) Grounding fault compressor	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]
(2) Inverter output related	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit] [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems] [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation] [8-10-15 Checking the Installation Conditions]
(3) Open phase in the power-supply due to improper power-supply wiring	Refer to item (6) in section [6-1 Read before Test Run]

In the case of 4255 and 4256

Cause	Check method and remedy
(1) Grounding fault of fan motor	Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(2) Fan board failure	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]

[HBC]

Cause	Check method and remedy
(1) Grounding fault of pump motor	Refer to the following page(s). [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]
(2) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]



## 7-6-27 Error Code [4250, 4255, 4256] Detail Code 105

### 1. Error code definition

Overcurrent error due to short-circuited motor (Detail code 105)

### 2. Error definition and error detection method

When a short is detected on the load side just before starting the inverter operation.

### 3. Cause, Check method and remedy

[Outdoor unit]

In the case of 4250

Cause	Check method and remedy
(1) Short-circuited compressor	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]
(2) Output wiring	Check for a short circuit.

In the case of 4255 and 4256

Cause	Check method and remedy
(1) Short-circuited fan motor	Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(2) Output wiring	Check for a short circuit.

[HBC]

Cause	Check method and remedy
(1) Short-circuited pump motor	Refer to the following page(s). [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]
(2) Output wiring	Check for a short circuit.

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-28 Error Code [4250, 4255, 4256] Detail Code 106 and 107

### 1. Error code definition

Instantaneous overcurrent (Detail code 106)  
 Overcurrent (effective value) (Detail code 107)

### 2. Error definition and error detection method

When a current above the specified value is detected by the electric current sensor.  
 Refer to the relevant pages for the details of model names and the specified values.

### 3. Cause, check method and remedy

[Outdoor unit]

In the case of 4250

Cause	Check method and remedy
(1) Inverter output related	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit] [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems] [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation] [8-10-15 Checking the Installation Conditions] Check the IGBT module resistance value of the INV board, if no problems are found. [8-10-19 Troubleshooting Problems with IGBT Module]
(2) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly.	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board). For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]]

In the case of 4255 and 4256

Cause	Check method and remedy
(1) Fan board failure	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]
(2) Outdoor unit fan failure	Check the outdoor unit fan for proper operation. Check the fan motor if problems are found with the operation of the fan. Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(3) Air passage blockage	Check that the heat sink cooling air passage is not blocked
(4) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly.	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board). For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]]

**[HBC]**

Cause	Check method and remedy
(1) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(2) Pump failure	Check the outdoor unit pump for proper operation. Check the pump motor if problems are found with the operation of the pump. Refer to the following page(s). [8-9-4 Water Pump Control] [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

**7-6-29 Error Code [4250] Detail Code 121, 128, and 122**

**1. Error code definition**

DCL overcurrent error (H/W) (Detail code 121 and 128)(outdoor unit) DCL overcurrent error (S/W) (Detail code 122) (outdoor unit)

**2. Error definition and error detection method**

When a DCL overcurrent is detected by the electric current sensor

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) Inverter-output-related items	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit]  Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]  Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load]  Refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation]  Refer to the following page(s). [8-10-15 Checking the Installation Conditions]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-30 Error Code [4255, 4256] Detail Code 137

### 1. Error code definition

Motor synchronization loss (Detail code 137)

### 2. Error definition and error detection method

#### [Outdoor unit]

Fan motor locking was detected during operation.

#### [HBC]

Pump motor locking was detected during operation.

### 3. Cause, check method and remedy

#### [Outdoor unit]

Cause	Check method and remedy
(1) Fan motor locking	Check the fan blades for objects obstructing fan rotation.
(2) Fan motor failure	Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(3) Fan board failure	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]

#### [HBC]

Cause	Check method and remedy
(1) Pump motor locking	Check the pump for objects obstructing pump rotation.
(2) Pump motor failure	Refer to the following page(s). [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]
(3) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]

#### Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-6-31 Error Code [4260]

### 1. Error code definition

Heatsink overheat protection at startup

### 2. Error definition and error detection method

When heatsink temperature (THHS) remains at or above TOH for 10 minutes or longer after inverter startup

models	TOH
INV35Y, INV42Y	100°C
INV37YC	94°C

### 3. Cause, check method and remedy

Same as 4230 error

## 7-7 Error Code Definitions and Solutions: Codes [5000 - 5999]

### 7-7-1 Error Code [5102] (Indoor unit)

#### 1. Error code definition

Incorrect pipe connection (indoor unit)

#### 2. Error definition and error detection method

Water inlet and outlet pipes are connected in reverse. (Detected only during commissioning)

- 1) The formula "Water inlet pipe temperature (TH22) + 4°C < Water outlet pipe temperature (TH23)" is met after at least 15 minutes have passed after the operation mode was changed from Cooling/Dry to Heating during commissioning.
- 2) The formula "Water inlet pipe temperature (TH22) + 4°C < Water outlet pipe temperature (TH23)" is met after at least 10 minutes have passed after the operation mode was changed from the mode other than Cooling/Dry to Heating during commissioning.
- 3) The formula "Water inlet pipe temperature (TH22) > Water outlet pipe temperature (TH23) + 4°C" is met after at least 15 minutes have passed after the operation mode was changed from Heating to Cooling/Dry during commissioning.
- 4) The formula "Water inlet pipe temperature (TH22) > Water outlet pipe temperature (TH23) + 4°C" is met after at least 10 minutes have passed after the operation mode was changed from the mode other than Heating to Cooling/Dry during commissioning.

#### Note

This error may not be detectable under certain operating conditions due to a lack of temperature differential.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Incorrect water pipe connection	Check that the water inlet and outlet pipes are not connected in reverse.
(2) Thermistor failure	Check the thermistor resistor.
(3) Connector contact failure	0°C [32°F]: 15 kΩ
(4) Disconnected wire or partial disconnected thermistor wire	10°C [50°F]: 9.7 kΩ
	20°C [68°F]: 6.4 kΩ
	30°C [86°F]: 4.3 kΩ
	40°C [104°F]: 3.1 kΩ
(5) Indoor board (detection circuit) failure	Check the connector contact. When no fault is found, the indoor board is a failure.

## 7-7-2 Error Code [5104]

### 1. Error code definition

**5104**

**Intake air temperature sensor (TH1) fault (OA processing unit)**

**Intake air temperature sensor (TH24) fault (All-fresh (100% outdoor air) type indoor unit)**

### 2. Error definition and error detection method

•If a short or an open is detected during thermostat ON, the outdoor unit turns to anti-restart mode for 3 minutes. When the error is not restored after 3 minutes (if restored, the outdoor unit runs normally), the outdoor unit makes an error stop.

Short: detectable at 90°C [194°F] or higher

Open: detectable at -40°C [-40°F] or lower

•Sensor error at gas-side cannot be detected under the following conditions.

\*During heating operation

\*During cooling operation for 3 minutes after the compressor turns on.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Thermistor failure	Check the thermistor resistor. 0°C [32°F]: 15 kΩ 10°C [50°F]: 9.7 kΩ 20°C [68°F] : 6.4 kΩ 30°C [86°F] : 4.3 kΩ 40°C [104°F] : 3.1 kΩ
(2)	Connector contact failure	
(3)	Disconnected wire or partial disconnected thermistor wire	
(4)	Unattached thermistor or contact failure	
(5)	Indoor board (detection circuit) failure	

### 7-7-3 Error Code [5103,5104,5105,5107,5115]

#### 1. Error code definition

**5103**  
Heat exchanger outlet temperature sensor (TH3) fault (Outdoor unit)

**5104**  
Discharge temperature sensor (TH4) fault (Outdoor unit)

**5105**  
Accumulator inlet temperature sensor (TH5) fault (Outdoor unit)

**5107**  
Outside temperature sensor (TH7) fault (Outdoor unit)

**5115**  
Compressor shell bottom temperature sensor (TH15) fault (Outdoor unit)

#### 2. Error definition and error detection method

- When a short (high temperature intake) or an open (low temperature intake) of the thermistor is detected (the first detection), the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts when the detected temperature of the thermistor.
- When a short or an open is detected again (the second detection) after the first restart of the outdoor unit, the outdoor unit stops, turns to anti-restart mode for 3 minutes, and restarts in 3 minutes when the detected temperature is within the normal range.
- When a short or an open is detected again (the third detection) after the previous restart of the outdoor unit, the outdoor unit makes an error stop.
- When a short or an open of the thermistor is detected just before the restart of the outdoor unit, the outdoor unit makes an error stop, and the error code "5102", "5103", "5104", "5105" or "5107", "5115" will appear.
- During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- A short or an open described above is not detected for 10 minutes after the compressor start, during defrost mode, or for 3 minutes after defrost mode.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Thermistor failure	Check thermistor resistance.
(2) Pinched lead wire	Check for pinched lead wire.
(3) Torn wire coating	Check for wire coating.
(4) A pin on the male connector is missing or contact failure	Check connector.
(5) Disconnected wire	Check for wire.
(6) Thermistor input circuit failure on the control board	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.

<Reference>

	Short detection	Open detection
TH3	110 °C [230 °F] and above (0.4 kΩ and below)	-40 °C [-40 °F] and below (130 kΩ and above)
TH4	240 °C [464 °F] and above (0.57 kΩ and below)	0 °C [32 °F] and below (698 kΩ and above)
TH5	70 °C [158 °F] and above (1.13 kΩ and below)	-40 °C [-40 °F] and below (130 kΩ and above)
TH7	110 °C [230 °F] and above (0.4 kΩ and below)	-40 °C [-40 °F] and below (130 kΩ and above)
TH15	110 °C [230 °F] and above (0.4 kΩ and below)	-40 °C [-40 °F] and below (130 kΩ and above)

### 7-7-4 **Error Code [5110]**

**1. Error code definition**

Heatsink temperature sensor (THHS) fault (Detail code 01, 05, 06)

**2. Error definition and error detection method**

When a short or an open of THHS is detected just before or during the inverter operation.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) INV board failure	If the problem recurs when the unit is put into operation, replace the INV board.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]



## 7-7-5 Error Code [5111-5178]

### 1. Error code definition

5111-5116

Temperature sensor fault (HBC) (TH11~TH16)

5132-5135

Temperature sensor fault (HBC) (TH32~TH35)

5141-5156

Temperature sensor fault (HBC) (TH31a~TH31p)

5161-5176

Temperature sensor fault (Sub-HBC) (TH31a~TH31p)

5177-5178

Temperature sensor fault (Sub-HBC) (TH32~TH33)

### 2. Error definition and error detection method

- If a shorted (high temperature intake) or open (low temperature intake) thermistor (TH11 through TH16, TH32 through TH35, TH31a through TH31p, TH31a through TH31p, TH32, or TH33) is detected during operation, the unit comes to an abnormal stop, and an error code "5111" through "5116," "5132" through "5135," "5141" through "5156," "5161" through "5176," or "5177" through "5178" appears on the display.
- Detection of a short- or open-circuit as described above is suspended during the defrost cycle and for 3 minutes after the operation mode is changed.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Thermistor failure	Check thermistor resistance.
(2) Pinched lead wire	Check for pinched lead wire.
(3) Torn wire coating	Check for wire coating.
(4) A pin on the male connector is missing or contact failure	Check connector.
(5) Disconnected wire	Check for wire.
(6) Thermistor input circuit failure on the control board (When an error is found with TH11-TH16 or TH32-TH35)	Check the intake temperature of the sensor with the LED monitor. When the temperature is far different from the actual temperature, replace the control board.
(7) Thermistor input circuit failure on the VB board (when an error is found with TH31a-TH3p)	Check the temperature sensor reading on the LED monitor. If there is a large discrepancy between the temperature that appears on the LED monitor and the actual temperature, replace the VB board.

<Reference>

	Short detection	Open detection
TH11	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH12	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH13	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH14	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH15	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH16	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH32~TH35	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH31a~TH31f	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH31a~TH31p (Sub-HBC)	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)
TH32~TH33 (Sub-HBC)	110°C [230°F] and above (0.4kΩ)	-40°C [-40°F] and below (130kΩ)

### 7-7-6 Error Code [5201]

**1. Error code definition**

High-pressure sensor fault (63HS1)

**2. Error definition and error detection method**

- If the high pressure sensor detects 0.098MPa [14psi] or less during the operation, the outdoor unit stops once, turns to anti-restart mode for 3 minutes, and restarts after 3 minutes when the detected high pressure sensor is 0.098MPa [14psi] or more.
- If the high pressure sensor detects 0.098MPa [14psi] or less just before the restart, the outdoor unit makes an error stop, and the error code "5201" will appear.
- During 3-minute antirestart mode, preliminary errors will be displayed on the LED display.
- A error is not detected for 3 minutes after the compressor start, during defrost operation, or 3 minutes after defrost operation.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) High pressure sensor failure	Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]
(2) Pressure drop due to refrigerant leak	
(3) Torn wire coating	
(4) A pin on the male connector is missing or contact failure	
(5) Disconnected wire	
(6) High pressure sensor input circuit failure on the control board	

### 7-7-7 Error Code [5201]

**1. Error code definition**

5201  
Water pressure sensor fault (indoor unit)

**2. Error definition and error detection method**

When a pressure sensor reading of 1.05 MPa [153 psi] or above OR -0.05 MPa [7.3 psi] or below is detected, error code "5201" will appear.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) The water inner pressure sensor is open- or short-circuited. (Regardless of the indoor unit operation status)	1) Check that the water inner pressure sensor is connected. Reset the indoor unit error.
	2) Check the water inner pressure sensor wiring for breakage. Reset the indoor unit error.

### 7-7-8 Error Code [5201, 5203]

**1. Error code definition**

**5201**  
High-pressure sensor fault (HBC PS1)

**5203**  
Intermediate pressure sensor fault (HBC PS3)

**2. Error definition and error detection method**

When a pressure sensor reading of 4.06 MPa [589 psi] or above or 0.098Mpa[142psi] or below is detected, error codes "5201" or "5203" will appear.

The unit will continue its operation by using other sensors as a backup.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) High pressure sensor failure	Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]
(2) Torn wire coating	Check for damaged wire coating
(3) A pin on the male connector is missing or contact failure	Check whether a connector pin is missing
(4) Disconnected wire	Check for disconnected or broken wire
(5) High pressure sensor input circuit failure on the control board	Check the temperature detected by the sensor from the LED monitor. If the temperature is significantly different from the actual temperature, replace the control board.

### 7-7-9 Error Code [5202]

**1. Error code definition**

**5202**  
Water pressure sensor fault (indoor unit)

**2. Error definition and error detection method**

When a pressure sensor reading of 1.05 MPa [153 psi] or above OR -0.05 MPa [7.3 psi] or below is detected, error code "5202" will appear.

**3. Cause, check method and remedy**

Cause	Check method and remedy
(1) The water outlet pressure sensor is open- or short-circuited. (Regardless of the indoor unit operation status)	1) Check that the water outlet pressure sensor is connected. Reset the indoor unit error.
	2) Check the water outlet pressure sensor wiring for breakage. Reset the indoor unit error.

## 7-7-10 Error Code [5211-5214]

### 1. Error code definition

- 5211  
Pump 1 suction pressure fault (HBC Pw1)
- 5212  
Pump 1 discharge pressure fault (HBC Pw2)
- 5213  
Pump 2 suction pressure fault (HBC Pw3)
- 5214  
Pump 2 discharge pressure fault (HBC Pw4)

### 2. Error definition and error detection method

- 1) If a short-circuit (high-pressure intake) or an open-circuit (low-pressure intake) of the pressure sensor Pw1 or Pw2 is detected while Pump 1 is in operation, the unit will come to an abnormal stop, and the error code 5211 or 5212 will appear.
- 2) If a short-circuit (high-pressure intake) or an open-circuit (low-pressure intake) of the pressure sensor Pw3 or Pw4 is detected while Pump 2 is in operation, the unit will come to an abnormal stop, and the error code 5213 or 5214 will appear.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Pressure sensor fault	Refer to [8-9-1 Pressure Sensor].
(2) Broken wire coating	Check for broken wire coating.
(3) Missing connector pins, contact failure	Check for missing connector pins.
(4) Disconnected wire	Check for disconnected or broken wire.

## 7-7-11 Error Code [5301] Detail Code 115

### 1. Error code definition

ACCT sensor fault (Detail code 115)

### 2. Error definition and error detection method

When the formula "output current < 1.8 Arms" remains satisfied for 10 seconds while the inverter is in operation.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Contact failure	Check the connector (CNCT2) on the INV board for proper connection.
(2) INV output phase loss	Check the output wire for proper connection.
(3) ACCT sensor failure	Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components]
(4) Compressor failure	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]
(5) INV board failure	Replace the INV board if the problem persists after the operation is resumed.

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-7-12 Error Code [5301] Detail Code 117

### 1. Error code definition

ACCT sensor circuit fault (Detail code 117)

### 2. Error definition and error detection method

When an error value is detected with the ACCT detection circuit just before the inverter starts

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) INV board failure	Refer to the following page(s). [8-10-2 Checking the Inverter Board Error Detection Circuit] [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation]
(2) Compressor failure	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-7-13 Error Code [5301, 5305, 5306] Detail Code 119

### 1. Error code definition

Open-circuited IPM/Loose ACCT connector (Detail code 119)

### 2. Error definition and error detection method

Presence of enough current cannot be detected during the self-diagnostic operation immediately before inverter startup.

### 3. Cause, check method and remedy

[Outdoor unit]

Cause	Check method and remedy
(1) ACCT sensor disconnection	Check the connector CNCT2 on the INV board for proper connection. Check the ACCT for proper connection.
(2) ACCT sensor failure	Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components]
(3) Inverter failure	Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation]
(4) Compressor failure	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]

[HBC]

Cause	Check method and remedy
(1) Pump inverter board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(2) Pump failure	Refer to the following page(s). [8-9-4 Water Pump Control] [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-7-14 Error Code [5301, 5305, 5306] Detail Code 120

### 1. Error code definition

Faulty ACCT wiring (Detail code 120)

### 2. Error definition and error detection method

Presence of target current cannot be detected during the self-diagnostic operation immediately before startup.

### 3. Cause, check method and remedy

[Outdoor unit]

Cause	Check method and remedy
(1) ACCT sensor connection error	Check the ACCT for proper connection. Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components]
(2) ACCT sensor failure	Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components]
(3) Inverter failure	Refer to the following page(s). [8-10-4 Checking the Inverter for Damage at No-Load] [8-10-5 Checking the Inverter for Damage during Compressor Operation]
(4) Compressor failure	Refer to the following page(s). [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]

[HBC]

Cause	Check method and remedy
(1) Pump inverter board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
(2) Pump failure	Refer to the following page(s). [8-9-4 Water Pump Control] [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]

Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-7-15 Error Code [5305, 5306] Detail Code 135

### 1. Error code definition

Current sensor fault (Detail code 135)

### 2. Error definition and error detection method

Detection of output current below 0.2 Arms for 10 continuous seconds while fan motor is in operation

### 3. Cause, check method and remedy

[Outdoor unit]

Cause	Check method and remedy
(1) Open output phase of fan board	Check the output wiring from the fan board for proper connection.
(2) Fan motor error	Refer to the following page(s). [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]
(3) Fan board failure	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]

[HBC]

Cause	Check method and remedy
(1) Open output phase of pump INV board	Check the output wiring from the pump INV board for proper connection.
(2) Pump motor error	Refer to the following page(s). [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems]
(3) Pump INV board failure	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]

**Note**

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]



## 7-7-16 Error Code [5305, 5306] Detail Code 136

### 1. Error code definition

Current sensor/circuit fault (Detail code 136)

### 2. Error definition and error detection method

#### [Outdoor unit]

Detection of abnormal value by the current detection circuit before the startup of fan motor

#### [HBC]

Detection of abnormal value by the current detection circuit before the startup of pump motor

### 3. Cause, check method and remedy

#### [Outdoor unit]

Cause	Check method and remedy
(1) Fan board fault	Refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]

#### [HBC]

Cause	Check method and remedy
(1) Pump INV board fault	Refer to the following page(s). [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)] [8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]

#### Note

For inverter-related error codes, refer to the following page(s). [8-10 Troubleshooting Inverter Problems]

## 7-7-17 Error Code [5701]

### 1. Error code definition

Loose float switch connector

### 2. Error definition and error detection method

Detection of the disconnected float switch (open-phase condition) during operation

### 3. Cause, check method and remedy

#### (1) CN4F/CN303 disconnection or contact failure

Check for disconnection of the connector (CN4F) on the indoor unit control board.  
Check the HBC controller box connector (CN303) for proper connection.

#### Note

Main-HBC does not have a float switch. Check the short-circuit connector (CN303) for proper connection.

---

## **7-8 Error Code Definitions and Solutions: Codes [6000 - 6999]**

---

### **7-8-1 Error Code [6201]**

---

---

**1. Error code definition**

Remote controller board fault (nonvolatile memory error)

**2. Error definition and error detection method**

This error is detected when the data cannot be read out from the built-in nonvolatile memory on the remote controller.

**3. Cause, check method and remedy**

**(1) Remote controller failure**

Replace the remote controller.

### **7-8-2 Error Code [6202]**

---

---

**1. Error code definition**

Remote controller board fault (clock IC error)

**2. Error definition and error detection method**

This error is detected when the built-in clock on the remote controller is not properly functioning.

**3. Cause, check method and remedy**

**(1) Remote controller failure**

Replace the remote controller.

### 7-8-3 Error Code [6600]

#### 1. Error code definition

Address overlaps

#### 2. Error definition and error detection method

An error in which signals from more than one indoor units with the same address are received

Detail code 001: Detection of overlapped address in centralized control system

Detail code 002: Detection of overlapped address in indoor unit system

**Note**

The address and attribute that appear on the remote controller indicate the controller that detected the error.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Two or more of the following have the same address: Outdoor units, HBCs, indoor units, LOSSNAY units, controllers such as ME remote controllers. <Example> 6600 "01" appears on the remote controller Unit #01 detected the error. Two or more units in the system have 01 as their address.	♦Find the unit that has the same address as that of the error source. <b>Once the unit is found, correct the address. Then, turn off the outdoor units, indoor units, HBCs, and LOSSNAY units, keep them all turned off for at least five minutes, and turn them back on.</b> ♦When air conditioning units are operating normally despite the address overlap error Check the transmission wave shape and noise on the transmission line. Refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]
(2) Signals are distorted by the noise on the transmission line.	

### 7-8-4 Error Code [6601]

#### 1. Error code definition

Polarity setting error

#### 2. Error definition and error detection method

The error detected when transmission processor cannot distinguish the polarities of the M-NET transmission line.

#### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) No voltage is applied to the M-NET transmission line that AE-200E/AG-150A/GB-50ADA/PAC-YG50ECA/BAC-HD150 are connected to.	Check if power is supplied to the M-NET transmission line of the AE-200E/AG-150A/GB-50ADA/PAC-YG50ECA/BAC-HD150, and correct any problem found.
(2) M-NET transmission line to which AE-200/AG-150A/GB-50ADA/PAC-YG50ECA/BAC-HD150 are connected is short-circuited.	
(3) When two or more power supplies are connected to the M-NET	

## 7-8-5 Error Code [6602]

### 1. Error code definition

Transmission processor hardware error

### 2. Error definition and error detection method

Although "0" was surely transmitted by the transmission processor, "1" is displayed on the transmission line.

Detail code 001: Transmission processor hardware error in centralized control system

Detail code 002: Transmission processor hardware error in indoor unit system


#### Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

### 3. Cause

- 1) When the wiring work of or the polarity of either the indoor or outdoor transmission line is performed or is changed while the power is on, the transmitted data will collide, the wave shape will be changed, and an error will be detected.
- 2) Grounding fault of the transmission line
- 3) When grouping the indoor units that are connected to different outdoor units, the male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).
- 4) When the power supply unit for transmission lines is used in the system connected with MELANS, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 5) Controller failure of the source of the error
- 6) When the transmission data is changed due to the noise on the transmission line
- 7) Voltage is not applied on the transmission line for centralized control (in case of grouped indoor units connected to different outdoor units or in case of the system connected with MELANS)

### 4. Check method and remedy



## 7-8-6 **Error Code [6603]**

### 1. Error code definition

Transmission line bus busy error

### 2. Error definition and error detection method

- Generated error when the command cannot be transmitted for 4-10 minutes in a row due to bus-busy
  - Generated error when the command cannot be transmitted to the transmission line for 4-10 minutes in a row due to noise
- Detail code 001: Transmission Bus-Busy error in centralized control system  
 Detail code 002: Transmission Bus-Busy error in indoor unit system

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	The transmission processor cannot be transmitted as the short-wavelength voltage like noise exists consecutively on the transmission line.	Check the transmission wave shape and noise on the transmission line. Refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference] → No noise indicates that the error source controller is a failure. → If noise exists, investigate the noise.
(2)	Error source controller failure	

## 7-8-7 **Error Code [6606]**

### 1. Error code definition

Communication error between device processor and transmission processor or M-NET processor

### 2. Error definition and error detection method

Communication error between device processor on circuit board and transmission processor or M-NET processor  
 Detail code 003: Communication error between device processor on circuit board and M-NET processor

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Data is not properly transmitted due to accidental erroneous operation of the controller of the error source.	Turn off the power source of the outdoor and the indoor units.(When the power source is turned off separately, the microcomputer will not be reset, and the error will not be corrected.) → If the same error occurs, the error source controller is a failure.
(2)	Error source controller failure	

## 7-8-8 Error Code [6607] Error Source Address = Outdoor Unit (OC)

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Incidental cause	1) Check whether Error Code [Er91] is displayed on the service LED on the outdoor unit.
(2) Contact failure of transmission line of OC or IC	2) If the code is not displayed, turn off the power to the outdoor unit, and then turn it back on.
(3) Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring. Farthest: 200 m [656ft] or less Remote controller wiring: 10m [32ft] or less	3) If the error is accidental, it will run normally. If not, check the causes (2) - (5).  * Skip check item 1) on the outdoor unit whose firmware does not need to be updated.
(4) Erroneous sizing of transmission line (Not within the range below). Wire diameter: 1.25mm <sup>2</sup> [AWG16] or more	
(5) Outdoor unit control board failure	
(6) Firmware update error on the outdoor unit	

## 7-8-9 Error Code [6607] Error Source Address = HBC (HB)

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Incidental cause	1) Turn off the power to the outdoor unit and the HBC, leave them turned off for at least 5 minutes, and then turn them back on.
(2) When HBC address is changed or modified during operation.	2) If the error is accidental, it will run normally. If not, check the causes (2) - (4).
(3) Faulty or disconnected transmission wiring of HBC	
(4) Faulty control board of HBC	

## 7-8-10 Error Code [6607] Error Source Address = Indoor Unit (IC)

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method


The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

**Error display**



#### (1) Troubleshooting problems for indoor units (A)

Cause	Check method and remedy
(1) Incidental cause	1) Turn off the outdoor/indoor units for 5 or more minutes, and turn them on again.
(2) When IC unit address is changed or modified during operation.	2) If the error is accidental, it will run normally. If not, check the causes (2) - (6).
(3) Faulty or disconnected IC transmission wiring	
(4) Disconnected IC connector (CN2M)	
(5) Indoor unit controller failure	
(6) ME remote controller failure	

**(2) Troubleshooting problems for indoor units (B)**

Cause		Check method and remedy	
(1)	When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control	1)	Check voltage of the transmission line for centralized control. •20 V or more: Check (1) on the left. •Less than 20 V: Check (2) on the left.
(2)	Disconnection or shutdown of the power source of the power supply unit for transmission line		
(3)	System controller (MELANS) malfunction	2)	Check the causes of the error indicated by the error codes listed in items (1) through (3) in the "Cause" column.



## 7-8-11 Error Code [6607] Error Source Address = ME Remote Controller

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method


The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

**Error display**



#### (1) Troubleshooting problems for ME remote controllers

Cause	Check method and remedy
(1) Incidental cause	1) Turn off the power source of the outdoor unit for 5 minutes or more, and turn it on again.
(2) Faulty transmission wiring at IC unit side.	2) If not, check the causes (2) - (5).
(3) Faulty wiring of the transmission line for ME remote controller	
(4) When the address of ME remote controller is changed in the middle of the operation	
(5) ME remote controller failure	

## 7-8-12 Error Code [6607] Error Source Address = System Controller

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method


The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

Error display



#### (1) Troubleshooting problems for system controllers

Cause	Check method and remedy
(1) Incidental cause	1) Turn off the power source of the outdoor unit for 5 minutes or more, and turn it on again.
(2) Faulty wiring of the transmission line for ME remote controller	2) If not, check the causes (2) - (4).
(3) When the address of ME remote controller is changed in the middle of the operation	
(4) ME remote controller failure	

## 7-8-13 Error Code [6607] All Error Source Addresses

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

#### (1) Troubleshooting problems for all units (A)

Cause	Check method and remedy
(1) Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized control line connection (TB7)	1) Check the causes of (1) - (4). If the cause is found, correct it. If no cause is found, check 2).
(2) When multiple outdoor units are connected and the power source of one of the outdoor units has been shut off.	2) Check the LED displays for troubleshooting on other remote controllers whether an error occurs.
(3) The male power supply connector of the outdoor unit is not connected to the female power supply switch connector (CN40).	<ul style="list-style-type: none"> <li>•When an error is present Check the causes of the error indicated by the error codes listed in item (4) in the "Cause" column.</li> <li>•When no errors are present Indoor unit circuit board failure</li> </ul>
(4) The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for centralized control.  If an error occurs, after the unit runs normally once, the following causes may be considered. <ul style="list-style-type: none"> <li>•Total capacity error (7100)</li> <li>•Capacity code error (7101)</li> <li>•Error in the number of connected units (7102)</li> <li>•Address setting error (7105)</li> </ul>	

#### (2) Troubleshooting problems for all units (B)

Cause	Check method and remedy
(1) Total capacity error (7100)	1) Check the LED display for troubleshooting on the outdoor unit. <ul style="list-style-type: none"> <li>•When an error is present Check the causes of the error indicated by the error codes listed in items (1) through (4) in the "Cause" column.</li> <li>•When no errors are present Check the causes of the error indicated by the error codes listed in items (5) through (7) in the "Cause" column.</li> </ul>
(2) Capacity code error (7101)	
(3) Error in the number of connected units (7102)	
(4) Address setting error (7105)	
(5) Disconnection or short circuit of the transmission line for the outdoor unit on the terminal block for centralized control line connection (TB7)	
(6) Turn off the power source of the outdoor unit	
(7) Malfunction of electrical system for the outdoor unit	

#### (3) Troubleshooting problems for all units (C)

Cause	Check method and remedy
(1) When the power supply unit for transmission lines is used and the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control	Check the causes of the error indicated by the error codes listed in items (1) through (3) in the "Cause" column.
(2) Disconnection or shutdown of the power source of the power supply unit for transmission line	
(3) System controller (MELANS) malfunction	

## 7-8-14 Error Code [6607] No Error Source Address

### 1. Error code definition

No ACK error

### 2. Error definition and error detection method

The error is detected when no acknowledgement (ACK signal) is received after the transmission. (eg. When the data is transmitted six times in a row with 30 seconds interval, the error is detected on the transmission side.)

**Note**

The address/attribute appeared on the display on the remote controller indicates the controller which did not provide the response (ACK).

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Although the address of ME remote controller has been changed after the group is set using ME remote controller, the indoor unit is keeping the memory of the previous address. The same symptom will appear for the registration with SC.	Delete unnecessary information of non-existing address which some indoor units have. Use either of the following two methods for deletion.
(2) Although the address of LOSSNAY has been changed after the interlock registration of LOSSNAY is made using ME remote controller, the indoor unit is keeping the memory of the previous address.	1) Address deletion by ME remote controller Delete unnecessary address information using the manual setting function of ME remote controller. Refer to the ME remote controller instructions manual for detail.  2) Deletion of connection information of the outdoor unit by the deleting switch  Note that the above method will delete all the group settings set via the ME remote controller and all the interlock settings between LOSSNAY units and indoor units.  Procedures 1) Turn off the power source of the outdoor unit, and wait for 5 minutes. 2) Turn on the dip switch (SW5-2) on the outdoor unit control board. 3) Turn on the power source of the outdoor unit, and wait for 5 minutes. 4) Turn off the power source of the outdoor unit, and wait for 5 minutes. 5) Turn off the dip switch (SW5-2) on the outdoor unit control board. 6) Turn on the power source of the outdoor unit.

## 7-8-15 **Error Code [6608]**

---

### 1. Error code definition

No response error

### 2. Error definition and error detection method

- When no response command is returned although acknowledgement (ACK) is received after transmission, an error is detected.
- When the data is transmitted 10 times in a row with 3 seconds interval, an error is detected on the transmission side.

#### Note

The address/attribute appeared on the display on the remote controller indicates the controller where an error occurred.

### 3. Cause

- 1) The transmission line work is performed while the power is on, the transmitted data will collide, and the wave shape will be changed.
- 2) The transmission is sent and received repeatedly due to noise.
- 3) Decrease of transmission line voltage/signal by exceeding acceptable range of transmission wiring.  
Farthest:200m [656ft] or less  
Remote controller wiring:12m [39ft] or less
- 4) The transmission line voltage/signal is decreased due to erroneous sizing of transmission line.  
Wire diameter: 1.25mm<sup>2</sup>[AWG16] or more

### 4. Check method and remedy

- 1) When an error occurs during commissioning, turn off the power sources for the outdoor unit, indoor unit, HBC, and LOSSNAY for 5 or more minutes, and then turn them on again.
  - When they return to normal operation, the cause of the error is the transmission line work performed with the power on.
  - If an error occurs again, check the cause 2).
- 2) Check 3) and 4) above.
  - If the cause is found, correct it.
  - If no cause is found, check 3).
- 3) Check the transmission waveform, and check the transmission line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]  
**Noise is the most possible cause of the error "6608".**

## 7-8-16 **Error Code [6831]**

---

### 1. Error code definition

**MA remote controller signal reception error (No signal reception)**

### 2. Error definition and error detection method

- Communication between the MA remote controller and the indoor unit is not done properly.
- No proper data has been received for 3 minutes.

### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
  - Wire length
  - Wire size
  - Number of remote controllers
  - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

### 4. Check method and remedy

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on.
  - If LED2 is lit, the MA remote controller line is being powered.

## 7-8-17 Error Code [6832]

### 1. Error code definition

MA remote controller signal transmission error (Synchronization error)

### 2. Error definition and error detection method

- MA remote controller and the indoor unit is not done properly.
- Failure to detect opening in the transmission path and unable to send signals
  - \*Indoor unit: 3 minutes
  - \*Remote controller: 6 seconds

### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
  - Wire length
  - Wire size
  - Number of remote controllers
  - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

### 4. Check method and remedy

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).  
[OK]: no problems with the remote controller (check the wiring regulations)  
[NG]: Replace the MA remote controller.  
[6832, 6833, ERC]: Due to noise interference <Go to 6>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller.  
The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on.
  - If LED2 is lit, the MA remote controller line is being powered.

## 7-8-18 **Error Code [6833]**

---

### 1. Error code definition

**MA remote controller signal transmission error (Hardware error)**

### 2. Error definition and error detection method

- Communication between the MA remote controller and the indoor unit is not done properly.
- An error occurs when the transmitted data and the received data differ for 30 times in a row.

### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit
- 2) 2 or more remote controllers are set to MAIN
- 3) Overlapped indoor unit address
- 4) Noise interference on the remote controller lines
- 5) Failure to meet wiring regulations
  - Wire length
  - Wire size
  - Number of remote controllers
  - Number of indoor units
- 6) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

### 4. Check method and remedy

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).  
[OK]: no problems with the remote controller (check the wiring regulations)  
[NG]: Replace the MA remote controller.  
[6832, 6833, ERC]: Due to noise interference <Go to 6>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on.
  - If LED2 is lit, the MA remote controller line is being powered.



## 7-8-19 **Error Code [6834]**

### 1. Error code definition

**MA remote controller signal reception error (Start bit detection error)**

### 2. Error definition and error detection method

- Communication between the MA remote controller and the indoor unit is not done properly.
- No proper data has been received for 2 minutes.

### 3. Cause

- 1) Contact failure of the remote controller lines of MA remote controller or the indoor unit.
- 2) All the remote controllers are set to SUB.
- 3) Failure to meet wiring regulations
  - Wire length
  - Wire size
  - Number of remote controllers
  - Number of indoor units
- 4) The remote controller is removed after the installation without turning the power source off.
- 5) Noise interference on the remote controller transmission lines
- 6) Faulty circuit that is on the indoor board and performs transmission/ reception of the signal from the remote controller
- 7) Problems with the circuit on the remote controller that sends or receives the signals from the remote controller

### 4. Check method and remedy

- 1) Check for disconnected or loose transmission lines for the indoor units or MA remote controllers.
- 2) Confirm that the power is supplied to the main power source and the remote controller line.
- 3) Confirm that MA remote controller's capacity limit is not exceeded.
- 4) Check the sub/main setting of the MA remote controllers. One of them must be set to MAIN.
- 5) Diagnose the remote controller (described in the remote controller installation manual).
  - [OK]: no problems with the remote controller (check the wiring regulations)
  - [NG]: Replace the MA remote controller.
  - [6832, 6833, ERC]: Due to noise interference <Go to 6>
- 6) Check the transmission waveform, and check the MA remote controller line for electrical noise. For details, refer to the following page(s). [8-4 Checking Transmission Waveform and for Electrical Noise Interference]
- 7) When no problems are found with items 1) through 6), replace the indoor unit board or the MA remote controller. The following status can be confirmed on LED1 and 2 on the indoor unit board.
  - If LED1 is lit, the main power source of the indoor unit is turned on
  - If LED2 is lit, the MA remote controller line is being powered.

## 7-8-20 Error Code [6840]

### 1. Error code definition

Indoor-outdoor communication: Reception error

### 2. Error definition and error detection method

- Abnormal if indoor controller board could not receive any signal normally for 6 minutes after turning the power on
- Abnormal if indoor controller board could not receive any signal normally for 3 minutes.
- Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to an outdoor unit, indoor controller board could not receive a signal for 3 minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Contact failure, short circuit or miswiring (converse wiring) of indoor/outdoor unit connecting wire.	Check disconnecting or looseness of indoor /outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin/triple/quadruple indoor unit system.
(2) Defective transmitting receiving circuit of outdoor controller circuit board.	
(3) Defective transmitting receiving circuit of indoor controller board.	
(4) Noise has entered into indoor/outdoor unit connecting wire.	
(5) Defective fan motor	Turn the power off, and detach fan motor from connector (CNF1, 2). Then turn the power on again. If abnormality is not displayed, replace fan motor. If abnormality is displayed, replace outdoor controller circuit board.
(6) Defective rush current resistor of outdoor power circuit board	Check the rush current resistor on outdoor power circuit board with tester. If open is detected, replace the power circuit board.

Note: Refer also to the Service Handbook for the indoor units.

## 7-8-21 Error Code [6841]

### 1. Error code definition

A control communication synchronism not recover

### 2. Error definition and error detection method

Indoor/outdoor unit communication error (Outdoor unit)

- Abnormal if "0" receiving is detected 30 times continuously though outdoor controller circuit board has transmitted "1".
- Abnormal if outdoor controller circuit board could not find blank of transmission path for 3 minutes.

### 3. Cause, check method and remedy

Cause	Check method and remedy
(1) Indoor/outdoor unit connecting wire has contact failure.	Check disconnection or looseness of indoor/ outdoor unit connecting wire.
(2) Defective communication circuit of outdoor controller circuit board.	
(3) Noise has entered power supply.	
(4) Noise has entered indoor/outdoor unit connecting wire.	

Note: Refer also to the Service Handbook for the indoor units.

## 7-8-22 **Error Code [6842]**

### 1. Error code definition

Indoor-outdoor communication: **Transmission error**

### 2. Error definition and error detection method

Indoor/outdoor unit communication error (Transmitting error)

Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Defective transmitting receiving circuit of indoor controller board	Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board.
(2)	Noise has entered into power supply.	
(3)	Noise has entered into outdoor control wire.	

Note: Refer also to the Service Handbook for the indoor units.

## 7-8-23 **Error Code [6843]**

### 1. Error code definition

A control communication start bit detection error

### 2. Error definition and error detection method

Indoor/outdoor unit communication error

- Abnormal if indoor control board could not receive any signal normally for 6 minutes after turning the power on.
- Abnormal if indoor control board could not receive any signal normally for 3 minutes.
- Consider the unit as abnormal under the following condition. When 2 or more indoor units are connected to an outdoor unit, indoor control board could not receive a signal for 3 minutes from outdoor control circuit board, a signal which allows outdoor control circuit board to transmit signals.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Contact failure, short circuit or miswiring (converse wiring) of indoor/outdoor unit connecting wire	Check disconnecting or looseness of indoor /outdoor unit connecting wire of all indoor units or outdoor units.  Turn the power off, and on again to check. If abnormality generates again, replace indoor control board or outdoor control circuit board. Note: other indoor control board may have defect.
(2)	Defective transmitting receiving circuit of outdoor control circuit board.	
(3)	Defective transmitting receiving circuit of indoor control board.	
(4)	Noise has entered into indoor/outdoor unit connecting wire.	
(5)	Defective fan motor	Turn the power off, and detach fan motor from connector (CNF1, 2). Then turn the power on again. If abnormality is not displayed, replace fan motor. If abnormality is displayed, replace outdoor control circuit board.
(6)	Defective rush current resistor of outdoor control circuit board	Check the rush current resistor on outdoor control circuit board with tester. If open is detected, replace the outdoor control circuit board.

### 1. Error code definition

A control communication start bit detection error

### 2. Error definition and error detection method

Indoor/outdoor unit communication error (Outdoor unit)

Abnormal if outdoor control circuit board could not receive anything normally for 3 minutes.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Contact failure of indoor/outdoor unit connecting wire	Check disconnection or looseness of indoor/ outdoor unit connecting wire of indoor or outdoor units.  Turn the power off, and on again to check. Replace indoor control board or outdoor control circuit board if abnormality is displayed again.
(2)	Defective communication circuit of outdoor control circuit board	
(3)	Defective communication circuit of indoor control board	
(4)	Noise has entered into indoor/outdoor unit connecting wire.	

Note: Refer also to the Service Handbook for the indoor units.

## 7-8-24 Error Code [6846]

### 1. Error code definition

Start-up time over

### 2. Error definition and error detection method

Start-up time over The unit cannot finish start-up process within 4 minutes after power on.

### 3. Cause, check method and remedy

Cause		Check method and remedy
(1)	Contact failure of indoor/outdoor unit connecting wire	Check disconnection or looseness or polarity of indoor/outdoor unit connecting wire of indoor and outdoor units.
(2)	Diameter or length of indoor/outdoor unit connecting wire is out of specified capacity.	Check the following: Diameter of the cables used for indoor-outdoor lines; maximum line distance between indoor and outdoor units (max. 50 m); maximum line distance between indoor units (daisy-changed cables) (max. 30 m); and if flat cables such as VVF is used, make sure they are connected in the order of S1, S2, and S3.
(3)	2 or more outdoor units have refrigerant address "0". (In case of group control)	When units are controlled as groups, check the refrigerant address (SW1 (3-6) on the outdoor unit control board settings) for duplicates.
(4)	Noise has entered into power supply or indoor/outdoor unit connecting wire.	Check the transmission lines for problems.

Note: Refer also to the Service Handbook for the indoor units.

# 7-9 Error Code Definitions and Solutions: Codes [7000 - 7999]

## 7-9-1 Error Code [7100]

### 1. Error code definition

Total capacity error

### 2. Error definition and error detection method

The model total of indoor units in the system with one outdoor unit exceeds limitations.

### 3. Error source, cause, check method and remedy,

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy																																																																																																															
Outdoor unit	(1) The Qj total of indoor units in the system with one outdoor unit exceeds the following table. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Model</th> <th>Qj Total</th> </tr> </thead> <tbody> <tr><td>(E)M200 model</td><td>62</td></tr> <tr><td>(E)M250 model</td><td>80</td></tr> <tr><td>(E)M300 model</td><td>99</td></tr> <tr><td>(E)M350 model</td><td>110</td></tr> <tr><td>(E)M400 model</td><td>123</td></tr> <tr><td>(E)M450 model</td><td>139</td></tr> <tr><td>(E)M500 model</td><td>159</td></tr> </tbody> </table>	Model	Qj Total	(E)M200 model	62	(E)M250 model	80	(E)M300 model	99	(E)M350 model	110	(E)M400 model	123	(E)M450 model	139	(E)M500 model	159	1) Check the Qj total (capacity code total) of indoor units connected. 2) Check the Qj setting (capacity code) of the connected indoor unit set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the outdoor and the indoor units, and change the setting of the Qj (capacity code). 3) Indoor unit Qj table <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Model</th> <th>Qj</th> </tr> </thead> <tbody> <tr><td>10</td><td>2</td></tr> <tr><td>15</td><td>3</td></tr> <tr><td>20</td><td>4</td></tr> <tr><td>25</td><td>5</td></tr> <tr><td>32</td><td>6</td></tr> <tr><td>40</td><td>8</td></tr> <tr><td>50</td><td>10</td></tr> <tr><td>63</td><td>13</td></tr> <tr><td>71</td><td>14</td></tr> <tr><td>80</td><td>16</td></tr> <tr><td>100</td><td>20</td></tr> <tr><td>125</td><td>25</td></tr> <tr><td>140</td><td>28</td></tr> <tr><td>200</td><td>40</td></tr> <tr><td>250</td><td>50</td></tr> </tbody> </table>	Model	Qj	10	2	15	3	20	4	25	5	32	6	40	8	50	10	63	13	71	14	80	16	100	20	125	25	140	28	200	40	250	50																																																															
	Model	Qj Total																																																																																																															
(E)M200 model	62																																																																																																																
(E)M250 model	80																																																																																																																
(E)M300 model	99																																																																																																																
(E)M350 model	110																																																																																																																
(E)M400 model	123																																																																																																																
(E)M450 model	139																																																																																																																
(E)M500 model	159																																																																																																																
Model	Qj																																																																																																																
10	2																																																																																																																
15	3																																																																																																																
20	4																																																																																																																
25	5																																																																																																																
32	6																																																																																																																
40	8																																																																																																																
50	10																																																																																																																
63	13																																																																																																																
71	14																																																																																																																
80	16																																																																																																																
100	20																																																																																																																
125	25																																																																																																																
140	28																																																																																																																
200	40																																																																																																																
250	50																																																																																																																
	(2) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th rowspan="2">Model</th> <th colspan="6">SW5</th> </tr> <tr> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> <th>8</th> </tr> </thead> <tbody> <tr><td>M200 model</td><td>OFF</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>M250 model</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>M300 model</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>M350 model</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>M400 model</td><td>ON</td><td>ON</td><td>ON</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>M450 model</td><td>OFF</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td></tr> <tr><td>M500 model</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td></tr> <tr><td>EM200 model</td><td>OFF</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>EM250 model</td><td>ON</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>EM300 model</td><td>OFF</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>EM350 model</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>EM400 model</td><td>ON</td><td>ON</td><td>ON</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>EM450 model</td><td>OFF</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr> <tr><td>EM500 model</td><td>ON</td><td>OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>ON</td></tr> </tbody> </table>	Model	SW5						3	4	5	6	7	8	M200 model	OFF	ON	OFF	OFF	ON	OFF	M250 model	ON	ON	OFF	OFF	ON	OFF	M300 model	OFF	OFF	ON	OFF	ON	OFF	M350 model	OFF	ON	ON	OFF	ON	OFF	M400 model	ON	ON	ON	OFF	ON	OFF	M450 model	OFF	OFF	OFF	ON	ON	OFF	M500 model	ON	OFF	OFF	ON	ON	OFF	EM200 model	OFF	ON	OFF	OFF	ON	ON	EM250 model	ON	ON	OFF	OFF	ON	ON	EM300 model	OFF	OFF	ON	OFF	ON	ON	EM350 model	OFF	ON	ON	OFF	ON	ON	EM400 model	ON	ON	ON	OFF	ON	ON	EM450 model	OFF	OFF	OFF	ON	ON	ON	EM500 model	ON	OFF	OFF	ON	ON	ON	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board).
Model	SW5																																																																																																																
	3	4	5	6	7	8																																																																																																											
M200 model	OFF	ON	OFF	OFF	ON	OFF																																																																																																											
M250 model	ON	ON	OFF	OFF	ON	OFF																																																																																																											
M300 model	OFF	OFF	ON	OFF	ON	OFF																																																																																																											
M350 model	OFF	ON	ON	OFF	ON	OFF																																																																																																											
M400 model	ON	ON	ON	OFF	ON	OFF																																																																																																											
M450 model	OFF	OFF	OFF	ON	ON	OFF																																																																																																											
M500 model	ON	OFF	OFF	ON	ON	OFF																																																																																																											
EM200 model	OFF	ON	OFF	OFF	ON	ON																																																																																																											
EM250 model	ON	ON	OFF	OFF	ON	ON																																																																																																											
EM300 model	OFF	OFF	ON	OFF	ON	ON																																																																																																											
EM350 model	OFF	ON	ON	OFF	ON	ON																																																																																																											
EM400 model	ON	ON	ON	OFF	ON	ON																																																																																																											
EM450 model	OFF	OFF	OFF	ON	ON	ON																																																																																																											
EM500 model	ON	OFF	OFF	ON	ON	ON																																																																																																											

## 7-9-2 Error Code [7101]

### 1. Error code definition

Capacity code setting error

### 2. Error definition and error detection method

Connection of incompatible (wrong capacity code) indoor unit or outdoor unit

### 3. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy																																																																																																															
Indoor unit	(1) The model name (capacity code) set by the switch (SW2) is wrong.  *The capacity of the indoor unit can be confirmed by the self-diagnosis function (SW1 operation) of the outdoor unit.	1) Check the model name (capacity code) of the indoor unit which has the error source address set by the switch (SW2 on indoor unit board). When the model name set by the switch is different from that of the unit connected, turn off the power source of the outdoor and the indoor units, and change the setting of the capacity code.																																																																																																															
Outdoor unit	(2) The model selection switches (SW5-3 - 5-8) on the outdoor unit are set incorrectly.  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Model</th> <th colspan="6">SW5</th> </tr> <tr> <th>3</th> <th>4</th> <th>5</th> <th>6</th> <th>7</th> <th>8</th> </tr> </thead> <tbody> <tr> <td>M200 model</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M250 model</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M300 model</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M350 model</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M400 model</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M450 model</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>M500 model</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>EM200 model</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM250 model</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM300 model</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM350 model</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM400 model</td> <td>ON</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM450 model</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>EM500 model</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	Model	SW5						3	4	5	6	7	8	M200 model	OFF	ON	OFF	OFF	ON	OFF	M250 model	ON	ON	OFF	OFF	ON	OFF	M300 model	OFF	OFF	ON	OFF	ON	OFF	M350 model	OFF	ON	ON	OFF	ON	OFF	M400 model	ON	ON	ON	OFF	ON	OFF	M450 model	OFF	OFF	OFF	ON	ON	OFF	M500 model	ON	OFF	OFF	ON	ON	OFF	EM200 model	OFF	ON	OFF	OFF	ON	ON	EM250 model	ON	ON	OFF	OFF	ON	ON	EM300 model	OFF	OFF	ON	OFF	ON	ON	EM350 model	OFF	ON	ON	OFF	ON	ON	EM400 model	ON	ON	ON	OFF	ON	ON	EM450 model	OFF	OFF	OFF	ON	ON	ON	EM500 model	ON	OFF	OFF	ON	ON	ON	Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-3 - 5-8 on the outdoor unit control board).
Model	SW5																																																																																																																
	3	4	5	6	7	8																																																																																																											
M200 model	OFF	ON	OFF	OFF	ON	OFF																																																																																																											
M250 model	ON	ON	OFF	OFF	ON	OFF																																																																																																											
M300 model	OFF	OFF	ON	OFF	ON	OFF																																																																																																											
M350 model	OFF	ON	ON	OFF	ON	OFF																																																																																																											
M400 model	ON	ON	ON	OFF	ON	OFF																																																																																																											
M450 model	OFF	OFF	OFF	ON	ON	OFF																																																																																																											
M500 model	ON	OFF	OFF	ON	ON	OFF																																																																																																											
EM200 model	OFF	ON	OFF	OFF	ON	ON																																																																																																											
EM250 model	ON	ON	OFF	OFF	ON	ON																																																																																																											
EM300 model	OFF	OFF	ON	OFF	ON	ON																																																																																																											
EM350 model	OFF	ON	ON	OFF	ON	ON																																																																																																											
EM400 model	ON	ON	ON	OFF	ON	ON																																																																																																											
EM450 model	OFF	OFF	OFF	ON	ON	ON																																																																																																											
EM500 model	ON	OFF	OFF	ON	ON	ON																																																																																																											
HBC	(3) The model name (capacity code) setting is wrong. Correct combinations of outdoor units and HBCs.  <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Outdoor unit</th> <th>HBC</th> </tr> </thead> <tbody> <tr> <td>(E)M200 model (E)M250 model</td> <td rowspan="2">WM350 model</td> </tr> <tr> <td>(E)M300 model (E)M350 model</td> </tr> <tr> <td>(E)M400 model (E)M450 model (E)M500 model</td> <td>WM500 model</td> </tr> </tbody> </table>	Outdoor unit	HBC	(E)M200 model (E)M250 model	WM350 model	(E)M300 model (E)M350 model	(E)M400 model (E)M450 model (E)M500 model	WM500 model	Check the model selection switch of the outdoor unit (Dip switches SW5-3 through 5-8) on the outdoor unit control board.																																																																																																								
Outdoor unit	HBC																																																																																																																
(E)M200 model (E)M250 model	WM350 model																																																																																																																
(E)M300 model (E)M350 model																																																																																																																	
(E)M400 model (E)M450 model (E)M500 model	WM500 model																																																																																																																

### 7-9-3 Error Code [7102]

#### 1. Error code definition

Wrong number of connected units

#### 2. Error definition and error detection method

The number of connected indoor units is "0" or exceeds the allowable value.

#### 3. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy										
Outdoor unit	(1) Number of indoor units connected to the outdoor terminal block (TB3) for indoor/ outdoor transmission lines exceeds limitations described below.	1) Check whether the number of units connected to the outdoor terminal block (TB3) for indoor/ outdoor transmission lines does not exceed the limitation. (See (1) and (2) on the left.) 2) Check (2) - (3) on the left. 3) Check whether the transmission line for the terminal block for centralized control (TB7) is not connected to the terminal block for the indoor/outdoor transmission line (TB3). 4) Check the setting for the model selection switch on the outdoor unit (Dipswitches SW5-7 on the outdoor unit control board).										
	<table border="1"> <thead> <tr> <th>Number of units</th> <th>Restriction on the number of units</th> </tr> </thead> <tbody> <tr> <td>Total number of indoor units</td> <td>1 - 31 : (E)M200 model 1 - 40 : (E)M250 model 1 - 49 : (E)M300 model 2 - 50 : (E)M350 - 500 models</td> </tr> <tr> <td>Number of Main HBCs</td> <td>1</td> </tr> <tr> <td>Number of Sub HBCs</td> <td>0 - 3</td> </tr> <tr> <td>Total number of LOSSNAY units (During auto address start-up only)</td> <td>0 or 1</td> </tr> <tr> <td>Total number of outdoor units</td> <td>1 : (E)M200 - (E)M500 YNW models</td> </tr> </tbody> </table>		Number of units	Restriction on the number of units	Total number of indoor units	1 - 31 : (E)M200 model 1 - 40 : (E)M250 model 1 - 49 : (E)M300 model 2 - 50 : (E)M350 - 500 models	Number of Main HBCs	1	Number of Sub HBCs	0 - 3	Total number of LOSSNAY units (During auto address start-up only)	0 or 1
Number of units	Restriction on the number of units											
Total number of indoor units	1 - 31 : (E)M200 model 1 - 40 : (E)M250 model 1 - 49 : (E)M300 model 2 - 50 : (E)M350 - 500 models											
Number of Main HBCs	1											
Number of Sub HBCs	0 - 3											
Total number of LOSSNAY units (During auto address start-up only)	0 or 1											
Total number of outdoor units	1 : (E)M200 - (E)M500 YNW models											
	(2) Disconnected transmission line from the outdoor unit or HBC											
	(3) Short-circuited transmission line When (2) and (3) apply, the following display will appear. ♦ME remote controller Nothing appears on the remote controller because it is not powered. ♦MA remote controller "HO" or "PLEASE WAIT" blinks.											
	(4) The model selection switch (SW5-7) on the outdoor unit is set to OFF. (Normally set to ON)											
	(5) Outdoor unit address setting error The outdoor units in the same refrigerant circuit do not have sequential address numbers.											
HBC	(1) The outdoor unit is not R32-compatible.	1) Check the model of the outdoor unit to see if it is R32-compatible.										



## 7-9-4 Error Code [7107]

### 1. Error code definition

Port setting error


### 2. Error definition and error detection method

The port with wrong number is connected to the indoor unit. The model total connected to the port is greater than the specification.

### 3. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy						
HBC	<p>(1) Model total of indoor units per each port or per each port merge is greater than the specification.</p> <table border="1" data-bbox="443 719 954 786"> <tr> <td>Total port number</td> <td>Single branching</td> <td>80</td> </tr> <tr> <td></td> <td>Two branches merge</td> <td>160</td> </tr> </table> <p>(2) 4 or more indoor units are connected to the same port.</p> <p>(3) When two ports are used, the port with the smaller number is not connected to the indoor unit.</p> <p>(4) For the address of the HBC (Sub 1 - 3), 50 is not added to the smallest indoor unit address, which is connected to the HBC (Sub 1 - 3).</p> <p>(5) In the system to which multiple HBCs are connected, the indoor unit address connected to the HBC is not set as shown below.</p> <ul style="list-style-type: none"> <li>(i) The indoor unit address which is connected to the HBC (main)</li> <li>(ii) The indoor unit address which is connected to the HBC (Sub 1)</li> <li>(iii) The indoor unit address which is connected to the HBC (Sub 2)</li> <li>(iv) The indoor unit address which is connected to the HBC (Sub 3)</li> </ul> <p>Address setting (i) &lt; (ii) &lt; (iii) &lt; (iv)</p> <p>(6) Indoor units (P80 or above) using two branch ports are connected to two branch ports across the groups listed below.</p> <p>[HBC] Group 1: Branch port No. 1 to No. 3 Group 2: Branch port No. 4 to No. 6</p> <p>[Sub HBC] Group 1: Branch port No. 1 to No. 4 Group 2: Branch port No. 5 to No. 8 Group 3: Branch port No. 9 to No. 12(*) Group 4: Branch port No. 13 to No. 16(*) * For Sub HBC with 16 branch ports</p>	Total port number	Single branching	80		Two branches merge	160	<p><b>Before resetting the port number using the port number setting switch or the model using the model (capacity code) setting switch, turn off the power of the outdoor unit, the HBC and the indoor unit.</b></p>
Total port number	Single branching	80						
	Two branches merge	160						



### 7-9-5 **Error Code [7110]**

**1. Error code definition**

Connection information signal transmission/reception error

**2. Error definition and error detection method**

The given indoor unit is inoperable because it is not properly connected to the outdoor unit in the same system.

**3. Error source, cause, check method and remedy**

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy
Outdoor unit	(1) Power to the transmission booster is cut off.	1) Confirm that the power to the transmission booster is not cut off by the booster being connected to the switch on the indoor unit. (The unit will not function properly unless the transmission booster is turned on.)  →Reset the power to the outdoor unit.
	(2) Power resetting of the transmission booster and outdoor unit.	
	(3) The model selection switch (SW5-7) on the outdoor unit is set to OFF. (Normally set to ON)	2) Check the model selection switch on the outdoor unit (Dipswitch SW5-7 on the control board.).

### 7-9-6 **Error Code [7111]**

**1. Error code definition**

Remote controller sensor fault

**2. Error definition and error detection method**

This error occurs when the temperature data is not sent although the remote controller sensor is specified.

**3. Error source, cause, check method and remedy**

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy
Indoor unit OA processing unit	The remote controller without the temperature sensor (the wireless remote controller or the ME compact remote controller (mounted type)) is used and the remote controller sensor for the indoor unit is specified. (SW1-1 is ON.)	Replace the remote controller with the one with built-in temperature sensor.

## 7-9-7 Error Code [7113]

### 1. Error code definition

Function setting error (improper connection of CNTYP)

### 2. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy
Outdoor unit	(1) Wiring fault	(Detail code 15)
		1) Check the connector CNTYP5 on the control board for proper connection. 2) Check the connector CNTYP4 on the control board for proper connection.
	(2) Loose connectors, short-circuit, contact failure	(Detail code 14)
		1) Check the connector CNTYP4 on the control board for proper connection. 2) Check the settings of SW5-3 through SW5-6 on the control board.
	(3) Incompatible control board and INV board (replacement with a wrong circuit board)	(Detail code 12)
	(4) DIP SW setting error on the control board	1) Check the connector CNTYP2 on the control board for proper connection. 2) Check the connector CNTYP5 on the control board for proper connection. 3) Check the settings of SW5-3 through SW5-6 on the control board.
HBC	(1) Wiring fault	(Detail code 16)
		1) Check the connector CNTYP on the INV board for proper connection. 2) Check the connector CNTYP5 on the control board for proper connection. 3) Check the settings of SW5-3 through SW5-6 on the control board. 4) Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]]
		(Detail code 0, 1, 5)
HBC	(2) Loose connectors, short-circuit, contact failure	1) Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]] 2) Check the settings of SW5-3 through SW5-6 on the control board. 3) Check the connector CNTYP5 on the control board for proper connection.
		(Detail code 1)
		1) Check the connector CN409 on the control board for proper connection.
HBC	(2) Loose connectors, short-circuit, contact failure	(Detail code 2)
		1) Check the connector CN410 on the control board for proper connection.
		(Detail code 82)
HBC	(2) Loose connectors, short-circuit, contact failure	1) Check the wiring between the control board and the PS board. Refer to the following page(s). [7-2-1 Error Code [0403]] 2) Check the power-supply voltage and the frequency. Refer to the following page(s). [7-6-5 Error Code [4115] Detail Code 101, 102] 3) Replace the power-supply board.

## 7-9-8 Error Code [7117]

### 1. Error code definition

Model setting error

### 2. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy
Outdoor unit	(1) Wiring fault (2) Loose connectors, short-circuit, contact failure	(Detail code 15) 1) Check the connector CNTYP5 on the control board for proper connection.
		(Detail code 14) 1) Check the connector CNTYP4 on the control board for proper connection.
		(Detail code 12) 1) Check the connector CNTYP2 on the control board for proper connection. 2) Check the connector CNTYP5 on the control board for proper connection.
		(Detail code 16) 1) Check the connector CNTYP on the INV board for proper connection. 2) Check the connector CNTYP5 on the control board for proper connection. 3) Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]]
		(Detail code 0, 1, 5) 1) Check the wiring between the control board and INV board. Refer to the following page(s). [7-2-1 Error Code [0403]] 2) Check the settings of SW5-3 through SW5-6 on the control board. 3) Check the connector CNTYP5 on the control board for proper connection.
HBC	(1) Wiring fault (2) Loose connectors, short-circuit, contact failure	(Detail code 1) 1) Check the connector CN409 on the control board for proper connection.
		(Detail code 2) 1) Check the connector CN410 on the control board for proper connection.
		(Detail code 82) 1) Check the wiring between the control board and the PS board. Refer to the following page(s). [7-2-1 Error Code [0403]] 2) Replace the power-supply board.

## 7-9-9 **Error Code [7130]**

### 1. Error code definition

Incompatible unit combination

### 2. Error definition and error detection method

The check code will appear when the indoor units and HBC with different refrigerant systems are connected.

### 3. Error source, cause, check method and remedy

After troubleshooting the error using the check methods and remedies shown below, turn the power back on.

Error source	Cause	Check method and remedy
Outdoor unit	The connected indoor unit is for use with R22, R407C, or R410A. Incorrect type of indoor units are connected. The M-NET connection adapter is connected to the indoor unit system in a system in which the Slim Model (A control) of units are connected to the M-NET.	Check the connected indoor unit model. Check whether the connecting adapter for M-NET is not connected to the indoor unit. (Connect the connecting adapter for M-NET to the outdoor unit.)
HBC	Indoor units with flow control valves and those without are connected to the outdoor terminal block (TB3) for indoor/outdoor transmission line.	Check the model of the indoor unit connected to the outdoor terminal block (TB3) for indoor/outdoor transmission line. (* ) Note that the following indoor units with the model name P**Y-W are treated the same as with the indoor units without flow control valves. <Applicable indoor units> PKFY-W**

---

## 7-10 Unit Error Code Definitions and Solutions: Codes [Er91 - Er99]

---

### 7-10-1 Error Code [Er91]

---

---

#### 1. Error code definition

Firmware update error (outdoor unit)

#### 2. Error definition and error detection method

The error code will be displayed when the outdoor unit fails to write the firmware update program.

#### 3. Error source, cause, check method and remedy

Error source	Cause	Check method and remedy
Outdoor unit	(1) Failure of the microcomputer or the flash memory on the control board	Replacement of the control board

---

## Chapter 8 Troubleshooting Based on Observed Symptoms

<b>8-1</b>	<b>MA Remote Controller Problems</b> .....	<b>1</b>
8-1-1	The LCD Does Not Light Up. ....	1
8-1-2	The LCD Momentarily Lights Up and Then Goes Off. ....	2
8-1-3	"HO" and "PLEASE WAIT" Do Not Go Off the Screen. ....	3
8-1-4	Air Conditioning Units Do Not Operate When the ON Button Is Pressed. ....	4
<b>8-2</b>	<b>ME remote Controller Problems</b> .....	<b>5</b>
8-2-1	The LCD Does Not Light Up. ....	5
8-2-2	The LCD Momentarily Lights Up and Then Goes Off. ....	6
8-2-3	"HO" or "Waiting for ..." Does Not Go Off the Screen.....	7
8-2-4	"88", "Request denied." Appears on the LCD. ....	9
<b>8-3</b>	<b>Refrigerant Control Problems</b> .....	<b>10</b>
8-3-1	Units in the Cooling Mode Do Not Operate at Expected Capacity.....	10
8-3-2	Units in the Heating Mode Do Not Operate at Expected Capacity. ....	12
8-3-3	Outdoor Units Stop at Irregular Times. ....	14
<b>8-4</b>	<b>Checking Transmission Waveform and for Electrical Noise Interference</b> .....	<b>15</b>
8-4-1	M-NET.....	15
8-4-2	MA Remote Controller .....	17
<b>8-5</b>	<b>Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems</b> .....	<b>18</b>
8-5-1	Comparing the High-Pressure Sensor Measurement and Gauge Pressure .....	18
8-5-2	High-Pressure Sensor Configuration (Outdoor unit, HBC) (63HS1, PS1, PS3) .....	19
8-5-3	Comparing the Low-Pressure Sensor Measurement and Gauge Pressure.....	20
8-5-4	Low-Pressure Sensor Configuration (63LS) .....	21
8-5-5	Pressure Sensor (Inner Water, Outlet Water) Configuration (Pw1, Pw2, Pw3, Pw4) .....	21
<b>8-6</b>	<b>Troubleshooting Solenoid Valve Problems</b> .....	<b>22</b>
<b>8-7</b>	<b>Troubleshooting Outdoor Unit Fan Problems</b> .....	<b>23</b>
<b>8-8</b>	<b>Troubleshooting LEV, FCV Problems</b> .....	<b>24</b>
8-8-1	General Overview on LEV Operation (Outdoor unit) .....	24
8-8-2	General Overview on LEV Operation (HBC).....	27
8-8-3	Possible Problems and Solutions .....	29
8-8-4	General Overview on FCV Operation (Indoor unit).....	30
8-8-5	Coil Removal Instructions .....	32
<b>8-9</b>	<b>Troubleshooting Problems with Major Components on HBC</b> .....	<b>34</b>
8-9-1	Pressure Sensor .....	34
8-9-2	Temperature Sensor .....	36
8-9-3	Troubleshooting Flowchart for LEVs, Solenoid Valves, and Valve Blocks .....	37
8-9-4	Water Pump Control .....	39
<b>8-10</b>	<b>Troubleshooting Inverter Problems</b> .....	<b>40</b>
8-10-1	Inverter-Related Problems and Solutions .....	40
8-10-2	Checking the Inverter Board Error Detection Circuit.....	42
8-10-3	Checking the Compressor for Ground Fault and Coil Resistance Problems .....	42
8-10-4	Checking the Inverter for Damage at No-Load .....	43
8-10-5	Checking the Inverter for Damage during Compressor Operation.....	44
8-10-6	Checking the Converter for Damage during Compressor Operation .....	45
8-10-7	Checking the Fan Motor for Ground Fault and Coil Resistance Problems .....	46
8-10-8	Checking the Fan Board Error Detection Circuit at No Load .....	46
8-10-9	Checking the Fan Board for Damage at No Load.....	46
8-10-10	Checking the Fan Board for Damage with Load .....	47



8-10-11	Checking the Pump Motor for Ground Fault and Coil Resistance Problems .....	48
8-10-12	Checking the Error-Detection Circuit on the Pump INV Board (Without load) .....	48
8-10-13	Checking the Pump INV Board for Damage (Without load) .....	48
8-10-14	Checking the Pump INV Board for Damage (During pump operation) .....	49
8-10-15	Checking the Installation Conditions .....	49
8-10-16	Solutions for the Main Breaker Trip .....	49
8-10-17	Solutions for the Main Earth Leakage Breaker Trip .....	50
8-10-18	Simple Check on Inverter Circuit Components .....	51
8-10-19	Troubleshooting Problems with IGBT Module .....	52
8-10-20	Checking the Fan Inverter Heatsink for Clogging .....	56
<b>8-11</b>	<b>Control Circuit.....</b>	<b>57</b>
8-11-1	Control Power Supply Function Block.....	57
8-11-2	Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit .....	62
<b>8-12</b>	<b>Measures for Refrigerant Leakage .....</b>	<b>66</b>
<b>8-13</b>	<b>Parts Replacement Instructions (Outdoor Unit) .....</b>	<b>68</b>
8-13-1	Ensuring Maintenance Space (Preparation for the Maintenance of Refrigerant Circuit Parts).....	68
8-13-2	Notes on Wiring Installation .....	72
8-13-3	Four-way Valve Replacement Procedure .....	76
8-13-4	Replacement Procedure for the Check Valve Block Assembly .....	85
8-13-5	Compressor Replacement Procedure.....	96
8-13-6	Removal Instructions for the Control Box .....	98
8-13-7	Maintenance Procedure for the Drain Pan.....	101
8-13-8	Maintenance Procedures for the Heat Exchanger .....	107
8-13-9	Accumulator Replacement Procedure .....	123
<b>8-14</b>	<b>HBC Maintenance Instructions (Applicable to main and sub HBCs).....</b>	<b>127</b>
8-14-1	Valve Block .....	127
8-14-2	Instructions for Debris Removal Operation .....	128
8-14-3	Instructions for the Air Vent Operation.....	131
8-14-4	Preparation for servicing .....	134
<b>8-15</b>	<b>Main-HBC Maintenance Instructions .....</b>	<b>138</b>
8-15-1	Solenoid Valve Coil (SV1) Replacement Procedure (HBC).....	138
8-15-2	4-Way Valve Coils (21S4Ma, 21S4Mb) Replacement Procedure (HBC).....	138
8-15-3	LEV Coils (LEV1, LEV2, LEV3) Replacement Procedure (HBC).....	139
8-15-4	Valve Motor and Valve Body Replacement Procedure (HBC).....	139
8-15-5	Valve Block Replacement Procedure (HBC) .....	140
8-15-6	Solenoid Valve and LEV Body Replacement Procedure (HBC) .....	141
8-15-7	Strainer Replacement Procedure (HBC).....	141
8-15-8	Pump Replacement Procedure (HBC).....	142
8-15-9	Disassembling the Pump and Replacing the Mechanical Seal (HBC).....	144
8-15-10	JOINT Replacement Procedure (HBC).....	161
8-15-11	Thermistor (TH31) Replacement Procedure (HBC).....	162
8-15-12	Thermistors (TH12, TH14, TH15, and TH34) Replacement Procedure (HBC).....	163
8-15-13	4-way Valve Body (21S4) Replacement Procedure (HBC).....	164
8-15-14	Plate Heat Exchanger Replacement Procedure (HBC) .....	166
8-15-15	Pressure Sensor Replacement Procedure (HBC) .....	174
8-15-16	Pressure Sensor (PS3) Replacement Procedure (HBC) .....	174
8-15-17	Water Pressure Sensor (PW1, 2, 4) Replacement Procedure (HBC).....	175
8-15-18	Water Pressure Sensor (PW3) Replacement Procedure (HBC).....	175
8-15-19	Refrigerator Circuit Side Strainer Replacement Procedure (HBC) .....	176

---

8-15-20	Water Pressure Protection Valve Replacement Procedure (HBC).....	176
<b>8-16</b>	<b>Sub-HBC Maintenance Instructions.....</b>	<b>177</b>
8-16-1	Valve Block Assembly Replacement Procedur (Sub HBC) .....	177
8-16-2	Thermistor (TH31) Replacement Procedur (Sub HBC) .....	179
8-16-3	Thermistor (TH32, TH33) Replacement Procedur (Sub HBC).....	180
8-16-4	Air Vent Valve Replacement Procedure (Sub HBC).....	181
<b>8-17</b>	<b>Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit .....</b>	<b>182</b>



---

## 8-1 MA Remote Controller Problems


---

### 8-1-1 The LCD Does Not Light Up.

---

---

#### 1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running. (Power indicator (  ) is unlit and no lines appear on the remote controller.)

#### 2. Cause

- 1) The power is not supplied to the indoor unit.
  - The main power of the indoor unit is not on.
  - The connector on the indoor unit board has come off.
  - The fuse on the indoor unit board has melted.
  - Transformer failure and disconnected wire of the indoor unit.
- 2) Incorrect wiring for the MA remote controller
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - Short-circuited MA remote controller wiring
  - Incorrect wiring of the MA remote controller cables
  - Incorrect connection of the MA remote wiring to the terminal block for transmission line (TB5) on the indoor unit
  - Wiring mixup between the MA remote controller cable and 220-240 VAC power supply cable
  - Reversed connection of the wire for the MA remote controller and the M-NET transmission line on the indoor unit
- 3) The number of the MA remote controllers that are connected to an indoor unit exceeds the allowable range (2 units).
- 4) The length or the diameter of the wire for the MA remote controller are out of specification.
- 5) Short circuit of the wire for the remote display output of the outdoor unit or reversed polarity connection of the relay.
- 6) The indoor unit board failure
- 7) MA remote controller failure

#### 3. Check method and remedy

- 1) Check the voltage at the MA remote controller terminals.
  - If the voltage is between DC 9 and 12V, the remote controller is a failure.
  - If no voltage is applied, check the causes 1) and 3) and if the cause is found, correct it.
  - If no cause is found, refer to 2).
- 2) Disconnect the remote controller cable from TB15 (MA remote controller terminal) on the indoor unit, and check the voltage across the terminals on TB15.
  - If the voltage is between DC 9 and 12 V, check the causes 2) and 4) and if the cause is found, correct it.
  - If no voltage is applied, check the cause 1) and if the cause is found, correct it.
  - If no cause is found, check the wire for the remote display output (relay polarity).
  - If no further cause is found, replace the indoor unit board.

## 8-1-2 The LCD Momentarily Lights Up and Then Goes Off.

### 1. Phenomena

When the remote controller operation SW is turned on, the operation status briefly appears on the display, then it goes off, and the display lights out immediately, and the unit stops.


### 2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit. For details, refer to the following page(s).[8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit]
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
  - The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).

In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit.
- 4) Disconnected M-NET transmission line on the indoor unit side.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.

### 3. Check method and remedy

When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.



## 8-1-3 "HO" and "PLEASE WAIT" Do Not Go Off the Screen.

### 1. Phenomena

"HO" or "PLEASE WAIT" display on the remote controller does not disappear, and no operation is performed even if the button is pressed. ("HO" or "PLEASE WAIT" display will normally turn off 5 minutes later after the power on.)


### 2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit. For details, refer to the following page(s). [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit]
- 2) Short-circuited transmission line
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
  - The male power supply connectors on the multiple outdoor units are connected to the female power supply switch connector (CN40).

In the system to which the power supply unit for transmission lines is connected, the male power supply connector is connected to the female power supply switch connector (CN40) on the outdoor unit
- 4) Disconnected M-NET transmission line on the indoor unit.
- 5) Disconnected wire between the terminal block for M-NET line (TB5) of the indoor unit and the indoor unit board (CN2M) or disconnected connector.
- 6) Incorrect wiring for the MA remote controller
  - Short-circuited wire for the MA remote controller
  - Disconnected wire for the MA remote controller (No.2) and disconnected line to the terminal block.
  - Reversed daisy-chain connection between groups
  - Incorrect wiring for the MA remote controller to the terminal block for transmission line connection (TB5) on the indoor unit
  - The M-NET transmission line is connected incorrectly to the terminal block (TB15) for the MA remote controller.
- 7) The sub/main setting of the MA remote controller is set to sub.
- 8) 2 or more main MA remote controllers are connected.
- 9) Indoor unit board failure (MA remote controller communication circuit)
- 10) Remote controller failure
- 11) Outdoor unit failure (Refer to the following page(s). [8-17 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit])

### 3. Check method and remedy

When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.





---

## 8-2 ME remote Controller Problems

---

### 8-2-1 The LCD Does Not Light Up.

---

---

#### 1. Phenomena

Even if the operation button on the remote controller is pressed, the display remains unlit and the unit does not start running. (Remote controller is not powered.)

#### 2. Cause

- 1) The power for the M-NET transmission line is not supplied from the outdoor unit.
- 2) Short circuit of the transmission line.
- 3) Incorrect wiring of the M-NET transmission line on the outdoor unit.
  - Disconnected wire for the MA remote controller or disconnected line to the terminal block.
  - The indoor transmission line is connected incorrectly to the transmission terminal block for centralized controller (TB7).
- 4) Disconnected transmission line on the remote controller.
- 5) Remote controller failure
- 6) Outdoor unit failure (For details, refer to the following page(s). [8-17 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit])

#### 3. Check method and remedy

- 1) Check voltage of the transmission terminal block for of the ME remote controller.
  - If voltage between is 17V and 30V → ME remote controller failure
  - When voltage is 17V or less → For details, refer to the following page(s). [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit]
- 2) **When 2) and 3) above apply, check code 7102 will be displayed on the self-diagnosis LED.**



## 8-2-2 The LCD Momentarily Lights Up and Then Goes Off.

### 1. Phenomena


When the remote controller operation SW is turned on, a temporary operation display is indicated, and the display lights out immediately.

### 2. Cause

- 1) The power is not supplied to the indoor unit.
  - The main power of the indoor unit (AC220V) is not on.
  - The connector on the indoor unit board has come off.
  - The fuse on the indoor unit board has melted.
  - Transformer failure and disconnected wire of the indoor unit
  - The indoor unit board failure
- 2) The outdoor control board failure
 

As the indoor unit does not interact with the outdoor unit, the outdoor unit model cannot be recognized.

### 3. Check method and remedy



## 8-2-3 "HO" or "Waiting for ..." Does Not Go Off the Screen.

### 1. Phenomena

"HO" or "Waiting for ..." display on the remote controller does not disappear, and no operation is performed even if the button is pressed.

### 2. Cause

#### Without using MELANS

- 1) Outdoor unit address is set to "00"
- 2) A wrong address is set.
  - The address of the indoor unit that is connected to the remote controller is incorrect. (It should equal the ME remote controller address minus 100.)
  - A wrong address is set to the ME remote controller. (100 must be added to the address of the indoor unit.)
- 3) Faulty wiring of the terminal block for transmission line (TB5) of the indoor unit in the same group with the remote controller.
- 4) The centralized control switch (SW5-1) on the outdoor unit is set to ON.
- 5) Disconnection or faulty wiring of indoor unit transmission line.
- 6) Disconnection between the terminal block for M-NET line connection (TB5) of the indoor unit and the male connector (CN2M)
- 7) The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.
- 8) Outdoor unit control board failure
- 9) Indoor unit control board failure
- 10) Remote controller failure


#### Interlocking control with MELANS

- 1) No group registration is made using MELANS. (The indoor unit and the ME remote controller are not grouped.)
- 2) Disconnected transmission line for centralized control (TB7) of the outdoor unit
- 3) The male power supply connector is connected to CN40 on more than one outdoor unit, or the connector is connected to CN40 on the outdoor unit in the system to which a power supply unit for transmission line is connected.

#### Using MELANS

- 1) When MELANS is used, "HO" or "Waiting for ..." display on the remote controller will disappear when the indoor unit and the local remote controller (ME remote controller) are grouped.  
If "HO" does not disappear after the registration, check items 1) through 3) in the "Cause" column of the section on interlocked control with MELANS.

### 3. Check method and remedy



\*1. When the outdoor unit address is set to 1 - 50, the address will be forcibly set to 100.

## 8-2-4 "88", "Request denied." Appears on the LCD.

### 1. Phenomena

"88", "Request denied." appears on the remote controller when the address is registered or confirmed.

### 2. Cause, check method and remedy

Cause	Check method and remedy
<b>An error occurs when the address is registered or confirmed. (common)</b>	
1. A wrong address is set to the unit to be coupled.	(1) Confirm the address of unit to be coupled.
2. The transmission line of the unit to be coupled is disconnected or is not connected.	(2) Check the connection of transmission line.
3. Circuit board failure of the unit to be coupled	(3) Check voltage of the terminal block for transmission line of the unit to be coupled.
4. Improper transmission line work	1) Normal if voltage is between 17 and 30 VDC. 2) Check (5) in case other than 1).
<b>Generates at interlocking registration between LOSSNAY and the indoor unit</b>	
5. The power of LOSSNAY is OFF.	(4) Check for the main power of LOSSNAY.
<b>Generates at confirmation of controllers used in the system in which the indoor units connected to different outdoor units are grouped</b>	
6. The power of the outdoor unit to be confirmed has been cut off.	(5) Check the power supply of the outdoor unit which is coupled with the unit to be confirmed.
7. Transmission line is disconnected from the terminal block for central control system connection (TB7) on the outdoor unit.	(6) Check that the transmission line for centralized control (TB7) of the outdoor unit is not disconnected.
8. When the indoor units connected to different outdoor units are grouped without MELANS, the male power supply connector is not connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	(7) Check voltage of the transmission line for centralized control.
9. The male power supply connectors on 2 or more outdoor units are connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	1) Normal when voltage is between 10V and 30V
10. In the system to which MELANS is connected, the male power supply connector is connected to the female power supply switch connector (CN40) for the transmission line for centralized control.	2) Check 8 - 11 described on the left in case other than 1).
11. Short circuit of the transmission line for centralized control	





# 8-3 Refrigerant Control Problems


## 8-3-1 Units in the Cooling Mode Do Not Operate at Expected Capacity.

### 1. Phenomena

Although cooling operation starts with the normal remote controller display, the capacity is not enough.

#### (1) Cause, check method and remedy

Cause	Check method and remedy
<p>1. Compressor frequency does not rise sufficiently.</p> <ul style="list-style-type: none"> <li>•Faulty detection of pressure sensor.</li> <li>•Protection works and compressor frequency does not rise due to high discharge temperature</li> <li>•Protection works and compressor frequency does not rise due to high pressure</li> <li>•Pressure drops excessively.</li> </ul>	<p>(1) Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED.</p> <p>-&gt; If the accurate pressure is not detected, check the pressure sensor.</p> <p>Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]</p> <p>Note: Lower inlet pressure by the low pressure sensor than the actual pressure causes insufficient capacity. SW4 setting (SW6-10: OFF)</p> <p>High pressure sensor SW4 ON </p> <p>Low pressure sensor SW4 ON </p> <p>(2) Check temperature difference between the evaporating temperature (Te) and the target evaporating temperature (Tem) with self-diagnosis LED.</p> <p>Note: Higher Te than Tem causes insufficient capacity. SW4 setting (SW6-10: OFF)</p> <p>Evaporating temperature Te SW4 ON </p> <p>Target evaporating temperature Tem SW4 ON </p> <p>Note: Protection works and compressor frequency does not rise even at higher Te than Tem due to high discharge temperature and high pressure. At high discharge temperature: Refer to the following page(s). [7-3-1 Error Code [1102]] At high pressure: Refer to the following page(s). [7-3-3 Error Code [1302] (during operation)]</p>
<p>2. HBC LEV1 and 2 actuation failure</p> <ul style="list-style-type: none"> <li>•Insufficient refrigerant flows due to LEV malfunction (not enough opening) or protection works and compressor frequency does not rise due to pressure drop.</li> </ul>	<p>Refer to the following page(s). [8-8-2 General Overview on LEV Operation (HBC)]</p>



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

8 Troubleshooting Based on Observed Symptoms





Cause	Check method and remedy
3. RPM error of the outdoor unit FAN ♦Motor failure or board failure, or airflow rate decrease due to clogging of the heat exchanger ♦The fan is not properly controlled as the outdoor temperature cannot be precisely detected by the temperature sensor. ♦The fan is not properly controlled as the pressure cannot be precisely detected by the pressure sensor.	Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems] [7-3-3 Error Code [1302] (during operation)]
4. Long piping length The cooling capacity varies greatly depending on the pressure loss. (When the pressure loss is large, the cooling capacity drops.)	Check the piping length to determine if it is contributing to performance loss. Piping pressure loss can be estimated from the temperature difference between the indoor unit heat exchanger outlet temperature and the saturation temperature (Te) of 63LS. ->Correct the piping.
5. Piping size is not proper (thin)	
6. Insufficient refrigerant amount Protection works and compressor frequency does not rise due to high discharge temperature.	Refer to item 1 (Compressor frequency does not rise sufficiently.) on the previous page. Refer to the following page(s). [6-3 Evaluating and Adjusting Refrigerant Charge]
7. Clogging by foreign object	Check the temperature difference between in front of and behind the place where the foreign object is clogging the pipe (upstream side and downstream side). When the temperature drops significantly, the foreign object may clog the pipe. -> Remove the foreign object inside the pipe.
8. The indoor unit inlet temperature is excessively low. (Less than 15°C [59°F] WB)	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
9. Compressor failure The amount of circulating refrigerant decreases due to refrigerant leak in the compressor.	Check the discharge temperature to determine if the refrigerant leaks, as it rises if there is a leak.
10. HBC LEV3 actuation failure Sufficient cold water is not supplied as sufficient sub cool cannot be secured on the HBC due to LEV1, 2, and 3 actuation failure.	Refer to the following page(s). [8-8-2 General Overview on LEV Operation (HBC)]
11. TH12, TH15 and 63HS1 sensor failure or faulty wiring LEV3 is not controlled normally.	Check the thermistor. Check wiring.
12. HBC valve block actuation failure Sufficient cold water is not supplied because of the insufficient water flow rate and coexistence of cold and hot water on the HBC due to valve block actuation failure.	Refer to the following page(s). [8-14 HBC Maintenance Instructions (Applicable to main and sub HBCs)]
13. Open phase in the power-supply due to improper power-supply wiring	Make sure that the power-supply wiring is properly connected. (Refer to item (6) in section [6-1 Read before Test Run].) Possible open phase.
14. LEV4 failure	Refer to the following page(s). [8-8-3 Possible Problems and Solutions]


## 8-3-2 Units in the Heating Mode Do Not Operate at Expected Capacity.

### 1. Phenomena

Although heating operation starts with the normal remote controller display, the capacity is not enough.

### 2. Cause, check method and remedy

Cause	Check method and remedy
<p>1. Compressor frequency does not rise sufficiently.</p> <ul style="list-style-type: none"> <li>•Faulty detection of pressure sensor.</li> <li>•Protection works and compressor frequency does not rise due to high discharge temperature</li> <li>•Protection works and compressor frequency does not rise due to high pressure.</li> </ul>	<p>(1) Check pressure difference between the detected pressure by the pressure sensor and the actual pressure with self-diagnosis LED. -&gt; If the accurate pressure is not detected, check the pressure sensor. Refer to the following page(s). [8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure]</p> <p>Note: Higher inlet pressure by the high pressure sensor than the actual pressure causes insufficient capacity. SW4 setting (SW6-10: OFF)</p> <p>High pressure sensor SW4 ON  </p> <p>Low pressure sensor SW4 ON  </p> <p>(2) Check the difference between the condensing temperature (Tc) and the target condensing temperature (Tcm) with self-diagnosis LED.</p> <p>Note: Higher Tc than Tcm causes insufficient capacity. SW4 setting (SW6-10: OFF)</p> <p>Condensing temperature Tc SW4 ON  </p> <p>Target condensing temperature Tcm SW4 ON  </p> <p>Note: Protection works and compressor frequency does not rise even at lower Tc than Tcm due to high discharge temperature and high pressure. At high discharge temperature: Refer to the following page(s). [7-3-1 Error Code [1102]] Refer to the following page(s). [7-3-3 Error Code [1302] (during operation)]</p>



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

Cause	Check method and remedy
2. HBC LEV1 and 2 actuation failure Sufficient hot water is not supplied on the HBC due to HBC LEV1, 2, and 3 actuation failure.	Refer to the following page(s). [8-8-2 General Overview on LEV Operation (HBC)]
3. Temperature reading error on the indoor unit piping temperature sensor If the temperature reading on the sensor is higher than the actual temperature, it makes the subcool seem smaller than it is, and the LEV opening decreases too much.	Check the thermistor.
4. RPM error of the outdoor unit FAN ♦Motor failure or board failure, or airflow rate decrease, pressure drop due to clogging of the heat exchanger leading to high discharge temperature ♦The fan is not properly controlled as the temperature cannot be precisely detected with the piping sensor.	Refer to the following page(s). [8-7 Troubleshooting Outdoor Unit Fan Problems] [7-3-3 Error Code [1302] (during operation)]
5. Insulation failure of the refrigerant piping	
6. Long piping length Excessively long piping on the high pressure side causes pressure loss leading to increase in the high pressure.	Confirm that the characteristic of capacity drop due to piping length. -> Change the pipe
7. Piping size is not proper (thin)	
8. Clogging by foreign object	Check the temperature difference between the upstream and the downstream of the pipe section that is blocked. Since blockage in the extended section is difficult to locate, operate the unit in the cooling cycle, and follow the same procedures that are used to locate the blockage of pipe during cooling operation. ->Remove the blockage in the pipe.
9. The indoor unit inlet temperature is excessively high.(exceeding 28°C [82°F])	Check the inlet air temperature and for short cycling. Change the environment where the indoor unit is used.
10. Insufficient refrigerant amount Protection works and compressor frequency does not rise due to low discharge temperature Refrigerant recovery operation is likely to start.	Refer to item 1 (Compressor frequency does not rise sufficiently.) on the previous page. Refer to the following page(s). [6-3 Evaluating and Adjusting Refrigerant Charge]
11. Compressor failure (same as in case of cooling)	Check the discharge temperature.
12. HBC LEV3 actuation failure A drop in the low pressure that is caused either by a blockage of liquid pipe or by a pressure loss and the resultant slowing of refrigerant flow causes a tendency for the discharge temperature to rise.	Refer to the following page(s). [8-8-2 General Overview on LEV Operation (HBC)]
13. HBC valve block actuation failure Sufficient hot water is not supplied because of the insufficient water flow rate and coexistence of cold and hot water on the HBC due to valve block actuation failure.	Refer to the following page(s). [8-14 HBC Maintenance Instructions (Applicable to main and sub HBCs)]
14. Open phase in the power-supply due to improper power-supply wiring	Make sure that the power-supply wiring is properly connected. (Refer to item (6) in section [6-1 Read before Test Run].) Possible open phase.
15. LEV4 failure	Refer to the following page(s). [8-8-3 Possible Problems and Solutions]



### 8-3-3 Outdoor Units Stop at Irregular Times.

#### 1. Phenomena

Outdoor unit stops at times during operation.

#### 2. Cause, check method and remedy

Cause	Check method and remedy
The first stop is not considered as an error, as the unit turns to anti-restart mode for 3 minutes as a preliminary error.	(1) Check the mode operated in the past by displaying preliminary error history on LED display with SW4.
<b>Error mode</b>	(2) Reoperate the unit to find the mode that stops the unit by displaying preliminary error history on LED display with SW4.
1) Abnormal high pressure	Refer to the reference page for each error mode.
2) Abnormal discharge air temperature	*Display the indoor piping temperature with SW4 to check whether the freeze proof operation runs properly, and check the temperature.
3) Heatsink thermistor failure	
4) Thermistor failure	
5) Pressure sensor failure	
6) Over-current break	
7) Refrigerant overcharge	
Note1: Frost prevention tripping only under cooling mode may be considered in addition to the above. (Freeze protection is detected by one or all indoor units.)	
Note2: Even the second stop is not considered as an error when some specified errors occur. (eg. The third stop is considered as an error when the thermistor error occurs.)	

## 8-4 Checking Transmission Waveform and for Electrical Noise Interference


### 8-4-1 M-NET

Control is performed by exchanging signals between the outdoor unit and the indoor unit (ME remote controller) through M-NET transmission. Noise interference on the transmission line will interrupt the normal transmission, leading to erroneous operation.

#### (1) Symptoms caused by noise interference on the transmission line

Cause	Erroneous operation	Error code	Error code definition
Noise interference on the transmission line	Signal is transformed and will be misjudged as the signal of another address.	6600	Address overlap
	Transmission wave pattern is transformed due to the noise creating a new signal	6602	Transmission processor hardware error
	Transmission wave pattern is transformed due to the noise, and will not be received normally leading to no acknowledgement (ACK).	6607	No ACK error
	Transmission cannot be performed due to the fine noise.	6603	Transmission line bus busy error
	Transmission is successful; however, the acknowledgement (ACK) or the response cannot be received normally due to the noise.	6607 6608	No ACK error No response error

#### (2) Wave shape check



#### Wave shape check

Check the wave pattern of the transmission line with an oscilloscope. The following conditions must be met.

- Small wave pattern (noise) must not exist on the transmission signal. (Minute noise (approximately 1V) can be generated by DC-DC converter or the inverter operation; however, such noise is not a problem when the shield of the transmission line is grounded.)
- The sectional voltage level of transmission signal should be as follows.

Logic	Voltage level of the transmission line
0	$V_{HL} = 2.5V$ or higher
1	$V_{BN} = 1.3V$ or below

**(3) Check method and remedy**

1) Measures against noise

Check the followings when noise exists on the wave or the errors described in (1) occur.

	Error code definition	Remedy
Check that the wiring work is performed according to wiring specifications.	1. The transmission line and the power line are not wired too closely.	Isolate the transmission line from the power line (5cm [1-31/32"] or more). Do not insert them in the same conduit.
	2. The transmission line is not bundled with that for another systems.	The transmission line must be isolated from another transmission line. When they are bundled, erroneous operation may be caused.
	3. The specified wire is used for the transmission line.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm <sup>2</sup> [AWG16] or more (Remote controller wire: 0.3 - 1.25mm <sup>2</sup> [AWG22-16])
	4. When the transmission line is daisy-chained on the HBC and the indoor unit terminals, are the shields daisy-chained on the terminals, too?	The transmission is two-wire daisy-chained. The shielded wire must be also daisy-chained. When the shielded cable is not daisy-chained, the noise cannot be reduced enough.
Check that the grounding work is performed according to grounding specifications.	5. Is the shield of the indoor-outdoor transmission cable grounded to the earth terminal on the outdoor unit?	Connect the shield of the indoor-outdoor transmission cable to the earth terminal (⌚) on the outdoor unit. If no grounding is provided, the noise on the transmission line cannot escape leading to change of the transmission signal.
	6. Check the treatment method of the shield of the transmission line (for centralized control).	The transmission cable for centralized control is less subject to noise interference if it is grounded to the outdoor unit whose power jumper cable was moved from CN41 to CN40 or to the power supply unit. The environment against noise varies depending on the distance of the transmission lines, the number of the connected units, the type of the controllers to be connected, or the environment of the installation site. Therefore, the transmission line work for centralized control must be performed as follows.  (1) When no grounding is provided: Ground the shield of the transmission cable by connecting to the outdoor unit whose power jumper connector was moved from CN41 to CN40 or to the power supply unit.  (2) When an error occurs even though one point grounding is provided: Ground the shield on all outdoor units.

2) Check the followings when the error "6607" occurs, or "HO" appears on the display on the remote controller.

Error code definition	Remedy
7. The farthest distance of transmission line is 200m [656ft] or longer.	Check that the farthest distance from the outdoor unit to the indoor unit and to the remote controller is within 200m [656ft].
8. The types of transmission lines are different.	Use the specified transmission line. Type: Shielded wire CVVS/CPEVS/MVVS (For ME remote controller) Diameter: 1.25mm <sup>2</sup> [AWG16] or more (Remote controller wire: 0.3-1.25mm <sup>2</sup> [AWG22-16])
9. Outdoor unit circuit board failure	Replace the outdoor unit control board or the power supply board for the transmission line.
10. Indoor unit circuit board failure or remote controller failure	Replace the indoor unit circuit board or the remote controller.
11. The MA remote controller is connected to the M-NET transmission line.	Connect the MA remote controller to the terminal block for MA remote controller (TB15).



### 8-4-2 MA Remote Controller

The communication between the MA remote controller and the indoor unit is performed with current tone burst.

#### (1) Symptoms caused by noise interference on the transmission line

If noise is generated on the transmission line, and the communication between the MA remote controller and the indoor unit is interrupted for 3 minutes in a row, MA transmission error (6831) will occur.

#### (2) Confirmation of transmission specifications and wave pattern





- ① Satisfies the formula  
12 msec/bit  $\pm$  5%
- ② Voltage among terminals must be between DC9 and 12 V.

# 8-5 Pressure Sensor Circuit Configuration and Troubleshooting Pressure Sensor Problems

## 8-5-1 Comparing the High-Pressure Sensor Measurement and Gauge Pressure

Setting the digital display switch (SW4 (SW6-10: OFF)) as follows will display the high-pressure sensor reading on the service LED (LED301) on the control board.



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

**(1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on the self-diagnosis service LED.**

- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on the self-diagnosis service LED is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on the self-diagnosis service LED exceeds 4.15MPa [601psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

**(2) Compare the gauge pressure and the pressure displayed on the self-diagnosis service LED while the sensor is running. (Compare them by MPa [psi] unit.)**

- 1) When the difference between both pressures is within 0.098MPa [14psi], both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.098MPa [14psi], the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis service LED does not change, the high pressure sensor has a problem.

**(3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis service LED.**

- 1) When the pressure displayed on the self-diagnosis service LED is between 0 and 0.098MPa [14psi], the high pressure sensor has a problem.
- 2) When the pressure displayed on the self-diagnosis service LED is approximately 4.15MPa [601psi], the control board has a problem.

**(4) Remove the high pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63HS1, PS1, PS3) to check the pressure with the self-diagnosis service LED.**

- 1) When the pressure displayed on the self-diagnosis service LED exceeds 4.15MPa [601psi], the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.

8 Troubleshooting Based on Observed Symptoms



### 8-5-2 High-Pressure Sensor Configuration (Outdoor unit, HBC) (63HS1, PS1, PS3)

The high pressure sensor consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.071V per 0.098MPa [14psi].

**Note**


The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



### 8-5-3 Comparing the Low-Pressure Sensor Measurement and Gauge Pressure

Setting the digital display switch (SW4 (SW6-10: OFF) as follows will display the low-pressure sensor reading on the service LED (LED301) on the control board.



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

8 Troubleshooting Based on Observed Symptoms

**(1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on the self-diagnosis service LED.**

- 1) When the gauge pressure is between 0 and 0.098MPa [14psi], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on the self-diagnosis service LED is between 0 and 0.098MPa [14psi], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on the self-diagnosis service LED exceeds 1.7MPa [247psi], go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

**(2) Compare the gauge pressure and the pressure displayed on the self-diagnosis service LED while the sensor is running. (Compare them by MPa [psi] unit.)**

- 1) When the difference between both pressures is within 0.03MPa [4psi], both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.03MPa [4psi], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis service LED does not change, the low pressure sensor has a problem.

**(3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis service LED display.**

- 1) When the pressure displayed on the self-diagnosis service LED is between 0 and 0.098MPa [14psi], the low pressure sensor has a problem.
- 2) When the pressure displayed on the self-diagnosis service LED is approximately 1.7MPa [247psi], the control board has a problem.
  - When the outdoor temperature is 30°C [86°F] or less, the control board has a problem.
  - When the outdoor temperature exceeds 30°C [86°F], go to (5).

**(4) Remove the low pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63LS:CN202) to check the pressure with the self-diagnosis service LED.**

- 1) When the pressure displayed on the self-diagnosis service LED exceeds 1.7MPa [247psi], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.

**(5) Remove the high pressure sensor (63HS1) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis service LED.**

- 1) When the pressure displayed on the self-diagnosis service LED exceeds 1.7MPa [247psi], the control board has a problem.
- 2) If other than 1), the low-pressure sensor has a problem.



### 8-5-4 Low-Pressure Sensor Configuration (63LS)

The low pressure sensor consists of the circuit shown in the figure below. If DC5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173V per 0.098MPa [14psi].

**Note**



The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



### 8-5-5 Pressure Sensor (Inner Water, Outlet Water) Configuration (Pw1, Pw2, Pw3, Pw4)

The pressure sensor (inner water, outlet water) consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure sensor between the white and the black wires will be output, and the values of the voltage will be converted by the microcomputer. The output is 0.392V per 0.098MPa [14psi].







## 8-6 Troubleshooting Solenoid Valve Problems

Check whether the output signal from the control board and the operation of the solenoid valve match. Setting the self-diagnosis switch (SW4) as shown in the figure below causes the ON signal of each relay to be output to the LED's. Each LED shows whether the relays for the following parts are ON or OFF. LEDs light up when relays are on.

**Note**

The circuits on some parts are closed when the relays are ON. Refer to the following instructions.

SW4 (SW6-10:OFF)		Display							
		LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8
	Upper	21S4a				SV1a		SV2	
	Lower			21S4b					
	Upper					21S4c			
	Lower								



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

•When a valve malfunctions, check if the wrong solenoid valve coil is not attached the lead wire of the coil is not disconnected, the connector on the board is not inserted wrongly, or the wire for the connector is not disconnected.

### (1) In case of 21S4a, 21S4b, 21S4c (4-way switching valve)

About this 4-way valve

When not powered:

Conducts electricity between the oil separator outlet and heat exchanger AND the gas ball valve (BV1) and the accumulator to complete the circuit for the cooling cycle.

When powered:

The electricity runs between the oil separator and the gas ball valve, and between the heat exchanger and the accumulator. This circulation is for heating.

Check the LED display and the intake and the discharge temperature for the 4-way valve to check whether the valve has no faults and the electricity runs between where and where. Do not touch the pipe when checking the temperature, as the pipe on the oil separator side will be hot. (Before checking the inlet and outlet temperatures, check that LEV2a, LEV2b and LEV2c are open. Refer to [8-8 Troubleshooting LEV, FCV Problems].)

**Note**

Do not give an impact from outside, as the outer hull will be deformed leading to the malfunction of the inner valve.

### (2) In case of SV1a (Bypass valve)

This solenoid valve opens when powered (Relay ON).

- 1) At compressor start-up, the SV1a turns on for 4 minutes, and the operation can be checked by the self-diagnosis LED display and the closing sound.
- 2) To check whether the valve is open or closed, check the change of the SV1a downstream piping temperature while the valve is being powered. Even when the valve is closed, high-temperature refrigerant flows inside the capillary next to the valve. (Therefore, temperature of the downstream piping will not be low with the valve closed.)

### (3) In the case of SV2 (Bypass valve)

This solenoid valve opens when powered (Relay ON).

The relay turns on in the following cases:

- 63HS1 is above 3.43 MPa (497 psi) even when the compressor operates at the minimum frequency in the heating-only or heating-main mode.
- 63LS is below 0.25 MPa (36 psi) and 63HS is below 1.47 MPa (213 psi) within 8 minutes after the recovery from defrosting in the heating-only or heating-main mode, or 3 minutes after and within 12 minutes after the start of the compressor. To see whether the valve is open or closed, check the change in the SV2 downstream piping temperature while the valve is being powered. Do not touch the pipe to check the valve status because hot gas flows while the valve is open.

# 8-7 Troubleshooting Outdoor Unit Fan Problems

## (1) Fan motor (common items)

•The number of revolutions of the outdoor fan is controlled by inverter. Check the number of revolutions of the fan while monitoring the inverter output indicated by the self-diagnosis LED. The table below shows approximate numbers of revolutions of the fan at the full speed.

Model	Number of revolutions (rpm) *SW6-4 and SW6-5 are OFF.		
	Cooling-only or cooling-main mode	1. Heating-only or heating-main mode 2. 5°C < TH7 ≤ 10°C	1. Heating-only or heating-main mode 2. TH7 ≤ 5°C
(E)M200 model	620	620	700
(E)M250 model	670	670	740
(E)M300 model	720	850	850
(E)M350 model	930	930	1010
(E)M400 model	1000	1150	1150
(E)M450 model	1040	1180	1180
(E)M500 model	610	610	690

- When starting the fan, the fan runs at full speed for 5 seconds.
- When setting the DIP SW4 (when SW6-10 is set to OFF) as shown in the figure below, the inverter output [%] will appear. 100% indicates the full speed and 0% indicates the stopping.



The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

- As the revolution of the fan changes under control, at the interphase or when the indoor unit operation capacity is low, the revolution of the fan may change.
- If the fan does not move or it vibrates, Fan board problem or fan motor problem is suspected. When checking the fan motor for problems by shutting down the power, be sure to disconnect the motor wire from the fan board. If a short-circuited fan board malfunctions, it will keep the fan motor from rotating smoothly. For details, refer to the following page(s).  
 [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]  
 [8-10-8 Checking the Fan Board Error Detection Circuit at No Load]  
 [8-10-9 Checking the Fan Board for Damage at No Load]  
 [8-10-10 Checking the Fan Board for Damage with Load]

# 8-8 Troubleshooting LEV, FCV Problems

## 8-8-1 General Overview on LEV Operation (Outdoor unit)


### LEV operation

LEV are stepping-motor-driven valves that operate by receiving the pulse signals from the indoor and outdoor unit control boards.

### (1) Outdoor LEV (LEV2a, 2b, 2c, and 2d)

The valve opening changes according to the number of pulses.

#### 1) Control boards and LEV (outdoor unit) (LEV2a, 2b, 2c, and 2d)




#### 2) Pulse signal output and valve operation

Output (phase) number	Output state			
	1	2	3	4
φ 1	ON	OFF	OFF	ON
φ 2	ON	ON	OFF	OFF
φ 3	OFF	ON	ON	OFF
φ 4	OFF	OFF	ON	ON

Output pulses change in the following orders when the Valve is closed; 1 → 2 → 3 → 4 → 1  
 Valve is open; 4 → 3 → 2 → 1 → 4

- \*1. When the LEV opening angle does not change, all the output phases will be off.
- \*2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

3) LEV valve closing and opening operation



\*When the power is turned on, the valve closing signal of 2200 pulses will be output from the outdoor unit circuit board to LEV to fix the valve position. It must be fixed at point A


When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from E to A in the chart or the valve is locked, a big sound occurs.

\*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.

## (2) Outdoor LEV (LEV4, LEV9)

The valve opening changes according to the number of pulses.

1) Connections between the outdoor control board and LEV9 (outdoor expansion valve)




2) Pulse signal output and valve operation

Output (phase) number	Output state							
	1	2	3	4	5	6	7	8
$\phi 1$	ON	OFF	OFF	OFF	OFF	OFF	ON	ON
$\phi 2$	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
$\phi 3$	OFF	OFF	ON	ON	ON	OFF	OFF	OFF
$\phi 4$	OFF	OFF	OFF	OFF	ON	ON	ON	OFF

Output pulses change in the following orders when the Valve is open; 1 → 2 → 3 → 4 → 5 → 6 → 7 → 8 → 1  
 Valve is closed; 8 → 7 → 6 → 5 → 4 → 3 → 2 → 1 → 8

- \*1. When the LEV opening angle does not change, all the output phases will be off.
- \*2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

3) LEV valve closing and opening operation



\*Upon power on, the outdoor unit circuit board sends a 520 pulse signal to the outdoor unit LEV to determine the valve position and always brings the valve to the position as indicated by "A" in the diagram. (Pulse signal is output for approximately 17 seconds.)

When the valve operates smoothly, there is no sound from the LEV and no vibration occurs, but when the valve is locked, noise is generated.

\*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.

\*If liquid refrigerant flows inside the LEV, the sound may become smaller.

## 8-8-2 General Overview on LEV Operation (HBC)


### LEV operation

HBC LEV1, 2, and 3 (linear expansion valves) are driven by the pulse signal from the control board and are controlled by a stepping motor.

### (1) HBC LEV

The valve opening changes according to the number of pulses.

#### 1) Control boards and the LEV (HBC LEV1, 2, 3)




#### 2) Pulse signal output and valve operation

Output (phase) number	Output state			
	1	2	3	4
φ 1	ON	OFF	OFF	ON
φ 2	ON	ON	OFF	OFF
φ 3	OFF	ON	ON	OFF
φ 4	OFF	OFF	ON	ON

Output pulses change in the following orders when the Valve is closed; 1 → 2 → 3 → 4 → 1  
 Valve is open; 4 → 3 → 2 → 1 → 4

- \*1. When the LEV opening angle does not change, all the output phases will be off.
- \*2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

3) LEV valve closing and opening operation



\* Upon power on, the HBC circuit board sends 3200 Hz pulse signals to the LEVs (HBC LEV 1, 2, and 3) to determine the valve position and bring the valve to the position as indicated by (A) in the diagram.

When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from (E) to (A) in the chart or the valve is locked, a big sound occurs.


\*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.

\*1 The LEV opening may become greater depending on the operation status.

(2) Judgment methods and possible failure mode

Malfunction mode	Judgment method	Remedy
Microcomputer driver circuit failure	Disconnect the control board connector and connect the check LED as shown in the figure below. <p>resistance : 0.25W 1kΩ LED : DC15V 20mA or more When the main power is turned on, the indoor unit circuit board outputs pulse signals to the indoor unit LEV for 10 seconds. If any of the LED remains lit or unlit, the drive circuit is faulty.</p>	When the drive circuit has a problem, replace the control board.
LEV mechanism is locked	If the LEV is locked, the drive motor runs idle, and makes a small clicking sound. When the valve makes a closing and opening sound, the valve has a problem.	Replace the LEV.
Disconnected or short-circuited LEV motor coil	Measure resistance between the coils (red - white, red -orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is 150ohm ±10%.	Replace the LEV coils.
Faulty wire connections in the connector or faulty contact	1. Check for loose pins on the connector and check the colors of the lead wires visually 2. Disconnect the control board's connector and conduct a continuity check using a tester.	Check the continuity at the points where an error occurs.

### 8-8-3 Possible Problems and Solutions

Malfunction mode	Judgment method	Remedy	LEV
Microcomputer driver circuit failure	<p>Disconnect the control board connector and connect the check LED as shown in the figure below.</p>  <p>resistance : 0.25W 1kΩ LED : DC15V 20mA or more When the main power is turned on, the indoor unit circuit board outputs pulse signals to the indoor unit LEV for 10 seconds. If any of the LED remains lit or unlit, the drive circuit is faulty.</p>	When the drive circuit has a problem, replace the control board.	Indoor unit, Outdoor unit and HBC controller
LEV mechanism is locked	If the LEV is locked, the drive motor runs idle, and makes a small clicking sound. When the valve makes a closing and opening sound, the valve has a problem.	Replace the LEV.	Indoor unit, Outdoor unit and HBC controller
Disconnected or short-circuited LEV motor coil	Measure resistance between the coils (red - white, red -orange, red - yellow, red - blue) using a tester. They are normal if resistance is $100\Omega \pm 10\%$ .	Replace the LEV coils.	Outdoor unit (LEV2a, 2b and 2d) and HBC controller (LEV3)
	Measure resistance between the coils (red - white, red -orange, brown - yellow, brown - blue) using a tester. They are normal if resistance is $150\Omega \pm 3\%$ .	Replace the LEV coils.	Indoor unit and HBC controller (LEV1, LEV3)
Faulty wire connections in the connector or faulty contact	<ol style="list-style-type: none"> <li>1 Check for loose pins on the connector and check the colors of the lead wires visually</li> <li>2 Disconnect the control board's connector and conduct a continuity check using a tester.</li> </ol>	Check the continuity at the points where an error occurs.	Indoor unit, Outdoor unit and HBC controller



### 8-8-4 General Overview on FCV Operation (Indoor unit)


#### Flow control valve (FCV) operation

The FCV is operated by a stepping motor, which operates by receiving a pulse signal from the indoor control board.

#### (1) Indoor FCV

The FCV position changes in response to the pulse signal.

##### 1) Indoor control board and FCV connection




- (A) Yellow
- (B) White
- (C) Black
- (D) Brown
- (E) Green
- (F) Blue
- (G) Orange
- (H) Purple
- (I) Control board
- (J) Connection (CN60)
- (K) Drive circuit
- (L) Flow control valve

##### 2) Pulse signal output and valve operation

Output (phase) number	Output status			
	1	2	3	4
4	ON	ON	OFF	OFF
5	OFF	ON	ON	OFF
7	OFF	OFF	ON	ON
8	ON	OFF	OFF	ON

The output pulse changes in the following order:  
 When the valve closes 1 -> 2 -> 3 -> 4 -> 1  
 When the valve opens 4 -> 3 -> 2 -> 1 -> 4

3) FCV operation



- (a) Close
- (b) Open
- (c) Fully open valve (85 pulses)
- (d) Fully close valve (770 pulses)
- (e) No. of pulses
- (f) Valve opening degree

**(2) Judgment methods and possible failure mode**


Malfunction mode	Judgment method	Remedy
(1) Loose connector	Check for connector connection failure.	Reinsert the connector, restart the operation, and check for proper operation.
(2) Wiring fault, flow control valve fault	Check for a broken wiring, and check the resistance of the flow control valve.	Replace the flow control valve.
(3) Control board fault	If no problems are found with the above items, replace the control board.	Replace the control board.

### 8-8-5 Coil Removal Instructions

#### (1) Outdoor unit LEV (LEV4 and 9)


1) Component

As shown in the figure, the outdoor LEV is made in such a way that the coils and the body can be separated.



2) Removing the coils


Fasten the body tightly at the bottom (Part A in the figure) so that the body will not move, then pull out the coils toward the top. If the coils are pulled out without the body gripped, undue force will be applied and the pipe will be bent.



3) Installing the coils

Fix the body tightly at the bottom (Part A in the figure) so that the body will not move, then insert the coils from the top, and insert the coil stopper securely in the pipe on the body.


If the coils are pushed without the body gripped, undue force will be applied and the pipe will be bent. Hold the body when pulling out the coils to prevent so that the pipe will not be bent.



## (2) Outdoor unit LEV (LEV2a, 2b, 2c, and 2d)


### 1) Components

The outdoor unit LEV consists of a coil and a valve body that can be separated from each other.




### 2) Removing the coil

Securely hold the LEV at the bottom (as indicated by A in the figure), and turn the coil. After checking that the stopper is removed, pull up and out the coil. When removing the coil, hold the LEV body securely to prevent undue force from being placed on the pipe and bending the pipe.



### 3) Installing the coil


Securely hold the bottom of the LEV (Part A in the figure), insert the coil from above, and turn the coil until the coil stopper is properly installed on the LEV body. When removing the coil, hold the LEV body securely to prevent undue force from being placed on the pipe and bending the pipe.



# 8-9 Troubleshooting Problems with Major Components on HBC

## 8-9-1 Pressure Sensor



Troubleshooting flow chart for pressure sensor




8 Troubleshooting Based on Observed Symptoms

**Note**

- 1) Check the self-diagnosis switch (Outdoor control board SW4 (SW6-10:OFF)).

Measurement data	Symbol	SW4 setting value
Outdoor high pressure	63HS1	
Outdoor low pressure	63LS	




The figure at left shows that the switches 1 through 5 are set to ON and 6 through 10 are set to OFF.

**Note**

- 2) Check the connector for P1 on the HBC control board for proper connections.
- 3) Check the pressure value on the self-diagnosis switch (same as note 2) with the connector of the applied pressure sensor is disconnected from the board.

## 8-9-2 Temperature Sensor

Troubleshooting instructions for thermistor



**Note**

1) Connectors on the circuit board are connected to the sensors as follows. Unplug the corresponding connectors before checking each sensor.

Sensor	Circuit board	Connector
TH11,TH13	Control board	CN401
TH12,TH14	Control board	CN402
TH15,TH16	Control board	CN403
TH31a,TH31b,TH31c	VB board 1	CNTH1
TH31d,TH31e,TH31f	VB board 1	CNTH2
TH31g,TH31h	VB board 1	CNTH3
TH31i,TH31j,TH31k	VB board 2	CNTH1
TH31l,TH31m,TH31n	VB board 2	CNTH2
TH31o,TH31p	VB board 2	CNTH3
TH32,TH35	Control board	CN404
TH33,TH34	Control board	CN405


\*VB board 1 is the one on the right when facing the control box.  
 \*VB board 2 is the one on the left when facing the control box.

2)

- Pull out the sensor connector from the VB board, Do not pull the sensor by holding the lead wire.
- Measure the resistance with such as a tester.
- Compare the measured value with that of shown in the figure below. When the result is  $\pm 10\%$ , it is normal.


### 8-9-3 Troubleshooting Flowchart for LEVs, Solenoid Valves, and Valve Blocks

#### (1) LEV





**Troubleshooting flow chart for solenoid valve body**





### 8-9-4 Water Pump Control

Check the connector and make sure that it is connected properly.

Pump failure as judged based on the inverter-related failure judgment may be caused by one or more of the following factors.

- Coil failure - replace pump. If the windings have been damaged the pump will require replacing.
- Internal mechanical failure such as bearing failure, turbine failure, magnet degradation. This will require pump replacement.

Before replacement the causes must be investigated and resolved. The pump shaft bearings and magnets can be easily damaged by overheating due to dry running or water system blockage. Check the strainer for blockage, investigate the water circuit for blockage and or foreign material, and that there is no air in the system or an uncontrolled leak.



# 8-10 Troubleshooting Inverter Problems


## 8-10-1 Inverter-Related Problems and Solutions

- Replace only the compressor if only the compressor is found to be defective. (Overcurrent will flow through the inverter if the compressor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage. Make sure that the model selection switches on the outdoor unit (Dip switches SW5-3 through 5-8 on the outdoor unit control board) are set correctly. For switch settings, refer to the following page(s). [7-9-2 Error Code [7101]])
- Replace only the fan motor if only the fan motor is found to be defective. (Overcurrent will flow through the inverter if the fan motor is damaged, however, the power supply is automatically cut when overcurrent is detected, protecting the inverter from damage.)
- Replace the defective components if the inverter is found to be defective.
- If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

### (1) Inverter-related problems: Troubleshooting and remedies

- 1) Inside the inverter is a large capacity electrolytic capacitor, and the residual voltage that remains after the main power is turned off presents a risk of electric shock. Before inspecting the inside of the control box, turn off the power, leave the unit turned off for at least 10 minutes, and check that the voltage across pins 1 (+) and 5 (-) of relay connector RYPN has dropped to 20 VDC or less. (It takes approximately 10 minutes to discharge electricity after the power is turned off.)
- 2) Perform the service after disconnecting the relay connectors of the outdoor unit fan (RYFAN1 and RYFAN2). Before plugging in or unplugging connectors, check that the outdoor unit fan is not rotating and that the voltage across Pin 1 (+) and Pin 5 (-) of connector RYPN is 20 VDC or less. The capacitor may collect a charge and cause an electric shock when the outdoor unit fan rotates in windy conditions. Refer to the wiring nameplate for details.
- 3) Reconnect the relay connectors (RYFAN 1 and RYFAN2) after completion of maintenance work.
- 4) The IPM on the inverter becomes damaged if there are loose screws or connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- 5) To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 6) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 7) When the IPM or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 8) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.
- 9) When the power is turned on, the compressor is energized even while they are not operating. Before turning on the power, disconnect all power supply wires from the compressor terminal block, and measure the insulation resistance of the compressor. Check the compressor for a ground fault. If the insulation resistance is 1.0 MΩ or below, connect all power supply wires to the compressor, and turn on the power to the outdoor unit. (The liquid refrigerant in the compressor will evaporate by energizing the compressor.)

8 Troubleshooting Based on Observed Symptoms

	Error display/failure condition	Measure/inspection item
[1]	Inverter related errors 4250, 4255, 4256, 4220, 4225, 4226, 4230, 4240, 4260, 5301, 5305, 5306, 0403	Implement solutions that correspond to the error codes or preliminary error codes. [7-1 Error Code and Preliminary Error Code Lists]
[2]	Main power breaker trip	Refer to the following page(s). [8-10-16 Solutions for the Main Breaker Trip]
[3]	Main power earth leakage breaker trip	Refer to the following page(s). [8-10-17 Solutions for the Main Earth Leakage Breaker Trip]
[4]	Only the compressor does not operate.	Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation]
[5]	The compressor vibrates violently at all times or makes an abnormal sound.	Refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation]
[6]	Compressor rotation speed does not reach the specified speed.	<1> Check for problems with compressor current and heatsink temperature. <2> Check for imbalance in power supply voltage. *Approximate target: 3% or less.
[7]	Only the fan motor does not operate.	Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]
[8]	The fan motor shakes violently at all times or makes an abnormal sound.	Check the inverter frequency on the LED monitor. If the frequency indicates that the units are in operation, refer to the following page(s). [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] [8-10-9 Checking the Fan Board for Damage at No Load] [8-10-10 Checking the Fan Board for Damage with Load]
[9]	Only the pump of the HBC does not operate.	Refer to the following pages if the HBC is operating. [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)]
[10]	Only the pump of the HBC constantly vibrates heavily or makes abnormal sounds.	[8-10-13 Checking the Pump INV Board for Damage (Without load)] [8-10-14 Checking the Pump INV Board for Damage (During pump operation)]
[11]	Noise is picked up by the peripheral device.	<1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the outdoor unit. <2> Check if the inverter output wiring is not running parallel to the power supply wiring and the transmission lines. <3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire. <4> Meg failure for electrical system other than the inverter <5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.) <6> Provide separate power supply to the air conditioner and other electric appliances. <7> If the problem suddenly appeared, inverter output may have had a ground fault. For details, refer to the following page(s). [8-10-5 Checking the Inverter for Damage during Compressor Operation] *Contact the factory for cases other than those listed above.
[12]	Sudden malfunction (as a result of external noise)	<1> Check that the grounding work is performed properly. <2> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire. <3> Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe. * Contact the factory for cases other than those listed above.

### 8-10-2 Checking the Inverter Board Error Detection Circuit

Items to be checked	Phenomena	Remedy
(1) Stop the unit. Remove power supply.	1) Overcurrent error Error code: 4250 Detail code: No. 101, 104, 105, 106, and 107	Replace the INV board.
(2) Disconnect the inverter output wires from the compressor terminals (U, V, W). <sup>*1</sup>	2) Logic error Error code: 4220 Detail code: No. 111	Replace the INV board.
(3) Apply power supply.	3) ACCT sensor circuit failure Error code: 5301 Detail code: No.117	Replace the INV board.
(4) Put the outdoor unit into operation.	4) IPM open Error code: 5301 Detail code: No.119	Normal

\*1 Output voltage is present at the inverter output wiring terminal. To avoid short-circuiting and ground fault, do not let the terminal come in contact with the unit or the compressor, and use caution not to damage the terminal.

\*2 Compressors are located in the back of the MAIN BOX. To disconnect the inverter output wiring, move the MAIN BOX out of the way first, and then disconnect the wiring from the terminal on the compressor. Refer to [8-13-1 Ensuring Maintenance Space (Preparation for the Maintenance of Refrigerant Circuit Parts)]for how to move the MAIN BOX.

### 8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems

Items to be checked	Phenomena	Remedy
Disconnect the compressor wiring, and check the compressor Meg, and coil resistance.	1) Compressor Meg failure Error if less than 1 MΩ.	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.
	2) Compressor coil resistance failure Coil resistance value of 0.192 Ω (20°C [68°F]): (E)M200 to (E)M350 models Coil resistance value of 0.219 Ω (20°C [68°F]): (E)M400 to (E)M500 model	Replace the compressor.

### 8-10-4 Checking the Inverter for Damage at No-Load

Items to be checked	Phenomena	Remedy
(1) Stop the unit. Remove power supply.	1) Inverter-related problems are detected.	Set SW7-1 on the MAIN board to ON, and go to [8-10-2 Checking the Inverter Board Error Detection Circuit].
(2) Disconnect the inverter output wires from the compressor terminals (U, V, W). <sup>*1</sup>	2) Inverter voltage is not output at the terminals (U, V, and W)	Replace the INV board.
(3) Set SW7-1 on the MAIN board to ON.	3) There is a voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the INV board.
(4) Apply power supply.  (5) Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	4) There is no voltage imbalance between the wires.	Normal *When done checking, set SW7-1 on the MAIN board back to as it was.

\*1 Output voltage is present at the inverter output wiring terminal. To avoid short-circuiting and ground fault, do not let the terminal come in contact with the unit or the compressor, and use caution not to damage the terminal.

\*2 Compressors are located in the back of the MAIN BOX. To disconnect the inverter output wiring, move the MAIN BOX out of the way first, and then disconnect the wiring from the terminal on the compressor. Refer to [8-13-1 Ensuring Maintenance Space (Preparation for the Maintenance of Refrigerant Circuit Parts)]for how to move the MAIN BOX.

### 8-10-5 Checking the Inverter for Damage during Compressor Operation

8 Troubleshooting Based on Observed Symptoms

Items to be checked	Phenomena	Remedy
Put the outdoor unit into operation. Check the inverter output voltage (at the compressor terminal) after the inverter output frequency has stabilized. <INV35Y, 42Y>	1) Overcurrent-related problems occur immediately after compressor startup. Error code : 4250 Detail code : 101, 102, 106, 107	a. Check items [8-10-2 Checking the Inverter Board Error Detection Circuit] through [8-10-4 Checking the Inverter for Damage at No-Load] for problems.  b. Check that high and low pressures are balanced.  c. Check that no liquid refrigerant is present in the compressor and that there is no liquid backflow. →Go to "d." when the problem persists after compressor startup was repeated several times.  d. Check that there is a pressure difference between high and low pressures after compressor start-up. →Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.)
	2) There is a voltage imbalance between the wires after the inverter output voltage is stabilized. Greater than the larger of the following values: imbalance of 5% or 5V	Replace the INV board if there is a voltage imbalance.

Items to be checked	Phenomena	Remedy
<INV37YC>	3) An overcurrent error occurs during operation. Error code : 4250 Detail code : 121,122	[8-10-6 Checking the Converter for Damage during Compressor Operation]
	4) An overcurrent error occurs immediately after compressor startup. Error code : 4250 Detail code :101,106,107,128	a. Check for refrigerant flooding. →When the problem persists after compressor startup was repeated several times, go to "d" after a certain time after energizing the compressor or the heater. If normal operation is restored, check the belt heater for problems.  b. Check that there is a pressure difference between high and low pressures after compressor start-up. →Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.)  c. Check for interphase voltage imbalance.  d. Replace the INV board if no problems were found with the items a or c.  e. If the problem persists after replacing the inverter board, [8-10-3 Checking the Compressor for Ground Fault and Coil Resistance Problems]
	5) An overvoltage error occurs during operation. Error code : 4220 Detail code :109,110,112	[8-10-6 Checking the Converter for Damage during Compressor Operation]
	6) No problems were found with items 1) through 5).	Normal [8-10-6 Checking the Converter for Damage during Compressor Operation]

### 8-10-6 Checking the Converter for Damage during Compressor Operation

Items to be checked	Phenomena	Remedy
(1) Operate the outdoor unit.	1) BUS voltage does not boost (does not change) BUS voltage does not boost to approximately between 650 and 750 VDC, or the following errors are detected. Error code : 4220 Detail code : 123	Replace the inverter board.
(2) Check the BUS voltage after the converter circuit went into operation and the BUS voltage has boost. *The voltage generally boost at or above 80 rps, depending on the power source voltage.	2) An overcurrent error occurs after converter circuit goes into operation. Error code : 4250 Detail code : 121,122	a.If the problem persists after startup, replace the inverter board.  b.If the problem persists after replacing the inverter board, replace the DCL.
	3) An overvoltage error occurs after converter circuit goes into operation. Error code : 4220 Detail code : 109,110,112	a.If the problem persists after startup, replace the inverter board.  b.If the problem persists after replacing the inverter board, replace the DCL.
	4) No problems were found with items 1) through 3).	Normal



### 8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems

Items to be checked	Phenomena	Remedy
Remove fan motor winding. Check insulation resistance and coil resistance.	1) Fan motor insulation failure. If < 1 MΩ, Defect.	Change fan motor.
	2) Fan motor wire failure. Target coil resistance: Approx. 10 Ω. (Changes with temperature)	Change fan motor.

### 8-10-8 Checking the Fan Board Error Detection Circuit at No Load

Items to be checked	Phenomena	Remedy
(1) Stop the unit. Turn off the breaker. *Be sure to turn off the power.	1) An error other than current sensor error (5305: Detail code 135) is detected during operation.	Replace the fan board.
(2) Disconnect the output wiring to the fan motor. Disconnect connector RY-FAN1.	2) Current sensor fault Error code: 5305 Detail code: 135	Normal *When done checking, reconnect all connectors as they were. Unless they are properly reconnected, current sensor fault will not be resolved.
(3) Turn on the breaker.		
(4) Operate the unit.		

### 8-10-9 Checking the Fan Board for Damage at No Load

Items to be checked	Phenomena	Remedy
(1) Stop the unit. Turn off the breaker. *Be sure to turn off the power.	1) An error other than the current sensor error (5305 Detail code 135) is detected within 30 seconds from the startup of operation.	Replace the fan board.
(2) To allow for the disconnection of output wiring from the fan motor, disconnect connector RYFAN1.	2) Inter-wire voltage imbalance of 5 V or above	Replace the fan board.
(3) Set SW7-2 on the control board to ON.	3) No inter-wire voltage imbalance exists. A current sensor error (Detail code 135) is detected 30 seconds after the startup of operation, and the operation stops.	Normal *When done checking, reconnect all connectors as they were. Unless they are properly reconnected, current sensor fault will not be resolved.
(4) Turn on the breaker.		
(5) Operate the unit		

### 8-10-10 Checking the Fan Board for Damage with Load

Items to be checked	Phenomena	Remedy
(1) Turn off breaker.	1) The operation stops within 20 seconds of startup and a step-out error or an overcurrent error occurs. Check code: 4255 Detail code: 101, 106, 107, 137	Check for fan motor lock. →If locked, change for fan motor. If the same error is still present after changing fan motor, change Fan board. →If not locked, refer to 3) & 4).
(2) Turn on breaker.	2) Motor synchronization loss or electrical current overload during operation Check code: 4255 Detail code: 101, 106, 107, 137	a. Check for gusts or windy conditions. b. Go to [8-10-8 Checking the Fan Board Error Detection Circuit at No Load]if not windy. c. After checking [8-10-9 Checking the Fan Board for Damage at No Load], and there is no problem, change Fan board. d. If replacing Fan board doesn't resolve issue, change fan motor.
(3) Operate unit.	3) Sensor error during operation Check code: 5305 Detail code: 135, 136	a. Check for disconnection of fan inverter output wiring and for broken wiring. b. If the error is not associated with any of the items above, replace the fan board. c. Change fan motor if Fan board change doesn't resolve issue.
	4) Voltage overload error Check code: 4225 Detail code: 109	a. Check for gusts or windy conditions. b. Change Fan board if it is not windy.
(3) Operate unit.	5) Load short circuit Check code: 4255 Detail code: 105	a. Check [8-10-7 Checking the Fan Motor for Ground Fault and Coil Resistance Problems]and [8-10-8 Checking the Fan Board Error Detection Circuit at No Load]. If no problem, then check wiring for short circuit. b. If there is no problem with item a. above, change fan motor. c. If same error after motor change, change Fan board.
	6) After RPM has stabilized, voltage unbalance of 5%, or 5V.	a. If voltage is unbalanced, go to [8-10-8 Checking the Fan Board Error Detection Circuit at No Load] b. After checking [8-10-9 Checking the Fan Board for Damage at No Load], and there is no problem, change Fan board. c. If replacing Fan board doesn't resolve issue, change fan motor.

### 8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems

Items to be checked	Phenomena	Remedy
Remove pump motor wiring. Check insulation resistance and coil resistance.	1) Pump motor insulation failure. If < 1 MΩ, defect.	Replace the pump.
	2) Pump motor wire failure. Target coil resistance: Approx. 10 Ω. (Changes with temperature)	Replace the pump.

### 8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)

Items to be checked	Phenomena	Remedy
<INV/S20>  1) Disconnect the inverter output wiring from the INV board connector (CNINV).  2) Operate the outdoor unit and the HBC.	1) IPM/overcurrent cut-off error occurs. Check code: 4255, 4256 Detail code: 101, 104, 105, 106, 107, 128	Replace the INV board.
	2) Logic error occurs. Check code: 4225, 4226 Detail code: 111	Replace the INV board.
	3) Sensor-related circuit error occurs. Check code: 5305, 5306 Detail code: 117, 127	Replace the INV board.
	4) Open-circuited IPM error occurs. Check code: 5305, 5306 Detail code: 119	Normal

### 8-10-13 Checking the Pump INV Board for Damage (Without load)

Items to be checked	Phenomena	Remedy
<INV/S20>  1) Disconnect the inverter output wiring from the INV board connector (CNINV).  2) Set SW 1-1 on the INV board to ON.  3) Operate the outdoor unit and the HBC. Wait until the inverter output frequency is stabilized, and then check the inverter output voltage.	1) Inverter-related error is detected.	Set SW 1-1 on the INV board to OFF, and go to [8-10-12 Checking the Error-Detection Circuit on the Pump INV Board (Without load)].
	2) Inverter voltage is not output.	Replace the INV board.
	3) Line voltage imbalance of at least 5% or 5 V occurs.	Replace the INV board.
	4) No line voltage imbalance exists.	Normal *Check the voltage, and set SW 1-1 on the INV board to OFF.

### 8-10-14 Checking the Pump INV Board for Damage (During pump operation)

Items to be checked	Phenomena	Remedy
Operate the outdoor unit and the HBC. Wait until the inverter output frequency is stabilized, and then check the inverter output voltage.	1) Overcurrent-related error occurs immediately after the startup of the pump or during operation of the pump. Check code: 4255, 4256 Detail code: 101, 102, 103, 106, 107	a. Check that the results of the check items in [8-10-11 Checking the Pump Motor for Ground Fault and Coil Resistance Problems] through [8-10-13 Checking the Pump INV Board for Damage (Without load)] are OK. →If the error persists after several compressor restarts, go to "b." b. After the startup of the compressor, check the high and low pressures for a proper differential pressure. (Water pressure) If a proper differential pressure does not exist, replace the pump. (The pump may be locked.)
	2) After the inverter output voltage is stabilized, line voltage imbalance of at least 5% or 5 V occurs.	If line voltage imbalance exists: <INV/S20> Replace the INV board.

### 8-10-15 Checking the Installation Conditions

Items to be checked	Phenomena	Remedy
(1) Check refrigerant charge.	Overcharge of refrigerant	Return to correct refrigerant charge.
(2) Check outdoor unit branch installation.	The branch approach <500 mm.	Make branch approach >500mm
	Is the branch angle <math>\pm 15^\circ</math> to horizontal?	Make branch angle <math>< \pm 15^\circ</math>

### 8-10-16 Solutions for the Main Breaker Trip

**Note**

Measure the secondary voltage of the main power breaker before checking because the main power breaker may have been broken.

	Items to be checked	Phenomena	Remedy
[1]	Check the breaker capacity.	Use of a non-specified breaker	Replace it with a specified breaker.
[2]	Perform Meg check between the terminals on the power terminal block TB1.	Zero to several ohm, or Meg failure	Check each part and wiring. Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components] ♦IGBT module ♦Rush current protection resistor ♦Electromagnetic relay ♦DC reactor
[3]	Turn on the power again and check again.	1) Main power breaker trip 2) No remote control display	
[4]	Turn on the outdoor unit and check that it operates normally.	1) Operates normally without tripping the main breaker.	a) The wiring may have been short-circuited. Search for the wire that short-circuited, and repair it. b) If item a) above is not the cause of the problem, refer to [8-10-2 Checking the Inverter Board Error Detection Circuit] - [8-10-10 Checking the Fan Board for Damage with Load]
		2) Main power breaker trip	

## 8-10-17 Solutions for the Main Earth Leakage Breaker Trip

**Note**

Measure the secondary voltage of the main power earth leakage breaker before checking because the main power earth leakage breaker may have been broken.

	Items to be checked	Phenomena	Remedy
[1]	Check the earth leakage breaker capacity and the sensitivity current.	Use of a non-specified earth leakage breaker	Replace with a regulation earth leakage breaker.
[2]	Check the resistance at the power supply terminal block TB1 with a megger.	Failure resistance value	Check each part and wiring. Refer to the following page(s). [8-10-18 Simple Check on Inverter Circuit Components] <ul style="list-style-type: none"> <li>•IGBT module</li> <li>•Rush current protection resistor</li> <li>•Electromagnetic relay</li> <li>•DC reactor</li> </ul>
[3]	Disconnect the compressor wirings and check the resistance of the compressor with a megger.	Failure compressor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 MΩ or less.	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.
[4]	Disconnect the fan motor wirings and check the resistance of the fan motor with a megger.	Failure fan motor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 MΩ or less.	Replace the fan motor.




**Earth leakage current measurement method**

- For easy on-site measurement of the earth leakage current, enable the filter with a measurement instrument that has filter functions as below, clamp all the power supply wires, and measure.  
Recommended measurement instrument: CLAMP ON LEAK HiTESTER 3283 made by HIOKI E.E. CORPORATION
- When measuring one device alone, measure near the device's power supply terminal block.

## 8-10-18 Simple Check on Inverter Circuit Components

**Note**

Turn off the power to the unit, and leave it turned off for at least 10 minutes. Check that the voltage across pins 1 (+) and 5 (-) of the connector RYPN1 is 20 VDC or less before removing components from the control box.

Part name	Judgment method																		
IGBT module	Refer to the following page(s). [8-10-19 Troubleshooting Problems with IGBT Module]																		
Rush current protection resistor R1, R5	Measure the resistance between terminals R1 and R5: $22 \Omega \pm 10\%$																		
Electromagnetic relay 72C	<p>This electromagnetic relay is rated at DC12V and is driven by a coil. Check the resistance between terminals</p> <p>M200-M450</p>  <table border="1" data-bbox="858 683 1359 896"> <thead> <tr> <th></th> <th>Check point</th> <th>Checking criteria</th> </tr> </thead> <tbody> <tr> <td>Coil</td> <td>INV board X901, X902 Across pins 1-2</td> <td><math>160 \Omega \pm 10\%</math></td> </tr> <tr> <td>Contact</td> <td>INV board FT-P1 and FT-P2 *Faston terminal removed</td> <td>INV board CNRY Open: <math>\infty</math> INV board CNRY At a voltage input of 12 VDC: <math>0 \Omega</math></td> </tr> </tbody> </table> <p>M500</p>  <table border="1" data-bbox="858 952 1359 1164"> <thead> <tr> <th></th> <th>Check point</th> <th>Checking criteria</th> </tr> </thead> <tbody> <tr> <td>Coil</td> <td>INV board X101, X102, X103 Across pins 1-2</td> <td><math>160 \Omega \pm 10\%</math></td> </tr> <tr> <td>Contact</td> <td>INV board FT100 and FT101 *Faston terminal removed</td> <td>INV board CNRY Open: <math>\infty</math> INV board CNRY At a voltage input of 12 VDC: <math>0 \Omega</math></td> </tr> </tbody> </table>		Check point	Checking criteria	Coil	INV board X901, X902 Across pins 1-2	$160 \Omega \pm 10\%$	Contact	INV board FT-P1 and FT-P2 *Faston terminal removed	INV board CNRY Open: $\infty$ INV board CNRY At a voltage input of 12 VDC: $0 \Omega$		Check point	Checking criteria	Coil	INV board X101, X102, X103 Across pins 1-2	$160 \Omega \pm 10\%$	Contact	INV board FT100 and FT101 *Faston terminal removed	INV board CNRY Open: $\infty$ INV board CNRY At a voltage input of 12 VDC: $0 \Omega$
	Check point	Checking criteria																	
Coil	INV board X901, X902 Across pins 1-2	$160 \Omega \pm 10\%$																	
Contact	INV board FT-P1 and FT-P2 *Faston terminal removed	INV board CNRY Open: $\infty$ INV board CNRY At a voltage input of 12 VDC: $0 \Omega$																	
	Check point	Checking criteria																	
Coil	INV board X101, X102, X103 Across pins 1-2	$160 \Omega \pm 10\%$																	
Contact	INV board FT100 and FT101 *Faston terminal removed	INV board CNRY Open: $\infty$ INV board CNRY At a voltage input of 12 VDC: $0 \Omega$																	
DC reactor DCL	<p>Measure the resistance between terminals: <math>1 \Omega</math> or lower (almost <math>0 \Omega</math>)</p> <p>Measure the resistance between terminals and the chassis: <math>\infty</math></p>																		
Current sensor ACCT	<p>Disconnect the wiring connector from CNCT2, and measure the inter-terminal resistance: <math>280 \Omega \pm 30 \Omega</math></p> <p>Between pins 1 and 2 (U-phase), pins 3 and 4 (W-phase)</p>  <p>*Check ACCT wiring for correct phase and direction.</p>																		

## 8-10-19 Troubleshooting Problems with IGBT Module

---

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the INV board are used for the measurement.

1) Notes on measurement

- Check the polarity before measuring. (On the tester, black normally indicates plus.)
- Check that the resistance is not open ( $\infty \Omega$ ) or not shorted (to  $0 \Omega$ ).
- The values are for reference, and the margin of errors is allowed.
- The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- Disconnect all the wiring connected the INV board, and make the measurement.

2) Tester restriction

- Use the tester whose internal electrical power source is 1.5V or greater
- Use the dry-battery-powered tester.

**Note**

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)

- Use a low-range tester if possible. A more accurate resistance can be measured.


<INV35Y>

Reference resistance value

		Black (+)				
		SC-PL	CN-N	SC-L1	SC-L2	SC-L3
Red (-)	SC-PL	-	-	5-200 Ω	5-200 Ω	5-200 Ω
	CN-N	-	-	∞	∞	∞
	SC-L1	∞	5-200 Ω	-	-	-
	SC-L2	∞	5-200 Ω	-	-	-
	SC-L3	∞	5-200 Ω	-	-	-

		Black (+)				
		SC-P1L	CN-N	SC-U	SC-V	SC-W
Red (-)	SC-P1L	-	-	5-200 Ω	5-200 Ω	5-200 Ω
	CN-N	-	-	∞	∞	∞
	SC-U	∞	5-200 Ω	-	-	-
	SC-V	∞	5-200 Ω	-	-	-
	SC-W	∞	5-200 Ω	-	-	-

INV board outline drawing





<INV42Y>


Reference resistance value

		Black (+)				
		SC-P	CN-N	SC-L1	SC-L2	SC-L3L
Red (-)	SC-P	-	-	5-200 Ω	5-200 Ω	5-200 Ω
	CN-N	-	-	∞	∞	∞
	SC-L1	∞	5-200 Ω	-	-	-
	SC-L2	∞	5-200 Ω	-	-	-
	SC-L3	∞	5-200 Ω	-	-	-

		Black (+)				
		SC-P1	CN-N	SC-U	SC-V	SC-W
Red (-)	SC-P1	-	-	5-200 Ω	5-200 Ω	5-200 Ω
	CN-N	-	-	∞	∞	∞
	SC-U	∞	5-200 Ω	-	-	-
	SC-V	∞	5-200 Ω	-	-	-
	SC-W	∞	5-200 Ω	-	-	-

INV board outline drawing




<INV37YC>

Reference resistance value

		Black (+)						
		SC-L1	SC-L2	SC-L3	SC-B	SC-L	FT100	CN-N
Red (-)	SC-L1	-	-	-	-	$\infty$	-	5-200 $\Omega$
	SC-L2	-	-	-	-	$\infty$	-	5-200 $\Omega$
	SC-L3	-	-	-	-	$\infty$	-	5-200 $\Omega$
	SC-B	-	-	-	-	-	$\infty$	-
	SC-L	5-200 $\Omega$	5-200 $\Omega$	5-200 $\Omega$	-	-	-	-
	FT100	-	-	-	5-200 $\Omega$	-	-	-
	CN-N	$\infty$	$\infty$	$\infty$	-	-	-	-

		Black (+)				
		FT100	CN-N	SC-U	SC-V	SC-W
Red (-)	FT100	-	-	5-200 $\Omega$	5-200 $\Omega$	5-200 $\Omega$
	CN-N	-	-	$\infty$	$\infty$	$\infty$
	SC-U	$\infty$	5-200 $\Omega$	-	-	-
	SC-V	$\infty$	5-200 $\Omega$	-	-	-
	SC-W	$\infty$	5-200 $\Omega$	-	-	-

INV board outline drawing




## 8-10-20 Checking the Fan Inverter Heatsink for Clogging


Check the fan inverter heatsink for clogging by removing part of the duct and checking inside the duct.

To remove the duct, follow the procedures 1) through 3) below.  
Reassemble the components in the reverse order as they were removed.


1) Remove the front service panel.




2) Remove the main control box (applicable to the (E)M200-300 models only).  
On the (E)M350-550 models, it is not necessary to remove the control box.



3) Remove the upper section of the duct by unscrewing the screws on the control box (on the inverter box on the (E)M200-300 models) shown in the figure below.  
Check inside the duct for clogging, and remove any foreign objects found.



(E)M200 - 300




(E)M350 - 550

# 8-11 Control Circuit

## 8-11-1 Control Power Supply Function Block


1) PURY-(E)M200 - (E)M300YNW-A1



\* MA remote controllers and ME remote controllers cannot be used together.  
 (Both the ME and MA remote controller can be connected to a system with a system controller.)


2) PURY-(E)M350 - (E)M450YNW-A1

8 Troubleshooting Based on Observed Symptoms




\* MA remote controllers and M-NET remote controllers cannot be used together.  
 (Both the M-NET and MA remote controller can be connected to a system with a system controller.)

3) PURY-(E)M500YNW-A1




\* MA remote controllers and M-NET remote controllers cannot be used together.  
 (Both the M-NET and MA remote controller can be connected to a system with a system controller.)

4) CMB-WM350, 500F-AA




5) CMB-WM1016V-BB



6) CMB-WM108V-BB


Power supply system (220-240 VAC, 260-338 VDC)  
 Control system (5-30 VDC)







## 8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit


### 1) PURY-(E)M200 - (E)M450YNW-A1





2) PURY-(E)M500YNW-A1






## 8-12 Measures for Refrigerant Leakage

### 1. Leak spot: In the case of extension pipes and HBC (Cooling season)

- 1) Mount a pressure gauge on the service check joint (CJ2) on the low-pressure side.
- 2) Connect the service port on the high-pressure gas service valve (BV2) to that on the low-pressure gas service valve (BV1) using a charge hose.
- 3) Stop all the indoor units. While the compressor is being stopped, turn the high-pressure gas service valve (BV2) on the outdoor unit 45 degrees in the close direction as shown below, and fully open the low-pressure gas service valve (BV1). (Do not close BV2 completely. Closing BV2 will cause the unit to stop in step 4.)  
\*Pump down operation can be performed with BV1 and BV2 open, except that it will take longer to collect refrigerant.



- 4) Stop all the indoor units; turn on SW4 (912) on the outdoor unit control board while the compressor is being stopped. (Pump down mode will start, and all the indoor units will run in cooling test run mode.)
- 5) In the pump down mode (SW4 (912)), all the indoor units and compressors will automatically stop when the low pressure (63LS) reaches 0.383MPa [55psi] or less or 15 minutes have passed after the pump mode started. Stop all the indoor units and compressors when the pressure indicated by the pressure gauge, which is on the check joint (CJ2) for low-pressure service, reaches 0.383MPa [55psi] or 20 minutes pass after the pump down operation is started.
- 6) Close the service ball valve (BV1) on the low-pressure pipe and the service ball valve (BV2) on the high-pressure pipe on the outdoor unit.
- 7) Collect the refrigerant that remains in the extended pipe for the indoor unit. Do not discharge refrigerant into the atmosphere when it is collected.
- 8) Repair the leak.
- 9) After repairing the leak, vacuum the extension pipe and the indoor unit\*<sup>1</sup>.
- 10) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit, and turn off SW4 (912).

### 2. Leak spot: In the case of outdoor unit (Cooling season)

#### (1) Run all the indoor units in the cooling test run mode.

- 1) To run the indoor unit in test run mode, turn SW4 (769) on the outdoor unit control board to ON.
- 2) Change the setting of the remote controller for all the indoor units to the cooling mode.
- 3) Check that all the indoor units are performing a cooling operation.

#### (2) Stop all the indoor units, and stop the compressor.

- 1) To stop all the indoor units and the compressors, turn SW4 (769) on the outdoor control board from ON to OFF.
- 2) Check that all the indoor units are being stopped.

#### (3) Close the ball valves (BV1 and BV2).

#### (4) Collect the refrigerant that remains inside the outdoor unit. Do not discharge refrigerant into air into the atmosphere when it is collected.

#### (5) Repair the leak.

#### (6) After repairing the leak, replace the dryer with the new one, and perform evacuation \*<sup>1</sup> inside the outdoor unit.

#### (7) To adjust refrigerant amount, open the ball valves (BV1 and BV2) inside the outdoor unit.

\*1. For details, refer to the following page(s). [1-3-3 Vacuum Drying]

**3. Leak spot: In the case of extension pipe and HBC (Heating season)**

**(1) Run all the indoor units in heating test run mode.**

- 1) To run the indoor unit in test run mode, set SW4 (769) on the outdoor unit control board to ON.
- 2) Change the setting of the remote controller for all the indoor units to the heating mode.
- 3) Check that all the indoor units are performing a heating operation.

**(2) Stop all the indoor units, and stop the compressor.**

- 1) To stop all the indoor units and the compressors, turn SW4 (769) on the outdoor control board from ON to OFF.
- 2) Check that all the indoor units are stopped.

**(3) Close the ball valves (BV1 and BV2).**

**(4) Extract any residual refrigerant in the extension pipes and HBC. Do not discharge refrigerant into air when it is collected.**

**(5) Repair the leak.**

**(6) After repairing the leak, evacuate the air from the extension pipes and HBC<sup>\*1</sup>. Then, open the ball valves (BV1 and BV2), and operate the unit in the refrigerant charge adjust mode.**

**4. Leak spot: In the case of outdoor unit (Heating season)**

- 1) Extract the refrigerant from the entire system (outdoor units, extension pipes, and HBC). Do not discharge refrigerant into the atmosphere when it is collected.
- 2) Repair the leak.
- 3) Repair the leak, and evacuate the air from the entire system<sup>\*1</sup>. Then, calculate the proper amount of refrigerant to be added (outdoor unit + extension pipe + HBC), and charge the system with that amount. Refer to the following page(s). [6-3-3 Maximum refrigerant charge]

\*1. For details, refer to the following page(s). [1-3-3 Vacuum Drying]

# 8-13 Parts Replacement Instructions (Outdoor Unit)

## 8-13-1 Ensuring Maintenance Space (Preparation for the Maintenance of Refrigerant Circuit Parts)

### 1. S-module

Take the following procedures to ensure sufficient maintenance space and good visibility.

- (1) Remove the front panel from the unit by unscrewing the eight screws. (See Figure 1.) \*Figure 1 shows the unit without the front panel.
- (2) Remove the drain pan cover by unscrewing the screw and cutting the cable tie. (See Figures 2 and 3.)  
When re-placing the drain pan cover after the completion of maintenance work, make sure that the silicon tube is properly placed on the defrost pipe, and then fix the drain pan cover in place with a cable tie. (Figures 2 and 3 show the cable ties to be cut.)
- (3) Remove the drain pan by unscrewing the two screws. (See Figure 2.)  
Be sure to remove the two rod holders holding the check joints to the drain pan. (See Figure 3.)




Figure 1 Cut the cable tie. Figure 2 Cut the cable tie. Figure 3

- (4) Remove the top attachment connecting the main control box and the inverter control box by unscrewing the two screws. (See Figure 4.)
- (5) Remove the bottom attachment connecting the main control box and the inverter control box by unscrewing the two screws. (See Figure 4.)
- (6) Remove the two screws from the sheet metal secured on the pipe on the left of the main control box. (See Figure 4.)
- (7) Remove the cover from the main control box by unscrewing the three screws. (See Figure 5.)
- (8) Cut the two cable ties holding the weak electrical wiring inside the main control box in place, and loosen the four cable straps holding the weak and strong electrical wirings. (See Figure 6.)
- (9) Cut the two cable ties holding the rubber bush at the bottom of the main control box. (See Figure 6.)
- (10) Cut the three cable ties and loosen the two cable straps holding the weak electrical wiring outside the main control box. (See Figure 7.)




Figure 4




Figure 5




Figure 6







Figure 7


- (11) Loosen the three cable straps holding the motor wiring outside and at the bottom of the main control box, and remove the wire from the two wire saddles. (See Figure 8.)
- (12) Loosen the two cable straps holding the strong electrical wiring outside the main control box. (See Figure 9.)
- (13) Cut the cable tie and loosen the two welding clamps holding the strong electrical wiring at the bottom of the main control box. (See Figure 10.)
- (14) Unscrew the two screws holding the main control box. (See Figure 11.)



- (15) Make sure that no undue force is applied to the wires from which cable straps were removed in steps (8) through (13). Position the bottom attachment that was removed in step (5) above on the fin guard as shown in Figure 13, and then hook the main control box on the attachment as shown in Figure 12.



- (16) Place the excess weak and strong electrical wirings in the space at the base legs as shown in Figure 14 to keep them from being caught during maintenance work.



This step completes the procedure for ensuring maintenance space.



## 2. L-module

- (1) Remove the front panel from the unit by unscrewing the 14 screws. (See Figure 1.) \*Figure 1 shows the unit without the front panel.
- (2) Remove the fin guard by unscrewing the 12 screws. (See Figure 1.)
- (3) Remove the cable straps holding the weak and strong electrical wirings. (See Figure 2.)
- (4) Remove the center pillar by unscrewing the five screws. (See Figure 1.)
- (5) Remove the drain pan cover by unscrewing the screw and cutting the cable tie. (See Figures 2 and 3.)  
When re-placing the drain pan cover, make sure that the silicon tube is properly placed on the defrost pipe, and then fix the drain pan cover in place with a cable tie.
- (6) Remove the drain pan by unscrewing the two screws. (See Figure 2.)  
Be sure to remove the two rod holders holding the check joints to the drain pan. (Figures 2 and 3 show the cable ties to be cut.)
- (7) Remove the two cable straps holding the weak electrical wiring and the two cable straps holding the strong electrical wiring from the control box. (See Figure 4.)
- (8) Place the excess weak and strong electrical wirings in the space at the base legs as shown in Figure 5 to keep them from being caught during maintenance work.




Figure 1

Figure 2




Figure 3

Cable strap for holding weak electrical wiring (front)




Figure 4




Figure 5

This step completes the procedure for ensuring maintenance space.

### 3. XL-module

- (1) Remove the front panel from the unit by unscrewing the 14 screws. (See Figure 1.)
- (2) Remove the external temperature sensor wiring from the left drain pan by cutting the two cable ties. Unhook the pipe cover from the left drain pan. (See Figure 3.)
- (3) Remove the left drain pan by unscrewing the two screws. (See Figure 4.)
- (4) Remove the right drain pan by unscrewing the two screws. (See Figure 5.)
- (5) Remove the three cable straps from the center pillar. (See Figure 6.)
- (6) Remove the right and left fin guards and the center pillar by unscrewing the 18 screws. (See Figure 7.)




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6




Figure 7


This step completes the procedure for ensuring maintenance space.

## 8-13-2 Notes on Wiring Installation


- If wiring was disconnected during maintenance, reconnect the wiring as follows.
- Isolate the strong and the weak electrical wiring to avoid noise interference.

### (1) S-module

#### FRONT VIEW




#### LEFT VIEW




**BOTTOM VIEW**

CONTROL BOX  
(MAIN)




**BOTTOM VIEW**

CONTROL BOX  
(INVERTER)




**(2) L-module**


**FRONT VIEW**




**LEFT VIEW**




**LEFT VIEW (TOP)**



**LEFT VIEW (BOTTOM)**



**BOTTOM VIEW**



**(3) XL-module**


**FRONT VIEW**

CONTROL BOX

Fix the wires in place with cable straps.  
<HIGH VOLTAGE WIRE>

Fix the wires in place with cable straps.  
<HIGH VOLTAGE WIRE>  
<FAN MOTOR WIRE (RIGHT) (HIGH VOLTAGE)>

Fix the wires in place with cable straps.  
<HIGH VOLTAGE WIRE>




Fix the wires in place with cable straps.  
<SENSOR WIRE>  
<LEV WIRE>

Bundle excess wiring inside the control box, and fix it in place with a cable tie.  
<SENSOR WIRE>  
<LEV WIRE>

Clamp the wires in place.  
<SENSOR WIRE>  
<LEV WIRE>

Fix the wires in place to leave no space between the rubber bushes and the wires.  
Fix the wires in place to leave no space between the notches on the rubber bushes and the wires.

**LEFT VIEW**



PILLAR C

CONTROL BOX


Fix the wires in place with cable straps.  
<HIGH VOLTAGE WIRE (21S4a, 21S4c, SV1a, SV2)>

Fix the wires in place with cable straps.  
<SENSOR WIRE (TH4, 5, 7, 15)>

Fix the wires in place with cable straps.  
<COMP WIRE (HIGH VOLTAGE)>

**LEFT VIEW**

CONTROL BOX



Fix the wires in place with cable straps.  
<HIGH VOLTAGE (21S4a, 21S4b, 21S4c, SV1a, SV2, 63H)>

Fix the wires in place with cable straps.  
<63HS WIRE>


Fix the wires in place with cable straps.  
<HIGH VOLTAGE WIRE>

Fix the wires in place with cable straps.  
<FAN MOTOR WIRE (HIGH VOLTAGE)>

Fix the wires in place with cable straps.  
<SENSOR WIRE>  
<LEV WIRE>

**BOTTOM VIEW**

CONTROL BOX



Clamp the wires in place.  
<COMP WIRE (HIGH VOLTAGE)>

Thread the wire through the rubber bush.  
<COMP WIRE (HIGH VOLTAGE)>

## 8-13-3 Four-way Valve Replacement Procedure

### 1. S, L-module (Applicable to four-way valves 21S4a and 21S4b)

Explained below is the procedure for replacing four-way valve (21S4a) (on the left when seen from the front of the unit) and four-way valve (21S4b) (on the right when seen from the front of the unit). Secure sufficient work space before starting maintenance work. (See 8-13-1 Ensuring Maintenance Space (Preparation for the Maintenance of Refrigerant Circuit Parts).)

- (1) Remove the top compressor cover by unscrewing the three screws. (See Figure 1.)  
Remove the compressor cover by unhooking the hooks on the back.
- (2) Remove the front compressor cover by unscrewing the four screws. (See Figure 2.)
- (3) Cut the two cable ties holding TH4 and TH15, and remove the wiring from the rubber bush on the left compressor cover. (See Figure 3.)
- (4) Remove the left compressor cover by unscrewing the two screws. (See Figure 4.)





Figure 1



Compressor cover (front)  
Figure 2




Figure 3




Figure 4

- (5) Remove the coils, coil covers, pipe covers, and adjacent wiring of the four-way valve and LEV. (See Figures 5-1 through 5-3.)




Figure 5-1

Figure 5-2




Figure 5-3

Remove the five pipe covers adjacent to the four-way valves.  
\*Save the pipe covers for later use.

- (6) Cut the band on the pipe cover and the rubber spacer on the heat-exchanger side to remove them. (See Figure 6.)




Figure 6

Remove the pipe cover adjacent to the brazed section of the heat exchanger.  
\*Save the pipe cover for later use.

Rubber spacer band

\*Notes on replacing refrigerant circuit components (four-way valve, solenoid valve, and LEV)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama  
 Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

Replacement procedure for the four-way valve (21S4a)

(7A) Cut the pipe below four-way valve (21S4a) and in the middle with a pipe cutter as shown in the figure.

Cut the pipe below four-way valve (21S4a) and in the back with a pipe cutter as shown in the figure.

After cutting the pipe in three sections as indicated in the figure, remove the braze at the three areas shown in Figure 7.




Figure 7

(8A) Remove the pipe below four-way valve (21S4a) and on the front by removing the braze at the three areas shown in Figure 8.




Figure 8



(9A) Remove four-way valve (21S4a) by removing the braze from the area above four-way valve (21S4a) as shown in Figure 9.




Figure 9

(10A) Mount a new four-way valve (21S4a). Figure 10 shows how to position a new four-way valve.




Figure 10

(11A) To make it easier to connect four-way valve (21S4a), cut the pipe end below the raised hole (cut off the section covered with brazing filler) on the pipe with a pipe cutter. Cut the pipe with an expanded end that is included with four-way valve (21S4a) to the same length as the pipe that was removed from the on-site pipe. (See Figure 11.)




Figure 11

(12A) Mount four-way valve (21S4a) to the pipe below four-way valve (21S4a) and on the back. A total of four areas require brazing, including the area indicated in (11A) and the areas indicated in Figure 12.




Figure 12

(13A) Install the pipe below four-way valve (21S4a) and in the middle by brazing at the three areas shown in Figure 13.




Figure 13

(14A) Install the pipe below four-way valve (21S4a) and on the front by brazing at the three areas shown in Figure 14.




Figure 14

This step completes the replacement procedure for four-way valve (21S4a). Re-place the components that were removed as they were.

Replacement procedure for the four-way valve (21S4b)

(15B) Cut the pipe below four-way valve (21S4b) and in the middle with a pipe cutter as shown in the figure.

After cutting the pipe where indicated in the figure, remove the braze at the two areas shown in Figure 15.




Figure 15

(16B) Remove the pipe below four-way valve (21S4b) and on the front by removing the braze at the two areas shown in Figure 16.




Figure 16

(17B) Remove four-way valve (21S4b) by removing the braze from the area above four-way valve (21S4b) as shown in Figure 17.




Figure 17

(18B) To make it easier to connect four-way valve (21S4b), cut the pipe between the section above four-way valve (21S4b) and the pipe bend with a pipe cutter. Cut the pipe with an expanded end that is included with four-way valve (21S4b) to the same length as the pipe that was removed from the on-site pipe. (See Figure 18.)




Figure 18

(19B) Mount four-way valve (21S4b) to the pipe below four-way valve (21S4b) and in the middle. A total of five areas require brazing, including the area indicated in (18B) and the areas indicated in Figure 19. Mount four-way valve (21S4b) horizontal to four-way valve (21S4a) as shown in (10A).




Figure 19

(20B) Install the pipe below four-way valve (21S4b) and on the front by brazing at the two areas shown in Figure 20.




Figure 20

This step completes the replacement procedure for four-way valve (21S4b). Re-place the components that were removed as they were.

## 2. XL-module (four-way valve (21S4a, 21S4b, and 21S4c))

Explained below is the procedure for replacing four-way valve (21S4a) (on the left when seen from the front of the unit), four-way valve (21S4b) (in the middle when seen from the front of the unit), and four-way valve (21S4c) (on the right when seen from the front of the unit). (See Figure 1.)






Figure 1



Four-way valve coil A      Four-way valve coil B      Four-way valve coil C

(1) Remove the pipe covers, wirings, and sheet metals. (See Figure 2.)






Figure 2

Two pipe covers  
\*Save the pipe covers for later use.



Wiring

Sheet metal

(2) Remove the coils from four-way valves (21S4a, 21A4b, and 21S4c), solenoid valve (SV2), coil cover, and wiring. (See Figure 3.)






Figure 3



Solenoid valve coils (SV2) and coil cover

(3) Remove the pipe cover adjacent to four-way valves. (See Figure 4.)





Figure 4




Remove the seven pipe covers adjacent to the four-way valves.  
\*Save the pipe covers for later use.


\*Notes on replacing refrigerant circuit components (four-way valve, solenoid valve, and LEV)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.  
 Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama  
 Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")


(4) Remove the braze from the pipe on the left side of four-way valve (21S4a) and between four-way valves (21S4b and 21S4c). (See Figure 5.)



Replacement procedure for the four-way valve (21S4a)  
 (5A) Install a flame-protection plate. (See Figure 6.)



(6A) Remove the braze from the area above four-way valve (21S4a) as shown in Figure 7.



(7A) Remove the braze from the three areas below four-way valve (21S4a) as shown in Figure 8.




Figure 8

(8A) Mount a new four-way valve (21S4a).

Replacement procedure for the four-way valve (21S4b)

(9B) Follow the steps (6A) through (7A).

(10B) Mount a new four-way valve (21S4b).

Replacement procedure for the four-way valve (21S4c)

(11C) Remove the braze from the area above four-way valve (21S4c) as shown in Figure 9.




Figure 9

(12C) Remove the braze from the two areas below four-way valve (21S4c) as shown in Figure 10.




Figure 10

A cap for sealing the refrigerant pipe is included with the replacement kit that contains four-way valve (21S4c). Use the parts included with the four-way valve.

(13C) Mount a new four-way valve (21S4c). Figure 11 shows how to position a new four-way valve.




Figure 11

When installing four-way valve (21S4c), first braze the pipe outside the unit and then install it to the unit.

When seen from above, four-way valve (21S4c) is tilted by 20°. Four-way valve (21S4c) is tilted to the opposite direction compared to the other four-way valves.

## 8-13-4 Replacement Procedure for the Check Valve Block Assembly

### 1. S, L-module

Explained below is the procedure for replacing the check valve block assembly.

- (1) Remove the top compressor cover by unscrewing the three screws. (See Figure 1.)  
Remove the compressor cover by unhooking the hooks on the back.
- (2) Remove the front compressor covers by unscrewing the four screws. (See Figure 2.)
- (3) Cut the two tie bands holding TH4 and TH15, and remove the wiring from the rubber bush on the left compressor cover. (See Figure 3.)
- (4) Remove the left compressor cover by unscrewing the two screws. (See Figure 4.)
- (5) Remove the saddle and the rubber spacers on the compressor by unscrewing the screw. (See Figure 5.)




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5

- (6) Remove the coils, coil covers, pipe covers, and adjacent wirings of the four-way valves, solenoid valves, and LEVs. (See Figures 6-1 through 6-3.)




Figure 6-1




Figure 6-2 (Four-way valve, solenoid valve, LEV coil, coil cover)




Figure 6-3 (adjacent pipe covers)



(7) Cut the bands on the TH3 wiring, and remove the pipe covers and rubber spacer on the heat-exchanger side. (See Figure 7.)




Figure 7

(8) Remove the pipe covers and the thermal insulation on the compressor. (See Figure 8.)




Figure 8

\*Notes on replacing refrigerant circuit parts (check valve block assemblies, four-way valves, solenoid valves, and LEVs)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama  
 Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

Check valve block replacement procedure

(9) Remove the braze at the three areas circled in the figure to remove LEV9 assembly. (See Figure 9.)




Figure 9

LEV9 assembly

(10) Remove the braze at the two areas circled in Figure 10 to remove SV2 assembly. (See Figure 10.)




Figure 10

SV2 assembly

(11) Cut the pipe with a pipe cutter at the area shown in Figure 11.  
 Remove the braze at the area circled in Figure 11 to remove LEV4 assembly. (See Figure 11.)




Figure 11

LEV4 assembly

(12) Remove the braze at the three areas circled in Figure 12 to remove LEV2a and 2b assembly. (See Figure 12.)




Figure 12

(13) There are two types (A and B) of gas-liquid separators that connect to the check valve block as shown below. The removal procedure depends on the type of gas-liquid separator. Follow the appropriate procedure that corresponds to the gas-liquid separator type. Removal procedures for gas-liquid separators A and B are explained separately below.

Gas-liquid separator A




Figure 13-1

Gas-liquid separator B




Figure 13-2

- (14) Cut the pipe below four-way valves (21S4a and 21S4b) with a pipe cutter as shown in the figure. Remove the braze at the areas circled in the figure to remove 21S4a and 21S4b assemblies.






Figure 14


Gas-liquid separator A (2 areas to be cut. 5 areas to remove braze from. See Figure 14-1.)



Gas-liquid separator B (2 areas to be cut. 5 areas to remove braze from. See Figure 14-2.)




Four-way valve (21S4a) Four-way valve (21S4b)




Four-way valve (21S4a and 21S4b) assemblies

Figure 14-1



The replacement parts for this part is included with the replacement kit that contains check valve block assembly. Use the pipe included with the check valve. (Applicable to both gas-liquid separators A and B)

Four-way valve (21S4a) Four-way valve (21S4b)



Four-way valve (21S4a and 21S4b) assemblies

Figure 14-2

(15) Remove the braze from the pipe where circled in the figure, and unscrew the two screws on the check valve block fixing plate to remove the check valve block assembly.

Gas-liquid separator A (2 areas to remove braze from. 2 screws to be removed. See Figure 15-1.)




Figure 15-1

Remove the braze here.

Remove the braze here.

Check valve block assembly

Gas-liquid separator B (1 area to be cut. 2 areas to remove braze from. 3 screws to be removed. See Figure 15-2.)




Figure 15-2

Check valve block assembly

(16) Remove the braze from the pipe that connects to the gas-liquid separator (where circled in the figure), remove the two screws on the check valve block fixing plate, and replace the check valve block assembly with a new one.

Gas-liquid separator A (1 area to remove braze from. 2 screws to be removed. 1 area to be brazed. See Figure 16-1.)




Figure 16-1

Check valve block assembly (Replacement parts)

Gas-liquid separator B (3 screws. See Figure 16-2.)




Figure 16-2

Check valve block assembly (Replacement parts)

(17) Re-place the four-way valves (21S4a and 21S4b) that were removed in step (14). Figure 17-1 shows how to position a new four-way valves.  
 Replace the center pipe below four-way valves (21S4a and 21S4b). (3 areas to remove braze from. 2 areas to be brazed. See Figure 17-2.)





Figure 17-1



Four-way valve 21S4a and 21S4b assemblies  
 Figure 17-2

(18) To make it easier to connect four-way valves (21S4a and 21S4b), cut the pipes above four-way valves (21S4a and 21S4b) with a pipe cutter. Cut the pipe with an expanded end that is included with the check valve block assembly to the same length as the pipe that was removed from the on-site pipe. (See Figure 18.)





Figure 18

Four-way valve (21S4a)	Four-way valve (21S4b)
<S module>	<S module>
Pipe diameter: φ19.05	Pipe diameter: φ12.7
ID of the pipe with an extended end: φ19.05	ID of the pipe with an extended end: φ12.7
<L module>	<L module>
Pipe diameter: φ19.05	Pipe diameter: φ19.05
ID of the pipe with an extended end: φ22.2	ID of the pipe with an extended end: φ19.05



(19) Re-place the check valve block assembly that was replaced in step (16).

Gas-liquid separator A (2 areas to be brazed. 2 screws. See Figure 19-1.)




Figure 19-1

Gas-liquid separator B (3 areas to be brazed. 3 screws. See Figure 19-2.)




Figure 19-2

(20) Re-place the check valve assemblies (21S4a and 21S4b) whose pipes were replaced in step (17).





Figure 20


Gas-liquid separator A (8 areas to be brazed. See Figure 20-1.)

Gas-liquid separator B (8 areas to be brazed. See Figure 20-2.)



Replace the pipe that was cut in step (14) with the pipe included with the check valve block assembly.


Figure 20-1



Replace the pipe that was cut in step (14) with the pipe included with the check valve block assembly.

Figure 20-2

(21) Re-place the LEV4 assembly that was removed in step (11) as it was. (3 areas to be brazed. See Figure 21.)



(22) Re-place the components that were removed as they were. This step completes the check valve block assembly replacement procedure.



## 2. XL-module

Explained below is the procedure for replacing the check valves. (See Figure 1.)




Figure 1

(1) Remove three pipe covers. (See Figure 2.)




Figure 2

(2) Cut the pipe near the check valve in two areas where circled. (See Figure 3.)




Figure 3

\*Notes on replacing refrigerant circuit parts (check valve block assemblies, four-way valves, solenoid valves, and LEVs)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama

Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

(3) Remove the braze from the pipe where circled in the figure. (See Figure 4.)




Figure 4

(4) Remove the braze from the pipe where circled in the figure. (See Figure 5.)




Figure 5

(5) Remove the check valve assembly (CV2a/b) from the area indicated in Figure 6.




Figure 6

(6) Braze the replacement parts at four areas. (See Figure 7.)




Figure 7

This step completes the check valve replacement procedure. Re-place the components that were removed as they were.

## 8-13-5 Compressor Replacement Procedure

Explained below are the procedures for replacing the compressor. Secure sufficient work space before starting replacement work. (See 8-13-1 Ensuring maintenance space (Preparation for the Maintenance of Refrigerant Circuit Parts).)

- (1) Remove the top compressor cover by unscrewing the three screws. (See Figure 1.)  
Remove the compressor cover by unhooking the hooks on the back.
- (2) Remove the front compressor cover by unscrewing the four screws. (See Figure 2.)
- (3) Cut the two cable ties holding TH4 and TH15, and remove the wiring from the rubber bush on the left compressor cover. (See Figure 3.)
- (4) Remove the right and left compressor covers by unscrewing the four screws. (See Figure 4.)
- (5) Remove the saddle and the rubber spacers on the compressor by unscrewing the screw. (See Figure 5.)
- (6) Remove the cover of the compressor terminal block box, mounting support metal, and the mounting plate by unscrewing the two screws. (See Figure 6.)




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6

- (7) Remove thermal insulation 1 and thermal insulation 2. (See Figure 7.)
- (8) Remove the inverter cooling duct by unscrewing the two screws. (See Figure 8. Applicable to the S-module only)




Figure 7




Figure 8

- (9) Remove the pipe cover and the damper, and cut the suction pipe where indicated in Figure 9.
- (10) Remove the pipe covers, and then remove the braze. (See Figure 10.)  
\* Do not force the injection pipe to deform.
- (11) Remove the compressor discharge pipe by cutting the pipe where indicated in Figure 11 or by removing the braze.




Figure 9




Figure 10




Figure 11

- (12) Remove the four bolts holding the compressor down. (See Figure 12.)  
The two bolts in the front are also holding down the metal sheets.
- (13) Tilting the compressor will cause the refrigerant oil to leak. Seal the pipe where it was cut or removed at the brazed section.
- (14) After replacing the compressor, braze the pipes that were removed as they were.  
In case of brazing the suction pipe, protect the surrounding components such as the control box, ACC, compressor cover, and damper with a fire protection panel (e.g., recommended felt soaked in water), attach the supplied pipe, and perform brazing. (See Figure 13.)  
\*Perform brazing, referring to "Notes on replacing refrigerant circuit parts (check valve block assemblies, four-way valves, solenoid valves, and LEVs)" in 8-13-4.
- (15) The recommended tightening torque for the compressor fixing bolts is 3.0 N·m. Fasten the bolts using a torque wrench or other tool that can apply the specified torque.
- (16) Re-place the compressor covers in the reverse order as they were removed.  
\*Hold the TH15 wiring in place with the bands to keep the wiring from coming in contact with insulation 2. (See Figures 3 and 7.)




Figure 12





Figure 13

**Note**

- After replacing the compressor, set SW4 (832) and (958) to "ON" before conducting a test run.
- After the test run has completed, set SW4 (832) and (958) to "OFF."


## 8-13-6 Removal Instructions for the Control Box

### 1. S module (INV box)




[Figure 1]

[Removing the left outside panel]  
Unscrew the four screws indicated with arrows in Figure 1 to remove the left outside panel.




[Figure 2]

[Removing the left inside panel]  
Unscrew the screw indicated with an arrow in Figure 2-a (located to the left of the terminal board) to remove the left panel.




[Figure 2-a]

[Removing the ground wire]  
Remove the two ground wires (screwed on) indicated by Arrow (A) in Figure 3-a, and unsaddle them from the saddle indicated by Arrow (B).




[Figure 3-a]


[Removing the wiring]  
Remove the following connectors and the screw terminals.  
(See Figures 3-b and 3-c.)  
CNINV on the FAN INV board  
CN-P, CN-N, FT-P1, FT-P2, SC-L1, SC-L2, and SC-L3 on the INV35 board  
Terminals on R1 and R5



[Figure 3-b]




[Figure 3-c]




[Figure 4-a]

[Removing the terminal board and top panel (Noise Filter board)]  
Unscrew the four screws indicated with arrows in Figure 4-a. Pull the right panel and the top panel forward. Lift the back end of the top panel and pull the terminal board and the top panel (Noise Filter board) together to remove them. (See Figure 4-b.)



[Figure 4-b]




[Figure 5]


[Removing the duct]  
Unscrew the screw indicated with arrows in Figure 5-a, and pull up the duct to remove it. (Figure 5-b shows the unit after the duct was removed.)



[Figure 5-a]




[Figure 5-b]




[Figure 6]

[Removing refrigerant cooling pipes]  
 Remove the braze from the two areas indicated by the arrows in Figure 6-a.  
 Before removing the pipes, collect the refrigerant.  
 Protect the surrounding components from the brazing torch flame as necessary.



[Figure 6-a]

[Removing the remaining relevant components]  
 Unscrew the three screws indicated with arrows A in Figure 7.  
 Pull the unscrewed part forward, and unhook the part indicated with Arrow B to remove the part from the base of the unit.



[Figure 7]

- \*Notes on replacing the control box (when replacing the refrigerant cooling pipes)
- Be sure to perform non-oxidized brazing.
  - Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
  - After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
  - Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
  - Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.  
 Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama  
 Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")


## 2. L/XL module

### [Removing the duct]

Unscrew the two screws indicated with arrows in Figure 1-a, and pull up the duct to remove it.

(Figure 1-b shows the unit after the duct was removed.)

\*The same procedures apply to both the L and the XL modules.



[Figure 1]

[Figure 1-a]


[Figure 1-b]

### [Removing the refrigerant cooling pipes]

Remove the braze at the two areas indicated with arrows in Figure 2-a(L module), Figure 2-b (XL module).

Before removing the pipes, collect the refrigerant.

Refer to "Notes on replacing refrigerant circuit components."



[Figure 2-a]


[Figure 2-b]

### [Removing the remaining relevant components]


Unscrew the four screws indicated with arrows (A) in Figure 3.

The arrow indicated with dotted lines is located where indicated in Figure 3-a.

Pull the unscrewed part forward, and unhook the part indicated with Arrow (B) to remove the part from the base of the unit.




[Figure 3]



[Figure 3-a]

To remove the rest of the components from the pillar, unscrew the two screws indicated with Arrow (C) in Figure 4.

\*The same procedures apply to both the L and the XL modules.



[Figure 4]

### \*Notes on replacing the control box (when replacing the refrigerant cooling pipes)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama

Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

## 8-13-7 Maintenance Procedure for the Drain Pan

### 1. S-module

[Drain pan removal procedure]

- (1) Remove the front panel from the unit by unscrewing the eight screws. (See Figure 1.)
  - (2) Cut the cable tie, unscrew the screw, and pull out the drain pan cover toward the right. (See Figure 3.)
  - (3) Remove the two rod holders holding the check joints in place, using a wrench. (See Figure 4.)
  - (4) Remove the drain pan by unscrewing the two screws. (See Figure 5.)
  - (5) Clean the drain pan and the drain pan cover. (See Figure 6.)
- Remove dust and dirt from the drain groove.




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5




Figure 6



[Drain pan mounting procedure]

\*Reuse the drain pan mounting screws that were removed from the replaced drain pan. (M5 x 16 mm with a nylon washer)

- (1) Screw down the drain pan with two screws. (See Figure 7.)
- (2) Hold the check joints to the drain pan with two rod holders. (See Figure 8.)
- (3) Make sure that the silicon tube is properly placed on the defrost pipe, and then place the drain pan cover. Place the drain pan cover along the defrost pipe, and fit it to the drain pan. (See Figures 9 and 10.)
- (4) Thread a cable tie through the rectangle hole on the screwed-down drain cover, and hold the silicon tube and the defrost pipe together in place. (See Figure 11.)
- (5) Screw down the front panel with eight screws. (See Figure 12.)




Figure 7




Figure 8




Figure 9




Figure 10




Figure 11




Figure 12

## 2. L-module

[Drain pan removal procedure]

- (1) Remove the front panel from the unit by unscrewing the 14 screws. (See Figure 1.)
- (2) Remove the fin guard and the center pillar by unscrewing the 11 screws shown in Figure 2.  
Remove the cable straps from the center pillar. (See Figure 2.)
- (3) Cut the cable tie, unscrew the screw, and pull the drain cover out to the right. (See Figure 3.)
- (4) Remove the two rod holders holding the check joints in place, using a wrench. (See Figure 4.)
- (5) Remove the drain pan by unscrewing the two screws. (See Figure 5.)
- (6) Clean the drain pan and the drain pan cover. (See Figure 6.)  
Remove dust and dirt from the drain groove.




Figure 1




Figure 2




Figure 3




Figure 4




Figure 5






Figure 6

[Drain pan mounting procedure]


\*Reuse the drain pan mounting screws from the replaced drain pan. (M5 x 16 mm with a nylon washer)

- (1) Screw down the drain pan with two screws. (See Figure 7.)
- (2) Hold the check joints to the drain pan with two rod holders. (See Figure 8.)
- (3) Make sure that the silicon tube is properly placed on the defrost pipe, and then place the drain pan cover. Place the drain pan cover along the defrost pipe, and fit it to the drain pan. (See Figures 9 and 10.)
- (4) Thread a cable tie through the rectangle hole on the screwed-down drain cover, and hold the silicon tube and the defrost pipe together in place. (See Figure 11.)
- (5) Screw down the fin guards, center pillar, and front panel with 14 screws. (See Figure 12.)




Make sure that the tab on the drain pan is properly placed in the groove, and screw down the drain pan with two screws (front and back).

Figure 7



Check joint

Figure 8



Make sure that the silicon tube is properly placed on the defrost pipe, and then place the drain pan cover.

Figure 9




Figure 10




Figure 11




Figure 12

### 3. XL-module

[Drain pan removal procedure]

- (1) Remove the front panel from the unit by unscrewing the 14 screws. (See Figure 1.)
  - (2) Remove the external temperature sensor wiring from the left drain pan by cutting the two cable ties. Unhook the pipe cover from the left drain pan. (See Figure 3.)
  - (3) Remove the left drain pan by unscrewing the two screws. (See Figure 4.)
  - (4) Remove the right drain pan by unscrewing the two screws. (See Figure 5.)
  - (5) Clean inside the right and left drain pans. (See Figure 6.)
- Remove dust and dirt from the drain groove.




Figure 1




Figure 2




Figure 3




Figure 4






Figure 5





Figure 6

[Drain pan mounting procedure]

\*Reuse the drain pan mounting screws that were removed from the replaced drain pan. (M5 x 16 mm with a nylon washer)

- (1) Screw down the right drain pan with two screws. (See Figure 7.)
- (2) Screw down the left drain pan with two screws. (See Figure 8.)
- (3) Hook the pipe cover on the left drain pan. (See Figure 9.)
- (4) Hold the external temperature sensor wiring to the left drain pan with two cable ties. (See Figure 10.)
- (5) Screw down the front panel. (See Figure 11.)





Figure 7




Figure 8




Figure 9




Figure 10






Figure 11

## 8-13-8 Maintenance Procedures for the Heat Exchanger


### 1. S-module



- (1) Remove the front panel from the unit by unscrewing the 8 screws. (See Figure 2.)
- (2) Remove the fin guard by unscrewing the 6 screws. (See Figure 2.)
- (3) Remove the drain cover by unscrewing the screw and cutting the cable tie. (See Figures 3 and 4.)  
When re-placing the drain pan cover, make sure that the silicon tube is properly placed on the defrost pipe, and then fix the drain pan cover in place with a cable tie.
- (4) Remove the drain pan by unscrewing the 2 screws. (See Figure 2.)  
Be sure to remove the two rod holders holding the check joints to the drain pan. (See Figure 4.)



- (5) Remove the top attachment that connects the main control box to the inverter control box by unscrewing the 2 screws. (See Figure 5.)
- (6) Remove the cover from the inverter control box by unscrewing the 3 screws. (See Figure 5.)
- (7) Remove the cable straps holding motor wiring. (See Figure 6.)



- (8) Remove the fan guard by unscrewing the 6 screws. (See Figure 7.)
- (9) Insert a spacer between the main control box and the heat exchanger.
- (10) Remove the motor ASSY by unscrewing the 8 screws, using caution not to damage the motor wiring or the fan. (See Figure 8.)




Figure 7




Figure 8

\*Use the supplied spacers.  
Use the spacers 60 (D) X 250 (W) X 60 (H) when replacing the heat exchangers for the maintenance of the accumulator and the pipes.

- (11) Remove the front pillar by unscrewing the 7 screws. (See Figure 9.)
- (12) Disconnect the TH7 sensor holder from the front pillar. (See Figure 9 Rear.)
- (13) Remove the TH7 wiring from the front heat exchanger by cutting the cable tie. (See Figure 10.)




Figure 9




Figure 10

- (14) To remove the front heat exchanger, first remove the front, left, and right frames by unscrewing the 10 screws. (See Figure 11.)  
 To remove the rear heat exchanger, remove the rear frame in addition to the front, left, and the right frames by unscrewing the 12 screws. (See Figure 11.)
- (15) Unscrew the two screws each on the right and left panels. (See Figure 12 Right and Left.)
- (16) Remove the left front pillar by unscrewing the 9 screws on a standard model or 10 screws on a high-efficiency model. (See Figure 12 Front and Left.)
- (17) Remove the right front pillar by unscrewing the 5 screws. (See Figure 12 Front and Right.)




Figure 11




Figure 12 Left


Figure 12 Front

Figure 12 Right


\*Use the supplied spacers. Use the spacers 60 (D) X 250 (W) X 60 (H) when replacing the heat exchangers for the maintenance of the accumulator and the pipes.




- (18) Before removing the front heat exchanger, protect the surrounding electrical components and the pipe cover with a recommended cloth soaked in water, and then remove the braze from four areas. (See Figures 13 and 14.)  
To remove the rear heat exchanger, remove the braze from four areas. (See Figures 15 and 16.)




Removal of the front heat exchanger on a high-efficiency model (Figure 13)



Removal of the front heat exchanger on a standard model (Figure 14)




Removal of the rear heat exchanger on a high-efficiency model (Figure 15)




Removal of the rear heat exchanger on a standard model (Figure 16)

- (19) To remove the front heat exchanger, loosen the screws on the right side of the right rear pillar. (4 screws on a standard model or 3 screws on a high-efficiency model) (See Figure 17.)  
 To remove the rear heat exchanger, loosen the screws on the back of the right rear pillar. (3 screws on a standard model or 2 screws on a high-efficiency model) (See Figure 18.)  
 Remove the screw holding the pillar to the rear heat exchanger support. (See Figure 18.)




Removing the front heat exchanger (Figure 17)




Removing the rear heat exchanger (Figure 18)

- (20) Remove the heat exchanger by diagonally lifting it up, using caution not to damage the fins or the pipes.



Removing the front heat exchanger (Figure 19)



Removing the rear heat exchanger (Figure 20)

Notes for replacing refrigerant circuit components (heat exchanger)

- Be sure to perform non-oxidized brazing.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Place the wet felt sheets listed below (or their equivalents) around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama

Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

2. L-module




Figure 1

- (1) Remove the two front panels from the unit by unscrewing the 14 screws. (See Figure 2.)
- (2) Remove the fin guard by unscrewing the 12 screws. (See Figure 2.)
- (3) Remove the cable straps holding the weak and strong electrical wirings. (See Figure 3.)
- (4) Remove the center pillar by unscrewing the 5 screws. (See Figure 2.)
- (5) Remove the drain cover by unscrewing the screw and cutting the cable tie. (See Figures 3 and 4.)  
When re-placing the drain pan cover, make sure that the silicon tube is properly placed on the defrost pipe, and then fix the drain pan cover in place with a cable tie.
- (6) Remove the drain pan by unscrewing the 2 screws. (See Figure 3.)  
Be sure to remove the two rod holders holding the check joints to the drain pan. (See Figure 4.)




Figure 2

Figure 3




Figure 4

- (7) Remove the cover from the control box by unscrewing the 5 screws. (See Figure 5.)
- (8) Remove the cable straps holding motor wiring. (See Figure 6.)




Figure 5




Figure 6

- (9) Remove the fan guard by unscrewing the 12 screws. (See Figure 7.)
- (10) Insert a spacer between the control box and the heat exchanger.
- (11) Remove the motor ASSY by unscrewing the 16 screws, using caution not to damage the motor wiring or the fan. (See Figure 8.)




Figure 7




Figure 8

\*Use the supplied spacers.  
Use the spacers 60 (D) x 250 (W) x 60 (H) when replacing the heat exchangers for the maintenance of the accumulator and the pipes.

- (12) Remove the front pillar by unscrewing the 7 screws. (See Figure 9.)
- (13) Disconnect the TH7 sensor holder from the front pillar. (See Figure 9 Rear.)
- (14) Remove the TH7 wiring from the heat exchanger by cutting the cable tie. (See Figure 10.)




Figure 9




Figure 10

- (15) To remove the front heat exchanger, first remove the front, left, right, and center frames by unscrewing the 14 screws. (See Figure 11.)  
 To remove the rear heat exchanger, remove the rear frame in addition to the front, left, right, and center frames by unscrewing the 16 screws. (See Figure 11.)
- (16) Unscrew the two screws each on the right and left panels. (See Figure 12 Right and Left.)
- (17) Remove the left front pillar by unscrewing the 9 screws on a standard model or 10 screws on a high-efficiency model. (See Figure 12 Front and Left.)
- (18) Remove the right front pillar by unscrewing the 5 screws. (See Figure 12 Front and Right)




Figure 11





Figure 12 Left

Figure 12 Front


Figure 12 Right

\*Use the supplied spacers. Use the spacers 60 (D) X 250 (W) X 60 (H) when replacing the heat exchangers for the maintenance of the accumulator and the pipes.


(19) Before removing the front heat exchanger, protect the surrounding electrical components and the pipe cover with a recommended felt soaked in water, and then remove the braze from four areas. (See Figures 13 and 14.)  
To remove the rear heat exchanger, remove the braze from four areas. (See Figures 15 and 16.)




Removal of the front heat exchanger on a high-efficiency model (Figure 13)



Removal of the front heat exchanger on a standard model (Figure 14)




Removal of the rear heat exchanger on a high-efficiency model (Figure 15)




Removal of the rear heat exchanger on a standard model (Figure 16)

- (20) To remove the front heat exchanger, loosen the screws on the right side of the right rear pillar. (4 screws on a standard model or 3 screws on a high-efficiency model) (See Figure 17.)  
 To remove the rear heat exchanger, loosen the screws on the back of the right rear pillar. (4 screws on a standard model or 3 screws on a high-efficiency model) (See Figure 18.)  
 Remove the screw holding the pillar to the rear heat exchanger support.




Removing the front heat exchanger (Figure 17)




Removing the rear heat exchanger (Figure 18)

- (21) Remove the heat exchanger by diagonally lifting it up, using caution not to damage the fins or the pipes.




Removing the front heat exchanger (Figure 19)



Removing the rear heat exchanger (Figure 20)

(22) After removing the heat exchangers, dispose of the front and the rear heat exchanger supports. (See Figures 21 and 22.) The front and the rear heat exchanger supports do not need to be installed. (The front and the rear heat exchanger supports are for suppressing vibration during transportation.)



(23) Re-place the front and the rear heat exchangers in the reverse order as they were removed. Re-place the components that were removed as they were.



### 3. XL-module




Figure 1

- (1) Remove the two front panels from the unit by unscrewing the 14 screws. (See Figure 2.)
- (2) Remove the fin guard by unscrewing the 12 screws. (See Figure 2.)
- (3) Remove pipe cover. (See Figure 3.)
- (4) Remove the left drain pan by unscrewing the two screws and cutting the two cable ties. (See Figure 3.)
- (5) Remove the right drain pan by unscrewing the 2 screws. (See Figure 3.)
- (6) Remove the 3 cable straps from the center pillar. (See Figure 4.)




Figure 2




Figure 3




Figure 4

- (7) Remove the 3 cable straps holding motor wiring from the control box. (See Figure 5.)
- (8) Remove the fan guard by unscrewing the 12 screws. (See Figure 6.)
- (9) Remove the wire from the center frame. (See Figure 7.)
- (10) Remove the motor ASSY by unscrewing the 16 screws, using caution not to damage the motor wiring or the fan. (See Figure 7.)




Figure 5




Figure 6





Figure 7


(11) Before removing the front heat exchanger, protect the surrounding electrical components and the pipe cover with a recommended felt soaked in water, and then remove the braze from four areas. (See Figures 8 and 9.)  
 To remove the right and left rear heat exchangers, remove the braze from four areas. (See Figures 10 - 13.)




Removal of the front heat exchanger on a high-efficiency model (Figure 8)




Removal of the front heat exchanger on a standard model (Figure 9)




Removal of the left rear heat exchanger on a high-efficiency model (Figure 10)



Removal of the left rear heat exchanger on a standard model (Figure 11)



Removal of the right rear heat exchanger on a high-efficiency model (Figure 12)



Removal of the right rear heat exchanger on a standard model (Figure 13)

- (12) Remove the front pillar by unscrewing the 7 screws. (See Figure 14.)
- (13) Disconnect the TH7 sensor holder from the front pillar. (See Figure 14 Rear.)




Figure 14

- (14) To remove the front heat exchanger, first remove the front, left, right, and center frames by unscrewing the 16 screws. (See Figure 15.)  
To remove the right and left rear heat exchangers, remove the top and the rear frames in addition to the front, left, right, and center frames by unscrewing the 21 screws. (See Figure 15.)
- (15) Remove the center front pillar by unscrewing the 4 screws. (See Figure 16.)




Figure 15







Figure 16


- (16) To remove the front heat exchanger, unscrew the screws on the front of the right front pillar. (4 screws on a standard model or 3 screws on a high-efficiency model) (See Figure 17.)  
 To remove the left rear heat exchanger, unscrew the screws on the left side of the left front pillar and the screws on the front of the center pillar (7 screws on a standard model or 8 screws on a high-efficiency model.) (See Figures 18 and 19.)  
 To remove the right rear heat exchanger, unscrew the screws on the right side of the right front pillar and the screws on the front of the center pillar (7 screws on a standard model or 6 screws on a high-efficiency model.) (See Figures 19 and 20.)



(17) Remove the heat exchanger by diagonally lifting it up, using caution not to damage the fins or the pipes.



Removing the front heat exchanger (Figure 21)



Removing the right-rear and left-rear heat exchangers (Figure 22)

(18) Re-place the front and the rear heat exchangers in the reverse order as they were removed.  
Re-place the components, except the rear heat exchanger support, that were removed as they were.

## 8-13-9 Accumulator Replacement Procedure

### 1. S, L-module

- (1) Remove the front heat exchanger. Refer to 8-13-8 Maintenance Procedures for the Heat Exchanger for details.
- (2) Remove the top, front, and right compressor covers. Refer to 8-13-5 Compressor Replacement Procedure for details.
- (3) Remove the duct from the control box. Refer to the control box replacement procedure for details.
- (4) Remove the right and inside (right) compressor panels by unscrewing the four screws. (Applicable only to the S-module. See Figures 1 and 2.)




Figure 1




Figure 2

- (5) Unscrew the two screws from the right accumulator fixing plate. (See Figures 3 and 5.)
- (6) Unscrew the two screws from the rear accumulator fixing plate. (See Figures 3 and 4.)
- (7) Remove the four screws from the accumulator fixing base legs. (See Figure 6.)




Figure 3




Figure 4




Figure 5





Figure 6

(8) Remove the braze at the four areas on the accumulator inlet and outlet pipes shown in Figure 7.



(9) Re-place the accumulator in the reverse order as it was removed.  
Re-place the components that were removed as they were.

\*Notes on replacing refrigerant circuit components (accumulator)

- Be sure to perform non-oxidized brazing.
- Before heating the pipes, wrap the refrigerant circuit components with a wet towel to keep the temperature of the components from rising above 120°C.
- After brazing is done, check that the brazing is done properly and check for leaks before vacuum-drying the pipes.
- Direct the brazing torch flame away from the wiring and sheet metals inside the unit not to damage them.
- Wet felt sheets listed below (or its equivalent), and place them around the areas to be brazed to protect the heat exchanger, pipes, and pipe covers from being damaged from the brazing torch flame.

Recommended felt sheets: Spatter felt 50CF-11 (5t x 1 m x 1 m) by TRUSCO Nakayama  
Felt sheets that meet the JIS standard (JIS A 1323 type A "Flame retardant testing method for spark droplets of welding and gas cutting on fabric sheets in construction works")

## 2. XL-module

- (1) Remove the front heat exchanger. Refer to 8-13-8 Maintenance Procedures for the Heat Exchanger for details.
- (2) Remove the top, front, and right compressor covers. Refer to 8-13-5 Compressor Replacement Procedure for details.
- (3) Remove the fixing plate 1 above four-way valve (21S4b), saddle, and rubber spacer by unscrewing the three screws shown in Figure 8.  
Either remove or protect the wiring, pipe cover, and plastic components to keep them from being damaged by the torch flame.




Figure 8

- (4) Remove the sheet metal, cable ties, and rubber spacers from the accumulator mounting plate by unscrewing the screw. (See Figure 9.)




Figure 9

- (5) Remove the braze at the three areas on the accumulator outlet (suction) pipe. (See Figure 10.)
- (6) Remove the braze at the two areas on the accumulator inlet pipe. (See Figure 11.)




Figure 10






Figure 11





- (7) For the four-pipe piping on the back of the accumulator, follow the procedures below.  
 Remove the braze at the four areas on the four pipes on the back of the accumulator. (See Figure 12.)  
 Remove the braze at the six areas that are located on the right side of the four pipes on the back of the accumulator. (See Figure 13.)




Figure 12





Figure 13



- (8) For the five-pipe piping on the back of the accumulator, follow the procedures below.  
 Remove the braze at the five areas on the five pipes on the back of the accumulator. (See Figure 14.)  
 Remove the braze at the seven areas that are located on the right side of the five pipes on the back of the accumulator. (See Figure 15.)




Figure 14





Figure 15




- (9) Re-place the accumulator in the reverse order as it was removed.  
 Re-place the components that were removed as they were.

# 8-14 HBC Maintenance Instructions (Applicable to main and sub HBCs)

## 8-14-1 Valve Block

VB3 (valve block) is driven by the pulse signal from the VB board and are controlled by a stepping motor.  
 1) VB board and valve block (VB3)




2) Pulse signal output and valve motion

Output (phase) number	Output status			
	1	2	3	4
4	ON	ON	OFF	OFF
5	OFF	ON	ON	OFF
7	OFF	OFF	ON	ON
8	ON	OFF	OFF	ON

When valve opens (0 → C800 or H800): 4 → 3 → 2 → 1  
 When valve closes (C800 or H800 → 0): 1 → 2 → 3 → 4

- If the LEDs (VB3a-VB3p) on the VB board are lit, check the relevant valve blocks for loose connectors and faulty wiring. Make sure that the valve blocks are properly controlling the refrigerant flow.
- If the LED is unlit, check all valve blocks for proper operation.
- If the problem persists after taking the above measures, replace the circuit board.

3) Opening and closing of the valve



## 8-14-2 Instructions for Debris Removal Operation

This operation removes the debris that may have been introduced during installation from the water circuit.

Perform this operation after completion of the following.

- Water piping work \*1
- Air-tightness test of water piping
- Electrical work
- Refrigerant piping work \*2
- Evacuation of refrigerant circuits \*2
- Refrigerant charging \*2

\*1. **Install an automatic air vent valve at the highest point of each branch pipe from the HBC (in two places at the highest point of the return pipe from the Sub-HBC, and in six places at the highest point of the return pipes from indoor units). (See Figure 1.)**

Failure to install air vent valves may leave air in the water circuit and damage the pump.

\*2. Debris removal operation can be performed before completing the refrigerant piping work, evacuation of refrigerant circuits, and refrigerant charging.

### 1. Preparation for debris removal operation

#### 1. DIP SW settings

[Main-HBC]

Turn on DIP SW001-1. (Water circuit valve setting (valve open when stopped))

Turn on DIP SW001-2. (Nullification of the drain overflow error for 9 hours) \*Applicable when a Sub-HBC (CMB-WM\*\*V-BB) is connected.

#### 2. Turn on the breaker for each unit, and then open the manual air vent valves on the Sub-HBC and the indoor units. (The Main-HBC does not have a manual air vent valve.)

\* Note that, if the manual air vent valves are opened too much, a large amount of water may blast out and overflow from the drain pan. (If there are air vent valves on the field-installed pipes, open the valves as well.)






Figure. 1 Automatic air vent valve




Sub-HBC (CMB-WM\*\*V-BB)



Indoor unit (Example: PEFY-WP-VMA-E)

#### 3. Supply water from the water supply pipe on the HBC.



Connection of water supply pipe


Install a non-return valve to prevent water in the unit from flowing back to the water supply pipe, or remove the water supply hose after the debris removal operation.

#### 4. Check that water is coming out of the manual air vent valve on each unit, and perform the debris removal operation.

**2. Debris removal operation**

**[When an outdoor unit is connected, and refrigerant piping work, evacuation of refrigerant circuits, and refrigerant charging have been completed]**

1. Turn on DIP SW002-1 if there is a possibility that the debris may have been introduced into the water circuits during piping work on site. (Refer to the flowchart below for debris removal operation for details.)  
Use DIP SW002-1 to start the debris removal operation. (Each manual air vent valve must stay open.)



Control board (LED, DIP SW positions)

2. Debris removal operation will be completed in 40 minutes, and the LED on the control board will indicate "Air0." The LED indication will change to "Air1," "Air2," and "AirE" in order. Then, the water pump inside the HBC will stop.
3. Stop the water supply, and check that no water is coming out of the manual air vent valves. Then, turn off DIP SW002-1.

**[When no outdoor units are connected, or refrigerant piping work, evacuation of refrigerant circuits, and refrigerant charging have not been completed (when performing debris removal operation for the water circuits only)]**


The following must be completed before performing debris removal operation.

- Assign M-NET addresses to the HBC and the indoor units.
  - Have a computer ready with the MN converter and the Maintenance Tool (Ver. 5.43 or later) installed.
  - Have a power-supply device (PAC-SC51KUA) ready.
- \* While the debris removal operation is being performed, no other functions of the Maintenance Tool are available for use.

1. Follow the procedures below after connecting the MN converter and starting up the Maintenance Tool. (Manuals are accessible from the Maintenance Tool.)

<Debris removal operation procedure (without connection to an outdoor unit)>

- ① Select Option → Commissioning support → HVRF-R2 commissioning.
- ② A confirmation window will appear. Check the message, and press Next to proceed.  
\* Manuals are accessible from the confirmation window.
- ③ After the units are searched for, a sign that indicates the completion of preparation will appear. Turn on DIP SW002-1 of the Main-HBC to start the operation.



Maintenance Tool window  
(Debris removal operation without connection to an outdoor unit)

2. The LED on the control board will indicate "Air1," "Air2," and "AirE" in order, and the pump will stop after a while.  
The progress of the debris removal operation will appear on the service LED of the Main-HBC and on the Maintenance Tool window.
3. Stop the water supply, and check that no water is coming out of the manual air vent valves. Then, turn off DIP SW002-1.


**[The rest of the procedures are the same for performing debris removal operation with connection to an outdoor unit (refrigerant piping work, evacuation of refrigerant circuits, and refrigerant charging have been completed) and without connection to an outdoor unit (refrigerant piping work, evacuation of refrigerant circuits, and refrigerant charging have not been completed)]**

- Turn on DIP SW002-6.

Close the field-installed manual on-off valve at each branch and on the pipe connected to the Sub-HBC.

Then, slowly turn the water vent screw of the two water pumps at the lower part inside the HBC. **(Maximum of two turns)**

\* **Note that, if the water vent screws are turned too much, a large amount of water may blast out and overflows from the drain pan.**



Water vent screw  
(Maximum of two turns)

Water pump (water vent screw position)

- Slowly open the strainer inside the HBC (on the maintenance side).

\* **Note that, if it is opened fast, water may blast out.**

Remove the strainer, and clean its inside.




Strainer maintenance

- Slowly open the strainer on the far side inside the HBC. Remove it in the same way as the other strainer, and clean its inside.

After cleaning and re-fitting the strainer, turn off DIP SW002-6.

- Make sure the strainers are re-installed properly.

Flowchart for debris removal operation (Turn on DIP SW002-1.)



- The operation can be forced to stop by turning on DIP SW002-4.
- If it is found during any step that air has not been discharged to the desired degree, repeat the air discharge operation from the beginning.
- If an error sign "Err" appears on the LED on the circuit board of the HBC, turn off the breaker, turn it back on, and repeat the air discharge operation from the beginning.

### 3. Final step

Turn off DIP SW001-1 and 001-2 after completion of debris removal operation.

### 8-14-3 Instructions for the Air Vent Operation

This operation removes the air from the water circuit after water is supplied to it. Perform this operation after completion of the following. \*1

- Water piping work \*2
- Air-tightness test of water piping
- Electrical work
- Refrigerant piping work \*3
- Air-tightness test of refrigerant piping \*3
- Evacuation of refrigerant circuits \*3
- Refrigerant charging \*3

\*1. Perform air vent operation after completion of water- and refrigerant-piping work, air-tightness tests, electrical work, evacuation of refrigerant circuits, refrigerant charging, and debris removal operation (shown on previous pages).

\*2. **Install an automatic air vent valve at the highest point of each branch pipe from the HBC (in two places at the highest point of the return pipe from the Sub-HBC, and in six places at the highest point of the return pipes from indoor units). (See Figure 1.)**

Failure to install air vent valves may leave air in the water circuit and damage the pump.

\*3. Air vent operation can be performed before completing the refrigerant piping work, air-tightness test of refrigerant piping, evacuation of refrigerant circuits, and refrigerant charging.

In this case, **perform an air vent operation again after refrigerant piping work, air-tightness test of refrigerant piping, evacuation of refrigerant circuits, and refrigerant charging have been completed**, because the initial air vent operation may not be able to remove all dissolved oxygen in the water circuit.

#### 1. Preparation for air vent operation

1. DIP SW settings


[Main-HBC]

Turn on DIP SW001-1. (Water circuit valve setting (valve open when stopped))

Turn on DIP SW001-2. (Nullification of the drain overflow error for 9 hours). \*Applicable when a Sub-HBC (CMB-WM\*\*V-BB) is connected.


2. Turn on the breaker for each unit, and then open the manual air vent valves on the Sub-HBC and the indoor units. (The Main-HBC does not have an manual air vent valve.)

\* Note that, if the manual air vent valves are opened too much, a large amount of water may blast out and overflow from the drain pan. (If there are air vent valves on the field-installed pipes, open the valves as well.)




Sub-HBC (CMB-WM\*\*V-BB)

Manual air vent valve



Indoor unit (Example: PEFY-WP-VMA-E)

3. Supply water from the water supply pipe on the HBC.



Connection of water supply pipe

Install a non-return valve to prevent water in the unit from flowing back to the water supply pipe, or remove the water supply hose after the air vent operation.

4. Check that water is coming out of the manual air vent valve on each unit, and perform the air vent operation.






Figure 1. Automatic air vent valve

**2. Air vent operation**

**[When an outdoor unit is connected, and refrigerant piping work, air-tightness test of refrigerant piping, evacuation of refrigerant circuits, and refrigerant charging have been completed]**

1. Turn on DIP SW002-3 of the Main-HBC.
2. The LED on the control board indicates "Air1," "Air2," "Air3," "Air 4," and "AirE" in order, and the pump will stop after a while. See the figure below for the approximate time it takes to complete an air vent operation.



3. Turn off DIP SW002-3.
4. Close all manual air vent valves.
5. Stop the water supply.

**[When no outdoor units are connected, or refrigerant piping work, air-tightness test of refrigerant piping, evacuation of refrigerant circuits, and refrigerant charging have not been completed (when performing air vent operation for the water circuits only)]**

The following must be completed before performing air vent operation.


- Assign M-NET addresses to the HBC and the indoor units.
- Have a computer ready with the MN converter and the Maintenance Tool (Ver. 5.43 or later) installed.
- Have a power-supply device (PAC-SC51KUA) ready.

\* While the air vent operation is being performed, no other functions of the Maintenance Tool are available for use.

1. Follow the procedures below after connecting the MN converter and starting up the Maintenance Tool. (Manuals are accessible from the Maintenance Tool.)

<Air vent operation procedure (without connection to an outdoor unit)>

- ① Select Option → Commissioning support → HVRF-R2 commissioning.
- ② A confirmation window will appear. Check the message, and press Next to proceed.  
\* Manuals are accessible from the confirmation window.
- ③ After the units are searched for, a sign that indicates the completion of preparation will appear. Turn on DIP SW002-3 of the Main-HBC to start the operation.



Maintenance Tool window (Air vent operation without connection to an outdoor unit)

2. The LED on the control board will indicate "Air1," "Air2," "Air3" and "AirE" in order, and the pump will stop after a while. The progress of the air vent operation will appear on the service LED of the Main-HBC and on the Maintenance Tool.
3. Stop the water supply, and check that no water is coming out of the manual air vent valves. Then, turn off DIP SW002-3.
4. Close all manual air vent valves.
5. Stop the water supply.

\* Before setting the DIP SW, make sure that the service LED of the Main-HBC is not indicating any error.


\* Debris removal operation or air vent operation cannot be executed from the Maintenance Tool.

\* An air vent operation using warm water cannot be performed to remove dissolved oxygen (Air4) from the water circuit without connection to an outdoor unit.

**After connecting the outdoor unit (refrigerant circuit), perform an air vent operation again to remove all air from the circuit.**

**Any air left in the water circuit may damage the pump.**

(Air4 operation alone can be performed by turning on DIP SW001-10 after connecting the outdoor unit (refrigerant circuit).)



**3. Final step**

Turn off DIP SW001-2 and 001-2 after completion of air vent operation.




### 8-14-4 Preparation for servicing

Before starting service work, remove the service panels and open the control box. See below for the necessary preparation work.


«To remove the service panel (upper panel)»

Unscrew the two fixing screws on the upper service panel, lift up the panel to unhook it from the hooks, and pull forward to remove it.




«To remove the service panel (lower panel)»

Unscrew the eight fixing screws on the lower service panel, lift up the panel to unhook it from the hooks, and pull forward to remove it.




«To open the control box»

- ① Remove the lower service panel.
- ② Disconnect all connectors except the power-supply wire connector, and then pull the wires out of the control box.
- ③ Unscrew the four screws on the control box, and loosen one screw.
- ④ **While lifting up** the control box, open the control box to 90°.
- ⑤ After completing service work, close the control box, and then reconnect all connectors to the circuit board.





«To drain water out of the unit»

- ① Open the lower service panel.
  - ② Loosen the nut on the pump that is indicated in the figure below to drain water. (same with Pump 1)
- \*Loosen the nut slowly. Loosening the nut too quickly will cause the water to blast out.




«To reconnect the wires»  
 Reconnect the wires by referring to the figures below.






## 8-15 Main-HBC Maintenance Instructions


### 8-15-1 Solenoid Valve Coil (SV1) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the eight fixing screws from the service panel (front lower).</li> <li>2) Disconnect the corresponding solenoid valve coil connector from the control board.</li> <li>3) Remove the solenoid valve coil wire secured by clamps. Remove the cable ties holding other wires.</li> <li>4) Remove the one solenoid valve coil fixing screw from the front and then remove the solenoid valve coil.</li> <li>5) Install the new solenoid valve coil in the position indicated in the figure and then connect the connector to the control board.</li> <li>6) Hold the wires in place with the clamps and the cable ties removed in step 3) above.</li> </ol>		Installation location


### 8-15-2 4-Way Valve Coils (21S4Ma, 21S4Mb) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the eight fixing screws from the service panel (front lower).</li> <li>2) Disconnect the corresponding 4-way valve coil connector from the control board.</li> <li>3) Remove the two 4-way valve coil wires secured by clamps. Remove the cable ties holding other wires.</li> <li>4) Remove the two 4-way valve coil fixing screws from the front and then remove two 4-way valve coils.</li> <li>5) Install the new 4-way valve coils in the position indicated in the figure and then connect the connector to the control board.</li> <li>6) Hold the wires in place with the clamps and the cable ties removed in step 3) above.</li> </ol> <p>*Take care not to mix up the 4-way valve coils on the left and right when installing them.</p>		Installation location

### 8-15-3 LEV Coils (LEV1, LEV2, LEV3) Replacement Procedure (HBC)






Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the eight fixing screws from the service panel (front lower).</li> <li>2) Disconnect the corresponding LEV coil connector from the control board.</li> <li>3) Remove the control box and then remove the LEV coil wires secured by clamps and cables ties. Remove the cable ties holding other wires.</li> <li>4) Rotate the LEV coils slightly and then remove them in the upward direction. Remove the water-proof cover from the coil of LEV3, and place it on the new coil.</li> <li>5) Install the new LEV coils in the position indicated in the figure and then connect the connector to the control board.</li> <li>6) Hold the wires in place with the clamps and the cable ties removed in step 3) above.</li> </ol> <p>*Take care not to mix up the three LEV coils when installing them.                      *Rotate the LEV coils until you hear them snap into place to attach them properly.</p>		Installation location

### 8-15-4 Valve Motor and Valve Body Replacement Procedure (HBC)


Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Perform the operation to drain the water from the system if necessary in accordance with the following.                             <ul style="list-style-type: none"> <li>♦When replacing only valve motor: Draining water from system not necessary.</li> <li>♦When replacing valve body: Draining water from system necessary.</li> </ul> </li> <li>2) Remove the two fixing screws from the service panel (front upper) and then remove the service panel (front upper).</li> <li>3) Perform the removal operation in accordance with the following.                             <ul style="list-style-type: none"> <li>♦When replacing only valve motor: Remove the two fixing screw and then remove the valve motor.</li> <li>♦When replacing valve body: Remove the motor as described above and then pull out the valve body in the direction of the arrow indicated in the figure.</li> </ul> </li> </ol>		Installation location

### 8-15-5 Valve Block Replacement Procedure (HBC)


8 Troubleshooting Based on Observed Symptoms

Operation procedures	Illustrations	Operation location
<p>1) Remove both front service panels (upper and lower).</p> <p>2) Drain water out of the unit through the pump.</p> <p>3) Disconnect all indoor unit pipes at the connections to on-site pipes.</p> <p>4) Disconnect all motor connectors.</p> <p>5) Unclip the six clips above the valve block (A) and the four clips on each side (B).</p>  <p style="text-align: center;">Clip</p> <p>6) Place your hand behind the block, and unclip the clips holding the indoor unit pipes on the back (C). (After unclipping the first clip, move the unclipped branch pipe at the upper part of the block to the side, and unclip other clips by placing your hand from above the block.)</p> <p>7) Unscrew the fixing screws on both sides of the block (two screws each on the left and the right). (If it is difficult to reach the screws, move the pipes to the side to create a space.)</p> <p>8) Pull the block forward and out.</p> <p>9) Install the new block on the unit in the reverse order as it was removed.</p>	   <p style="text-align: center;">Pull the block forward and out.</p> 	<p>Installation location</p>

### 8-15-6 Solenoid Valve and LEV Body Replacement Procedure (HBC)





Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the eight fixing screws from the service panel (front lower) and then remove the service panel (front lower).</li> <li>2) Disconnect the corresponding valve coil connectors from the control board and also remove the coil from the valve. (For how to remove the coil, follow the operation procedures of [8-15-1 Solenoid Valve Coil (SV1) Replacement Procedure (HBC)].)</li> <li>3) Debraze the corresponding valve to remove them.</li> <li>4) Reinstall the LEV coil.</li> </ol> <p>*Protect the insulation materials from heat damage before brazing.</p>		Installation location





### 8-15-7 Strainer Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the service panel (lower panel).</li> <li>2) Drain water through the pump.</li> </ol> <ol style="list-style-type: none"> <li>3) Remove the strainer cap with a spanner. (A spanner with a total length of 190 mm or shorter recommended)</li> <li>4) Pull the cap off in the direction of the arrow, and replace the filter.</li> </ol> <p>*Fully tighten the cover at the bottom of the strainer. Failing to do so may cause a water leakage.</p>		Installation location




### 8-15-8 Pump Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<p>«Note»                      Pump 2 needs to be removed to replace Pump 1 (even when Pump 2 needs no replacement).</p> <ol style="list-style-type: none"> <li>1) Remove the service panel (lower panel).</li> <li>2) Drain water through the pump.</li> </ol>		Installation location
<p>«Start with Pump 2.»</p> <ol style="list-style-type: none"> <li>3) Remove the pump terminal block cover (fixed with two screws).                      *The Victaulic joint will not come out unless the cover is removed.</li> <li>4) Remove the two Victaulic joints. (Unscrew the two nuts on each joint.)</li> </ol>		
<ol style="list-style-type: none"> <li>5) Slide the gasket in the Victaulic joint to the pump side.</li> </ol>		
<ol style="list-style-type: none"> <li>6) Remove the relay connector from Pump 2.                      (See the figure at right for its location.)</li> <li>7) Unscrew the screws at the base of the pump. (x4)</li> </ol>		

Operation procedures	Illustrations	Operation location
<p>8) Pull Pump 2 forward and out, using caution not to let it come in contact with the base sheet metal, and replace it with a new one.</p>		<p>Installation location</p>
<p>«When replacing Pump 1»            9) As with the procedure for replacing Pump 2, remove the terminal block cover of Pump 1, and remove the two Victaulic joints.</p>		
<p>10) Remove the relay connector.            (The location of the relay connector of Pump 1 is shown in the figure at right.)            11) Unscrew the screws at the base of the pump. (x4)</p>		
<p>12) Pull the pump forward and out from the unit, using caution not to let it come in contact with the base sheet metal. Replace Pump 1 with a new pump, and replace Pump 2.</p>		

## 8-15-9 Disassembling the Pump and Replacing the Mechanical Seal (HBC)

### 1. Breakdown diagram of the pump



### 2. Cautionary notes for replacement

#### (1) Points for attention when replacing mechanical seals

- 1) The mechanical seal should be handled gently to prevent damage to the seal, and the mechanical seal and pump cavity should be cleaned before installation.
- 2) Mechanical seals shall be kept clean and shall not be contaminated with stains, impurities, dust or dirt.
- 3) During the installation of the mechanical seal, the sealing element shall not be struck directly with a tool to prevent damage to the sealing element.

#### (2) Points for attention when replacing plug components

- 1) Ensure that the O-ring is not distorted and overstretched when installing the plug assembly.
- 2) Plug components should be kept clean and should not be contaminated with stains, impurities, dust or dirt.
- 3) Check the installation surface for no burrs, flying edges, impurities, dust and other defects and scratches before installation.
- 4) Do not reuse the plug assembly.
- 5) Do not clean the pump with cleaning oil or gasoline when the plug assembly is installed to avoid denaturation of the O-ring.

#### (3) Points for attention when replacing gaskets

- 1) Before installing the gasket, make sure that the seal face is clean, free of burr rust and smooth.
- 2) The gasket shall not be pulled and twisted, shall not be damaged, and shall not be contaminated with stains, impurities, dust or dirt.
- 3) Make sure the gasket is flattened to avoid wrinkling when fastening.

#### (4) Points for attention when replacing nylon lock nuts

- 1) Do not clean the pump with cleaning oil or gasoline when the nylon lock nut is installed to avoid denaturation.
- 2) The nylon lock nuts should be kept clean and should not be contaminated with stains, impurities, dust or dirt.


### 3. Disassembly procedure for the pump

#### (1) Before disassembly





- Cut off the motor power.
- Close the valve to prevent the system liquid from flowing out.

#### (2) Precautions for disassembly



- Before disassembling the pump, thoroughly drain residues out of the pump.





 Do not place the water pump vertically during disassembly, so as to avoid residual water from the pump body entering the motor casing or rotor.






(3) Disassembly tool





Name	Specifications	Photo
Inner hexagonal wrench	S3	
Wrench	S14	
Inner hexagonal sleeve	S13	
Fixed piece Included in the service kit	-	


(4) Removal procedure

Operation procedures	Illustrations
<p>1) Unscrew the plug assembly (part 2) from the water drain valve and the air-discharge valve using wrench S14.</p>	 <p>Air-discharge valve</p> 


Operation procedures	Illustrations
<p>2) Use wrench S14 to loosen the hexagonal nut (part 25) and remove it and the spring washer (part 24).</p>	 <p>Spring washer</p> <p>Hexagonal nut</p>
<p>3) Remove the water inlet body (part 1).</p>	 <p>Water inlet</p>
<p>4) Remove four pull rods (part 11). *Not all four rods do not need to be removed unless necessary to replace the parts.</p>	 <p>Rod</p>
<p>5) Remove the rotation sign. &lt;&lt;Note&gt;&gt; Save the label for reuse in the way its adhesive quality is maintained.</p>	 <p>Rotation sign label</p>

Operation procedures	Illustrations
<p>6) Use the fixing piece to extend into the center of the motor (part 32) wind shield to clamp the slot at the end of the motor shaft, while using the Inner hexagonal sleeve S13 to unscrew the nylon lock nut (part 20).</p> <p>&lt;&lt;Note&gt;&gt;                      Rotate the nylon lock nut counterclockwise when seen from the nylon lock nut side.</p>	 
<p>7) Remove the nylon lock nut (part 20), flat washer (part 31), shaft-end sleeve (part 19), and impeller (part 4).</p>	  

Operation procedures	Illustrations
<p>8) Remove the sealing gasket (part 17), guide vane (part 12), long spacer sleeve of impeller (part 14), and impeller (part 4).</p>	 <p>Sealing gasket</p>
	 <p>Guide vane</p>
	 <p>Long spacer sleeve</p>
	 <p>Impeller</p>

Operation procedures	Illustrations
<p>9) Remove the sealing sleeve (part 15) and sealing gasket (part 17).</p>	 <p>The top photograph shows a person's hands using a tool to remove a cylindrical 'Sealing sleeve' from the motor's shaft. The bottom photograph shows the 'Sealing gasket' being removed from the motor's housing.</p>


\*Part number that appear in the disassembly procedure correspond to the numbers in the pump breakdown drawing.

	<p>Please keep the motor and parts completely dry during installation to prevent the contaminated media from entering the motor shell or rotor.</p>
--	---






The disassembly of water pump is completed.

#### 4. Removing the mechanical seal

##### (1) Removal procedure

Operation procedures	Illustrations
<p>1) Loosen the hexagonal socket screw of the mechanical seal (part 8) with an inner hexagonal wrench S3.</p>	 <p>The photograph shows a person's hands using an inner hexagonal wrench to loosen a 'Mechanical seal hexagonal socket screw' from the motor's housing.</p>




Operation procedures	Illustrations
<p>2) Remove the spring seat, spring, and rotation ring of the mechanical seal (part 8).</p>	 <p>Mechanical seal spring seat</p>  <p>Mechanical seal spring</p>  <p>Mechanical seal rotation ring</p>
<p>3) Remove the water outlet body (part 7) and remove the static ring of the mechanical seal (part 8) Have a new mechanical seal ready.</p>	 <p>Water outlet body</p>  <p>Mechanical seal static ring</p>







5. Pump assembly steps


(1) Before assembly

- Clean and check all parts.
- Replace all damaged parts.




 Please keep the motor and parts completely dry during installation to prevent the contaminated media from entering the motor shell or rotor.






(2) Assembly tool





Name	Specifications	Photo
Plastic hammer	-	
Hexagonal torque wrench (Range: 3-5 N·m)	S3	
Wrench	S14	
Inner hexagonal sleeve	S13	
Fixed piece Included in the service kit	-	
Horizontal ruler	-	


Name	Specifications	Photo
Torque wrench (Range: 11-13 N·m)	-	
Brush or sponge <<Note>> Don't let the coating area get hairy when using the brush.	-	-
Appropriate amount of methyl silicone oil (Viscosity: 1000 mm <sup>2</sup> /s, 25°C) (Flash point: 300°C or above) (Freezing point: -50°C or below)	-	-



(3) Assembly sequence






Operation procedures	Illustrations
<p>1) Note to keep the work bench at the level state. &lt;&lt;Important&gt;&gt; Make sure bubbles are located between the two lines of the level.</p>	
<p>2) Remove the stationary ring of the mechanical seal (part 8), and coat it with methyl silicone oil evenly (soaked).</p>	
<p>3) Install the stationary ring of the mechanical seal (part 8) into the water outlet body (part 7) (with the smooth surface facing upwards). &lt;&lt;Note&gt;&gt; When loading, the static ring of mechanical seal shall not be skewed and shall be installed in place.</p>	

Operation procedures	Illustrations
<p>4) Wipe the static ring grinding surface of the mechanical seal (part 8) with a sponge pad inside the mechanical seal (part 8). *Discard the sponge pad after use.</p>	
<p>5) Coat one circle of the mechanical seal matched with the motor shaft with methyl silicone oil (Soaked).</p>	
<p>6) Install the water outlet body (part 7), the water outlet faces one side of the motor junction box.</p>	
<p>7) Load the rotation ring, spring and spring seat of the mechanical seal (part 8), adjust the position of the set screw in the spring seat, so that it is facing the arc surface of the motor shaft. &lt;&lt;Note&gt;&gt; Loosen the hexagonal socket screw of the spring seat beforehand.</p>	 






Operation procedures	Illustrations
<p>8) Press the spring seat by hand from above to contract the spring and get the touch of the spring seat touching the step part of the shaft, then tighten the inner hexagonal screw of the spring seat with a hexagonal torque wrench S3 in that position.</p> <p>&lt;&lt;Note 1&gt;&gt; The fastening torque of the inner hexagon bolt is 3-5 N·m.</p> <p>&lt;&lt;Note 2&gt;&gt; Check that the distance between the end of the mechanical seal and the tip of the shaft is 51 mm.</p>	 
<p>9) Install the sealing sleeve (part 15), and install the sealing gasket (part 17) in the slot of the water outlet body (part 7), and note that the smooth surface of the sealing gasket faces downwards.</p> <p>&lt;&lt;Note&gt;&gt; The smooth surface of the sealing gasket faces downwards.</p>	 



Operation procedures	Illustrations
<p>10) Install the impeller (part 4) into the guide vane (part 12), and install the motor (part 32) shaft.</p> <p>&lt;&lt;Note&gt;&gt; Align the impeller mounting hole and the guide vane mounting hole, and fit the impeller, using caution not to let the tip of the impeller come in contact with the port ring (part 12b).</p>	

Operation procedures	Illustrations
<p>11) Install the long spacer sleeve (part 14), impeller (part 4), Shaft-end sleeve (part 19) and flat washer (part 31) in turn.</p>	 <p>Long spacer sleeve</p> <p>Impeller tip</p> <p>Impeller</p> <p>Shaft-end sleeve</p> <p>Flat washer</p>
<p>12) Tighten the nylon lock nut (part 20).</p>	 <p>Nylon lock nut</p>

Operation procedures	Illustrations
<p>13) To flatten the motor, insert the fixed piece into the central hole of the motor air hood to lock the horizontal groove at the end of the motor shaft, and use the torque wrench S13 to screw the nylon lock nut (part 20).</p> <p>&lt;&lt;Note&gt;&gt; Tightening torque: 11-13 N·m</p>	
<p>14) Erect the motor and mount the sealing gasket (part 17) on the guide vane (part 12) stop.</p> <p>&lt;&lt;Note&gt;&gt; Gasket light face down.</p>	
<p>15) Install them into the water inlet body (part 1).</p> <p>&lt;&lt;Note&gt;&gt; The plug hole on the side aligns with the water outlet hole on the water outlet body (part 7).</p>	
<p>16) Install four pull rods (part 11), screw the pull rod into the threaded hole of the motor (part 32). Install the spring washer (part 24), and tighten the hexagonal (part 25).</p>	 




Operation procedures	Illustrations
<p>17) The whole pump is placed horizontally and the plug assembly (part 2) is screwed into the water discharge hole and air discharge hole into the water inlet body (part 1).</p>	
<p>18) Use the horizontal ruler to put it on the outlet of the water outlet, and adjust the level of the outlet until the bubbles are located within two grids.                      &lt;&lt;Important&gt;&gt;                      Make sure bubbles are in the space between the two lines of the level.</p>	
<p>19) Tighten the hexagonal nut (part 25) with torque wrench.                      &lt;&lt;Note 1&gt;&gt;                      The rod screw should protrude by two to three threads after being tightened.                      &lt;&lt;Note 2&gt;&gt;                      Tightening torque: 11-13 N·m</p>	
<p>20) Tighten the plug assembly (part 2) with wrench S14.</p>	
<p>21) Use the horizontal ruler to place the horizontal ruler on the outlet of the water body and make sure that the horizontal ruler bubble is in the two-grid line.                      &lt;&lt;Important&gt;&gt;                      Make sure bubbles are located between the two lines of the level.</p>	

Operation procedures	Illustrations
<p>22) Check: Turn the nylon lock nut (part 20) of the water inlet with inner hexagonal sleeve S13 counterclockwise seen from the motor impeller end to check for free rotation without blockage.</p>	
<p>23) Paste the rotation sign on the center of the motor fan cover.</p>	





The water pump installation is completed.  
 Replace the O-RING on the JOINT along with the mechanical seal.

6. Common faults and solution

 Please cut off the power supply before removal of the motor junction box and dismantlement of the pump.

Fault	Cause	Solution	Remarks
When the operation is started, the motor does not start.	<ul style="list-style-type: none"> <li>a) Power failure</li> <li>b) Fuse is broken</li> <li>c) Motor is overloaded</li> <li>d) INV circuit board failure</li> <li>e) The control circuit is failed</li> </ul>	<ul style="list-style-type: none"> <li>a) Replace the power supply</li> <li>b) Replace the fuse</li> <li>c) Check the system</li> <li>d) Replace the INV circuit board</li> <li>e) Check the control circuit</li> </ul>	
Uneven water flow from the pump	<ul style="list-style-type: none"> <li>a) The water inlet pipe is too small</li> <li>b) No sufficient water at the pump inlet</li> <li>c) The liquid level is too low</li> <li>d) The inlet pressure is too small comparing with the water temperature, pipeline loss and flow</li> <li>e) The water inlet pipe is partially blocked by impurities</li> </ul>	<ul style="list-style-type: none"> <li>a) Increase the water inlet pipe diameter</li> <li>b) Improve the system, and try to increase the water volume</li> <li>c) Try to lift the liquid level</li> <li>d) Improve the system, and try to increase the outlet pressure</li> <li>e) Check and remove dirt</li> </ul>	
The pump is running but no water is pumped	<ul style="list-style-type: none"> <li>a) The water inlet pipe is blocked by impurities</li> <li>b) The bottom valve or check valve is at the Closed position</li> <li>c) The water inlet pipe leaks</li> <li>d) Air in the water inlet pipe or pump</li> </ul>	<ul style="list-style-type: none"> <li>a) Check and remove dirty</li> <li>b) Check the bottom valve and check valve</li> <li>c) Check and repair the water inlet pipe</li> <li>d) Re-fill water, and discharge air</li> </ul>	
After power-off, the pump is rotating in the reverse direction	<ul style="list-style-type: none"> <li>a) Water inlet pipe is leaked</li> <li>b) The bottom valve or check valve is failed</li> <li>c) The bottom valve is blocked at the open or partial open position</li> <li>d) Air pockets in the water inlet pipe</li> </ul>	<ul style="list-style-type: none"> <li>a) Check and repair the water inlet pipe</li> <li>b) Check and repair the bottom valve and check valve</li> <li>c) Check and repair the bottom valve</li> <li>d) Check and repair the water inlet pipeline and discharge air</li> </ul>	
Abnormal vibration and noise inside the pump	<ul style="list-style-type: none"> <li>a) Water inlet pipe is leaked</li> <li>b) The water inlet pipe is too small or is partially blocked by impurities</li> <li>c) Air in the water inlet pipe or pump</li> <li>d) The device head is lower than the pump head</li> <li>e) The mechanical parts of pump are connected</li> </ul>	<ul style="list-style-type: none"> <li>a) Check and repair the water inlet pipe</li> <li>b) Increase or check and repair the water inlet pipe</li> <li>c) Re-fill to exhaust air</li> <li>d) Improve the system or re-select</li> <li>e) Check and repair the pump</li> </ul>	Notes for item e): The pump must not be disassembled by the user.

### 8-15-10 JOINT Replacement Procedure (HBC)



Operation procedures	Illustrations
<p>1) Remove the JOINT.</p>	
<p>2) Remove the O-RING from the JOINT.</p> <p>The figure at right shows JOINT (IN). The same procedure applies to JOINT (OUT).</p>	
<p>3) Tape the thread of the JOINT not to damage the O-RING.</p> <p>4) Attach the O-RING.</p> <p>Make sure the O-RING is free of dust and dirt. Make sure the O-RING is not twisted.</p> <p>5) Reinstall the JOINT.</p> <p>Tighten the JOINT to a torque of 60 N·m.</p> <p>The figure at right shows JOINT (IN). The same procedure applies to JOINT (OUT).</p>	
<p>6) Remove the tape from the thread of the JOINT screw. Make sure the thread is clean.</p>	

### 8-15-11 Thermistor (TH31) Replacement Procedure (HBC)





8 Troubleshooting Based on Observed Symptoms



Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the two fixing screws from the service panel (front upper) and then remove the service panel (front upper).</li> <li>2) Remove the eight fixing screws from the service panel (front lower) and then remove the service panel (front lower).</li> <li>3) Disconnect all TH31 connectors from the control board.</li> <li>4) Unclamp the wires.</li> <li>5) Pull all TH31 thermistors out of the holders.</li> <li>6) Pull the wires out of the service panel (front upper).</li> <li>7) Insert the new thermistors, route the wire connectors from the service panel (front upper) side and into the control box, and reconnect the thermistors.</li> <li>8) Hold the new thermistors with the clamps mentioned in step 4) above.</li> </ol>		<p>Installation location</p>

### 8-15-12 Thermistors (TH12, TH14, TH15, and TH34) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location																																	
<p>1) Remove the eight fixing screws from the service panel (front lower) and then remove the service panel (front lower). Disconnect all wires from the circuit board except the power-supply wire, and open the control box.</p> <p>2) Remove the thermistor from the front of the unit and then replace it.</p> <p>3) Pull the thermistors to be replaced out of the thermistor holder, and unclamp the wires. Two thermistors are connected to the same connector. Disconnect both thermistors when one is replaced. Table below shows which thermistors are paired. It also shows the holder and wire label colors. See the figures at right for the locations of the thermistors.</p> <table border="1" data-bbox="156 913 564 1176"> <thead> <tr> <th colspan="5">TH pairs</th> </tr> <tr> <th>Number</th> <th>Color</th> <th>—</th> <th>Number</th> <th>Color</th> </tr> </thead> <tbody> <tr> <td>TH11</td> <td>White</td> <td rowspan="2">↔</td> <td>TH13</td> <td>Yellow</td> </tr> <tr> <td>TH12</td> <td>Red</td> <td>TH14</td> <td>Blue</td> </tr> <tr> <td>TH15</td> <td>Green</td> <td rowspan="2">↔</td> <td>TH16</td> <td>Red</td> </tr> <tr> <td>TH32</td> <td>Orange</td> <td>TH35</td> <td>Pink</td> </tr> <tr> <td>TH33</td> <td>Purple</td> <td></td> <td>TH34</td> <td>Black</td> </tr> </tbody> </table> <p>4) Replace the thermistors with the new ones, reconnect all connectors. Reconnect the wires, and close the control box.</p> <p>*Lift the bottom of the control box when closing the control box. Otherwise, the tab at the control box may become bent.</p>	TH pairs					Number	Color	—	Number	Color	TH11	White	↔	TH13	Yellow	TH12	Red	TH14	Blue	TH15	Green	↔	TH16	Red	TH32	Orange	TH35	Pink	TH33	Purple		TH34	Black	 <p>Control box</p> <p>Service panel (front lower)</p>  <p>TH13</p> <p>TH32</p> <p>TH33</p> <p>TH15</p> <p>TH16</p> <p>TH14</p> <p>TH12</p> <p>TH11</p> <p>TH35</p> <p>TH34</p>	<p>Installation location</p>
TH pairs																																			
Number	Color	—	Number	Color																															
TH11	White	↔	TH13	Yellow																															
TH12	Red		TH14	Blue																															
TH15	Green	↔	TH16	Red																															
TH32	Orange		TH35	Pink																															
TH33	Purple		TH34	Black																															

### 8-15-13 4-way Valve Body (21S4) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<p>«Note»</p> <ul style="list-style-type: none"> <li>•Protect the insulation materials in the periphery of the area to be brazed.</li> <li>•Replace the entire four-way valve assembly when only the four-way valve on one side needs replacement.</li> </ul>		<p>Installation location</p>
<ol style="list-style-type: none"> <li>1) Remove the service panel (lower panel).</li> <li>2) Collect the refrigerant.</li> <li>3) Disconnect all connectors from the control box except the connectors of the on-site wiring, and open the control box.</li> <li>4) Remove the pipe covers shown in the figure at right.</li> </ol>		
<ol style="list-style-type: none"> <li>5) Remove LEV3, SV1, and four-way valve coils. See sections [8-15-1 Solenoid Valve Coil (SV1) Replacement Procedure (HBC)] through [8-15-3 LEV Coils (LEV1, LEV2, LEV3) Replacement Procedure (HBC)] for details about the removal procedure.</li> <li>6) Remove the braze from the areas shown in the figure at right, and remove the SV1 ASSY.</li> </ol>		
<ol style="list-style-type: none"> <li>7) Remove the clamps and the rubber packing holding the four-way valve ASSY. (x2)</li> </ol>		





Operation procedures	Illustrations	Operation location
<p>8) Cut the pipes and remove the braze where indicated to remove the four-way valve ASSY from the unit.</p> <p>9) Pull the four-way valve ASSY out.</p>		<p>Installation location</p>
<p>10) Braze the supplied new pipe to the pipe on the unit where the pipes of the old four-way valve ASSY were cut out. See the figure at right for how to adjust the pipe length and braze the pipes.</p>	 <p>Braze the supplied pipe (expanded on one end) to the pipe on the unit, and cut the end of the pipe off so that the straight section of the pipe will be 110 mm.</p> <p>Braze the new pipe (expanded on both ends).</p>	
<p>11) Hold the new four-way ASSY in place with the clamps and the packing to the sheet metal, and braze the pipes.</p> <p>12) Re-place the pipe ASSY and the pipe covers as they were.</p>		













### 8-15-14 Plate Heat Exchanger Replacement Procedure (HBC)






Almost all pipes need to be removed from the unit to replace the plate heat exchanger. Because high skills are required to replace the plate heat exchanger, **the standard procedure is to replace the entire unit.** (Replacement of the plate heat exchanger will take about two days.)






8 Troubleshooting Based on Observed Symptoms






Operation procedures	Illustrations	Operation location
<p>«Note»</p> <ul style="list-style-type: none"> <li>•Remove the ASSY on the Cooling-main side first before replacing the one on the Heating-main side (even when the one on the Cooling-main side needs no replacement).</li> <li>•Protect the insulation materials in the periphery of the areas to be brazed.</li> <li>•Remove the caps from the replacement parts before installing (brazing) them on the unit.</li> </ul>	 <p style="text-align: center;">Replacement ASSY for the Heating-main side      Replacement ASSY for the Cooling-main side</p>	<p>Installation location</p>
<ol style="list-style-type: none"> <li>1) Remove the service panel (lower panel).</li> <li>2) Collect the refrigerant, and drain water through the pump.</li> <li>3) Disconnect all connectors from the control box including the connector of the power-supply wire. Completely unmount the control box from the unit.</li> </ol>	 <p style="text-align: center;">Control box      Service panel (lower panel)</p>	
<ol style="list-style-type: none"> <li>4) Remove all pipe covers from the pipes between the plate heat exchangers to prevent them from being damaged by heat.</li> <li>5) Remove the three LEV coils, one solenoid valve coil, and two four-way valve coils. (See sections [8-15-1 Solenoid Valve Coil (SV1) Replacement Procedure (HBC)] through [8-15-3 LEV Coils (LEV1, LEV2, LEV3) Replacement Procedure (HBC)] for details.)</li> </ol>	 <p style="text-align: center;">Remove all pipe covers from the pipes between the plate heat exchangers.</p>	
<ol style="list-style-type: none"> <li>6) Remove the three-way valve and the water pipes in its periphery. (Held in place with a clip)</li> </ol>	 <p style="text-align: center;">Clip</p> <p style="text-align: center;">Three-way valve      Remove      Remove</p>	






Operation procedures	Illustrations	Operation location
<p>7) Remove the spacers and the sheet metal near LEV1 and LEV2. Remove the braze from the areas where indicated in the figure at right, and pull out the SV1 and LEV ASSY.</p>		<p>Installation location</p>
<p>8) Remove the four-way valve ASSY from the unit. See steps 7 through 9 in section [8-15-13 4-way Valve Body (21S4) Replacement Procedure (HBC)] for details about the four-way valve ASSY.</p>		
<p>9) Remove the braze from the pipe that connects to the double-tube pipe. 10) Remove the water-pressure sensor (Pw2) shown in the figure at right. (See section [8-15-17 Water Pressure Sensor (PW1, 2, 4) Replacement Procedure (HBC)].)</p>		
<p>11) Remove the water pipe located behind the four-way valve fixing plate. (Held in place with a clip)</p>		
<p>12) Remove the four-way valve fixing plate (screwed down with two screws). 13) Remove the water-pressure sensors Pw2 and Pw4. See section for details about the removal procedure [8-15-17 Water Pressure Sensor (PW1, 2, 4) Replacement Procedure (HBC)].</p>		




Operation procedures	Illustrations	Operation location
<p>14) Remove the pipe with a protective valve from the fixing plate.                      Unclip the pipe located behind the Cooling-main plate heat exchanger that connects to the pipe explained above.                      The pipe only needs to be laid down and does not need to be taken out of the unit.</p>	 <p>Remove the parts holding the pipe.</p> <p>Unclip the pipe located behind the plate heat exchanger.</p>	<p>Installation location</p>
<p>15) Remove the braze from the pipe in front of the plate heat exchanger.</p>	 <p>Remove</p>	
<p>16) At this point, few parts are left between the Cooling-main and Heating-main plate heat exchangers as shown in the figure at right.</p> <p>Start by removing the Cooling-main side plate heat exchanger as explained below.                      *Remove the plate heat exchanger on the Cooling-main side first before replacing the one on the Heating-main side (even when the one on the Cooling-main side needs no replacement).</p>		
<p>17) Cut the pipe and remove the braze from the areas where indicated in the figure at right, and then remove the elbow.</p>	 <p>Cut the pipe here.</p> <p>Remove the elbow.</p>	
<p>18) Remove the Victaulic joint.</p> <p>«Removing the Victaulic joint»</p> <ol style="list-style-type: none"> <li>① Remove the terminal block cover (screwed down with two screws).</li> <li>② Remove the nuts from the Victaulic joint. (x2)</li> <li>③ Remove the separated Victaulic joint, and push the gasket inside to the pump side.</li> </ol>	 <p>① Remove the terminal block cover (screwed down with two screws).</p> <p>② Remove the nuts.</p> <p>③ Remove the separated Victaulic joint, and push the gasket inside to the pump side.</p> <p>④ Lower the gasket.</p>	

Operation procedures	Illustrations	Operation location
<p>19) Remove the nut by holding a spanner between the back of the plate heat exchanger and the side panel. (One nut in the front)</p>		<p>Installation location</p>
<p>20) Unscrew the screws on the plate heat exchanger fixing plate. (x3)</p>		
<p>21) Slide the plate heat exchanger forward so that the plate heat exchanger pipe and the pump port do not overlap.</p>		
<p>22) Remove the braze at the connection of the pipe, and pull out the lower section of the pipe.</p>		
<p>23) Slide the plate heat exchanger forward on the base plate to remove it.</p> <p>When replacing only the Cooling-main side plate heat exchanger, replace the plate heat exchanger, and connect the pipes by brazing them in the reverse order as they were removed.</p> <p>Explained below are the procedures for replacing the Heating-main side plate heat exchanger after removing the Cooling-main side plate heat exchanger.</p>		

Operation procedures	Illustrations	Operation location
<p>24) Remove the insulation material shown in the figure at right. Remove the braze from the double-tube pipe, the pipe with a pressure sensor, and the refrigerant circuit pipe of the plate heat exchanger.</p>		<p>Installation location</p>
<p>«Removing the Cooling-main side water pipe ASSY»                  25) Remove the clamps and the fixing plate (screwed down with two screws).                  26) Remove the Victaulic joint (held with two nuts), and slide the gasket in the Victaulic joint to the pump side.</p>		
<p>27) Remove the plate supporting the water pipe ASSY (screwed down with two screws) next to the pump.                  28) Remove the braze and the clips where indicated in the figure at right, and pull the water pipe ASSY out of the unit.</p>		
<p>29) Remove the six clips from the pipe at the upper part of the unit, and remove the pipe ASSY and the single pipe shown in the figure at right.</p>		
<p>30) Remove the braze where indicated in the figure at right, and remove the pipe ASSY out of the unit.</p>		


Operation procedures	Illustrations	Operation location
<p>31) Remove the nut by holding a spanner between the back of the plate heat exchanger and the side panel. (One nut in the front)</p>		<p>Installation location</p>
<p>32) Unscrew the screws from the plate heat exchanger fixing plate. (x3)</p>		
<p>33) Remove the Victaulic joint. See step 18 for how to remove the joint.</p>		
<p>34) Remove the nut from the sheet metal on the plate heat exchanger pipe side, and remove the sheet metal.</p>		
<p>35) As with the Cooling-main side, slide the plate heat exchanger forward so that the pipe on the plate heat exchanger and the pump port do not overlap. Then, remove the braze and pull out the pipe.</p>		

Operation procedures	Illustrations	Operation location
<p>36) Rotate the plate heat exchanger toward the back, and then pull it forward and out of the unit.</p> <p>37) Braze the new plate heat exchanger to the unit in the reverse order as it was removed.</p> <p>Points to note when re-placing the parts in the unit are explained below.</p>		<p>Installation location</p>
<p><b>1. Re-brazing the pipe that was removed in step 32</b></p> <p>Replace the <math>\phi 44.5</math> pipe (indicated with an arrow in the right figure) on the discharge-side pump ASSY of the plate heat exchanger with the supplied pipe.</p>		
<p><b>2. Timing of re-placing the terminal block cover</b></p> <p>Re-place the terminal block cover of the pump after installing the Victaulic joint.</p>		
<p><b>3. Brazing the pipe explained in step 30</b></p> <p>Before brazing the pipe, hold the pipe in place with clips to determine the angle of the pipe to be brazed.</p>		
<p><b>4. Brazing the double-tube pipe and the pipe with a sensor that were explained in step 24</b></p> <ul style="list-style-type: none"> <li>•Brazing the double-tube pipe at an angle shown in the figure at right.</li> <li>•Fix the pipe with a sensor on the sheet metal before brazing the pipe.</li> </ul>		


Operation procedures	Illustrations	Operation location
<p><b>5. The elbow that was removed and the pipe that was cut in step 17</b></p> <ul style="list-style-type: none"> <li>See the figure at right for the installation angle of the elbow. The swing angle against the T-joint on the plate heat exchanger: 0°</li> <li>Notes on the cut out pipe                     <ul style="list-style-type: none"> <li>«When replacing the Cooling-main side plate heat exchanger with a new one» No modification needs to be made to the new one.</li> <li>«When replacing only the plate heat exchanger on the Heating-main side, and continue using the one on the Cooling-main side» Remove the section of the pipe indicated in the figure at right from the plate heat exchanger on the Cooling-main side, and replace it with the one that is supplied with the new Heating-main plate heat exchanger.</li> </ul> </li> </ul>		<p>Installation location</p>
<p><b>6. The pipe that was removed in step 9</b></p> <p>Braze the pipe so that the straight section of the pipe will be parallel to the plate heat exchanger as shown in the figure at right.</p>		
<p><b>7. Four-way valve ASSY that was removed in step 8</b></p> <ul style="list-style-type: none"> <li>Refer to the figure at right when re-brazing the pipe section that was removed from the four-way valve ASSY.</li> <li>Refer to step 10 in section [8-15-13 4-way Valve Body (21S4) Replacement Procedure (HBC)] when reinstalling the four-way ASSY, which requires a replacement of the pipe.</li> </ul>		




**8-15-15 Pressure Sensor Replacement Procedure (HBC)**

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Collect the refrigerant.</li> <li>2) Remove the service panel (front lower).</li> <li>3) Disconnect all connectors except the connectors of the on-site wiring, and open the control box.</li> <li>4) Remove the pipe cover from the pipe with a sensor.</li> <li>5) Remove the braze from the pressure sensor, and replace the sensor.</li> </ol> <p>*Protect the insulation materials of the plate heat exchanger from heat damage before brazing.</p>		<p>Installation location</p>


**8-15-16 Pressure Sensor (PS3) Replacement Procedure (HBC)**

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Collect the refrigerant.</li> <li>2) Remove the service panel (front lower).</li> <li>3) Disconnect the connectors from the control box of the pressure sensor to be replaced.</li> <li>4) Free the wires from the clamps and the cable ties.</li> <li>5) Remove the braze from the pressure sensor, and replace the sensor.</li> </ol> <p>*Protect the insulation materials from heat damage before brazing.</p>		<p>Installation location</p>


### 8-15-17 Water Pressure Sensor (PW1, 2, 4) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the service panel (front lower).</li> <li>2) Drain water through the pump.</li> <li>3) Disconnect the connectors of the pressure sensor to be replaced, and release the wires from the clamps and the cable ties.</li> <li>4) Loosen the flare nut at the pressure sensor using two spanners, and remove the sensor.</li> <li>5) When installing a new sensor, tighten the nut using two spanners to a torque of 16 N·m.</li> <li>6) Reconnect the connectors.</li> </ol>		Installation location


### 8-15-18 Water Pressure Sensor (PW3) Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the service panel (front lower).</li> <li>2) Drain water through the pump.</li> <li>3) Disconnect all connectors except the connectors of the on-site wiring, and open the control box.</li> <li>4) Loosen the flare nut at the pressure sensor using two spanners, and remove the sensor.</li> <li>5) When installing a new sensor, tighten the nut using two spanners to a torque of 16 N·m.</li> <li>6) Reconnect the connectors.</li> </ol>		Installation location

### 8-15-19 Refrigerator Circuit Side Strainer Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Collect the refrigerant.</li> <li>2) Remove the service panel (front lower).</li> <li>3) Remove the pipe covers from the surrounding components to avoid heat damage.</li> <li>4) Remove the braze from the pipes, pull out the L-pipe, and replace the strainer inside.</li> <li>5) Re-braze the pipes.</li> </ol> <p>*Protect the resin part on the valve block from damage from the brazing torch flame.</p>		<p>Installation location</p>

### 8-15-20 Water Pressure Protection Valve Replacement Procedure (HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Remove the service panel (front lower).</li> <li>2) Drain water through the pump.</li> <li>3) Remove the cover plate from the storage water heater body protection valve.</li> <li>4) Unclip the clip, pull the storage water heater body up, and replace it with a new one.</li> <li>5) Reinstall the cover plate.</li> </ol>		<p>Installation location</p>

# 8-16 Sub-HBC Maintenance Instructions

## 8-16-1 Valve Block Assembly Replacement Procedur (Sub HBC)

Operation procedures	Illustrations	Operation location
<p>1) Drain water from the system, and move the unit out of the ceiling space.</p> <p>2) Unscrew all screws from the service panels (top, front, back, left), and remove the service panels.</p> <p>•Number of screws on the panels</p> <p>Service panel (right): 4                      Service panel (left): 6                      Service panel (top left): 2                      Service panel (top right): 2                      Service panel (front upper): 6                      Service panel (front lower): 4                      Service panel (front middle top): 5                      Service panel (front middle bottom): 5                      Service panel (side-left): 4</p> <p>3) Unscrew the control box fixing screws (x4), and remove the control box. Disconnect all wire connectors from the control box.</p> <p>4) Unscrew the float switch mounting screws (x2), and remove the float switch.</p> <p>5) Unscrew the screws (x14) on the right and left panels, lift the valve block by holding the hanging brackets, and remove the service panel (bottom) and the drain pan.</p>	<p>The illustrations show the following components being removed:</p> <ul style="list-style-type: none"> <li>Service panel (top left)</li> <li>Service panel (top right)</li> <li>Service panel (left)</li> <li>Control box</li> <li>Service panel (right)</li> <li>Service panel (front upper)</li> <li>Service panel (front middle top)</li> <li>Service panel (front lower)</li> <li>Service panel (side-left)</li> <li>Service panel (front middle bottom)</li> <li>Float switch</li> <li>Service panel (bottom)</li> <li>Drain pan</li> </ul>	<p>Under the ceiling</p>

8 Troubleshooting Based on Observed Symptoms



## 8-16-2 Thermistor (TH31) Replacement Procedure (Sub HBC)


Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Unscrew the fixing screws (x4) on the service panel (right), and remove the service panel (right).</li> <li>2) Unscrew the fixing screws (x2) on the service panel (top left), and remove the service panel (top left).</li> <li>3) Disconnect all TH31 connectors from the control board.</li> <li>4) Unscrew the fixing screws (x4) on the control box, and remove the control box. Disconnect all wiring connectors from the control box.</li> <li>5) Unscrew the fixing screws (x6) on the service panel (left), and remove the service panel (left).</li> <li>6) Release the thermistor wires from the clamps.</li> <li>7) Pull TH31 out of the top of the unit, and replace it with a new one.</li> </ol>		<p>Above the ceiling</p>

### 8-16-3 Thermistor (TH32, TH33) Replacement Procedur (Sub HBC)

8 Troubleshooting Based on Observed Symptoms

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Unscrew the fixing screws (x4) on the service panel (right), and remove the service panel (right).</li> <li>2) Unscrew the fixing screws (x2) on the service panel (top right), and remove the service panel (top right).</li> <li>3) Unscrew the fixing screws (x2) on the service panel (top left), and remove the service panel (top left).</li> <li>4) Disconnect the connectors of the thermistors to be replaced from the control board.</li> <li>5) Release the thermistor wires from the clamps.</li> <li>6) Cut the cable ties shown in the figure to release the thermistor wires.</li> <li>7) Remove the thermistors from the top of the unit.</li> </ol>		<p>Above the ceiling</p>

### 8-16-4 Air Vent Valve Replacement Procedure (Sub HBC)

Operation procedures	Illustrations	Operation location
<ol style="list-style-type: none"> <li>1) Unscrew the fixing screws (x4) on the service panel (right), and remove the service panel (right).</li> <li>2) Cut the cable tie that is holding the PVC tube.</li> <li>3) Release the clamp that is holding the pipes with the air vent valve from the metal plate.</li> <li>4) Loosen the flare nut using a spanner, and replace the air vent valves with new ones (service parts).</li> <li>5) Hold the PVC tube with a cable tie as it was. *To prevent the PVC tube from moving when the valve is opened.</li> <li>6) Perform air vent operation.</li> </ol>	 <p>The illustrations show the internal components of the Sub HBC unit. The top diagram shows the air vent valve assembly with labels for 'Air vent valve', 'Cable tie', and 'Service panel (right)'. The bottom diagram shows a replacement 'Air vent valve (service parts)' which is a curved white PVC tube with a black cap.</p>	<p>Above the ceiling</p>



## 8-17 Troubleshooting Problems Using the LED Status Indicators on the Outdoor Unit

If the LED error display appear as follows while all the SW4 switches and SW6-10 are set to OFF, check the items under the applicable item numbers below.

### 1. Error code appears on the LED display.

Refer to the following page(s). [7-1 Error Code and Preliminary Error Code Lists]

### 2. LED is blank.

Take the following troubleshooting steps.

- (1) Refer to the section on troubleshooting the transmission power supply circuit, if the voltage across pins 1 through 2 of CN600 on the control panel is outside the range between 8 VDC and 12 VDC. [8-11-2 Troubleshooting Problems with Outdoor Unit Transmission Power Supply Circuit]
- (2) If the LED error display becomes lit when the power is turned on with all the connectors on the control board except CN600 disconnected, there is a problem with the wiring to those connectors or with the connectors themselves.
- (3) If nothing appears on the display under item (2) above AND the voltage between pins 1 and 2 of CN600 is within the range between 8 VDC and 12 VDC, control board failure is suspected.

### 3. Only the software version appears on the LED display.

- (1) Only the software version appears while the transmission cables to TB3 and TB7 are disconnected.

- 1) Wiring failure between the control board and PS board. (CN62, CNPS, CNIT, CNS2, CN102)
- 2) If item 1) checks out OK, the transmission line power supply board failure is suspected.
- 3) If items 1) and 2) check out OK, control board failure is suspected.

- (2) If the LED shows the same display as the initial display upon disconnection of transmission lines (TB3, TB7), there is a problem with the transmission lines or with the connected devices. [10-1-2 Initial LED Display]

---

## Chapter 9 USB Function

<b>9-1</b>	<b>Service Overview .....</b>	<b>1</b>
9-1-1	Function Overview .....	1
9-1-2	System Structure .....	2
9-1-3	Necessary Materials .....	3
<b>9-2</b>	<b>Operation Data Collection and Storage Functions (Outdoor unit).....</b>	<b>4</b>
9-2-1	Preparation .....	4
9-2-2	Storing Data on a USB Memory Stick.....	4
9-2-3	Collecting Operation Data.....	6
9-2-4	Precautions .....	7
<b>9-3</b>	<b>Software Rewrite Function on the USB (Outdoor unit, HBC) .....</b>	<b>8</b>
9-3-1	Preparation .....	8
9-3-2	Rewriting Software.....	8
9-3-3	Precautions .....	9
<b>9-4</b>	<b>Maintenance LED Display and Troubleshooting .....</b>	<b>10</b>
9-4-1	Maintenance LED Display Content List .....	10
9-4-2	Troubleshooting .....	13



---

## 9-1 Service Overview

---

### 9-1-1 Function Overview

---

---

The control board has a USB port that allows the use of the following two functions.

#### 1. Collection and storage of operation data (Outdoor unit)

Operation information from indoor units, outdoor units, and other equipment and devices in the system are collected and stored in the flash memory in the control board of the outdoor unit (OC).

The data can be transferred and stored in a USB memory stick.

- Operation data in the multiple-outdoor-unit system will be saved on the OC unit.
- Attempting to collect the operation data from the OS unit will result in an error.

#### 2. Software rewrite function (Outdoor unit, HBC)


The software on outdoor units and HBC can be rewritten using a USB memory stick.

For detailed information about each function, refer to Section [9-2 Operation Data Collection and Storage Functions (Outdoor unit)] and Section [9-3 Software Rewrite Function on the USB (Outdoor unit, HBC)].


For information regarding the maintenance LED display content and regarding troubleshooting, refer to Section [9-4 Maintenance LED Display and Troubleshooting].

## 9-1-2 System Structure

### (1) Control board on the outdoor unit



## (2) Control board on the HBC



### 9-1-3 Necessary Materials

The use of the USB function requires a USB memory stick and a portable battery charger. See below for the types of USB memory stick and portable charger that can be used.

#### (1) USB memory stick

Use a USB memory stick that meets the following specifications.

- USB 2.0 compatible
- Formatted in FAT 32
- Without a security function

#### (2) Portable battery charger

Use a portable battery charger that meets the following specifications for rewriting the software.

- USB 2.0 compatible
- Voltage and amperage rating of 5 V and 2.1 A (MAX)
- Supports the energy-saving mode  
A battery charger not compatible with the energy-saving mode may turn off while the data are being collected or while the S/W is being re-written, and these actions may not be completed successfully.

A LEAD WIRE ASSY USB is required to connect the control board and the portable charger.

Use a cable that meets the following specifications.

- [Type A male] - [Male XA connector for the PCB] USB cable. For details of “LEAD WIRE ASSY USB”, please contact the sales office.

The connector on the control board side is a female XA connector for the PCB.

## 9-2 Operation Data Collection and Storage Functions (Outdoor unit)

Operation data of the units collected on the outdoor unit can be recorded in the flash memory of the control board. These data can also be exported to and recorded in a USB memory stick.

See Section [9-2-2 Storing Data on a USB Memory Stick] for information on storing data on a USB memory stick.

See Section [9-2-3 Collecting Operation Data] for information on the collection of operation data.

### 9-2-1 Preparation

A USB memory stick and a portable battery charger are required to store data on a USB memory stick (not supplied). Prepare a USB memory stick and a portable battery charger as described in Section [9-1-3 Necessary Materials].

### 9-2-2 Storing Data on a USB Memory Stick

Store operation data recorded in the flash memory on the control board in a USB memory stick.

The content of the stored file can be confirmed using the maintenance tool.

Operation data should be stored in a dedicated mode (Store Mode).

#### 1. Procedure

##### (1) Preparation of a USB memory stick

- 1) Since the size of the saved file containing operation data is 50 MB, prepare a USB memory stick with 50 MB or more available memory. A USB memory stick which has other data in it may also be used. However, it is recommended to clear the remaining data in advance to prevent any malfunctions. The saved file is named "MNTXXX.MT." XXX represents a serial number from 000 to 100. Since files named "MNT101.MT" or more cannot be created, unnecessary folders and files should be deleted.

##### (2) Storing data on a USB memory stick

Data can be stored to a USB memory stick either with the main power to the outdoor unit (OC) turned on (Method 2) or off (Method 1). For safety reasons, it is recommended to store the data on a USB memory stick with the main power to the outdoor unit (OC) turned off (Method 1). If turning off the power is not feasible, take appropriate measures to ensure safety.

#### [Method 1 (recommended)] Storing data on a USB memory stick with the main power to the outdoor unit (OC) turned off

##### <Starting up the unit in the data storage mode>

- Turn off the main power to the outdoor unit (OC).
- Connect a USB memory stick to the USB port (CNUSB) on the control board.
- With SWP3 (ENTER) being held down, connect the portable battery charger to the XA connector (CN601) for the PCB, and supply power to the control board. Wait for five seconds until the USB memory stick is recognized.
- [USB] will appear on the monitoring LED301. If "USB" does not appear, refer to Section 1.(1) in [9-4-2 Troubleshooting].



- When [USB] has appeared on the LED, lift the finger off SWP3 (ENTER). The unit is now in the data storage mode.

##### <Storing data>

- Press SWP3 (ENTER). If the data storage process has properly started, the progress (0-99) will be shown on the monitoring LED 301.
- [End] on the LED indicates successful completion of the data storage process.
- \*It takes approximately five minutes for the data storage process to be completed.



**<Ending the data storage mode>**

- When done storing data, disconnect the portable battery charger from the control board.
- Then disconnect the USB memory stick from the control board.
- Turn the main power to the outdoor unit (OC) back on.
- If the data collection process needs to be started, check the operation data collection status by following the procedures explained in [9-2-3 Collecting Operation Data] and making the necessary settings.

**[Method 2] Storing data on a USB memory stick with the main power to the outdoor unit (OC) turned on**

**<Starting up the unit in the data storage mode>**

- Stop the operation of all indoor units.  
\*Although operation data can be collected without stopping all indoor units, doing so may be detected as a communication error.
- Connect a USB memory stick to the USB port (CNUSB) on the control board of the outdoor unit (OC).
- Press and hold SWP3 (ENTER) for approximately 10 seconds until [USB] appears on the monitoring LED 301.



- When [USB] has appeared on the LED, lift the finger off SWP3 (ENTER).  
The unit is now in the data storage mode.

**<Storing data>**

- Press SWP3 (ENTER). If the data storage process has properly started, the progress (0-99) will be shown on the monitoring LED 301.
- [End] on the LED indicates successful completion of the data storage process.  
\*It takes approximately five minutes for the data storage process to be completed.



**<Ending the data storage mode>**

- When done storing data, disconnect the USB memory stick from the control board.
- Press and hold SWP3 (ENTER) for approximately 10 seconds until [End] disappears from the monitoring LED 301.
- Restart the indoor and outdoor units (OC) that were stopped to perform data storage.
- If the data collection process needs to be started, check the operation data collection status by following the procedures explained in [9-2-3 Collecting Operation Data] and making the necessary settings.

**(3) Confirmation of stored file**

Confirm that the operation data is stored in the USB memory stick. Insert the USB memory stick into a computer, and check the contents in the memory stick.

Check that there is the following file in the memory stick.

File: MNTXXX.MT

“XXX” represents serial numbers from “000” to “100.”



### 9-2-3 Collecting Operation Data

This function is used to collect the operation data of the outdoor and indoor units via M-NET, and record the data in the flash memory on the control board. When the memory is full, it is overwritten from the first segment.

The settings for checking the status of operation data collection, for starting/ending data collection, and for continuing/stopping error-data collection are made, using the switches on the control board. The items to be set are shown in the table below. The data collection setting is enabled by default, and the setting for error data collection during an error is disabled by default.

Switch			Function	Operation set by the switch		Timing for switch operation	Unit for setting
SW6-10	SW4 (0: OFF, 1: ON)			OFF (LED3 OFF)	ON (LED3 ON)		
OFF	NO.28	00111000000	Data being collected	-	-	Anytime after power-on	OC setting necessary
ON	NO.817	10001100110	Data collection enabled	Enabled	Disabled	Anytime after power-on	OC setting necessary
ON	NO.818	01001100110	Data collection during an error	Disabled	Enabled	Anytime after power-on	OC setting necessary

\*When setting the switch SW4 on the control board, make sure the outdoor unit is energized. Also use Section [5-1 Dipswitch Functions and Factory Settings] as a reference.

The procedure for making the operation data settings is shown below.

#### 1. Operation procedure

##### (1) Status Confirmation

- 1) Confirm the current status of operation data collection by setting the switches on the control board following the table shown above.

Switch setting: SW6-10: OFF

SW4: 28

Check the status on the maintenance LED display (LED301).

\* For details, refer to Section [9-4-1 Maintenance LED Display Content List]

- When “ON” or “OFF” is displayed, go to step (2) and the later steps.
- When “Err” is displayed, go to step (3) and the later steps.
- When “F-Er” is displayed, it indicates an error in the flash memory on the control board. Refer to Section [9-4-2 Troubleshooting]

##### (2) Setting Start and End of data collection

- 1) Set the switches on the control board by following the table shown above.

Switch setting: SW6-10: ON

SW4: 817

- 2) Press SWP3 (ENTER). With each switch operation, the setting can be alternately switched ON and OFF.

- 3) After conducting step (1), check that the operating condition is stable.

Data collection start: OFF (Enabled)

Data collection end: ON (Disabled)

Setting procedure is now complete.

##### (3) Settings for error-data collection during an error

Stops or continues error-data collection when an error occurs.

- 1) Referring to the table above, set the control switches.

Switch setting: SW6-10: ON

SW4: 818

Stop collecting error-data when an error occurs: OFF

Continue collecting error-data when an error occurs: ON

- 2) To set the switches, press SWP3 (ENTER). Each pressing of SWP3 (ENTER) toggles between ON and OFF. Error data in the 6000's and the 7000's will be collected, regardless of the SW4 (818) settings.

##### (4) Restarting data collection

- 1) If “Err” is shown, it indicates that data collection is being suspended for some reason, even though data collection is enabled. To restart, it is necessary to set the switches on the control board. Referring to (2)-1) and (2)-2), set the switches on the control board from OFF (original setting) to ON, and then to OFF again, and make sure the switches settings are indicated as being ON, following the instructions in (1)-1).

## 9-2-4 Precautions

---

For dealing with display on the maintenance LED and other problems, refer to Section [9-4 Maintenance LED Display and Troubleshooting].

### 1. Storage of data in a USB memory stick

- Take extra care regarding electric shock during the work on the control board, such as the insertion of the USB memory stick.
- Before starting in Normal Mode, remove the USB memory stick from the control board.
- Storing data in the USB memory stick may take a long time resulting in OS and communication errors. These errors affect neither storing process nor unit operation. If an error occurs, refer to [9-4-2 Troubleshooting].
- After normal startup, set the operation status of the air-conditioning units to the original status.
- USB memory sticks may become unusable due to unexpected damage or memory shortage. It is recommended to take extra USB memory sticks to the site.
- If only the OS is operated due to problems with the OC, collect data also from the OS by following the same operation procedure as for OC. Refer to Section [9-2-2 Storing Data on a USB Memory Stick].

### 2. Collection of operation data

- The collection of operation data does not start immediately after power-on, but does after ten minutes.
- When the operation data are being collected from AE-200 or the Maintenance Tool, the function to collect outdoor unit (OC) data with a USB memory stick will not be available for use.

## 9-3 Software Rewrite Function on the USB (Outdoor unit, HBC)

The USB memory stick may be used to rewrite the software of the outdoor unit and the HBC in the same way as using a ROM writer.

### 9-3-1 Preparation

- Prepare a USB memory stick and a portable battery charger.  
A LEAD WIRE ASSY USB for connecting the control board and the charger is also necessary.  
Make sure the portable battery charger is sufficiently charged.
- Prepare a countermeasure program file "\*\*\*\*\*.mot" for the intended model.
- Copy the software rewrite program file "\*\*\*\*\*.mot" onto the root folder of the USB memory stick.  
Install only one program and only in the root folder of the USB memory stick.

### 9-3-2 Rewriting Software

The procedure is shown below.

#### 1. Operation procedure

##### (1) Starting software rewrite mode

###### [Outdoor unit]

- 1) Shut down the power for the outdoor unit. Make sure the power for the control board of the outdoor unit is off.  
This is done by confirming LED2 is off.
- 2) Turn on switches SW7-9 of the control board of the outdoor unit.
- 3) Insert the USB memory stick into the USB port (CNUSB) on the control board of the outdoor unit.
- 4) Connect the portable battery charger to CN601 on the control board of the outdoor unit.  
The power of the control board of the outdoor unit will turn on. Wait for five seconds until the USB memory stick is recognized.
- 5) Make sure the display "Pro" is shown on the maintenance LED (LED301)  
This shows that Software Rewrite Mode has been started.

###### [HBC]


- 1) Shut down the power for the outdoor unit and the HBC. Make sure the power for the HBC control board is off.  
This is done by confirming that LED (LD001) will not light up when SWP1 is pressed.
- 2) Turn on switches SW002-9 of the HBC control board.
- 3) Insert the USB memory stick into the USB port (CNUSB) on the HBC control board.
- 4) Connect the portable battery charger to the CN703 of the HBC control board. The power of the HBC control board will turn on.
- 5) Make sure the display "Pro" is shown on the maintenance LED (LD001)  
This shows that Software Rewrite Mode has been started.



##### (2) Performing software rewriting

###### [Outdoor unit, HBC]

- 1) Wait for 5 seconds after "Pro" appeared on the LED, and press SWP3 (ENTER) to start software rewrite.  
When the rewrite process is in progress, progress bars move as shown below.



- 2) If "End" is displayed on the LED, the rewrite process has been completed correctly. \* Generally, this process takes about five minutes.



### (3) Confirmation of operation

#### [Outdoor unit]

- 1) Disconnect the portable battery charger from CN601 on the control board of the outdoor unit. The control board of the outdoor unit will be turned off.
- 2) Remove the USB memory stick from the USB port (CNUSB) on the control board of the outdoor unit.
- 3) Turn off the switches SW7-9 on the control board of the outdoor unit.
- 4) Turn on the outdoor unit, and check that the versions of the outdoor unit and the software are the same.  
The version of the software may be found using the maintenance tool or other means.  
Perform a test run, and check for normal operation.

#### [HBC]

- 1) Disconnect the portable battery charger from CN703 on the HBC control board. The control board of the HBC will be turned off.
- 2) Remove the USB memory stick from the USB port (CNUSB) on the control board of the outdoor unit.
- 3) Turn off the switches SW002-9 on the HBC control board.
- 4) Turn on the HBC, and check that the versions of the HBC and the software are the same.  
The version of the software may be found using the Maintenance Tool or other means.  
Perform a test run, and check for normal operation.

### 9-3-3 Precautions

---

For dealing with the displays shown on the maintenance LED and other problems, refer to Section [9-4 Maintenance LED Display and Troubleshooting]

- Take care to choose the correct countermeasure program for the intended model and version.  
Store only one software rewrite program on the USB memory stick.  
If this requirement is not met, software rewrite may not start.
- Be cautious of electric shock when connecting an USB memory stick or a portable battery charger to the control board.
- Connect the portable battery charger to the LEAD WIRE ASSY USB and then to the control board.
- Use a portable charger that supports the energy-saving mode.
- Make sure the portable battery charger is sufficiently charged. Rewrite error may occur if battery charge is insufficient.
- Take care not to forget to remove the USB memory stick in step (3) - 2) or forget to turn off the switch in step (3) - 3). [9-3-2 Rewriting Software] If these precautions are not taken, the system may not start normally.
- When rewriting ended unsuccessfully, redo the procedure from step (1) - 3). [9-3-2 Rewriting Software]When rewriting ended unsuccessfully, the system may be started in Software Rewrite Mode instead of using the switches on the control board.  
Also refer to Section [9-4-2 Troubleshooting].
- If software cannot be successfully rewritten using an USB memory stick, use a ROM writer to rewrite the software.
- A battery charger not compatible with the energy-saving mode may turn off while the data are being collected or while the S/W is being re-written, and these actions may not be completed successfully.

## 9-4 Maintenance LED Display and Troubleshooting

### 9-4-1 Maintenance LED Display Content List

The following table shows the maintenance LED displays for each function.  
When dealing with the errors shown on the display, refer to Section [9-4-2 Troubleshooting]

#### 1. Storing data on a USB memory stick (Outdoor unit)

No.	Switch	Meaning	Maintenance LED Display	Description
1	Not applicable	Storage Mode activated	U S b	"USB" Storage Mode to USB memory stick is active. Storage is enabled. See Section [9-4-2 Troubleshooting]1-(1) and 1- (2).
2		Storage in progress	0 ~ 99	0 to 99 is displayed. Status of the data storage to the USB memory stick is shown by the progress rate.
3		Storage completed	End	"END" The storage process has been completed successfully.
4		Error (USB memory side)	Er01	"Er01" The storage process cannot be started due to failure of the USB memory stick. See Section [9-4-2 Troubleshooting]1- (3).
			Er02	"Er02" The storage process was stopped due to failure of the USB memory stick during processing. See Section [9-4-2 Troubleshooting]1- (4).
5	Error (control board side)	Er10	"Er10" The storage process cannot be started due to failure of the control board. See Section [9-4-2 Troubleshooting]1- (5).	

## 2. Collecting operation data (Outdoor unit)

No.	Switch	Meaning	Maintenance LED Display	Description
6	SW6-10: OFF SW4: No.28	Collection in progress		"ON" OC is collecting operation data. A blinking display indicates that data collection is temporarily suspended. No switch setting is necessary. Data collection will be resumed automatically. See Section [9-4-2 Troubleshooting]2-(1).
7		Collection suspended		"OFF" Collection of operation data is suspended.
8		Flash memory error		"F-Er" Collection of operation data is suspended due to failure in the flash memory used to store operation data. It may be necessary to change the board. See Section [9-4-2 Troubleshooting]2-(2).
9		Error		"Err" Error was found due to the failure in units. After addressing the cause, data collection needs to be restated. See Section [9-4-2 Troubleshooting]2- (3).

- Collect data from both OC and OS from multiple-outdoor unit systems. System operation data are stored on OC, and compressor operation time of OS and switch settings are stored on OS.
- When importing the OS data to the Maintenance Tool, an import error may appear. This error indicates that no data are available for import and does not indicate equipment failure.

### 3. Rewriting software (Outdoor unit, HBC)

No.	Switch	Meaning	Maintenance LED Display	Description
10	[Outdoor unit] SW7-9: ON [HBC] SW 002-9: ON	Rewrite Mode activated		"PRO" Software rewrite mode is active. Software rewrite is enabled. See Section [9-4-2 Troubleshooting]3-(1), 3-(2) and 3- (3).
11		Rewrite in progress		Software rewrite is in progress. Bars are displayed in turn.
12		Software rewrite has been completed.		"END" Software rewrite has been completed successfully.
13		Error (USB memory side)		"Er01" Software rewrite process cannot be started due to failure of the USB memory stick. See Section [9-4-2 Troubleshooting]3- (4).
				"Er02" Software rewrite was stopped due to failure of the USB memory stick during the software rewrite process. See Section [9-4-2 Troubleshooting]3- (5).
14		Error (control board side)		"Er10" Software rewrite was not completed due to failure in deleting the existing software. See Section [9-4-2 Troubleshooting]3- (6).
				"Er11" Software rewrite has not been completed due to failure in writing new software. See Section [9-4-2 Troubleshooting]3- (6).

## 9-4-2 Troubleshooting

Troubleshooting of USB functions are shown below.

The displays on the maintenance LED described in Section [9-4-1 Maintenance LED Display Content List] may also be used as a reference.

### 1. Storing on a USB memory stick (outdoor unit)

#### (1) Maintenance LED does not display "USB."

(Meaning or Cause)

The system was not started in Storage Mode.

The USB memory stick is not connected. Or, switch SWP3 may not be pressed deeply enough.

(Solution)

Check the connection of the USB memory stick, and try again using Section [9-2-2 Storing Data on a USB Memory Stick] as a reference.

Hold down the switch SWP3 until "USB" is displayed on the maintenance LED.

If the problem persists, there may be a problem with the USB memory stick.

Check if the USB memory stick meets the specification described in Section [9-1-3 Necessary Materials](1) USB memory stick.

If compliance is confirmed, the USB memory stick may be broken. Replace it with a new one.

#### (2) Pressing the switch SWP3 does not start data storage, and the maintenance LED continues to display "USB."

(Meaning or Cause)

There may be a problem with the USB memory stick.

(Solution)

Check the connection of the USB memory stick.

If no problem is found, the USB memory stick may be at fault.

Check that the USB memory stick meets the specification described in Section [9-1-3 Necessary Materials](1) USB memory stick.

If compliance is confirmed, the USB memory stick may be broken. Replace it with a new one.

#### (3) Maintenance LED displays "Er01."

(Meaning or Cause)

- Because there was a problem regarding the USB memory before the start of data storage, data storage has not been completed.

- Error Er01 occurs when SWP3 on the control board is pressed to rewrite the software immediately after power is supplied to the USB-connected control board.

(When the software rewriting is started before the control board recognizes the USB memory stick.)

(Solution)

Check the connection of the USB memory stick.

If no problem is found, the USB memory stick may be at fault.

Check the following four items.

- After supplying power to the USB-connected control board, wait at least five seconds before pressing SWP3 on the control board to rewrite software because it takes approximately five seconds for the control board to recognize the USB memory stick.

- Compliance of the USB memory stick to the specification described in Section [9-1-3 Necessary Materials](1) USB memory stick.

- Available free space of the USB memory stick exceeding 50 MB.

- The maximum number of folders or files is not exceeded. When files are created in the USB memory stick, the upper limit of files is 101, including those files from "MNT000.MT" to "MNT100.MT."

Delete unnecessary folders or files.

When there is no problem in the four items above, the USB memory stick may be broken. Replace it with a new one.

#### (4) Maintenance LED displays "Er02."

(Meaning or Cause)

Because there was a problem regarding the USB memory during data storage, data storage is unfinished.

For example, if the USB memory stick is disconnected during data storage, this display appears on the maintenance LED.

(Solution)

Check the connection of the USB memory stick.

If no problem was found, remove the USB memory stick from the control board and insert it again. Then conduct data storage referring to Section [9-2-2 Storing Data on a USB Memory Stick].



**(5) Maintenance LED displays "Er10."**

(Meaning or Cause)

Because there was a problem regarding the control board during data storage, data storage is unfinished.

(Solution)

Perform data storage again.

Remove the USB memory stick from the control board and insert it again. Then conduct data storage using Section [9-2-2 Storing Data on a USB Memory Stick] as a reference.

If this still does not correct the problem, there may be a problem with the control board.

**(6) System does not start in Normal Mode.**

(Meaning or Cause)

The USB memory stick may be left connected.

(Solution)

Remove the USB memory stick from the control board by referring to <Ending the data storage mode> under Section [9-2-2 Storing Data on a USB Memory Stick]. Then press SWP3 (ENTER). If the problem is not resolved, turn off the power to the outdoor unit, and restart the unit.

**(7) Unit cannot be started in the data storage mode.**

(Meaning or Cause)

There may be problems with the control board.

(Solution)

Take the two measures 1 and 2 explained in (2) Storing data on a USB memory stick in 1 Procedure under [9-2-2 Storing Data on a USB Memory Stick].

If the unit cannot be started up in the data storage mode by following either of the two methods 1 or 2, the control board may be malfunctioning.

**2. Collecting operation data (outdoor unit)**

**(1) Maintenance LED displays blinking "ON."**

(Meaning or Cause)

Despite data collection function being enabled, it is not started yet.

There may be two causes.

Firstly, the initialization process immediately after the system startup may have inhibited the start of data collection.

Secondly, M-NET communication may be underway to enable maintenance tools or collect AE-200 logs.

(Solution)

After a certain time, the problem will resolve itself, requiring no corrective actions.

**(2) Maintenance LED displays "F-Er."**

(Meaning or Cause)

Because there was a problem with the flash memory used to store operation data, the collection of operation data is unfinished.

(Solution)

Restart the outdoor unit, check the status of data collection.

If the LED displays "F-Er," the flash memory may be broken.

Depending on the local conditions, replace the control board.

When the flash memory is not working correctly, data collection and storage to a memory stick cannot be performed, but the outdoor unit itself functions normally.

**(3) Maintenance LED displays blinking "Err."**

(Meaning or Cause)

An error occurred in the unit, suspending data collection.

(Solution)

After resolving the error, resume data collection, referring to 1. Operation procedure (4) Restarting data collection under Section [9-2-3 Collecting Operation Data].

### 3. Rewriting software (outdoor unit/HBC)

#### (1) Maintenance LED does not display "Pro."

(Meaning or Cause)

- The system is not started in Software Rewrite Mode.  
Switches (outdoor unit: SW7-9; HBC: SW002-9) on the control board may not be in the ON position, or the portable charger may not be charged sufficiently.
- Power-supply units (outdoor units/power-supply expansion unit) may not be turned off.  
\*Applicable only when rewriting the S/W of the HBC.

(Solution)

- Make sure switches are ON using Section [9-3-2 Rewriting Software] as a reference.  
Restart using a fully charged portable charger or a different charger.
- Check that the power-supply units (outdoor units/power-supply expansion unit) are turned off.

#### (2) Pressing the switch (SWP3) for starting the rewriting process does not start the process, and Maintenance LED continues to display "Pro."

(Meaning or Cause)

There may be a problem with the USB memory stick.

(Solution)

Check the connection of the USB memory stick.

If no problem is found, the USB memory stick may be at fault.

Check if the USB memory stick meets the specification described in Section [9-1-3 Necessary Materials](1) USB memory stick.

If compliance is confirmed, the USB memory stick may be broken. Replace it with a new one.

#### (3) At the time of the system start after "END" was displayed, Maintenance LED displays "Pro."

(Meaning or Cause)

The system was started in Software Rewrite Mode.

Switches (outdoor unit: SW7-9; HBC: SW002-9) on the control board may not be in the OFF position.

If the switches are in the OFF position, it means the software rewrite process has failed.

(Solution)

After turning off control board switches, turn on the system again.

If the switches are in the OFF position, it means the software rewrite process has failed.

Try rewriting the software again by following the procedure detailed in Section [9-3-2 Rewriting Software]. If the problem persists, rewrite the software, using a ROM writer.

#### (4) Maintenance LED displays "Er01."

(Meaning or Cause)

- Because an error occurred in the USB memory stick before the start of software rewrite, software rewrite has not been completed.
- Error Er01 occurs when SWP3 on the control board is pressed to rewrite the software immediately after power is supplied to the USB-connected control board.  
(When the software rewriting is started before the control board recognizes the USB memory stick.)

(Solution)

Check the connection of the USB memory stick.

If no problem is found, the USB memory stick may be at fault.

Check the following five items.

- After supplying power to the USB-connected control board, wait at least five seconds before pressing SWP3 on the control board to rewrite software because it takes approximately five seconds for the control board to recognize the USB memory stick.
- Compliance of the USB memory stick to the specification of Section [9-1-3 Necessary Materials](1) USB memory stick.
- The countermeasure program file "\*\*\*\*\*.mot" for the intended model is used.  
The countermeasure program is not for a different model or version.
- The countermeasure program file "\*\*\*\*\*.mot" is stored in the root folder. It is not stored in another folder.
- Make sure that the program file "\*\*\*\*\*.mot" is stored in the root folder of the USB memory and not in any folder created on the USB memory stick.

When there is no problem in the five items above, the USB memory stick may be broken. Replace it with a new one. After the check is completed, follow the procedure starting with the step explained in under [9-3-2 Rewriting Software].

**(5) Maintenance LED displays "Er02."**

(Meaning or Cause)

Software rewrite is suspended due to a problem with the USB memory stick during the software rewrite process. For example, if the USB memory stick is disconnected during data storage, this display appears on the maintenance LED.

(Solution)

Check the connection of the USB memory stick.

If no problems are found, follow the procedure starting with the step explained in 1. Operation procedure (1) Starting software rewrite mode under [9-3-2 Rewriting Software].

**(6) Maintenance LED displays "Er10" or "Er11."**

(Meaning or Cause)

Because there was a problem in the control board during the software rewrite process, software rewrite has not been completed.

(Solution)

Try rewriting the software again by following the procedure detailed in 1. Operation procedure (1) Starting software rewrite mode under Section [9-3-2 Rewriting Software]. If the problem persists, rewrite the software, using a ROM writer.

**(7) Service monitor LED lights off while the S/W is being re-written, and the process cannot be completed.**

(Meaning or Cause)

The re-writing process may not have been completed due to a power-supply interruption from the battery charger.

(Solution)

- Make sure the battery charger is compatible with the low-current mode.
- If a battery charger that is compatible with the low-current mode is not available, re-write the S/W using a ROM writer.

---

## Chapter 10 LED Status Indicators


<b>10-1</b>	<b>LED Status Indicators (Outdoor unit)</b> .....	<b>1</b>
10-1-1	How to Read the LED .....	1
10-1-2	Initial LED Display .....	2
10-1-3	Clock Memory Function .....	3
<b>10-2</b>	<b>LED Status Indicators (HBC)</b> .....	<b>4</b>
10-2-1	How to Read the LED .....	4
10-2-2	Initial LED Display (HBC).....	5
<b>10-3</b>	<b>LED Status Indicators Table</b> .....	<b>6</b>



# 10-1 LED Status Indicators (Outdoor unit)

## 10-1-1 How to Read the LED

By setting the DIP SW 4-1 through 4-10 (Set SW6-10 to OFF.)(Switch number 10 is represented by 0), the operating condition of the unit can be monitored on the service monitor. (Refer to the table on the following pages for DIP SW settings.) The service monitor uses 4-digit 7-segment LED to display numerical values and other types of information.




•In the example above, 1 through 9 are set to ON, and 10 is set to OFF.

Pressure and temperature are examples of numerical values, and operating conditions and the on-off status of solenoid valve are examples of flag display.

1) Display of numerical values


Example: When the pressure data sensor reads 18.8kg/cm<sup>2</sup> (Item No. 58)

- The unit of pressure is in kg/cm<sup>2</sup>
- Use the following conversion formula to convert the displayed value into a value in SI unit.  
Value in SI unit (MPa) = Displayed value (kg/cm<sup>2</sup>) x 0.098




2) Flag display

Example: When 21S4a, 21S4b, SV1a are ON. (Item No. 3)







Example: 3-minutes restart mode (Item No. 14)



## 10-1-2 Initial LED Display

From power on until the completion of initial settings, the following information will be displayed on the monitor screen. (Displays No. 1 through No. 4 in order repeatedly.)

No	Item	Display	Remarks
1	Software version		[0103] : Version 1.03
2	Refrigerant type		[ 32] : R32
3	Model and capacity		[H-20] : Cooling/Heating 20 HP For the first few minutes after power on, the capacity of each outdoor unit is displayed. Thereafter, the combined capacity is displayed.
4	Communication address		[ 51] : Address 51

After the initial settings have been completed, the information on these items can be checked by making the switch setting that corresponds to No. 517 in the LED display table.

**Note**

Only item No. 1 "Software Version" appears on the display if there is a wiring failure between the control board and the transmission line power supply board or if the circuit board has failed. LED may not light up at all.

### 10-1-3 Clock Memory Function

The outdoor unit has a simple clock function that enables the unit to calculate the current time with an internal timer by receiving the time set by the system controller, such as AG-150A.

If an error (including a preliminary error) occurs, the error history data and the error detection time are stored into the service memory.


The error detection time stored in the service memory and the current time can be seen on the service LED.

**Note**

- 1) Use the time displayed on the service LED as a reference.
- 2) The date and the time are set to "00" by default. If a system controller that sets the time, such as AG-150A is not connected, the elapsed time and days since the first power on will be displayed.  
If the time set on a system controller is received, the count will start from the set date and the time.
- 3) The time is not updated while the power of the indoor unit is turned off. When the power is turned off and then on again, the count will resume from the time before the power was turned off. Thus, the time that differs the actual time will be displayed. (This also applies when a power failure occurs.)  
The system controller, such as AG-150A, adjusts the time once a day. When the system controller is connected, the time will be automatically updated to the correct current time after the time set by the system controller is received. (The data stored into the memory before the set time is received will not be updated.)


**(1) Reading the time data:**

- 1) Time display  
Example: 12 past 9




\* Disappears if the time data is deviated due to a power failure, or if a system controller that sets the time is not connected.

- 2) Date display  
•When the main controller that can set the time is connected  
Example: May 10, 2003



\* Appears between the year and the month, and nothing appears when the date is displayed.

- When the main controller that can set the time is not connected  
Example: 52 days after power was turned on




\* Appears between the year and the month, and nothing appears when the date is displayed.




## 10-2 LED Status Indicators (HBC)

### 10-2-1 How to Read the LED

The operation status of the unit can be monitored on the service monitor.  
The service monitor uses 4-digit 7-segment LED to display flags.  
There are no check items using dipswitch settings.



- LD1: Pump in operation
- LD2: DIP SW 002-7 ON
- LD3: DIP SW 002-8 ON
- LD5: 52C
- LD7: HB
- LD8: Microcomputer in operation



### 10-2-2 Initial LED Display (HBC)

From power on until the completion of initial settings, the following information will be displayed on the monitor screen. (Displays No. 1 through No. 4 in order repeatedly.)

No	Item	Display	Remarks
1	Software version		[1100] : Version 11.00
2	Refrigerant type		[ 32] : R32
3	Model and capacity		[Hb-3] : WM350F    [HS08] : WM108V [Hb-4] : WM500F    [HS16] : WM1016V
4	Communication address		[ 52] : Address 52

**Note**

Only item No. 1 "Software Version" appears on the display if there is a wiring failure between the control board and the transmission line power supply board or if the circuit board has failed.  
 If nothing appears on the display after the power is turned on, 4130 error may be occurring.  
 Take the procedure described in section [7-6-12 Error Code [4130]].

# 10-3 LED Status Indicators Table

**Current data**

No.	SW4 (SW6 - 9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit, <sup>1,2</sup> (A, B)	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
0	0000000000	Relay output display 1 Lighting	Comp in operation									OC		A	
		Check (error) display 1 OC error		72C											
1	1000000000	Check (error) display 2 OC error												B	Display of the latest preliminary error If no preliminary errors are detected, "----" appears on the display.
2	0100000000	Check (error) display 3 (Including IC and BC)												A	Display of the latest preliminary error If no preliminary errors are detected, "----" appears on the display.
3	1100000000	Relay output display 2 Top	21S4a		CH11									A	
		Bottom			21S4b						SV2				
4	0010000000	Relay output display 3 Top												A	
		Bottom													
7	1110000000	Special control	Retry operation											B	Communication error 3-minute restart delay mode
9	1001000000	Communication demand capacity												B	If not demanded controlled, "----" " [% ]" appears on the display.
10	0101000000	Contact point demand capacity												B	If not demanded controlled, "----" " [% ]" appears on the display.
11	1101000000	External signal (Open input contact point)	Contact point demand	Low-noise mode (Capacity priority)	Snow sensor	Cooling-heating changeover (Cooling)	Cooling-heating changeover (Heating)							A	
12	0011000000	External signal (Open input contact point)												A	Low-noise mode (Quiet priority) Cooling fan output
13	1011000000	Outdoor unit operation status	HBC operation signal	Warm-up mode	3-minutes restart mode	Compressor in operation	Preliminary error	Error						A	3-minutes restart after instantaneous power failure Preliminary low pressure error
15	1111000000	OC/OS identification	OC/OS identification											A	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

No.	Current data		Item	Display												Unit (A, B) <sup>*1,2</sup>	Remarks
	SW4 (SW6-9: OFF, SW6-10: OFF)	1234567890		LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8	OC					
16	0000100000		Indoor unit check	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8				B	The lamp that corresponds to the unit that came to an abnormal stop lights. The lamp goes off when the error is reset. Each unit that comes to an abnormal unit will be given a sequential number in ascending order starting with 1.	
17	1000100000		Top	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16						
18	0100100000		Bottom	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24						
19	1100100000		Top	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32						
20	0010100000		Bottom	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40						
21	1010100000		Top	Unit No. 41	Unit No. 42	Unit No. 43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48						
22	0110100000		Bottom	Unit No. 49	Unit No. 50												
23	1110100000		Indoor unit thermostat	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8				B	Lit during cooling Blinking during heating Unit while the unit is stopped or in the fan mode	
24	0001100000		Top	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16						
25	1001100000		Bottom	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24						
26	0101100000		Top	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32						
27	1101100000		Bottom	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40						
28	0011100000		Indoor unit thermostat	Unit No. 41	Unit No. 42	Unit No. 43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48						
29	1101100000		Top	Unit No. 49	Unit No. 50												
30	0011100000		Bottom	Unit No. 1	Unit No. 2	Unit No. 3	Unit No. 4	Unit No. 5	Unit No. 6	Unit No. 7	Unit No. 8						
31	1011100000		Indoor unit thermostat	Unit No. 9	Unit No. 10	Unit No. 11	Unit No. 12	Unit No. 13	Unit No. 14	Unit No. 15	Unit No. 16						
32	1001100000		Top	Unit No. 17	Unit No. 18	Unit No. 19	Unit No. 20	Unit No. 21	Unit No. 22	Unit No. 23	Unit No. 24						
33	0101100000		Bottom	Unit No. 25	Unit No. 26	Unit No. 27	Unit No. 28	Unit No. 29	Unit No. 30	Unit No. 31	Unit No. 32						
34	1101100000		Top	Unit No. 33	Unit No. 34	Unit No. 35	Unit No. 36	Unit No. 37	Unit No. 38	Unit No. 39	Unit No. 40						
35	0110100000		Bottom	Unit No. 41	Unit No. 42	Unit No. 43	Unit No. 44	Unit No. 45	Unit No. 46	Unit No. 47	Unit No. 48						
36	1110100000		Indoor unit thermostat	Unit No. 49	Unit No. 50												
37	1010010000		Drive recorder status	Drive recorder is stopped (OFF): "OFF" Drive recorder is in operation (ON): "ON" On-board flash error <sup>2</sup> : "F-Er"												B	Lit when thermostat is on Unit when thermostat is off
38	0011100000		Drive recorder status	Drive recorder is stopped (OFF): "OFF" Drive recorder is in operation (ON): "ON" On-board flash error <sup>2</sup> : "F-Er"												B	Lit when thermostat is on Unit when thermostat is off
39	1010010000		HBC operation mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF	Fan	Stop						
40	1110010000		Outdoor unit operation mode	Permissible stop	Standby	Cooling	Cooling-main	Heating	Heating-main								
41	0101010000		Outdoor unit control mode	Stop	Thermo OFF	Abnormal stop	Scheduled control	Initial start up	Defrost	Oil balance	Low frequency oil recovery						
42	1101010000		Warm-up mode	Warm-up mode	Refrigerant recovery			Continuous heating 2	Continuous heating 1								
43	1011010000		TH4					-99.9 to 999.9								The unit is [°C]	
44	0111010000		TH3					-99.9 to 999.9								The unit is [°C]	
45	1111010000		TH7					-99.9 to 999.9								The unit is [°C]	
46	0100110000		TH5					-99.9 to 999.9								The unit is [°C]	
47	1000110000		THS1					-99.9 to 999.9								The unit is [kgf/cm <sup>2</sup> ]	
48	0101110000		High-pressure sensor data					-99.9 to 999.9								The unit is [kgf/cm <sup>2</sup> ]	
49	1101110000		Low-pressure sensor data					-99.9 to 999.9								The unit is [kgf/cm <sup>2</sup> ]	
50	0111100000		TH15					-99.9 to 999.9								The unit is [°C]	
51	0111000000		Σ Qj					0000 to 9999								The unit is [°C]	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

10 LED Status Indicators

Current data

No.	SW4 (SW6-9: OFF, SW6-10: OFF)	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks				
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8	LD9	LD10						
79	1111001000	Σ Qjc														B		
80	0000101000	Σ Qjh															B	
81	1000101000	Target Tc															B	The unit is [°C]
82	0100101000	Target Te															B	
83	1100101000	Tc															A	
84	0010101000	Te															A	
86	0110101000	Total frequencies (OC+OS) <sup>*2</sup>															B	Control data [ Hz ]
87	1110101000	Total frequency of each unit															A	
88	0001101000	COMP frequency															A	
91	1101101000	COMP operating frequency															A	The unit is [rps] Output frequency of the inverter depends on the type of compressor and equals the integer multiples (x1, x2 etc.) of the operating frequency of the compressor.
92	0011101000	Number of times error occurred during crankcase heating by compressor motor															A	Number of times [NV error occurred during IH crankcase heating by compressor motor
93	1011101000	All AK (OC+OS) <sup>*2</sup>															B	
94	0111101000	AK															A	
95	1111101000	FAN1															A	Fan output [ % ]
96	0000011000	Fan inverter output rpm (FAN1)															A	[rpm]
97	1000011000	FAN2															A	Fan output [ % ]
98	0100011000	Fan inverter output rpm (FAN2)															A	[rpm]
104	0001011000	LEV2															A	
105	1001011000	LEV4															A	
108	0011011000	COMP operating current (DC)															A	Peak value [A]
109	1011011000	LEV2b															A	
110	0111011000	LEV2c															A	
111	1111011000	COMP bus voltage															A	The unit is [V]
112	0000111000	LEV2d															A	
113	1000111000	LEV9															A	
116	0010111000	Number of times the unit went into the mode to remedy wet vapor suction															B	
117	1010111000	COMP Operation time Upper 4 digits															A	The unit is [h]
118	0110111000	COMP Operation time Lower 4 digits															A	
121	1001111000	Backup mode															A	Stays lit for 90 seconds after the completion of backup control

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Current data**

No.	SW4 (SW6 - 9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8				
123	1101111000	COMP number of start-stop events Upper 4 digits	0000 to 9999										A	Count-up at start-up The unit is [Time]
124	0011111000	COMP number of start-stop events Lower 4 digits	0000 to 9999										A	
129	1000000100	Integrated operation time of compressor (for rotation purpose)	0000 to 9999										B	The unit is [ h ]
178	01001110100	Error history 1	0000 to 9999										B	Address and error codes highlighted If no errors are detected, "----" appears on the display. Preliminary error information of the OS does not appear on the OC. Neither preliminary error information of the OC nor error information of the IC appears on the OS.
179	11001110100	Error details of inverter	Error details of inverter (0001-0120)										A	
180	00101110100	Error history 2	0000 to 9999										B	
181	10101110100	Error details of inverter	Error details of inverter (0001-0120)										A	
182	01101110100	Error history 3	0000 to 9999										B	
183	11101110100	Error details of inverter	Error details of inverter (0001-0120)										A	
184	00011110100	Error history 4	0000 to 9999										B	
185	10011110100	Error details of inverter	Error details of inverter (0001-0120)										A	
186	01011110100	Error history 5	0000 to 9999										B	
187	11011110100	Error details of inverter	Error details of inverter (0001-0120)										A	
188	00111110100	Error history 6	0000 to 9999										B	
189	10111110100	Error details of inverter	Error details of inverter (0001-0120)										A	
190	01111110100	Error history 7	0000 to 9999										B	
191	11111110100	Error details of inverter	Error details of inverter (0001-0120)										A	
192	0000001100	Error history 8	0000 to 9999										B	
193	1000001100	Error details of inverter	Error details of inverter (0001-0120)										A	
194	0100001100	Error history 9	0000 to 9999										B	
195	1100001100	Error details of inverter	Error details of inverter (0001-0120)										A	
196	0010001100	Error history 10	0000 to 9999										B	
197	1010001100	Error details of inverter	Error details of inverter (0001-0120)										A	
198	0110001100	Error history of inverter (At the time of last data back-up before error)	0000 to 9999										B	
199	1110001100	Error details of inverter	Error details of inverter (0001-0120)										A	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

10 LED Status Indicators

Data before error

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1, *2</sup>	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8				
201	1001001100	Outdoor unit operation status	HBC operation signal	Warm-up mode	3-minutes restart mode	Compressor in operation	Preliminary error	Error	3-minutes restart after instantaneous power failure	Preliminary low pressure error		OC		
202	0101001100	OC/OS identification <sup>*2</sup>					OC/OS					A		
203	1101001100	HBC operation mode	Cooling-only ON	Cooling-only OFF	Heating-only ON	Heating-only OFF	Mixed-mode ON	Mixed-mode OFF			Stop	A		
205	1011001100	Outdoor unit Operation mode	Permissible stop	Standby	Cooling	Cooling-main	Heating	Heating-main			Fan	A		
208	0000101100	Outdoor unit control mode	Stop	Thermo OFF	Abnormal stop	Scheduled control	Initial start up	Defrost		Oil balance	Low frequency oil recovery	A		
209	1000101100			Refrigerant recovery			Continuous heating 2	Continuous heating 1				A		
211	1100101100	Relay output display 1 Lighting	Comp in operation				72C			OC	Always lit	A		
212	0010101100	Relay output display 2 Lighting	21S4a		CH11		SV1a			SV2		A		
		Relay output display 3 Lighting	Bottom		21S4b							A		
213	1010101100		Top				21S4c				Lit while power to the indoor units is being supplied	A		
216	0001101100	TH4					-99.9 to 999.9					A	The unit is [°C]	
217	1001101100	TH3					-99.9 to 999.9					A		
218	0101101100	TH7					-99.9 to 999.9					A		
221	1011101100	TH5					-99.9 to 999.9					A		
227	1100011100	THHS1					-99.9 to 999.9					A	The unit is [°C]	
229	1010011100	High-pressure sensor data					-99.9 to 999.9					A	The unit is [kgf/cm <sup>2</sup> ]	
230	0110011100	Low-pressure sensor data					-99.9 to 999.9					A		
233	0101011100	TH15					-99.9 to 999.9					A	The unit is [°C]	
249	1001111100	Σ Qj					0000 to 9999					B		
250	0101111100	Σ Qjc					0000 to 9999					B		
251	1101111100	Σ Qjh					0000 to 9999					B		
252	0011111100	Target Tc					-99.9 to 999.9					B	The unit is [°C]	
253	1011111100	Target Te					-99.9 to 999.9					B		
254	0111111100	Tc					-99.9 to 999.9					A	The unit is [°C]	
255	1111111100	Te					-99.9 to 999.9					A		
257	1000000010	Total frequencies (OC+OS) <sup>*2</sup>					0000 to 9999					B	Control data [ Hz ]	
258	0100000010	Total frequency of each unit					0000 to 9999					A		
259	1100000010	COMP frequency					0000 to 9999					A		
264	0001000010	All AK (OC+OS) <sup>*2</sup>					0000 to 9999					B		
265	1001000010	AK					0000 to 9999					A		
266	0101000010	FAN1					0000 to 9999					A	Fan inverter output [ % ]	
267	1101000010	Fan inverter output rpm (FAN1)					0000 to 9999					A	[rpm]	
268	0011000010	FAN2					0000 to 9999					A	Fan inverter output [ % ]	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.  
 \*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data before error**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display								Unit (A, B) <sup>*1, *2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8			
269	1011000010	Fan inverter output rpm (FANZ)							0000 to 9999			A	[rpm]
275	1100100010	LEV2							0000 to 9999			A	
276	0010100010	LEV4							0000 to 480			A	
279	1110100010	COMP operating current (DC)							00.0 to 999.9			A	Peak value[A]
282	0101100010	COMP bus voltage							00.0 to 999.9			A	The unit is [ V ]
283	1101100010	LEV2b							0000 to 9999			A	
284	0011100010	LEV2c							0000 to 9999			A	
285	1011100010	LEV2d							0000 to 9999			A	
286	0111100010	LEV9							0000 to 9999			A	
288	0000010010	COMP Operation time Upper 4 digits							0000 to 9999			A	The unit is [ h ]
289	1000010010	COMP Operation time Lower 4 digits							0000 to 9999			A	
294	0110010010	COMP number of start-stop events Upper 4 digits							0000 to 9999			A	Count-up at start-up The unit is [Time]
295	1110010010	COMP number of start-stop events Lower 4 digits							0000 to 9999			A	
300	0011010010	Integrated operation time of compressor (for rotation pur- pose)							0000 to 9999			B	The unit is [ h ]
301	1011010010	Power supply unit							OC/OS ↔ Address			B	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.



10 LED Status Indicators

Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit <sup>*1, *2</sup> (A, B)	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
351	1111101010	IC1 Address/capacity code	0000 to 9999											0000 to 9999	B Displayed alternately every 5 seconds
352	0000011010	IC2 Address/capacity code	0000 to 9999											0000 to 9999	
353	1000011010	IC3 Address/capacity code	0000 to 9999											0000 to 9999	
354	0100011010	IC4 Address/capacity code	0000 to 9999											0000 to 9999	
355	1100011010	IC5 Address/capacity code	0000 to 9999											0000 to 9999	
356	0010011010	IC6 Address/capacity code	0000 to 9999											0000 to 9999	
357	1010011010	IC7 Address/capacity code	0000 to 9999											0000 to 9999	
358	0110011010	IC8 Address/capacity code	0000 to 9999											0000 to 9999	
359	110011010	IC9 Address/capacity code	0000 to 9999											0000 to 9999	
360	0001011010	IC10 Address/capacity code	0000 to 9999											0000 to 9999	
361	1001011010	IC11 Address/capacity code	0000 to 9999											0000 to 9999	
362	0101011010	IC12 Address/capacity code	0000 to 9999											0000 to 9999	
363	1101011010	IC13 Address/capacity code	0000 to 9999											0000 to 9999	
364	0011011010	IC14 Address/capacity code	0000 to 9999											0000 to 9999	
365	1011011010	IC15 Address/capacity code	0000 to 9999											0000 to 9999	
366	0111011010	IC16 Address/capacity code	0000 to 9999											0000 to 9999	
367	1111011010	IC17 Address/capacity code	0000 to 9999											0000 to 9999	
368	0000111010	IC18 Address/capacity code	0000 to 9999											0000 to 9999	
369	1000111010	IC19 Address/capacity code	0000 to 9999											0000 to 9999	
370	0100111010	IC20 Address/capacity code	0000 to 9999											0000 to 9999	
371	1100111010	IC21 Address/capacity code	0000 to 9999											0000 to 9999	
372	0010111010	IC22 Address/capacity code	0000 to 9999											0000 to 9999	
373	1010111010	IC23 Address/capacity code	0000 to 9999											0000 to 9999	
374	0110111010	IC24 Address/capacity code	0000 to 9999											0000 to 9999	
375	1110111010	IC25 Address/capacity code	0000 to 9999											0000 to 9999	
376	0001111010	IC26 Address/capacity code	0000 to 9999											0000 to 9999	
377	1001111010	IC27 Address/capacity code	0000 to 9999											0000 to 9999	
378	0101111010	IC28 Address/capacity code	0000 to 9999											0000 to 9999	
379	1101111010	IC29 Address/capacity code	0000 to 9999											0000 to 9999	
380	0011111010	IC30 Address/capacity code	0000 to 9999											0000 to 9999	
381	1011111010	IC31 Address/capacity code	0000 to 9999											0000 to 9999	
382	0111111010	IC32 Address/capacity code	0000 to 9999											0000 to 9999	
383	1111111010	IC33 Address/capacity code	0000 to 9999											0000 to 9999	
384	000000110	IC34 Address/capacity code	0000 to 9999											0000 to 9999	
385	100000110	IC35 Address/capacity code	0000 to 9999											0000 to 9999	
386	010000110	IC36 Address/capacity code	0000 to 9999											0000 to 9999	
387	110000110	IC37 Address/capacity code	0000 to 9999											0000 to 9999	
388	0010000110	IC38 Address/capacity code	0000 to 9999											0000 to 9999	
389	1010000110	IC39 Address/capacity code	0000 to 9999											0000 to 9999	
390	0110000110	IC40 Address/capacity code	0000 to 9999											0000 to 9999	
391	1110000110	IC41 Address/capacity code	0000 to 9999											0000 to 9999	
392	0001000110	IC42 Address/capacity code	0000 to 9999											0000 to 9999	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data on indoor unit system**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1*2</sup>	Remarks		
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8						
393	1001000110	IC43 Address/capacity code	0000 to 9999												B	Displayed alternately every 5 seconds
394	0101000110	IC44 Address/capacity code	0000 to 9999													
395	1101000110	IC45 Address/capacity code	0000 to 9999													
396	0011000110	IC46 Address/capacity code	0000 to 9999													
397	1011000110	IC47 Address/capacity code	0000 to 9999													
398	0111000110	IC48 Address/capacity code	0000 to 9999													
399	1111000110	IC49 Address/capacity code	0000 to 9999													
400	0000100110	IC50 Address/capacity code	0000 to 9999													
408	0001100110	IC1 Suction temperature	-99.9 to 999.9													
409	1001100110	IC2 Suction temperature	-99.9 to 999.9													
410	0101100110	IC3 Suction temperature	-99.9 to 999.9													
411	1101100110	IC4 Suction temperature	-99.9 to 999.9													
412	0011100110	IC5 Suction temperature	-99.9 to 999.9													
413	1011100110	IC6 Suction temperature	-99.9 to 999.9													
414	0111100110	IC7 Suction temperature	-99.9 to 999.9													
415	1111100110	IC8 Suction temperature	-99.9 to 999.9													
416	0000010110	IC9 Suction temperature	-99.9 to 999.9													
417	1000010110	IC10 Suction temperature	-99.9 to 999.9													
418	0100010110	IC11 Suction temperature	-99.9 to 999.9													
419	1100010110	IC12 Suction temperature	-99.9 to 999.9													
420	0010010110	IC13 Suction temperature	-99.9 to 999.9													
421	1010010110	IC14 Suction temperature	-99.9 to 999.9													
422	0110010110	IC15 Suction temperature	-99.9 to 999.9													
423	1110010110	IC16 Suction temperature	-99.9 to 999.9													
424	0001010110	IC17 Suction temperature	-99.9 to 999.9													
425	1001010110	IC18 Suction temperature	-99.9 to 999.9													
426	0101010110	IC19 Suction temperature	-99.9 to 999.9													
427	1101010110	IC20 Suction temperature	-99.9 to 999.9													
428	0011010110	IC21 Suction temperature	-99.9 to 999.9													
429	1011010110	IC22 Suction temperature	-99.9 to 999.9													
430	0111010110	IC23 Suction temperature	-99.9 to 999.9													
431	1111010110	IC24 Suction temperature	-99.9 to 999.9													
432	0000110110	IC25 Suction temperature	-99.9 to 999.9													
433	1000110110	IC26 Suction temperature	-99.9 to 999.9													
434	0100110110	IC27 Suction temperature	-99.9 to 999.9													
435	1100110110	IC28 Suction temperature	-99.9 to 999.9													
436	0010110110	IC29 Suction temperature	-99.9 to 999.9													
437	1010110110	IC30 Suction temperature	-99.9 to 999.9													
438	0110110110	IC31 Suction temperature	-99.9 to 999.9													
439	1110110110	IC32 Suction temperature	-99.9 to 999.9													
440	0001110110	IC33 Suction temperature	-99.9 to 999.9													
441	1001110110	IC34 Suction temperature	-99.9 to 999.9													
442	0101110110	IC35 Suction temperature	-99.9 to 999.9													

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

10 LED Status Indicators

Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8				
443	1101110110	IC36 Suction temperature	-99.9 to 999.9										B	The unit is [°C]
444	0011110110	IC37 Suction temperature	-99.9 to 999.9											
445	1011110110	IC38 Suction temperature	-99.9 to 999.9											
446	0111110110	IC39 Suction temperature	-99.9 to 999.9											
447	1111110110	IC40 Suction temperature	-99.9 to 999.9											
448	000001110	IC41 Suction temperature	-99.9 to 999.9											
449	100001110	IC42 Suction temperature	-99.9 to 999.9											
450	010001110	IC43 Suction temperature	-99.9 to 999.9											
451	110001110	IC44 Suction temperature	-99.9 to 999.9											
452	001001110	IC45 Suction temperature	-99.9 to 999.9											
453	101001110	IC46 Suction temperature	-99.9 to 999.9											
454	011001110	IC47 Suction temperature	-99.9 to 999.9											
455	111001110	IC48 Suction temperature	-99.9 to 999.9											
456	000100110	IC49 Suction temperature	-99.9 to 999.9											
457	100100110	IC50 Suction temperature	-99.9 to 999.9											
458	010100110	IC1 Water pipe inlet temperature	-99.9 to 999.9											
459	110100110	IC2 Water pipe inlet temperature	-99.9 to 999.9											
460	001100110	IC3 Water pipe inlet temperature	-99.9 to 999.9											
461	101100110	IC4 Water pipe inlet temperature	-99.9 to 999.9											
462	011100110	IC5 Water pipe inlet temperature	-99.9 to 999.9											
463	111100110	IC6 Water pipe inlet temperature	-99.9 to 999.9											
464	000010110	IC7 Water pipe inlet temperature	-99.9 to 999.9											
465	100010110	IC8 Water pipe inlet temperature	-99.9 to 999.9											
466	010010110	IC9 Water pipe inlet temperature	-99.9 to 999.9											
467	110010110	IC10 Water pipe inlet temperature	-99.9 to 999.9											
468	001010110	IC11 Water pipe inlet temperature	-99.9 to 999.9											
469	101010110	IC12 Water pipe inlet temperature	-99.9 to 999.9											
470	011010110	IC13 Water pipe inlet temperature	-99.9 to 999.9											
471	111010110	IC14 Water pipe inlet temperature	-99.9 to 999.9											
472	000110110	IC15 Water pipe inlet temperature	-99.9 to 999.9											
473	100110110	IC16 Water pipe inlet temperature	-99.9 to 999.9											
474	010110110	IC17 Water pipe inlet temperature	-99.9 to 999.9											
475	110110110	IC18 Water pipe inlet temperature	-99.9 to 999.9											
476	001110110	IC19 Water pipe inlet temperature	-99.9 to 999.9											
477	101110110	IC20 Water pipe inlet temperature	-99.9 to 999.9											
478	011110110	IC21 Water pipe inlet temperature	-99.9 to 999.9											
479	111110110	IC22 Water pipe inlet temperature	-99.9 to 999.9											
480	000001110	IC23 Water pipe inlet temperature	-99.9 to 999.9											
481	100001110	IC24 Water pipe inlet temperature	-99.9 to 999.9											
482	010001110	IC25 Water pipe inlet temperature	-99.9 to 999.9											
483	110001110	IC26 Water pipe inlet temperature	-99.9 to 999.9											
484	001001110	IC27 Water pipe inlet temperature	-99.9 to 999.9											
485	101001110	IC28 Water pipe inlet temperature	-99.9 to 999.9											

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data on indoor unit system**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
486	0110011110	IC29 Water pipe inlet temperature					-99.9 to 999.9							OC	The unit is [°C]
487	1110011110	IC30 Water pipe inlet temperature					-99.9 to 999.9							B	
488	0001011110	IC31 Water pipe inlet temperature					-99.9 to 999.9								
489	1001011110	IC32 Water pipe inlet temperature					-99.9 to 999.9								
490	0101011110	IC33 Water pipe inlet temperature					-99.9 to 999.9								
491	1101011110	IC34 Water pipe inlet temperature					-99.9 to 999.9								
492	0011011110	IC35 Water pipe inlet temperature					-99.9 to 999.9								
493	1011011110	IC36 Water pipe inlet temperature					-99.9 to 999.9								
494	0111011110	IC37 Water pipe inlet temperature					-99.9 to 999.9								
495	1111011110	IC38 Water pipe inlet temperature					-99.9 to 999.9								
496	0000111110	IC39 Water pipe inlet temperature					-99.9 to 999.9								
497	1000111110	IC40 Water pipe inlet temperature					-99.9 to 999.9								
498	0100111110	IC41 Water pipe inlet temperature					-99.9 to 999.9								
499	1100111110	IC42 Water pipe inlet temperature					-99.9 to 999.9								
500	0010111110	IC43 Water pipe inlet temperature					-99.9 to 999.9								
501	1010111110	IC44 Water pipe inlet temperature					-99.9 to 999.9								
502	0110111110	IC45 Water pipe inlet temperature					-99.9 to 999.9								
503	1110111110	IC46 Water pipe inlet temperature					-99.9 to 999.9								
504	0001111110	IC47 Water pipe inlet temperature					-99.9 to 999.9								
505	1001111110	IC48 Water pipe inlet temperature					-99.9 to 999.9								
506	0101111110	IC49 Water pipe inlet temperature					-99.9 to 999.9								
507	1101111110	IC50 Water pipe inlet temperature					-99.9 to 999.9								

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

Setting data

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display								Unit (A, B) <sup>*1,2</sup>	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8		
512	0000000001	Self-address	Alternate display of self address and unit model								OC	
513	1000000001	IC/FU address	Count-up display of number of connected units								A	
514	0100000001	RC address	Count-up display of number of connected units								B	
515	1100000001	HBC address	Count-up display of number of connected units								B	
516	0010000001	Version/Capacity	Count-up display of number of connected units								B	
517	1010000001	Version/Capacity	SW version → Refrigerant type → Model and capacity → Communication address								A	
518	0110000001	OC address	OC address display									

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data on indoor unit system**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
523	1101000001	IC1 Water pipe outlet temperature	-99.9 to 999.9											B	The unit is [°C]
524	0011000001	IC2 Water pipe outlet temperature	-99.9 to 999.9												
525	1011000001	IC3 Water pipe outlet temperature	-99.9 to 999.9												
526	0111000001	IC4 Water pipe outlet temperature	-99.9 to 999.9												
527	1110000001	IC5 Water pipe outlet temperature	-99.9 to 999.9												
528	0000100001	IC6 Water pipe outlet temperature	-99.9 to 999.9												
529	1000100001	IC7 Water pipe outlet temperature	-99.9 to 999.9												
530	0100100001	IC8 Water pipe outlet temperature	-99.9 to 999.9												
531	1100100001	IC9 Water pipe outlet temperature	-99.9 to 999.9												
532	0010100001	IC10 Water pipe outlet temperature	-99.9 to 999.9												
533	1010100001	IC11 Water pipe outlet temperature	-99.9 to 999.9												
534	0110100001	IC12 Water pipe outlet temperature	-99.9 to 999.9												
535	1110100001	IC13 Water pipe outlet temperature	-99.9 to 999.9												
536	0001100001	IC14 Water pipe outlet temperature	-99.9 to 999.9												
537	1001100001	IC15 Water pipe outlet temperature	-99.9 to 999.9												
538	0101100001	IC16 Water pipe outlet temperature	-99.9 to 999.9												
539	1101100001	IC17 Water pipe outlet temperature	-99.9 to 999.9												
540	0011100001	IC18 Water pipe outlet temperature	-99.9 to 999.9												
541	1011100001	IC19 Water pipe outlet temperature	-99.9 to 999.9												
542	0111100001	IC20 Water pipe outlet temperature	-99.9 to 999.9												
543	1111100001	IC21 Water pipe outlet temperature	-99.9 to 999.9												
544	0000010001	IC22 Water pipe outlet temperature	-99.9 to 999.9												
545	1000010001	IC23 Water pipe outlet temperature	-99.9 to 999.9												
546	0100010001	IC24 Water pipe outlet temperature	-99.9 to 999.9												
547	1100010001	IC25 Water pipe outlet temperature	-99.9 to 999.9												
548	0010010001	IC26 Water pipe outlet temperature	-99.9 to 999.9												
549	1010010001	IC27 Water pipe outlet temperature	-99.9 to 999.9												
550	0110010001	IC28 Water pipe outlet temperature	-99.9 to 999.9												
551	1110010001	IC29 Water pipe outlet temperature	-99.9 to 999.9												
552	0001010001	IC30 Water pipe outlet temperature	-99.9 to 999.9												
553	1001010001	IC31 Water pipe outlet temperature	-99.9 to 999.9												
554	0101010001	IC32 Water pipe outlet temperature	-99.9 to 999.9												
555	1101010001	IC33 Water pipe outlet temperature	-99.9 to 999.9												
556	0011010001	IC34 Water pipe outlet temperature	-99.9 to 999.9												
557	1011010001	IC35 Water pipe outlet temperature	-99.9 to 999.9												
558	0111010001	IC36 Water pipe outlet temperature	-99.9 to 999.9												
559	1111010001	IC37 Water pipe outlet temperature	-99.9 to 999.9												
560	0000110001	IC38 Water pipe outlet temperature	-99.9 to 999.9												
561	1000110001	IC39 Water pipe outlet temperature	-99.9 to 999.9												
562	0100110001	IC40 Water pipe outlet temperature	-99.9 to 999.9												
563	1100110001	IC41 Water pipe outlet temperature	-99.9 to 999.9												
564	0010110001	IC42 Water pipe outlet temperature	-99.9 to 999.9												

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

# 10 LED Status Indicators

[10 - 3 LED Status Indicators Table]

### Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
565	1010110001	IC43 Water pipe outlet temperature					-99.9 to 999.9							B	The unit is [°C]
566	0110110001	IC44 Water pipe outlet temperature					-99.9 to 999.9								
567	1110110001	IC45 Water pipe outlet temperature					-99.9 to 999.9								
568	0001110001	IC46 Water pipe outlet temperature					-99.9 to 999.9								
569	1001110001	IC47 Water pipe outlet temperature					-99.9 to 999.9								
570	0101110001	IC48 Water pipe outlet temperature					-99.9 to 999.9								
571	1101110001	IC49 Water pipe outlet temperature					-99.9 to 999.9								
572	0011110001	IC50 Water pipe outlet temperature					-99.9 to 999.9								
573	1011110001	IC1SH					-99.9 to 999.9								
574	0111110001	IC2SH					-99.9 to 999.9								
575	1111110001	IC3SH					-99.9 to 999.9								
576	0000001001	IC4SH					-99.9 to 999.9								
577	1000001001	IC5SH					-99.9 to 999.9								
578	0100001001	IC6SH					-99.9 to 999.9								
579	1100001001	IC7SH					-99.9 to 999.9								
580	0010001001	IC8SH					-99.9 to 999.9								
581	1010001001	IC9SH					-99.9 to 999.9								
582	0110001001	IC10SH					-99.9 to 999.9								
583	1110001001	IC11SH					-99.9 to 999.9								
584	0001001001	IC12SH					-99.9 to 999.9								
585	1001001001	IC13SH					-99.9 to 999.9								
586	0101001001	IC14SH					-99.9 to 999.9								
587	1101001001	IC15SH					-99.9 to 999.9								
588	0011001001	IC16SH					-99.9 to 999.9								
589	1011001001	IC17SH					-99.9 to 999.9								
590	0111001001	IC18SH					-99.9 to 999.9								
591	1111001001	IC19SH					-99.9 to 999.9								
592	0000101001	IC20SH					-99.9 to 999.9								
593	1000101001	IC21SH					-99.9 to 999.9								
594	0100101001	IC22SH					-99.9 to 999.9								
595	1100101001	IC23SH					-99.9 to 999.9								
596	0010101001	IC24SH					-99.9 to 999.9								
597	1010101001	IC25SH					-99.9 to 999.9								
598	0110101001	IC26SH					-99.9 to 999.9								
599	1110101001	IC27SH					-99.9 to 999.9								
600	0001101001	IC28SH					-99.9 to 999.9								
601	1001101001	IC29SH					-99.9 to 999.9								
602	0101101001	IC30SH					-99.9 to 999.9								
603	1101101001	IC31SH					-99.9 to 999.9								
604	0011101001	IC32SH					-99.9 to 999.9								
605	1011101001	IC33SH					-99.9 to 999.9								
606	0111101001	IC34SH					-99.9 to 999.9								
607	1111101001	IC35SH					-99.9 to 999.9								

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data on indoor unit system**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks		
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8						
608	0000011001	IC36SH					-99.9 to 999.9							B	The unit is [°C]	
609	1000011001	IC37SH					-99.9 to 999.9									
610	0100011001	IC38SH					-99.9 to 999.9									
611	1100011001	IC39SH					-99.9 to 999.9									
612	0010011001	IC40SH					-99.9 to 999.9									
613	1010011001	IC41SH					-99.9 to 999.9									
614	0110011001	IC42SH					-99.9 to 999.9									
615	1110011001	IC43SH					-99.9 to 999.9									
616	0001011001	IC44SH					-99.9 to 999.9									
617	1001011001	IC45SH					-99.9 to 999.9									
618	0101011001	IC46SH					-99.9 to 999.9									
619	1101011001	IC47SH					-99.9 to 999.9									
620	0011011001	IC48SH					-99.9 to 999.9									
621	1011011001	IC49SH					-99.9 to 999.9									
622	0111011001	IC50SH					-99.9 to 999.9									
623	1111011001	IC1SC					-99.9 to 999.9									
624	0000111001	IC2SC					-99.9 to 999.9									
625	1000111001	IC3SC					-99.9 to 999.9									
626	0100111001	IC4SC					-99.9 to 999.9									
627	1100111001	IC5SC					-99.9 to 999.9									
628	0010111001	IC6SC					-99.9 to 999.9									
629	1010111001	IC7SC					-99.9 to 999.9									
630	0110111001	IC8SC					-99.9 to 999.9									
631	1110111001	IC9SC					-99.9 to 999.9									
632	0001111001	IC10SC					-99.9 to 999.9									
633	1001111001	IC11SC					-99.9 to 999.9									
634	0101111001	IC12SC					-99.9 to 999.9									
635	1101111001	IC13SC					-99.9 to 999.9									
636	0011111001	IC14SC					-99.9 to 999.9									
637	1011111001	IC15SC					-99.9 to 999.9									
638	0111111001	IC16SC					-99.9 to 999.9									
639	1111111001	IC17SC					-99.9 to 999.9									
640	0000000101	IC18SC					-99.9 to 999.9									
641	1000000101	IC19SC					-99.9 to 999.9									
642	0100000101	IC20SC					-99.9 to 999.9									
643	1100000101	IC21SC					-99.9 to 999.9									
644	0010000101	IC22SC					-99.9 to 999.9									
645	1010000101	IC23SC					-99.9 to 999.9									
646	0110000101	IC24SC					-99.9 to 999.9									
647	1110000101	IC25SC					-99.9 to 999.9									
648	0001000101	IC26SC					-99.9 to 999.9									
649	1001000101	IC27SC					-99.9 to 999.9									
650	0101000101	IC28SC					-99.9 to 999.9									

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.



10 LED Status Indicators

Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks		
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8						
651	1101000101	IC29SC	-99.9 to 999.9											B	The unit is [°C]	
652	0011000101	IC30SC	-99.9 to 999.9													
653	1011000101	IC31SC	-99.9 to 999.9													
654	0111000101	IC32SC	-99.9 to 999.9													
655	1111000101	IC33SC	-99.9 to 999.9													
656	0000100101	IC34SC	-99.9 to 999.9													
657	1000100101	IC35SC	-99.9 to 999.9													
658	0100100101	IC36SC	-99.9 to 999.9													
659	1100100101	IC37SC	-99.9 to 999.9													
660	0010100101	IC38SC	-99.9 to 999.9													
661	1010100101	IC39SC	-99.9 to 999.9													
662	0110100101	IC40SC	-99.9 to 999.9													
663	1110100101	IC41SC	-99.9 to 999.9													
664	0001100101	IC42SC	-99.9 to 999.9													
665	1001100101	IC43SC	-99.9 to 999.9													
666	0101100101	IC44SC	-99.9 to 999.9													
667	1101100101	IC45SC	-99.9 to 999.9													
668	0011100101	IC46SC	-99.9 to 999.9													
669	1011100101	IC47SC	-99.9 to 999.9													
670	0111100101	IC48SC	-99.9 to 999.9													
671	1111100101	IC49SC	-99.9 to 999.9													
672	0000010101	IC50SC	-99.9 to 999.9													

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Setting data**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
676	0010010101	INV board S/W version				0.00 to 99.99								OC	
679	1110010101	Fan board (address 5) S/W version				0.00 to 99.99								A	
680	0001010101	Fan board (address 6) S/W version				0.00 to 99.99								A	
688	0000110101	Current time				00:00 to 23:59								A	Hour: minute
689	1000110101	Current time -2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
690	0100110101	Time of error detection 1				00:00 to 23:59								A	Hour: minute
691	1100110101	Time of error detection 1-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
692	0010110101	Time of error detection 2				00:00 to 23:59								A	Hour: minute
693	1010110101	Time of error detection 2-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
694	0110110101	Time of error detection 3				00:00 to 23:59								A	Hour: minute
695	1110110101	Time of error detection 3-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
696	0001110101	Time of error detection 4				00:00 to 23:59								A	Hour: minute
697	1001110101	Time of error detection 4-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
698	0101110101	Time of error detection 5				00:00 to 23:59								A	Hour: minute
699	1101110101	Time of error detection 5-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
700	0011110101	Time of error detection 6				00:00 to 23:59								A	Hour: minute
701	1011110101	Time of error detection 6-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
702	0111110101	Time of error detection 7				00:00 to 23:59								A	Hour: minute
703	1111110101	Time of error detection 7-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
704	000001101	Time of error detection 8				00:00 to 23:59								A	Hour: minute
705	100001101	Time of error detection 8-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
706	010001101	Time of error detection 9				00:00 to 23:59								A	Hour: minute
707	110001101	Time of error detection 9-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
708	0010001101	Time of error detection 10				00:00 to 23:59								A	Hour: minute
709	1010001101	Time of error detection 10-2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display
710	0110001101	Time of last data backup before error -2				00:00 to 23:59								A	Hour: minute
711	1110001101	Time of last data backup before error -2				00.00 to 99.12/1 to 31								A	Year and month, and date alternate display

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

# 10 LED Status Indicators

[10 - 3 LED Status Indicators Table]

### Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*2</sup>	Remarks		
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8						
764	0011111101	IC1 Operation mode													B	
765	1011111101	IC2 Operation mode														
766	0111111101	IC3 Operation mode														
767	1111111101	IC4 Operation mode														
768	0000000011	IC5 Operation mode														
769	1000000011	IC6 Operation mode														
770	0100000011	IC7 Operation mode														
771	1100000011	IC8 Operation mode														
772	0010000011	IC9 Operation mode														
773	1010000011	IC10 Operation mode														
774	0110000011	IC11 Operation mode														
775	1110000011	IC12 Operation mode														
776	0001000011	IC13 Operation mode														
777	1001000011	IC14 Operation mode														
778	0101000011	IC15 Operation mode														
779	1101000011	IC16 Operation mode														
780	0011000011	IC17 Operation mode														
781	1011000011	IC18 Operation mode														
782	0111000011	IC19 Operation mode														
783	1111000011	IC20 Operation mode														
784	0000100011	IC21 Operation mode														
785	1000100011	IC22 Operation mode														
786	0100100011	IC23 Operation mode														
787	1100100011	IC24 Operation mode														
788	0010100011	IC25 Operation mode														
789	1010100011	IC26 Operation mode														
790	0110100011	IC27 Operation mode														
791	1110100011	IC28 Operation mode														
792	0001100011	IC29 Operation mode														
793	1001100011	IC30 Operation mode														
794	0101100011	IC31 Operation mode														
795	1101100011	IC32 Operation mode														
796	0011100011	IC33 Operation mode														

0000: Stop 0001: Ventilation 0002: Cooling 0003: Heating 0004: Dry

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Data on indoor unit system**

No.	SW4 (SW6-9: OFF, SW6-10: OFF)		Item	Display								Unit (A, B) <sup>*1,2</sup>	Remarks	
	1234567890	1011100011		LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8			
797	1011100011	IC34	Operation mode										B	
798	0111100011	IC35	Operation mode											
799	1111100011	IC36	Operation mode											
800	0000010011	IC37	Operation mode											
801	1000010011	IC38	Operation mode											
802	0100010011	IC39	Operation mode											
803	1100010011	IC40	Operation mode											
804	0010010011	IC41	Operation mode											
805	1010010011	IC42	Operation mode											
806	0110010011	IC43	Operation mode											
807	1110010011	IC44	Operation mode											
808	0001010011	IC45	Operation mode											
809	1001010011	IC46	Operation mode											
810	0101010011	IC47	Operation mode											
811	1101010011	IC48	Operation mode											
812	0011010011	IC49	Operation mode											
813	1011010011	IC50	Operation mode											
814	0111010011	IC1	filter						0000 to 9999				B	Hours since last maintenance [ h ]
815	1111010011	IC2	filter						0000 to 9999					
816	0000110011	IC3	filter						0000 to 9999					
817	1000110011	IC4	filter						0000 to 9999					
818	0100110011	IC5	filter						0000 to 9999					
819	1100110011	IC6	filter						0000 to 9999					
820	0010110011	IC7	filter						0000 to 9999					
821	1010110011	IC8	filter						0000 to 9999					
822	0110110011	IC9	filter						0000 to 9999					
823	1110110011	IC10	filter						0000 to 9999					
824	0001110011	IC11	filter						0000 to 9999					
825	1001110011	IC12	filter						0000 to 9999					
826	0101110011	IC13	filter						0000 to 9999					
827	1101110011	IC14	filter						0000 to 9999					
828	0011110011	IC15	filter						0000 to 9999					
829	1011110011	IC16	filter						0000 to 9999					
830	0111110011	IC17	filter						0000 to 9999					
831	1111110011	IC18	filter						0000 to 9999					
832	0000010111	IC19	filter						0000 to 9999					
833	1000010111	IC20	filter						0000 to 9999					
834	0100010111	IC21	filter						0000 to 9999					
835	1100010111	IC22	filter						0000 to 9999					
836	0010001011	IC23	filter						0000 to 9999					
837	1010001011	IC24	filter						0000 to 9999					
838	0110001011	IC25	filter						0000 to 9999					
839	1110001011	IC26	filter						0000 to 9999					

0000: Stop 0001: Ventilation 0002: Cooling 0003: Heating 0004: Dry

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

10 LED Status Indicators

Data on indoor unit system

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks	
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8					
840	0001001011	IC27 filter					0000 to 9999							OC	Hours since last maintenance [ h ]
841	1001001011	IC28 filter					0000 to 9999							B	
842	0101001011	IC29 filter					0000 to 9999								
843	1101001011	IC30 filter					0000 to 9999								
844	0011001011	IC31 filter					0000 to 9999								
845	1011001011	IC32 filter					0000 to 9999								
846	0111001001	IC33 filter					0000 to 9999								
847	1111001011	IC34 filter					0000 to 9999								
848	0000101011	IC35 filter					0000 to 9999								
849	1000101011	IC36 filter					0000 to 9999								
850	0100101011	IC37 filter					0000 to 9999								
851	1100101011	IC38 filter					0000 to 9999								
852	0010101011	IC39 filter					0000 to 9999								
853	1010101011	IC40 filter					0000 to 9999								
854	0110101011	IC41 filter					0000 to 9999								
855	1110101011	IC42 filter					0000 to 9999								
856	0001101011	IC43 filter					0000 to 9999								
857	1001101011	IC44 filter					0000 to 9999								
858	0101101011	IC45 filter					0000 to 9999								
859	1101101011	IC46 filter					0000 to 9999								
860	0011101011	IC47 filter					0000 to 9999								
861	1011101011	IC48 filter					0000 to 9999								
862	0111101011	IC49 filter					0000 to 9999								
863	1111101011	IC50 filter					0000 to 9999								

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

**Other types of data**

No.	SW4 (SW6-9: OFF, SW6-10: OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,2</sup>	Remarks				
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8	OC							
871	1110011011	U-phase current effective value 1														A	The unit is [ A ]	
872	0001011011	W-phase current effective value 1															A	
873	1001011011	Power factor phase angle 1															A	The unit is [ deg ]
880	0000111011	Control board Reset counter															A	The unit is [ time ]
881	1000111011	INV board Reset counter															A	
884	0010111011	Fan board (address 5) reset counter															A	The unit is [ time ]
885	1010111011	Fan board (address 6) reset counter															A	
980	0010101111	M-NET processor SW version															A	

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.

\*2 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

10 LED Status Indicators

Current data

No.	SW4 (SW6-9:ON, SW6-10:OFF) 1234567890	Item	Display										Unit (A, B) <sup>*1,3</sup>	Remarks			
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8	OC						
1320	0001010010	Relay output display HBC main	SV1	21S4Ma	21S4Mb	52C											
1321	1001010010	WP1 control (HBC) (Main)															
1322	0101010010	WP2 control (HBC) (Main)															
1323	1101010010	WP1 rotation (HBC) (Main)															
1324	0011010010	WP2 rotation (HBC) (Main)															
1325	1011010010	TH11 (HBC) (Main)															
1326	0111010010	TH12 (HBC) (Main)															
1327	1111010010	TH13 (HBC) (Main)															
1328	0000110010	TH14 (HBC) (Main)															
1329	1000110010	TH15 (HBC) (Main)															
1330	0100110010	TH16 (HBC) (Main)															
1331	1100110010	TH31a (HBC) (Main)															
1332	0010110010	TH31b (HBC) (Main)															
1333	1010110010	TH31c (HBC) (Main)															
1334	0110110010	TH31d (HBC) (Main)															
1335	1110110010	TH31e (HBC) (Main)															
1336	0001110010	TH31f (HBC) (Main)															
1347	1100001010	TH32 (HBC) (Main)															
1348	0010001010	TH33 (HBC) (Main)															
1349	1010001010	TH34 (HBC) (Main)															
1350	0110001010	TH35 (HBC) (Main)															
1351	1110001010	SC1 (HBC) (Main)															
1352	0001001010	SC2 (HBC) (Main)															
1353	1001001010	SH1 (HBC) (Main)															
1354	0101001010	SH2 (HBC) (Main)															
1355	1101001010	PT1 (HBC) (Main)															
1356	0011001010	dPHM (HBC) (Main)															
1357	1011001010	PS1 (HBC) (Main)															
1358	0111001010	PS3 (HBC) (Main)															
1359	1111001010	LEV1 opening (HBC) (Main)															
1360	0000101010	LEV2 opening (HBC) (Main)															
1361	1000101010	LEV3 opening (HBC) (Main)															
1362	0100101010	TH31a (HBC) (Sub)															
1363	1100101010	TH31b (HBC) (Sub)															
1364	0010101010	TH31c (HBC) (Sub)															
1365	1010101010	TH31d (HBC) (Sub)															
1366	0110101010	TH31e (HBC) (Sub)															
1367	1110101010	TH31f (HBC) (Sub)															
1368	0001101010	TH31g (HBC) (Sub)															

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.  
 \*2 When multiple sub HBCs are connected to the outdoor unit, the addresses and the values of these controllers will be displayed on the maintenance LED in the following cycle: HBC (Sub1) address → HBC (Sub1) value → Blank → HBC (Sub2) address → HBC (Sub2) value → Blank → HBC (Sub3) address → HBC (Sub3) value → Blank → HBC (Sub1) address (cycles back to the beginning and repeats).  
 \*3 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.

No.	SW4 (SW6-9:ON, SW6-10:OFF) 1234567890	Item	Display								Unit (A, B) <sup>*1,3</sup> OC	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8		
1369	1001101010	TH31h (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1370	0101101010	TH31i (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1371	1101101010	TH31j (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1372	0011101010	TH31k (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1373	1011101010	TH31l (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1374	0111101010	TH31m (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1375	1111101010	TH31n (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1376	0000011010	TH31o (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1377	1000011010	TH31p (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1378	0100011010	TH32 (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1379	1100011010	TH33 (HBC) (Sub)	HBC (Sub) address ↔ -99.9 to 999.9 <sup>2</sup>									
1380	0010011010	VB3a (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1381	1010011010	VB3b (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1382	0110011010	VB3c (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1383	1110011010	VB3d (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1384	0001011010	VB3e (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1385	1001011010	VB3f (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999									
1396	0010111010	VB3a (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1397	1010111010	VB3b (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1398	0110111010	VB3c (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1399	1110111010	VB3d (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1400	0001111010	VB3e (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1401	1001111010	VB3f (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1402	0101111010	VB3g (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1403	1101111010	VB3h (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1404	0011111010	VB3i (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1405	1011111010	VB3j (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1406	0111111010	VB3k (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1407	1111111010	VB3l (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1408	0000000110	VB3m (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1409	1000000110	VB3n (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1410	0100000110	VB3o (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1411	1000000110	VB3p (HBC) (Sub)	HBC (Sub) address ↔ 0 or C1 to C999 or H1 to H999 or 1000 to 9999 <sup>2</sup>									
1412	0010000110	THHS1 (HBC) (Main)	HBC (Main) address ↔ -99.9 to 999.9									
1413	1010000110	THHS2 (HBC) (Main)	HBC (Main) address ↔ -99.9 to 999.9									
1414	0110000110	Pw1 (HBC) (Main)	HBC (Main) address ↔ 0.0 to 999.9									
1415	1110000110	Pw2 (HBC) (Main)	HBC (Main) address ↔ 0.0 to 999.9									
1416	0001000110	Pw3 (HBC) (Main)	HBC (Main) address ↔ 0.0 to 999.9									
1417	1001000110	Pw4 (HBC) (Main)	HBC (Main) address ↔ 0.0 to 999.9									
1420	0011000110	MV1 (HBC) (Main)	HBC (Main) address ↔ 0 or C1 to C715 or H1 to H800									

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.  
 \*2 When multiple sub HBCs are connected to the outdoor unit, the addresses and the values of these controllers will be displayed on the maintenance LED in the following cycle: HBC (Sub1) address → HBC (Sub1) value → Blank → HBC (Sub2) address → HBC (Sub2) value → HBC (Sub3) address → HBC (Sub3) value → Blank → HBC (Sub1) address (cycles back to the beginning and repeats).  
 \*3 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.









**Data before error**

No.	SW4 (SW6-9: ON, SW6-10: OFF) 1234567890	Item	Display								Unit (A, B) <sup>*1,3</sup> OC	Remarks
			LD1	LD2	LD3	LD4	LD5	LD6	LD7	LD8		
1757	1011101101	Pump1 inverter Vdc (HBC) (Main)	HBC (Main) address ↔ -99.9 to 999.9									
1758	0111101101	Pump2 inverter Vdc (HBC) (Main)	HBC (Main) address ↔ -99.9 to 999.9									

\*1 A: The condition of either OC or OS is displayed individually. B: The condition of the entire refrigerant system is displayed.  
 \*2 When multiple sub HBCs are connected to the outdoor unit, the addresses and the values of these controllers will be displayed on the maintenance LED in the following cycle: HBC (Sub1) address → HBC (Sub1) value → Blank → HBC (Sub2) address → HBC (Sub2) value → Blank → HBC (Sub3) address → HBC (Sub3) value → Blank → HBC (Sub1) address (cycles back to the beginning and repeats).  
 \*3 This model of outdoor units are not used in combination, so there are no OS units. Only the state of OC will be displayed.



# Service Handbook

**Model**

**PURY-M200, M250, M300, M350, M400, M450, M500YNW-A1**

**PURY-EM200, EM250, EM300, EM350, EM400, EM450, EM500YNW-A1**

**CMB-WM350, 500F-AA**

**CMB-WM108, 1016V-BB**

**MITSUBISHI ELECTRIC CORPORATION**

[www.MitsubishiElectric.com](http://www.MitsubishiElectric.com)