


# LOSSNAY HEAT RECOVERY VENTILATOR HANDBOOK

---

## MODELS

**VL-250CZPVU-L-E**  
**VL-250CZPVU-R-E**  
**VL-350CZPVU-L-E**  
**VL-350CZPVU-R-E**  
**VL-500CZPVU-L-E**  
**VL-500CZPVU-R-E**  
**VL-250CZPVU-L-ERT**  
**VL-250CZPVU-R-ERT**  
**VL-350CZPVU-L-ERT**  
**VL-350CZPVU-R-ERT**  
**VL-500CZPVU-L-ERT**  
**VL-500CZPVU-R-ERT**



Nameplate

\* The figure shows VL-350CZPVU-R-E.

### RC cover (Optional)

**P-RCC-E**

### Silencer box (Optional)

**P-250SB-E**

**P-350SB-E**

**P-500SB-E**

### Filter (Optional)

**P-250F-E**

**P-250SF-E**

**P-250MF-E**

**P-250PF-E**

**P-250PFH-E**

**P-250NF-E**

**P-350F-E**

**P-350SF-E**

**P-350MF-E**

**P-350PF-E**

**P-350PFH-E**

**P-350NF-E**

**P-500F-E**

**P-500SF-E**

**P-500MF-E**

**P-500PF-E**

**P-500PFH-E**

**P-500NF-E**

**Warning:**









Repair work must be performed by the manufacturer, its service agent or a similarly qualified person in order to avoid hazards.




# Contents

1. Safety precautions .....	3
2. Changed points .....	4
3. Names and functions of components .....	4-5
4. Specifications .....	6-8
5. Outside dimensions .....	9-16
6. Electrical wiring diagrams .....	17
7. Circuit board diagrams .....	18-20
8. Principles of operation .....	21-26
9. Troubleshooting .....	27-47
10. Service inspection list .....	48
11. Overhauling procedures .....	49-93
11-1 VL-250CZPVU-L type, VL-250CZPVU-R type .....	50-68
11-2 VL-350CZPVU-L type, VL-350CZPVU-R type .....	69-84
11-3 VL-500CZPVU-L type, VL-500CZPVU-R type .....	85-93
12. Parts catalog .....	94-166
VL-250CZPVU-L-E .....	95-100
VL-250CZPVU-R-E .....	101-106
VL-350CZPVU-L-E .....	107-112
VL-350CZPVU-R-E .....	113-118
VL-500CZPVU-L-E .....	119-124
VL-500CZPVU-R-E .....	125-130
VL-250CZPVU-L-ERT .....	131-136
VL-250CZPVU-R-ERT .....	137-142
VL-350CZPVU-L-ERT .....	143-148
VL-350CZPVU-R-ERT .....	149-154
VL-500CZPVU-L-ERT .....	155-160
VL-500CZPVU-R-ERT .....	161-166

# 1. Safety precautions

- Read the following precautions thoroughly before the maintenance, and then inspect and repair the product in a safe manner.
- The types and levels of danger that may arise if the product is handled improperly are described with the warning symbols shown below.

 <b>Warning</b>		Improper handling of the product may result in serious injury or death.	
<p>◇ <b>Electric shock</b> If you must inspect the circuitry while the power is on, do not touch the live parts.</p> <p>(Failure to observe this warning may result in electric shock.)</p>	 <small>Caution against electric shock</small>	<p>◇ <b>Turn off the power supply</b> Be sure to shut off the power supply isolator before disassembling the unit for repair.</p> <p>(Failure to observe this warning may result in electric shock.)</p>	 <small>Be sure to follow this instruction.</small>
<p>◇ <b>Modification is prohibited</b> Do not modify the unit.</p> <p>(Failure to observe this warning may result in electric shock, fire and/or injury.)</p>	 <small>Prohibited</small>	<p>◇ <b>Use proper parts and tools</b> For repair, be sure to use the parts listed in the parts catalog of the applicable model and use the proper tools.</p> <p>(Failure to observe this warning may result in electric shock, fire and/or injury.)</p>	 <small>Be sure to follow this instruction.</small>
<p>◇ <b>Proper electric work</b> Qualified electricians shall conduct electric work in accordance with your local electric work regulations and the installation manuals.</p> <p>(Improper connection or wiring installation may result in electric shock and/or fire.)</p>	 <small>Be sure to follow this instruction.</small>	<p>◇ <b>Replace damaged and/or degraded parts</b> Be sure to replace the power cord and lead wires if they are damaged and/or degraded.</p> <p>(Failure to observe this warning may result in electric shock and/or fire.)</p>	 <small>Be sure to follow this instruction.</small>
		<p>◇ <b>Check insulation</b> Upon completing repair work, always measure the insulation resistance. Verify that it is at least 10 MΩ (with a 500-V DC insulation resistance tester), and then turn on the power.</p> <p>(Inadequate insulation may result in electric shock.)</p>	 <small>Be sure to follow this instruction.</small>

 <b>Caution</b>		Improper handling of the product may result in injury or damage to properties including buildings and equipment.	
<p>◇ <b>Caution for injury</b> Do not work at a location where you do not have a sure footing.</p> <p>(Failure to observe this caution may result in a fall.)</p>	 <small>Prohibited</small>	<p>◇ <b>Wear gloves</b> Wear gloves when servicing.</p> <p>(Failure to observe this caution may result in injury to your hands from sharp metal or other edges.)</p>	 <small>Be sure to follow this instruction.</small>


## Notes for servicing

- Inspect the earth condition, and repair it if it is incomplete. Make sure that a power supply isolator and an over-load protection device are installed. If they are not installed, recommend the customer to install them.
- Make sure that the product operates properly upon completion of repair. Clean the product and the surrounding area, and then notify the customer of the completion of repair.

## 2. Changed points

New model	Previous model	Changes from the previous model
VL-250CZPVU-L-ERT	VL-250CZPVU-L-E	To meet certification requirements of the destination countries, Instruction Manual and Installation Manual are provided in the local languages: Russian, Kazakh, Armenian, and Ukrainian. The structure and characteristic values of the product are not changed.
VL-250CZPVU-R-ERT	VL-250CZPVU-R-E	
VL-350CZPVU-L-ERT	VL-350CZPVU-L-E	
VL-350CZPVU-R-ERT	VL-350CZPVU-R-E	
VL-500CZPVU-L-ERT	VL-500CZPVU-L-E	
VL-500CZPVU-R-ERT	VL-500CZPVU-R-E	

## 3. Names and functions of components



\* The figure shows VL-350CZPVU-R-E.

- For L-type (for example, VL-350CZPVU-L-E), filters, controller, and name plate are on the reflected positions.

No.	Name	Function
1	Exhaust air filter	It prevents the heat exchanger from clogging.
2	Exhaust air filter case	It holds the exhaust air filter.
3	Optional air filter case	For the optional filter (See the table below.)
4	Filter cover	-
5	Drain pipe attachment	It is connected to the drain pipe.
6	Control box	It holds the circuit board.
7	Name plate	It shows product name and serial No.
8	Outdoor air filter	It removes insects, pollen, dirt, dust, and other particles from the outdoor air that is taken into the room.
9	Outdoor air filter case	It holds the outdoor air filter.
10	Heat exchanger (Lossnay core)	It exchanges heat between the supply air and the return air.
11	Controller	Product operation * The controller can be installed externally. (Use the optional component P-RCC-E for external installation)

### Optional filter

Filter name	MODEL	Applicable model	Location to use	Main material	Replacement intervals
Replacement filter	P-250F-E	VL-250CZPVU series	RA, OA	PET, acrylic fiber	Three years
	P-350F-E	VL-350CZPVU series			
	P-500F-E	VL-500CZPVU series			
Standard filter	P-250SF-E	VL-250CZPVU series	RA, OA, SA	Polypropylene, polyester	One year
	P-350SF-E	VL-350CZPVU series			
	P-500SF-E	VL-500CZPVU series			
Medium efficiency filter	P-250MF-E	VL-250CZPVU series	RA, OA, SA	Polypropylene, polyester	One year
	P-350MF-E	VL-350CZPVU series			
	P-500MF-E	VL-500CZPVU series			
PM2.5 filter	P-250PF-E	VL-250CZPVU series	RA, OA, SA	Polypropylene, polyester	For SA installation: One year For OA and RA installations: Six months
	P-350PF-E	VL-350CZPVU series			
	P-500PF-E	VL-500CZPVU series			
PM1 filter	P-250PFH-E	VL-250CZPVU series	RA, OA, SA	Polypropylene, polyester	For SA installation: One year For OA and RA installations: Six months
	P-350PFH-E	VL-350CZPVU series			
	P-500PFH-E	VL-500CZPVU series			
NOx filter	P-250NF-E	VL-250CZPVU series	SA	Pulp	Six months
	P-350NF-E	VL-350CZPVU series			
	P-500NF-E	VL-500CZPVU series			


\* When a NOx filter and an optional dust catch filter (P-250/350/500SF-E, P-250/350/500MF-E, P-250/350/500PF-E, P-250/350/500PFH-E) are used together, be sure to install a NOx filter on the SA side and a dust catch filter on the OA side.

\* Install any of the filters other than NOx filter on the OA and RA side to protect the product.

# Installation example

## Notes

- Make sure that the exhaust air connection has two or more confluence points with the piping from the bathroom.
- Pre-heaters and electric dampers may be required in your region.
- Read the instructions carefully in advance when using optional components and commercially available components.



## 4. Specifications

Model	VL-250CZPVU-L-E, VL-250CZPVU-R-E VL-250CZPVU-L-ERT, VL-250CZPVU-R-ERT	
Heat exchange system	Heat recovery ventilating system	
Heat exchanger material	Sensible heat exchanger	
Cladding	Steel sheet	
Heat insulation material	Polyethylene foam	
Motor	DC motor	
Blower	180 mm diameter centrifugal fan	
Filter	Non-woven fabrics filter	
Duct connecting	Synthetic resin	
Duct connecting cover	Styrene foam	
Outside air condition	Shall be higher than -15°C	
Return (Suction) air condition	Shall be lower than 40°C, 95%RH	
Surrounding air condition	Indoor temperature and humidity should not exceed the dew point temperature 12°C (e.g. RH 60%, 20°C)	
Supply fan operation under low outdoor temperature	-3°C to -15°C: Intermittent operation -15°C or less: Supply air fan stopped.	*Exhaust air fan: continuous operation
Function	Heat exchange ventilation/ By-pass ventilation, Fan speed 1,2,3,4 The air flow increment by 1% from 25% to 100%	
Dimensions (Height x Width x Depth)	565 mm x 595 mm x 356 mm	
Weight	26 kg	
Electrical power supply	220–240 V 50 Hz/ 220 V 60 Hz	
Insulation resistance	10 MΩ or more	
Dielectric strength	1000 V AC 1 minute	
Maximum current [A]	1.00	

### ■ Specifications

Ventilation mode	Heat exchange mode			
	Fan Speed 4 (100%)	Fan Speed 3 (70%)	Fan Speed 2 (50%)	Fan Speed 1 (30%)
Fan speed				
Running current [A]	0.76	0.35	0.20	0.12
Input power [W]	106	44	23	11
Air volume	[m <sup>3</sup> /h]	250	175	125
	[L/s]	69	49	35
External static pressure [Pa]	150	74	38	14
Temperature exchange efficiency [%]	85	87	88	90
Sound pressure level at 3 m [dB]	31	22	16	15 >

### ■ Attention

1. The above values are at factory default.
2. The running current, the input power, the efficiency and the noise are based on the rating air volume, and 230 V 50 Hz.
3. The sound pressure level at 3 m is spherical.
4. Temperature exchange efficiency (%) is based on winter conditions.
5. Mitsubishi Electric measures figures in the chart according to EN13141-7:2010, and the characteristic curves are measured by chamber method.

Model	VL-350CZPVU-L-E, VL-350CZPVU-R-E VL-350CZPVU-L-ERT, VL-350CZPVU-R-ERT	
Heat exchange system	Heat recovery ventilating system	
Heat exchanger material	Sensible heat exchanger	
Cladding	Steel sheet	
Heat insulation material	Polyethylene foam	
Motor	DC motor	
Blower	210 mm diameter centrifugal fan	
Filter	Non-woven fabrics filter	
Duct connecting	Synthetic resin	
Duct connecting cover	Styrene foam	
Outside air condition	Shall be higher than -15°C	
Return (Suction) air condition	Shall be lower than 40°C, 95%RH	
Surrounding air condition	Indoor temperature and humidity should not exceed the dew point temperature 12°C (e.g. RH 60%, 20°C)	
Supply fan operation under low outdoor temperature	-3°C to -15°C: Intermittent operation -15°C or less: Supply air fan stopped.	*Exhaust air fan: continuous operation
Function	Heat exchange ventilation/ By-pass ventilation, Fan speed 1,2,3,4 The air flow increment by 1% from 25% to 100%	
Dimensions (Height x Width x Depth)	623 mm x 658 mm x 432 mm	
Weight	32 kg	
Electrical power supply	220–240 V 50 Hz/ 220 V 60 Hz	
Insulation resistance	10 MΩ or more	
Dielectric strength	1000 V AC 1 minute	
Maximum current [A]	1.32	

#### ■ Specifications

Ventilation mode	Heat exchange mode			
	Fan Speed 4 (100%)	Fan Speed 3 (70%)	Fan Speed 2 (50%)	Fan Speed 1 (30%)
Fan speed				
Running current [A]	1.08	0.52	0.31	0.18
Input power [W]	155	71	37	19
Air volume	[m <sup>3</sup> /h]	320	224	160
	[L/s]	89	62	44
External static pressure [Pa]	150	74	38	14
Temperature exchange efficiency [%]	85	87	88	90
Sound pressure level at 3 m [dB]	35	26	19	15 >

#### ■ Attention

1. The above values are at factory default.
2. The running current, the input power, the efficiency and the noise are based on the rating air volume, and 230 V 50 Hz.
3. The sound pressure level at 3 m is spherical.
4. Temperature exchange efficiency (%) is based on winter conditions.
5. Mitsubishi Electric measures figures in the chart according to EN13141-7:2010, and the characteristic curves are measured by chamber method.

Model	VL-500CZPVU-L-E, VL-500CZPVU-R-E VL-500CZPVU-L-ERT, VL-500CZPVU-R-ERT	
Heat exchange system	Heat recovery ventilating system	
Heat exchanger material	Sensible heat exchanger	
Cladding	Steel sheet	
Heat insulation material	Polyethylene foam	
Motor	DC motor	
Blower	230 mm diameter centrifugal fan	
Filter	Non-woven fabrics filter	
Duct connecting	Synthetic resin	
Duct connecting cover	Styrene foam	
Outside air condition	Shall be higher than -15°C	
Return (Suction) air condition	Shall be lower than 40°C, 95%RH	
Surrounding air condition	Indoor temperature and humidity should not exceed the dew point temperature 12°C (e.g. RH 60%, 20°C)	
Supply fan operation under low outdoor temperature	-3°C to -15°C: Intermittent operation -15°C or less: Supply air fan stopped.	*Exhaust air fan: continuous operation
Function	Heat exchange ventilation/ By-pass ventilation, Fan speed 1,2,3,4 The air flow increment by 1% from 25% to 100%	
Dimensions (Height x Width x Depth)	632 mm x 725 mm x 556 mm	
Weight	39 kg	
Electrical power supply	220–240 V 50 Hz/ 220 V 60 Hz	
Insulation resistance	10 MΩ or more	
Dielectric strength	1000 V AC 1 minute	
Maximum current [A]	2.3	

#### ■ Specifications

Ventilation mode	Heat exchange mode			
	Fan Speed 4 (100%)	Fan Speed 3 (70%)	Fan Speed 2 (50%)	Fan Speed 1 (30%)
Fan speed				
Running current [A]	1.73	0.77	0.40	0.19
Input power [W]	275	104	49	21
Air volume	[m <sup>3</sup> /h]	500	350	250
	[L/s]	139	97	69
External static pressure [Pa]	200	98	50	18
Temperature exchange efficiency [%]	85	87	89	92
Sound pressure level at 3 m [dB]	37	29	22	15 >


#### ■ Attention

1. The above values are at factory default.
2. The running current, the input power, the efficiency and the noise are based on the rating air volume, and 230 V 50 Hz.
3. The sound pressure level at 3 m is spherical.
4. Temperature exchange efficiency (%) is based on winter conditions.
5. Mitsubishi Electric measures figures in the chart according to EN13141-7:2010, and the characteristic curves are measured by chamber method.




# 5. Outside dimensions

VL-250CZPVU-L-E, VL-250CZPVU-L-ERT




## Working space (Required space around the Lossnay unit)




Unit (mm)


VL-250CZPVU-R-E, VL-250CZPVU-R-ERT



RA: Return Air  
 SA: Supply Air  
 EA: Exhaust Air  
 OA: Outdoor Air




**Working space (Required space around the Lossnay unit)**




Unit (mm)

VL-350CZPVU-L-E, VL-350CZPVU-L-ERT

RA: Return Air  
 SA: Supply Air  
 EA: Exhaust Air  
 OA: Outdoor Air




**Working space (Required space around the Lossnay unit)**




Unit (mm)

VL-350CZPVU-R-E, VL-350CZPVU-R-ERT

RA: Return Air  
 SA: Supply Air  
 EA: Exhaust Air  
 OA: Outdoor Air




**Working space (Required space around the Lossnay unit)**




Unit (mm)

VL-500CZPVU-L-E, VL-500CZPVU-L-ERT

RA: Return Air  
 SA: Supply Air  
 EA: Exhaust Air  
 OA: Outdoor Air




**Working space (Required space around the Lossnay unit)**




Unit (mm)

VL-500CZPVU-R-E, VL-500CZPVU-R-ERT




**Working space (Required space around the Lossnay unit)**




Unit (mm)

P-RCC-E

■ RC cover



■ Cable with noise filter



Unit (mm)


P-250F-E, P-250SF-E, P-250MF-E, P-250PF-E, P-250PFH-E, P-250NF-E, P-350F-E, P-350SF-E, P-350MF-E, P-350PF-E, P-350PFH-E, P-350NF-E, P-500F-E, P-500SF-E, P-500MF-E, P-500PF-E, P-500PFH-E, P-500NF-E



MODEL	A	B
P-250F-E	302	178
P-250SF-E, P-250MF-E, P-250PF-E P-250PFH-E, P-250NF-E	306	177
P-350F-E	377	178
P-350SF-E, P-350MF-E, P-350PF-E P-350PFH-E, P-350NF-E	382	177
P-500F-E	502	178
P-500SF-E, P-500MF-E, P-500PF-E P-500PFH-E, P-500NF-E	506	177


Unit (mm)

P-250SB-E




Unit (mm)

P-350SB-E



Unit (mm)

P-500SB-E




Unit (mm)




# 6. Electrical wiring diagrams

VL-250CZPVU-L-E, VL-250CZPVU-R-E, VL-350CZPVU-L-E, VL-350CZPVU-R-E, VL-500CZPVU-L-E  
 VL-500CZPVU-R-E, VL-250CZPVU-L-ERT, VL-250CZPVU-R-ERT, VL-350CZPVU-L-ERT, VL-350CZPVU-R-ERT  
 VL-500CZPVU-L-ERT, VL-500CZPVU-R-ERT



### Wiring example

- NOTE
1. Connect the bold lines.
  2. Make sure to connect the ground wire.



Definition of symbols			
M1	Motor for exhaust fan	CN18, CN19, CN118, CN119	Connector
M2	Motor for supply fan	CN130, CN131, CN132, CN232	Connector
GM	Motor for By-pass damper	CN217, CN26, CN32	Connector
TH1	Thermistor for outside air	CN22	Connector (Thermistor OA)
TH2	Thermistor for return air	CN5	Connector (Thermistor RA)
TM2	Terminal block (External control input)	CN7	Connector (Motor for By-pass damper)
TM4	Terminal block (Remote controller)	LED1 to LED4	Inspection indicator lamp
TM3	Terminal block (Monitor output)	LED6	Power supply indicator lamp
TM200	Terminal block (0-10 V DC)	SA1	Not in use
TM201	Terminal block (Volt-free)	SA2	Not in use
TAB1, TAB2	Connector (Power supply)	SW2	Function selection Switch
TAB3, 4	Connector (Reactor)	SW5, SW7	Not in use (or Not equipped)
TAB5	Not in use (or Not equipped)	SW6	Model selection switch
CN9, CN10	Connector (Fan motor)	SYMBOL	Terminal block
CN17 to CN20	Connector	⊙ □	Connector on PCB
CN105	Connector (IT)	Ⓛ	


### Attention

1. Electrical work must be carried out safely and reliably by a professional electrical contractor (properly qualified electrician) in accordance with internal wiring provisions and electrical-equipment technical standards.
2. Use 220 to 240 V AC Power.
3. Use the designated electric wires, and connect them securely so that they do not come loose.
4. Be sure to install the ground wire.
5. Install an all-pole power supply isolator at the power supply side as per local electrical regulations. All supply circuits must be disconnected before obtaining access to the terminal devices. Use the specified size cable and connect the cables securely to prevent disconnection when they are pulled.

# 7. Circuit board diagrams

## ● Circuit board diagrams and check points


### (1) Control circuit board



## (2) Power circuit board

### Caution:


The power circuit board is not insulated from the power line (high voltage part), except for the connection part (CN118 and CN119) with the control circuit board. Also, even when the power supply is cut off, the capacitor is charged. Therefore, wait for at least five minutes before starting work.




### (3) Power interface circuit board

**Caution:**

The power interface circuit board is not insulated from the power line (high voltage part), except for the connection part (CN132) with the signal interface circuit board. Also, even when the power supply is cut off, the capacitor is charged. Therefore, wait for at least five minutes before starting work.



### (4) Signal interface circuit board




# 8. Principles of operation

## (1) Terminal connection specifications and functions

Terminal		Category	No.	Input/ Output	Terminal rating	Selection requirement		Wiring example		
						Diameter and length of wires	Sensor, switch, etc.			
TM200	1	Analog input (for sensor)	1	Input	Max.: 10 V DC Polarity	0.5 mm <sup>2</sup> –0.75 mm <sup>2</sup>	0-10 V DC	Fig. 1		
	-									
	2	Analog input (for sensor)	2	Input						
	-									
TM201	1	Volt-free contact (for By-pass switch)		Input	No-Polarity	0.5 mm <sup>2</sup> –0.75 mm <sup>2</sup>	Contact rating: 15 V DC, 0.1 A Min. applicable load: 1 mA	Fig. 2		
	2									
	3								Volt-free contact (for boost switch)	
	4									
TM2	1	Slim-Lossnay interlocking		Input	No-Polarity	0.5 mm <sup>2</sup> –1.5 mm <sup>2</sup> * See the manual of the external device (Slim).	—	Fig. 3		
	2									
	3									
TM3	7	Volt-free contact signal for By-pass monitor or Pre-heater signal		Output	Max.: 24 V DC, 1 A Min.: 5 V DC, 0.1 A No-Polarity	0.5 mm <sup>2</sup> –0.75 mm <sup>2</sup>	Max.: 24 V DC, 1 A Min.: 5 V DC, 0.1 A	Fig. 4		
	8								Volt-free contact signal for Malfunction moni- tor or Outdoor shutter signal	
	9									Volt-free contact signal for Operation monitor (Exhaust fan, Supply fan, or After-heater)
	10									
TM4	1	Remote Controller		In/Out	No-Polarity	0.3 mm <sup>2</sup> Max. 200 m	—	Fig. 5		
	2									
CN105		IT interconnection Wi-Fi		In/Out	—	—	—	Fig. 6		

Fig. 1




The unit can be operated by the DC power supply input from external devices.

**Notes**

- Misconnection may cause malfunction of external device.
- Be sure to check the polarity.
- Be sure to connect electric wires correctly.
- Terminal block has a seal attached on No. 2 terminals. When using No. 2 terminals, remove the seal.

Fig. 2




**Volt-free contact**

When the contact is ON (closed), the signal is input, when the contact is OFF (open), the signal is stopped.

**Note**

- Since the circuit ensures 1 mA when the switch is turned on, the maximum number of switches that can be used for Volt-Free contact input is one when the minimum load capacity is 1 mA.

Fig. 3



You can control the product by Mr. Slim's remote controller. Extend the Slim-Lossnay interlocking cable connected to Mr. Slim PCB. Connect the cable to TM2 of the product. When interlocked with Mr. Slim, signals from Mr. Slim operate/stop Lossnay. (The product stops regardless of the Enable OFF button setting.)

**Notes**

- Be sure to check the setting of Mr. Slim in line with the following.
- At the selection of the remote controller functions of Mr. Slim, check that the Lossnay connectivity setting is set to "Not supported".
- This use method limits the functions is as below.
  - Other external input functions cannot be used together.
  - Interlocking commands from Mr. Slim do not operate the Boost/Purge modes.

Lossnay external control input TM2






Fig. 4

**<Examples of electric wiring for function setting No. 57 TM3 9-10>**

Function setting value [1]: Exhaust air fan  
 Function setting value [2]: Supply air fan




Function setting value [3]: Supply air after-heater




**<Examples of electric wiring for function setting No. 58 TM3 7-10>**

Function setting value [1]: By-pass ventilation




Function setting value [2]: Supply air pre-heater



**<Examples of electric wiring for function setting No. 81 TM3 8-10>**

Function setting value [0]: Malfunction monitor



Function setting value [1]: Outdoor air shutter





Fig. 5


Remote controller



**Note**

- Remove the controller installed on the product. Install the controller externally with extension cables following the manual attached to P-RCC-E. The product cannot be controlled by multiple remote controllers.

Fig. 6



**Note**



- Applications are not included.

## (2) Function setting list

Function No.	Function name	Function setting value									Factory default setting	Function description	
		[0]	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]			[9]
1	1: Filter maintenance indicator / 2: Fan power increase	—	1: Yes / 2: No	1: No / 2: No	1: Yes / 2: Yes	—	—	—	—	—	—	1	1: Set the filter maintenance indication to Show/Hide. 2: Set Use/No use of the function that increases the fan output every 1/3 of maintenance interval passes described in "6.4.11 Maintenance interval" of the Installation Manual. - This function cannot be used when the fan output is set to the highest (100%).
2	Lossnay core maintenance indicator setting	Not available	Available	—	—	—	—	—	—	—	—	0	Lossnay core maintenance icon display setting To show the icon 1. Set the function No. 86 to "Show". 2. Set the display interval on the "Maintenance interval" screen.
5	Power recovery mode	—	Stop	Run	Auto- matic recov- ery	—	—	—	—	—	—	3	Set the operation mode when the power is recovered after a power failure. [1] Stop: Lossnay remains stopped when the power is recovered. [2] Run: Lossnay starts operation when the power is recovered. [3] Automatic recovery: Lossnay returns to the state before interruption.
9	Delay start setting for air conditioner starting	—	Not available	Available /15 min.	Available /30 min.	—	—	—	—	—	—	1	This function delays operation of Lossnay for the specified period of time while the air-conditioner is warming up to mitigate outdoor air load.
13	Exhaust fan setting during air conditioner defrosting	—	Stop	No Change	—	—	—	—	—	—	—	1	Operation status setting of the exhaust fan when the air-conditioner (Mr. Slim) starts defrosting operation while it is interlocked with Lossnay.
36	Outdoor temperature indication	Hide	Show	—	—	—	—	—	—	—	—	0	Set to Show/Hide the temperature detected by the built-in thermistors. Set the settings of "6.4.2.4 Display details" of the Installation Manual also.
37	Indoor temperature indication	Hide	Show	—	—	—	—	—	—	—	—	0	No. 36: LO is displayed when lower than 2°C and HI is displayed when 36°C or higher. No. 37: LO is displayed when lower than 9°C and HI is displayed when 37°C or higher. No. 38: This is the same as No. 37.
38	Supply air (calculated value) temperature indication	Hide	Show	—	—	—	—	—	—	—	—	0	<b>Note</b> If both function settings No. 38 and 84 are [1], only the function setting No. 84: CO <sub>2</sub> concentration is displayed on the Main display screen. (Since the same display position is allocated, the priority is given to the indication of function setting No. 84: CO <sub>2</sub> concentration.)
39	Correction of temperature exchange efficiency (tens digit)	Function setting value: 0 to 9 → Temperature exchange efficiency (tens digit): 0 to 9									8	Set the value of temperature exchange efficiency used for the calculated value of No. 38 Supply air temperature indication.	
40	Correction of temperature exchange efficiency (ones digit)	Function setting value: 0 to 9 → Temperature exchange efficiency (ones digit): 0 to 9									5	Factory default setting: 85%	



Function No.	Function name	Function setting value									Factory default setting	Function description
		[0]	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]		
41	Correction of outdoor temperature	Function setting value: 0 to 14 → Correction of outdoor temperature: -7°C to 7°C (1°C intervals)									7	<p>When No. 36 Outdoor temperature indication and No. 37 Indoor temperature indication are set to <i>Show</i>, set the correction value of the temperature shown on the controller. Example: If the temperature detected by the built-in thermistor is 20°C and the correction value is +3°C (the function setting value is 10), the temperature indicated by the controller will be 23°C.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>- The indication value is not corrected when <i>Lo</i> or <i>Hi</i> is displayed.</li> <li>- Correction values are not reflected to the control (such as Auto By-pass) using outdoor/indoor temperatures.</li> </ul>
42	Correction of indoor temperature	Function setting value: 0 to 14 → Correction of indoor temperature: -7°C to 7°C (1°C intervals)									7	
57	External output setting 1	—	Exhaust air fan monitor	Supply air fan monitor	Supply air after-heater	—	—	—	—	—	1	<p>Set the ON/OFF conditions of terminal block TM3 9–10.</p> <p>[1] Exhaust air fan monitor: The output turns ON/OFF in line with the operation/stop of the exhaust air fan. (The operation is the same as ON/OFF operation by the controller.)</p> <p>[2] Supply air fan monitor: The output turns ON/OFF in line with the operation/stop of the supply air fan. (Depending on the conditions such as outdoor temperatures, the output can be off automatically.)</p> <p>[3] Supply air after-heater: The output turns ON 10 seconds after the supply air fan operation./ The supply air fan stops three minutes after the output is turned OFF. - Set the setting when supply air after-heaters are connected.</p>
58	External output setting 2	—	By-pass ventilation monitor	Supply air pre-heater	—	—	—	—	—	—	1	<p>Set the ON/OFF conditions of terminal block TM3 7–10.</p> <p>[1] By-pass ventilation monitor: The output turns ON/OFF in line with the status (By-pass/Heat exchange ventilation) of the ventilation mode. (The output turns ON/OFF in line with the operation of the built-in By-pass damper.)</p> <p>[2] Supply air pre-heater: The output turns ON 10 seconds after the supply air fan operation./ The supply air fan stops three minutes after the output is turned OFF. - Set the setting when supply air pre-heaters are connected. - The output turns OFF when the outdoor temperature is 15°C or higher. - The output ON/OFF conditions can be changed by the function settings Nos. 59 and 60.</p>

Function No.	Function name	Function setting value										Factory default setting	Function description	
		[0]	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]			
59	Conditions for pre-heater ON (Supplemental setting for the function setting No. 58 )	Function setting value: 0 to 15 → Threshold of outdoor temperature: 0°C to -15°C (1°C intervals)										0	Set the ON/OFF conditions of the function setting No. 58 [2] Supply air pre-heater. No. 59: Set the threshold of the outdoor temperature that makes the pre-heater turns ON. (The pre-heater turns ON when the temperature becomes lower than the threshold temperature.)	
60	Conditions for pre-heater OFF (Supplemental setting for the function setting No. 58 )	1 hour	2 hours	3 hours	4 hours	5 hours	—	—	—	—	—	0	No. 60: Set the time to turn OFF the pre-heater after the turning ON.	
81	External output setting 3	Mal-function monitor	Outdoor air shutter	—	—	—	—	—	—	—	—	0	Set the ON/OFF conditions of terminal block TM3 8–10. [0] Malfunction monitor: The output turns ON when a malfunction occurs on the product. (This is used to indicate malfunctions aside from the controller.) [1] Outdoor air shutter: Set the setting so that the output ON/OFF match with the open/closed of the shutter installed on the OA duct. - Output ON (shutter: open) conditions: 10 seconds before starting the supply air fan operation - Output OFF (shutter: closed) conditions: The built-in thermistors detect that the outdoor temperature is -18°C or lower and 20 seconds have elapsed after the supply air fan stopped.	
82	Standard air speed setting			—	—	—	—	—	—	—	—	0	Set the base fan speed. The setting can be changed with the controller. See "6.4.2.7 Control mode" of the Installation Manual. The priority is given to the latest setting.	
83	Manual input priority mode	Not available	Available (See below for time setting.)								—	—	0	Set the base fan speed to a higher priority for the certain period of time. Use this mode when you want to prioritize manual input (input from the controller or MELCloud application) over external input control.
84	CO <sub>2</sub> concentration indication	Hide	Show	—	—	—	—	—	—	—	—	0	Set Show/Hide the CO <sub>2</sub> concentration values connected to the Analog input 1 of TM200. Set the settings of "6.4.2.4 Display details" and "6.4.5.2 Analog input 1" of the Installation Manual also. <b>Note</b> If both function settings No. 38 and 84 are [1], only the function setting No. 84: CO <sub>2</sub> concentration is displayed on the Main display screen. (Since the same display position is allocated, the priority is given to the indication of function setting No. 84: CO <sub>2</sub> concentration.)	
86	Lossnay core maintenance item display setting	Hide	Show	—	—	—	—	—	—	—	—	0	Set to Show/Hide "Lossnay core maintenance indicator setting" on the controller. Use the function No. 2 to configure the Lossnay core maintenance icon display setting.	
100	Initialization	—	Initialize	—	—	—	—	—	—	—	—	0	Reset the function settings done by the user to the factory settings.	

In the following conditions, error code 3126 (external device error) is displayed on the controller and the output of the function setting No. 81 "[0] Malfunction monitor" turns ON.

- When the built-in OA thermistor detects 15°C or higher within 15 minutes from the start of output of the supply air pre-heater/after-heater.
- When the built-in OA thermistor detects -10°C or lower 60 minutes after the start of output of the supply air pre-heater/after-heater.

# 9. Troubleshooting


## ■ Work precautions

- When servicing, recreate the malfunction two or three times before starting repairs.
- When servicing, always keep proper footing.
- When servicing, be sure to turn off the circuit breaker. Pay sufficient attention to avoid electric shock or injury.
- Be sure to connect the power supply wires correctly.
- Avoid application of abnormal voltage.
- Before connecting or disconnecting the motor connectors (CN9, CN10), be sure to turn off the circuit breaker and check that the LEDs on the control circuit board are not lit. Otherwise, the circuit board inside the DC motor may get damaged.
- When removing the circuit board, always hold it at both ends and remove carefully in order not to apply force to the surface mounted parts.
- When removing the circuit board, be careful of the metal edges on the board.
- When removing or inserting the connectors for the circuit board, hold the entire housing section. Never pull on the lead wires.
- When circuit board failure is considered to be a cause, check closely for any broken section on the copper foil patterns, burning or discoloration of parts.
- After replacing a circuit board, be sure to restore the same controller settings as before the replacement.
- Do not touch the circuit board and fan motor while the LED on the power circuit board is on.
- When the controller or control circuit board is replaced, the information set by the user using the controller will be lost. It is recommended to keep a record of the settings before replacement so that you can restore them. (Settings such as the fan speed might have been recorded during installation on the settings sheet included with the product.)

## (1) Service flowchart

After checking the preliminary check items below, follow the troubleshooting for servicing depending on the failure mode.

	Preliminary check items	Details
Service call	1. Product information	<ul style="list-style-type: none"> <li>• Model name of the product, circuit board name</li> <li>• Serial number of the product, manufacturing lot number of the circuit board</li> <li>• Microcomputer identification number on circuit board</li> </ul>
	2. Condition of trouble	<ul style="list-style-type: none"> <li>• Fault status (e.g., the fan does not operate.)</li> <li>• Error code display and icon display on the controller</li> <li>• Operation setting of the controller (ventilation mode setting, fan speed setting, etc.)</li> </ul>
	3. Frequency of fault occurrence	<ul style="list-style-type: none"> <li>• Frequency of fault occurrence (frequency of time and date of occurrence, regularity of occurrence, etc.)</li> <li>• Operating time up to fault occurrence</li> <li>• Date of start of use, date of fault occurrence</li> </ul>
	4. Timing of fault occurrence	<ul style="list-style-type: none"> <li>• Controller operation performed before fault occurrence</li> <li>• Operating status, etc.</li> </ul>
	5. System settings	<ul style="list-style-type: none"> <li>• Interlock operation with an external device</li> <li>• Function setting using the controller</li> </ul>
	6. With or without working drawings	<ul style="list-style-type: none"> <li>• System configuration (connection of auxiliary fan, etc.)</li> <li>• Wiring</li> <li>• Record of the Lossnay function setting statuses</li> </ul>



## (2) Checklist

Failure mode 1	Lossnay does not work.
----------------	------------------------

### ● Initial check items

If the product does not start properly, check the following items.

#### [1] Power

No.	Check item	Corrective action
1	Is the main power supply on?	Turn the main power supply on.
2	Is the current capacity of the power supply isolator appropriate?	Use the appropriate isolator.
3	Is the designated cable used for the power supply cable?	Use the designated cable.
4	Is the specified power supplied to the power supply connector?	Use the specified voltage.
5	Is the power supply cable incorrectly wired, or is there a faulty connection?	Connect the power supply cable securely.
6	Is the power supply indicator on the control circuit board "LED4 (red)" lit?	Pull out the control circuit board from the product and check the LED indication. The LED lights while power is being supplied. If not lit, check the points above.

[2] Transmission cables (remote controller cable (when the controller is installed externally), external input signal cable)

No.	Check item	Corrective action
1	Are the designated cables used for the remote controller cable? (Table [2]-1)	Use the designated cables.
2	Are the designated parts used for the external input signal cable? (Table [2]-2)	Use the designated parts.
3	Are the transmission cables wired using multicore cables?	Use the designated transmission cables.
4	Are multiple transmission cables wired in the same cable duct?	Wire the cables apart from each other.
5	Is the power supply cable wired at least 50 mm away from transmission cables?	Wire the cables at least 50 mm away from the other cables.
6	Are the transmission cables connected to the designated terminal blocks? (Tables [2]-1 and [2]-2)	Connect the cables to the specified terminal blocks.
7	Are the transmission cables incorrectly wired, is there a faulty connection or are screws loose?	Connect them securely, and tighten the screws firmly.
8	Is the wiring length of the transmission cable within the regulations? (Tables [2]-1 and [2]-2)	Wire the cables within the regulations.
9	Does the external input signal match the specifications? (Table [2]-2)	Input the signal that matches the specifications.

Table [2]-1 Remote controller cable specifications

Type	Sheathed cable
Number of cores	2-core cable
Cable diameter	0.3 mm <sup>2</sup>
The wiring length	200 m or shorter (total length)
Terminal block	TM4 [1] [2]

Table [2]-2 External input specifications

Function name	Terminal block on the circuit board	Signal specifications (Note 1)	Materials used	The wiring length
Analog input 1	TM200 [1]	10 V DC	Twisted cable 0.5 mm <sup>2</sup> - 0.75 mm <sup>2</sup>	Not specified
Analog input 2	TM200 [2]			
Bypass input	TM201 [1] [2]	Volt-free contact		
Boost input	TM201 [3] [4]			
Air conditioner (Mr. Slim) control signal	TM2 [1] [2]	Serial signal	Twisted cable 0.5 mm <sup>2</sup> - 1.5 mm <sup>2</sup>	500 m

(Note 1) The input signal specifications must conform to the following specifications.

In the case of relay contact input, use a relay having a contact rating of 15 V DC/0.1 A or higher and a minimum applicable load of 1 mA or less.

### [3] Monitor output signal cable

No.	Check item	Corrective action
1	Is the signal cable wired by multicore cable?	Wire the cable using a 2-core cable.
2	Are the signal cables and transmission cables wired in the same piping duct?	Wire the signal cables away from the transmission cables.
3	Is the power supply cable wired at least 50 mm away from signal cables?	Wire the cables at least 50 mm away from the other cables.
4	Are the signal cables connected to the designated terminal blocks? (Table [3]-1)	Connect the cables to the specified terminal blocks.
5	Are the signal cables incorrectly wired, is there a faulty connection or are screws loose?	Connect them securely, and tighten the screws firmly.
6	Is the output capacity of the signal cable within rating? (Table [3]-1)	Use the signal cable within rating.

Table [3]-1 Monitor output specifications

Terminal block	TM3 [9] [10]	TM3 [7] [10]	TM3 [8] [10]
Function Name (Factory default) (Note 1)	Operation monitor	By-pass ventilation monitor	Malfunction monitor
Signal specifications	Volt-free a contact		
Terminal rating	24 V DC / 1 A		
Min. applicable load	5 V DC / 100 mA		

(Note 1) Output can be changed with function settings.

### [4] Function setting

No.	Check item	Corrective action
1	Is the function selection switch on the circuit board set correctly to suit the required application?	Set the function selection switch (SW2) on the control circuit board correctly.
2	Is the supplied controller used?	Use the supplied controller. The Lossnay controllers sold separately (PZ-61DR-E, PZ-43SMF-E, etc.) cannot be used.
3	When the controller is used, are the function selections set correctly to suit the required application?	Set the function selections correctly. After setting the controller functions, operating the model selection switch (SW6) on the control circuit board resets the settings to the initial settings.

### [5] LED Indications on the circuit board

No.	LED	Contents	Check item	Corrective action
1	LED1 (green)	Lossnay main unit error indicator	Blinking: Starting up, error occurred	Refer to Failure mode 5.
			Lit: During delay operation	The unit operates after the delay time has passed.
			Unlit: Other than above	It is normal.
2	LED2 (red)	M-NET system Error indication	Lit: No M-NET connection information	It is normal.
3	LED3 (green)	Controller power supply indicator	Lit: Power supplied to the controller.	It is normal.
4	LED4 (red)	Control circuit board power supply indicator	Check that this LED is lit.	The LED lights while power is being supplied to the control circuit board.
5	LED6 (red)	Power circuit board power supply indicator	Check that this LED is lit.	The LED lights while power is being supplied to the power circuit board. (Never touch the board while power is supplied to avoid an electric shock.)

● Individual function check items

If Lossnay does not work in the trial operation or Lossnay stops working during use, check the following items.

No.	Symptom	Cause	Corrective action
1	The fan does not operate even though the trial operation switch (SW2-1) is turned ON.	The connectors between the fan motor and power circuit board are disconnected.	Check the connector (CN9) for the exhaust fan motor and the connector (CN10) for the supply fan motor. * Before connecting or disconnecting the motor connectors (CN9, CN10), be sure to turn off the circuit breaker and check that the LEDs on the control circuit board are not lit.
		The connectors between the control circuit board and power circuit board are disconnected.	Check connection of the following connectors: Control circuit board: CN18, CN19 Power circuit board: CN118, CN119
		The relay connector is disconnected.	Check the relay connector connection. * Before connecting or disconnecting the relay connectors, be sure to turn off the circuit breaker and check that the LEDs on the control circuit board are not lit.
		Fan motor malfunction	Refer to "Failure mode 5 - Error code: 4116" (page 37).
		Circuit board failure	If LED6 on the power circuit board is not lit, check power supply to TAB1 and TAB2. If no error is found with power supply, replace the power circuit board. If the problem persists, replace the DC motor of the fan.
		Power with the rated voltage is not supplied to the product.	Check the power supply voltage.
2	Though the controller display indicates the fan is running, the fan stops by itself.	Automatic supply air stop/ Automatic supply air intermittent operation is being performed.	The icon "⚡" indicating operation in the protective mode is displayed. Refer to "Display" in Chapter 5 of the Instruction Manual.
		The unit is set to the delay operation.	LED1 (green) on the control circuit board lights. Lossnay operates in 30 minutes (or 15 minutes) after being turned on. Check the function setting No. 9 value of the controller. (Refer to the function No. 9 in "8. (2) Function setting list (page 24)" for details.)
		An interlocked air conditioner (Mr. Slim) is defrosting and the fan is stopped.	The fan has been stopped to prevent cold air from blowing out. When the air conditioner fan starts, the fan of Lossnay starts automatically. The operation status of the exhaust fan can be selected. (Refer to the function No. 13 in "8. (2) Function setting list (page 24)" for details.)
		The ventilation switching damper is operating.	The fan stops while the ventilation switching damper is operating. Also, the fan may stop temporarily to check the damper operation regularly.
3	Even though the controller is operated to change the fan speed, the fan speed does not change.	Automatic supply air stop/ Automatic supply air intermittent operation is being performed.	The icon "⚡" indicating operation in the protective mode is displayed. Refer to "Display" in Chapter 5 of the Instruction Manual.

No.	Symptom	Cause	Corrective action
4	Even though the controller is operated to change the ventilation mode, the ventilation switching damper is not moved.	The outdoor air temperature is 8 °C or lower.	When the outdoor air temperature is 8°C or lower, the ventilation mode is fixed to the Heat exchange ventilation mode.
5	When the ventilation mode is set to automatic ventilation mode, the ventilation switching damper does not operate.	Temperature condition for the Heat exchange ventilation or By-pass ventilation is not satisfied.	Check the temperature map. For details, see "6.4.4 Auto Bypass" of the Installation Manual.
		The outdoor air temperature is 8 °C or lower.	When the outdoor air temperature is 8°C or lower, the ventilation mode is fixed to the Heat exchange ventilation mode.
		The operation mode of the interlocked air conditioner (Mr. Slim) is set to heating or air-blowing operation.	If the operation mode of the interlocked air conditioner is heating or air-blowing operation, the ventilation mode is fixed to the Heat exchange ventilation mode.



Failure mode 2	The controller does not work.
----------------	-------------------------------

If the controller does not work, check the following items.

No.	Symptom	Cause	Corrective action
1	Nothing is displayed on the screen. The ON/OFF lamp does not blink.	The power of the Lossnay unit is not ON.	Refer to section [1] of "Failure mode 1".
		Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1".
		The wiring length of the controller exceeds 200 m.	The wiring length of the controller shall be within 200 m.
		The controller is connected to the incorrect terminal block (TB5 [A] [B]).	Connect the controller cable to the terminal block (TM4 [1] [2]).
		If the above does not solve the problem	Refer to [Nothing is displayed on the controller] (page 33).
2	The controller continues to display "Please Wait". Error code "6831" is displayed.	The controller is starting up.	The controller displays "Please Wait" during start-up for maximum three minutes.
		Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1."
		The controller is connected to the incorrect terminal block (TB5 [A] [B]).	Connect the controller cable to the terminal block (TM4 [1] [2]).
		The separately sold controller is connected.	Use the supplied controller.
		Lossnay units and the air conditioner (Mr. Slim) units are connected within the same group.	Assign the Lossnay units and air conditioner (Mr. Slim) units to the different groups.
3	It takes time for the controller to be fed with power after turning the power to the Lossnay unit ON.	The Lossnay unit is starting up.	The controller is not fed with power during start-up of the Lossnay unit for a maximum of one minute.

[Nothing is displayed on the controller]

[1] If the ON/OFF lamp does not light (or blink) and nothing is displayed on the LCD screen, check the following:

- a. Inter-terminal voltage at the terminal block in the bottom case of the controller is approximately 12 V.  
→ Check that the bottom case connector is firmly engaged with the top case connector.
- b. Inter-terminal voltage at the terminal block in the bottom case of the controller is approximately 0 V.
  - All LEDs on the Lossnay control circuit board are not lit.  
→ The power of the Lossnay unit may not be turned on. Check the power of the Lossnay unit.
  - LED1 on the Lossnay control circuit board blinks 11 times.  
→ Check that a 2-core sheathed 0.3 mm<sup>2</sup> cable of up to 200 m in length is used for the remote controller cable.  
→ Power off the Lossnay unit and check if the controller cable is short-circuited.  
If it is short-circuited, check connection between the controller and Lossnay terminal block as well as damage of the controller cable.


[2] If the ON/OFF lamp lights but nothing is displayed on the LCD screen, check the following:

- The ON/OFF lamp remains blinking, or pressing the ON/OFF button after the lamp turns off does not start the Lossnay unit.  
→ Power off the Lossnay unit and power it on again after a while.
- Pressing the ON/OFF button after the ON/OFF lamp turns off starts the Lossnay unit.  
→ The LCD screen of the controller may be faulty. Replace the controller.

Failure mode 3	Operations on the controller are not possible.
----------------	--

### ● Initial check items


If Lossnay cannot be operated with the controller, check the following items.

No.	Check item	Note
1	Is the function selection switch on the circuit board set correctly to suit the required application?	Depending on the setting, it may automatically operate or stop, or specific operation may become unusable.
2	Are icons and characters displayed on the controller screen?	Control mode status such as boost/purge, silent, holiday, manual bypass, protective operation can be checked.
3	Is the external input used?	The icon  indicating external input is displayed. Refer to "Display" in Chapter 5 of the Instruction Manual.

### ● Individual check items

If Lossnay cannot be started/stopped using the controller, check the following items.

#### [1] Controller

No.	Symptom	Cause	Corrective action
1	Lossnay cannot be controlled by the controller.	The power of the Lossnay unit is not ON.	Refer to section [1] of "Failure mode 1".
		Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1".
		Automatic supply air stop/ Automatic supply air intermittent operation is being performed.	The icon  indicating operation in the protective mode is displayed. Refer to "Display" in Chapter 5 of the Instruction Manual.
2	The screen display of the controller changes by itself. Even if you press the buttons, the screen returns to the original screen right away.	Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1".
3	The ventilation mode cannot be changed.	The By-pass ventilation is set to "Skipped".	Change the By-pass ventilation setting to "-". (For details, see "6.4.2.7 Control mode" of the Installation Manual.)
4	The temperature is not displayed on the controller.	The By-pass ventilation operation is being performed.	The indoor air temperature and/or supply air temperature are not displayed during the By-pass ventilation operation.
		"Sensor value" display is set to "No: Hide" by the display details setting of the controller.	Set "Sensor value" display of the controller to "Yes: Show." (Refer to "6.4.2.4 Display details" in the Installation Manual for details.)
		"Outdoor temperature indication", "Indoor temperature indication", and "Supply air temperature indication" of the controller function setting are set to "0: Hide".	Set "Outdoor temperature indication", "Indoor temperature indication", and "Supply air temperature indication" of the controller display setting to "1: Show". (Refer to the function No. 36 to 38 in "8. (2) Function setting list (page 24)" for details.)

No.	Symptom	Cause	Corrective action
5	CO <sub>2</sub> concentration is not displayed on the controller.	With the function setting No. 84, CO <sub>2</sub> concentration indication setting is set to "0: Hide".	Set the function setting No. 84 to "1: Show". (Refer to the function No. 84 in "8. (2) Function setting list (page 26)" for details.)
		The By-pass ventilation operation is being performed, or exhaust air fan is being stopped.	Since CO <sub>2</sub> concentration cannot be measured correctly in the operation status shown in the left, CO <sub>2</sub> concentration is not displayed.
		The detected CO <sub>2</sub> concentration is outside the measurement range.	Density lower than 400 ppm is shown as "Lo" and density equal to or higher than 2000 ppm is shown as "2000".
6	Indoor, outdoor, and/or supply air temperature indication is shown as "LO" or "HI".	The indoor and/or outdoor air temperature is outside the measurement range.	<ul style="list-style-type: none"> <li>Outdoor air temperature: Temperature lower than 2°C is shown as "LO" and temperature higher than 36 °C is shown as "HI".</li> <li>Indoor and supply air temperature: Temperature lower than 9°C is shown as "LO" and temperature higher than 37 °C is shown as "HI".</li> </ul>


[2] Interlocking with air conditioner (Mr. Slim) or external devices

No.	Symptom	Cause	Corrective action
1	Interlock settings cannot be performed with the controller.	The power of the Lossnay unit is not ON.	Refer to section [1] of "Failure mode 1".
		Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1".
2	Interlocking operation is not performed.	The power of the Lossnay unit is not ON.	Refer to section [1] of "Failure mode 1".
		Faulty connection of the controller cable or external input signal cables	Refer to section [2] of "Failure mode 1".
		The terminal block connected and the type of external signal do not match (charged or volt-free).	Check the type of external signal and the connections of the external control input terminal.
		The unit is set to the delay operation.	LED1 (green) on the circuit board lights. It starts operation in 30 or 15 minutes after starting operation by the air conditioner or external signal. Check the function setting No. 9 value of the controller. (Refer to the function No. 9 in "8. (2) Function setting list (page 24)" for details.)
	Automatic supply air stop/Automatic supply air intermittent operation is being performed.	The icon "⌘" indicating operation in the protective mode is displayed. Refer to "Display" in Chapter 5 of the Instruction Manual.	

Failure mode 4	Lossnay does not work properly.
----------------	---------------------------------


### ● Initial check items

If Lossnay does not work properly, check the following items.

No.	Check item	Note
1	Are the function settings set correctly for the required application?	Depending on the setting, it may automatically operate or stop, or specific operation may become unusable.
2	Are icons and characters displayed on the controller screen?	Control mode status such as boost/purge, silent, holiday, manual bypass, protective operation can be checked.
3	Is the external input used?	The icon “  ” indicating external input is displayed. Refer to “Display” in Chapter 5 of the Instruction Manual.
4	Have you changed the model selection switch (SW6) on the control circuit board?	Set the model selection switch (SW6) on the control circuit board in accordance with the model name. (Refer to Note 1 in “(3) b. Function selection switch (page 47)” for details.) Operating the model selection switch resets all settings done with the controller to the factory settings.


### ● Individual check items

If Lossnay does not work properly, check the following items.

No.	Symptom	Cause	Corrective action
1	Actual fan speed of the Lossnay unit differs from the fan speed set with the controller.	Automatic supply air stop/Automatic supply air intermittent operation is being performed.	The icon “  ” indicating operation in the protective mode is displayed. Refer to “Display” in Chapter 5 of the Instruction Manual.
2	Even though the controller is operated to change the ventilation mode, the ventilation switching damper is not moved.	The outdoor air temperature is 8°C or lower.	When the outdoor air temperature is 8°C or lower, the ventilation mode is fixed to the Heat exchange ventilation mode.
		The By-pass ventilation is set to “Skipped”.	Change the By-pass ventilation setting to “-”. (For details, see “6.4.2.7 Control mode” of the Installation Manual.)

Failure mode 5	Error code and LED error display
----------------	----------------------------------

An error code displayed on the controller and the number of blinks of LED1 (green) on the control circuit board show the type of an error. The LED blink interval is 0.25 seconds for both ON and OFF. The display duration is approximately 7 seconds.



Error indication example of LED (two blinks)

### Error indication list

Error code (Controller display)	LED1 (green)	Error	Cause	Corrective action
0900	-	Trial operation	The trial operation switch (SW2-1) on the control circuit board is set to "ON".	Check the trial operation switch.
4101	11 blinks	Overcurrent error of the controller terminal	Short-circuiting between controller terminals	Check connection between the control circuit board and the controller cable. Check for short-circuit with the transmission cable on the controller wiring.
			Controller failure	Replace the controller.
			Circuit board failure	If the problem persists, replace the control circuit board.
4116	1 blink	Abnormal rotation of the supply air (SA) fan motor	Foreign substance is attached to the centrifugal fan.	Remove it.
			The fan touches the casing. [1] Any fixing nut is loose. [2] The casing is deformed or disengaged.	[1] Tighten the nuts. [2] Check for fixing and replace any faulty parts.
			The SA fan motor connector CN10 on the circuit board is not firmly connected.	Connect the connector securely.
	2 blinks	Abnormal rotation of the exhaust air (EA) fan motor	The EA fan motor connector CN9 on the circuit board is not firmly connected.	Connect the connector securely.
			The fan cannot be turned manually.	If the fan does not turn, diagnose the DC motors on the EA and SA sides as directed in "[3] Diagnosis of the power circuit board and DC motor" in "Failure mode 7".
			The following voltages are not output from the connectors on the circuit board. • EA side: Disconnect the connector CN9 and check that the voltage between pins 1 and 4 is 280 to 360 V DC. • SA side: Disconnect the connector CN10 and check that the voltage between pins 1 and 3 is 280 to 360 V DC.	Perform the following diagnosis as directed in "[3] Diagnosis of the power circuit board and DC motor" in "Failure mode 7". • Output detected → Diagnose the DC motor on the EA and SA sides. • Output not detected → Diagnose the power circuit board.

Error code (Controller display)	LED1 (green)	Error	Cause	Corrective action
5101	4 blinks	Outdoor air (OA) thermistor related error	Faulty connection of the thermistor (OA) connector	Check connection of the relay connector and the connector (CN22) on the control circuit board.
			Thermistor (OA) failure	Disconnect the connector (CN22) on the control circuit board, and check the resistance of the thermistor. If the equivalent thermistor resistance differs greatly from the ambient temperatures, replace the thermistor. (Refer to “[4] Diagnosis of the thermistor (page 46)” in “Failure mode 7”.)
5102	5 blinks	Return air (RA) thermistor related error	Faulty connection of the thermistor (RA) connector	Check connection of the relay connector and the connector (CN5) on the control circuit board.
			Thermistor (RA) failure	Disconnect the connector (CN5) on the control circuit board, and check the resistance of the thermistor. If the equivalent thermistor resistance differs greatly from the ambient temperatures, replace the thermistor. (Refer to “[4] Diagnosis of the thermistor (page 46)” in “Failure mode 7”.)
6201	-	Controller circuit board failure	Controller failure	Replace the controller.
6202	-	Controller circuit board failure	Controller clock does not function correctly.	Replace the controller.
6831	9 blinks	Controller communication error (no signal)	The controller is connected to the incorrect terminal block (TB5 [A] [B]).	Connect the controller cable to the terminal block (TM4 [1] [2]).
			Faulty connection of the controller cable	Refer to section [2] of “Failure mode 1”. If the error code does not disappear, investigate noise on the controller cable. If the problem persists, replace the control circuit board or controller.
6832	9 blinks	Controller communication error (synchronization recovery error)	Faulty connection of the controller cable	Refer to section [2] of “Failure mode 1”. If the error code does not disappear, investigate noise on the controller cable.
				If the problem persists, replace the control circuit board or controller.

Error code (Controller display)	LED1 (green)	Error	Cause	Corrective action
6833	9 blinks	Controller communication error (hardware error)	Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1". If the error code does not disappear, investigate noise on the controller cable. If the problem persists, replace the control circuit board or controller.
6834	9 blinks	Controller communication error (start bit detection error)	Faulty connection of the controller cable	Refer to section [2] of "Failure mode 1". If the error code does not disappear, investigate noise on the controller cable. If the problem persists, replace the control circuit board or controller.
7113	10 blinks	Function setting error	The model selection switch (SW6) is not set correctly.	Check the model selection switch (SW6). Refer to (Note 1) in "(3) b. Function selection switch (page 47)".

Failure mode 6	The product has an error.
----------------	---------------------------


[1] When condensation occurs in or on the product

No.	Symptom	Cause	Corrective action
1	Condensation occurs on the exterior of the product.	When the surrounding temperature and return air temperature is outside the following range, condensation may occur. • 0 - 40°C, 80%RH or lower • Absolute humidity with the dew point temperature of 12°C (equivalent to 20°C, 60%RH) or lower	<ul style="list-style-type: none"> <li>• Stop the product temporarily.</li> <li>• Lower the humidity of the room where the product is installed (e.g., by stopping a humidifier).</li> <li>• Condensation may be suppressed by reducing the fan speed.</li> </ul>
2	Condensation occurs around or on the piping duct.	Insufficient heat insulation of piping duct	Use commercial heat insulation materials to insulate the duct. (Refer to the Installation Manual for the insulation procedure.)
3	Condensation or icing occurs inside the product.	Condensation or icing may occur inside the product depending on the temperature and humidity.	It is normal.
4	Condensation or icing occurs on the filter.	Condensation or icing may occur inside the product depending on the temperature and humidity.	It is normal.


[2] Abnormal noises are heard

No.	Symptom	Cause	Corrective action
1	Fan touch noise	Foreign substance entering the fan assembly	Remove the foreign substance from the fan.
		Fan damage	Replace the centrifugal fan if it is damaged.
		Loosened or disengaged fan fixing nuts	Tighten the fan fixing nuts.
2	Air suction sound (bubbling sound) from the drainage parts when draining	The check valves are not installed correctly. * The check valves (commercially available) must be installed to this product.	Install the check valves correctly.
		The check valves are damaged. * The check valves (commercially available) must be installed to this product.	Replace the check valve with a new one (commercially available) if it is damaged.
3	Wind noise	The filter cases are not inserted to the deepest position correctly.	Insert the filter cases to the deepest position correctly.
		The filter is not attached to the filter case correctly.	Attach the filter to the filter case correctly.
4	Damper operation noise	A click sound is heard when the unit is switching from Heat exchange ventilation to By-pass ventilation. The sound is due to operation of the solenoid inside the damper motor.	It is normal.
		A slam sound is heard when the unit is switching from Heat exchange ventilation to By-pass ventilation. The sound is due to operation of the damper by a spring.	It is normal.
5	Abnormal sound is generated from the motor.	Disassemble the product to see the motor and check if it is heard from the motor. (Refer to "11. Overhauling procedures".)	If the abnormal sound is generated by the motor, replace the DC motor. (The motor may generate abnormal sound due to aging or deterioration caused by the environment.)



No.	Symptom	Cause	Corrective action
6	The product generates vibration. The product generates vibration noise.	The filter cases are not inserted to the deepest position correctly.	Insert the filter cases to the deepest position correctly.
		Clogged filter	Clean or replace the filters. (Refer to the Instruction Manual for the cleaning procedure.)
		Any fixing screw is loose.	Tighten the screws correctly.
		Vibration noise from the duct pipe	<ul style="list-style-type: none"> <li>• Check if the duct pipe connection is loose, and reinforce the connection if it is loose.</li> <li>• Check if the duct pipe fixing is loose, and reinforce the fixing if it is loose.</li> </ul>
		Pressure loss in the duct pipe is too high.	If there is a foreign substance at any terminal part such as grill or hood, remove it.
		Vibration noise from the drain pipe	<ul style="list-style-type: none"> <li>• Check if the drain pipe connection is loose, and reinforce the connection if it is loose.</li> <li>• Check if the drain pipe fixing is loose, and reinforce the fixing if it is loose.</li> </ul>
		Foreign substance is attached to the fan.	Remove the foreign substance.
		The fan is loose or disengaged.	Tighten the fan.
		The fan is swinging.	Tighten the fan.
7	Operating noise has increased. Operating noise has decreased.	Check if the fan rotation has increased, decreased or stopped due to Automatic supply air stop/Automatic supply air intermittent operation because of the decrease in outside air temperature. * During icing suppress operation the icon “  ” is displayed on the controller.	Fan rotation speed may change or the fan may stop due to Automatic supply air stop/Automatic supply air intermittent operation, however, it is normal. * Fan rotation speed may also change immediately after the icing suppress operation ends (the icon disappears from the controller) by returning to the normal operation.
		Check if the symptom is caused by the control mode specifically set. (Refer to the Instruction Manual and Installation Manual for the modes.) * A displayed icon on the controller does not indicate ON/OFF status of the setting. (The icon appears whenever the control is in effect.)	Change the setting if the operation noise is abnormal.
		Check if it is affected by the outdoor wind.	It is normal.
		Check if it is affected by the indoor pressure change due to another air-conditioner.	It is normal. When another ventilator such as a range hood fan operates, the indoor pressure can change and affect the fan speed of the product.
		The filter cases are not inserted to the deepest position correctly.	Insert the filter cases to the deepest position correctly.
		Clogged filter	Clean or replace the filters. (Refer to the Instruction Manual for the cleaning procedure.)
		Foreign substance is attached to the fan.	Remove the foreign substance.
		The fan is loose or disengaged.	Tighten the fan.
		Pressure loss in the duct pipe is too high.	If there is a foreign substance at any terminal part such as grill or hood, remove it.

[3] Abnormal air volume

No.	Symptom	Cause	Corrective action
1	Air volume changed. The product stopped.	Check if the fan rotation has increased, decreased or stopped due to Automatic air supply stop/Automatic air supply intermittent operation because of the decrease in outside air temperature. * During icing suppress operation the icon “  ” is displayed on the controller.	Fan rotation speed may change or the fan may stop due to Automatic supply air stop/Automatic supply air intermittent operation, however, it is normal. * Fan rotation speed may also change immediately after the icing suppress operation ends (the icon disappears from the controller) by returning to the normal operation.
		Check if the symptom is caused by the control mode specifically set. (Refer to the Instruction Manual and Installation Manual for the modes.) * A displayed icon on the controller does not indicate ON/OFF status of the setting. (The icon appears whenever the control is in effect.)	Change the setting if the air volume variation is abnormal.
		Clogged filter	Clean or replace the filters. (Refer to the Instruction Manual for the cleaning procedure.)
		Pressure loss in the duct pipe is too high.	If there is a foreign substance at any terminal part such as grill or hood, remove it.
		Check if it is affected by the indoor pressure change due to another air-conditioner.	It is normal. When another ventilator such as a range hood fan operates, the indoor pressure can change and affect the fan speed of the product.
		The duct pipe is disconnected or loose.	Check if the duct pipe is disconnected or loose, and reinforce the fixing if it is loose.

[4] Water leak

No.	Symptom	Cause	Corrective action
1	Water leaks from the drain pipe.	Connection between the drain connection port and the drain pipe is loose or has a gap.	Connect the drain pipes securely without any gap.
		The gradient of the drain pipe is not correct. (It should be tilted downward at an angle of 3° or more.)	Connect the drain pipes correctly. (Refer to the Installation Manual for the procedure.)
		The drain cap is disengaged.	Attach the drain cap correctly.
		Condensation occurred in the drain piping.	<ul style="list-style-type: none"> <li>• Stop the product temporarily.</li> <li>• Lower the humidity of the room where the product is installed (e.g., by stopping a humidifier).</li> <li>• Insulate the drain pipe (e.g., by using insulation materials).</li> </ul>

No.	Symptom	Cause	Corrective action
2	Water leaks from the duct pipe.	The pipe guide and duct are not caulked with silicone with no gap.	If there is a gap, caulk it using silicone. (Refer to the Installation Manual for the procedure.)
		Condensation occurs around the pipe guide or in the pipe guide.	Use commercial heat insulation materials to insulate the duct. (Refer to the Installation Manual for the insulation procedure.)
		The gradient of the duct pipe is not correct. (It should be tilted upward for 1/30 or more from outdoors to indoors to prevent rain drops, snow, or mist from entering the unit.)	Connect the duct correctly.
		Rain drops, snow, or mist enters the unit.	<ul style="list-style-type: none"> <li>• Stop the product temporarily in case of a hard rain, snow, or dense mist.</li> <li>• Use an outdoor hood which prevents rain drops or snow from entering the unit.</li> </ul>

Failure mode 7	Individual troubleshooting
----------------	----------------------------

[1] Diagnosis of the damper

No.	Symptom	Diagnosis method	Corrective action
1	Damper motor failure	Disassemble the product to see the damper assembly. (Refer to “11. Overhauling procedures”.) Check if the damper operates in the trial operation mode. (Refer to “6.7 Trial operation” in the Installation Manual for details of the trial operation mode.)	If the damper does not operate, replace the damper assembly.
2	Damper adhesion	Disassemble the product to see the damper assembly. (Refer to “11. Overhauling procedures”.) Open and close the damper plate manually and check if a foreign substance is adhered to the damper plate and/or the damper plate is adhered.	Remove the foreign substance or cause of adhesion.

[2] Diagnosis of an externally connected device

No.	Symptom	Diagnosis method	Corrective action
1	Lossnay operation is not correct for the analog signal sent from the external device connected to TM200 on the signal interface circuit board.	Check if connection with the external device is disconnected or loose.	Connect the external device correctly.
		Check that terminal block connection is correct.	Connect the terminals correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Power (low-voltage output) is not supplied from the externally connected device.	Check the external device. * TM200 is a low-voltage input terminal. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Lossnay setting is incorrect.	Check the controller settings. (Refer to "6.4.5 External input" of the Installation Manual.)
2	Lossnay operation is not correct for the contact signal sent from the external device connected to TM201 on the signal interface circuit board.	Check if connection with the external device is disconnected or loose.	Connect the external device correctly.
		Check that terminal block connection is correct.	Connect the terminals correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		No signal (volt-free contact signal) is supplied from the externally connected device.	Check the external device. * TM201 is the contact input terminal. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Lossnay setting is incorrect.	Check the controller settings. (Refer to "6.4.5 External input" of the Installation Manual.)
3	Lossnay operation is not correct for the signal sent from the air conditioner (Mr. Slim) connected to TM2 on the control circuit board.	Check if connection with the air conditioner is disconnected or loose.	Connect the air conditioner (Mr. Slim) correctly.
		Check that terminal block connection is correct.	Connect the terminals correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		The air conditioner (Mr. Slim) setting is incorrect.	Check the setting of the air conditioner (Mr. Slim).
4	External device operation is not correct for the signal sent to the external device connected to TM3 on the control circuit board.	Check if connection with the external device is disconnected or loose.	Connect the external device correctly.
		Check that terminal block connection is correct.	Connect the terminals correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Check if the externally connected device is faulty.	Check the external device.
		Lossnay setting is incorrect.	Check the controller setting. (Refer to the functions No. 57, 58, 81 in "8. (2) Function setting list" (page 25 and 26).)
5	The externally installed controller connected to TM4 on the control circuit board cannot be turned on.	Check if connection with the externally installed controller is disconnected or loose.	Connect the controller correctly.
		Check that terminal block connection is correct.	Connect the terminals correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Check if the cable between the Lossnay unit and controller is disconnected.	Connect the cable and connector correctly. (Refer to the Installation Manual of P-RCC-E.)

No.	Symptom	Diagnosis method	Corrective action
6	Lossnay operation is not correct for communication with the Wi-Fi interface connected to CN105 on the control circuit board.	Check if connection with the Wi-Fi interface is disconnected or loose.	Connect the Wi-Fi interface correctly.
		Check that connector connection is correct.	Connect the connector correctly. (Refer to "5.2 External device connection use" in the Installation Manual.)
		Check if Wi-Fi communication has an error.	Check the Wi-Fi interface setting.


[3] Diagnosis of the power circuit board and DC motor



(Diagnosis of the electric components for failures caused by abnormal voltage or lightning strike)

When the product gets faulty due to abnormal voltage or lightning strike, it can be diagnosed in the following procedures.

**Precaution**

After disassembling the DC motor, it cannot be installed in the product again even if it has no failure.  
(This is because the waterproof seal is broken to disassemble the motor.)

Components	Checklist
Power circuit board	<p>1. Abnormal voltage or lightning strike can randomly damage the following elements:</p> <ul style="list-style-type: none"> <li>• NR1</li> <li>• NR3</li> <li>• NR4</li> <li>• NR5</li> <li>• FUSE1</li> <li>• FUSE2</li> <li>• FUSE3</li> </ul> <div style="text-align: center;">  </div> <p>2. Other check points</p> <ul style="list-style-type: none"> <li>• Check that the circuit name is correct. (LG-X07DC-E2)</li> <li>• Are any parts discolored to black?</li> <li>• Is any liquid adhered to any parts?</li> <li>• Are there any dead bodies of insects or small animals?</li> <li>• Is the circuit board broken?</li> <li>• Is the solder cracked?</li> <li>• Checking the power supply indicator LED LED6 is lit when power is supplied.</li> <li>• Voltage check With 15 V power supply, voltage at both ends of C30 should be 14 - 16 V DC.</li> <li>• SA fan motor drive check Voltage between pins 1 and 3 of CN10 should be 280 - 360 V DC. Voltage between pins 3 and 4 of CN10 should be 14 - 16 V DC.</li> <li>• EA fan motor drive check Voltage between pins 1 and 4 of CN9 should be 280 - 360 V DC. Voltage between pins 4 and 5 of CN9 should be 14 - 16 V DC.</li> </ul>

Components	Checklist
DC motor	<p>1. Remove the motor cover, and measure resistance at the following points to check for coil breakage: (Measure the resistance with the motor connectors (CN9, CN10) disconnected from the power circuit board.)</p> <p>&lt;VL-250 type&gt;</p> <ul style="list-style-type: none"> <li>• Between V and U...102.8 Ω</li> <li>• Between V and W...102.8 Ω</li> <li>• Between W and U...102.8 Ω</li> </ul> <p>&lt;VL-350 type, VL-500 type&gt;</p> <ul style="list-style-type: none"> <li>• Between V and U...27.8 Ω</li> <li>• Between V and W...27.8 Ω</li> <li>• Between W and U...27.8 Ω</li> </ul> <p>* Resistance in a 30 °C atmosphere</p> <div style="text-align: right;">  <p>&lt;Circuit board in the DC motor for VL-250 type&gt;</p>  <p>&lt;Circuit board in the DC motor for VL-350 type and VL-500 type&gt;</p> </div> <p>2. Other check points</p> <ul style="list-style-type: none"> <li>• Are any parts discolored to black?</li> <li>• Is any liquid adhered to any parts?</li> <li>• Is the circuit board broken?</li> <li>• Is the solder cracked?</li> </ul>

[4] Diagnosis of the thermistor

Remove the thermistor connector (RA thermistor: CN15, OA thermistor: CN22) from the control circuit board, and measure resistance to detect a failure.

Resistance (reference)	Reference temperature for failure detection
Open (100 kΩ or higher)	It is abnormal.
Shorted (1.0 kΩ or lower)	It is abnormal.
3.0 kΩ	30°C
4.2 kΩ	20°C
6.0 kΩ	10°C
8.8 kΩ	0°C
20.6 kΩ	-10°C
32.8 kΩ	-20°C
53.9 kΩ	-30°C

### (3) Setting status record

#### ● Record of the Lossnay setting

Date: \_\_\_\_\_

##### a. Basic information

Installed location : \_\_\_\_\_

Model name of the product : VL- ( 250 • 350 • 500 ) CZPVU- ( L • R ) - ( E • ERT )

Address setting : \_\_\_\_\_

Manufacturing lot number of the circuit board : \_\_\_\_\_ (Number on the circuit board)

Microcomputer software number on circuit board : \_\_\_\_\_ (Symbol on the circuit board)

Interlock setting : ( Yes / No )                      Model: \_\_\_\_\_

##### b. Function selection switch

Enter the settings of the function selection switch (SW2) and model selection switch (SW6) on the circuit board.

SW2	ON	OFF
1	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>
8	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>

SW6	ON	OFF
1 (Note 1)	<input type="checkbox"/>	<input type="checkbox"/>
2 (Note 1)	<input type="checkbox"/>	<input type="checkbox"/>
3 (Note 1)	<input type="checkbox"/>	<input type="checkbox"/>
4 (Note 1)	<input type="checkbox"/>	<input type="checkbox"/>

(Note 1) Model selection switch (SW6)

Model	SW6-1	SW6-2	SW6-3	SW6-4
VL-250 type	ON	OFF	OFF	OFF
VL-350 type	OFF	ON	OFF	OFF
VL-500 type	ON	ON	OFF	OFF

##### c. Function setting

When the functions are set by using the controller, fill in the setting values.

Setting of the function numbers not mentioned in this table is prohibited.

Function No.	Setting value	Function No.	Setting value	Function No.	Setting value	Function No.	Setting value
1	(1)	38	(0)	53	(6)	82	(0)
2	(0)	39	(8)	54	(1)	83	(0)
5	(3)	40	(5)	57	(1)	84	(0)
9	(1)	41	(7)	58	(1)	86	(0)
13	(1)	42	(7)	59	(0)		
36	(0)	51	(3)	60	(0)		
37	(0)	52	(0)	81	(0)		

( ): Factory default

##### d. External input/output

Fill in usage of the external input/output on the circuit board.

Terminal block	Terminal name	In use	Not in use	Connection target
TM200 [1]	Analog input 1	<input type="checkbox"/>	<input type="checkbox"/>	
TM200 [2]	Analog input 2	<input type="checkbox"/>	<input type="checkbox"/>	
TM201 [1] [2]	Bypass input	<input type="checkbox"/>	<input type="checkbox"/>	
TM201 [3] [4]	Boost input	<input type="checkbox"/>	<input type="checkbox"/>	
TM2 [1] [2]	External control input	<input type="checkbox"/>	<input type="checkbox"/>	
TM3 [9] [10]	Monitor output	<input type="checkbox"/>	<input type="checkbox"/>	
TM3 [7] [10]	By-pass ventilation monitor	<input type="checkbox"/>	<input type="checkbox"/>	
TM3 [8] [10]	Malfunction monitor	<input type="checkbox"/>	<input type="checkbox"/>	

## 10. Service inspection list

Inspection item	Check result
Is the power cable connected correctly?	
Are the cables to the external devices connected correctly?	
Is the product installed correctly?	
Is the product grounded correctly?	
Are the drain pipes connected correctly?	
Does controller display work correctly?	
After replacing the control circuit board or controller, setting the operation mode and functions is necessary. Set them as directed in the Instruction Manual and Installation Manual to suit the required application.	
Are the SA and EA fans rotating?	
Does Lossnay operate without abnormal noise?	




# 11. Overhauling procedures

## ■ Work precautions

- When touching the electric components such as circuit boards and fan motors, do not touch the components for more than 5 minutes after power-off, and then start working. If LED4 on the circuit board is lit, do not touch the electric components.
- Before replacing parts or components, follow the instructions described in the troubleshooting.
- When servicing, always keep proper footing.
- When servicing, be sure to turn off the circuit breaker. Pay sufficient attention to avoid electric shock or injury.
- Be sure to connect the power supply wires correctly.
- Avoid application of abnormal voltage.
- Pay attention not to drop the parts or components.
- When the tightening torque for assembling is specified, be sure to tighten to the specified tightening torque.
- After connecting the lead wires, make sure that they are securely connected.
- After completing repairs, check that the product operates properly.

\* **Always wear a pair of gloves when servicing.**

## <Outer and inner view of the product>



\*The figure shows VL-250CZPVU-L-E.

## 11-1 VL-250CZPVU-L type, VL-250CZPVU-R type


**Note:** The following procedure applies to the VL-250CZPVU-L type. For VL-250CZPVU-R type, the components are placed in the right-left opposite positions.

### (1) Turn off the power supply

- [1] Stop the operation.
- [2] Turn off the circuit breaker on the distribution board.


### (2) Remove the heat exchanger

- [1] Remove the filter cover (A) (1 pc.) and filter covers (B) (2 pcs.).  
**Note:** For VL-250CZPVU-R, remove the filter covers (A) (2 pcs.) and filter cover (B) (1 pc.).



- [2] Pull out the filter cases (OA) and (RA).

**Precaution**  
To prevent the front casing (IN) from dropping, pull out the filter case (SA) with the front casing (IN) after removing the front casing (OUT). (Refer to [4].)



**Assembly precaution**  
When installing the filter cases, be sure to return the filter cases to the original positions. (Check the position with the label attached to each filter case.)

[3] Remove the front casing (OUT).

- a. Remove the screws from the bottom side.  
(2 screws: Special (spl) screw PT 4x10 (painted), indicated by ○)

**Tightening torque**  
○ :  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$




- b. Open the bottom part of the front casing (OUT) a little bit, and raise it diagonally upward to unhook the top hook.

Front casing (OUT)



**Precaution**  
Do not remove the screws (indicated by ○) on the top of the front casing (OUT).

Front casing (OUT)



[4] Remove the front casing (IN) and filter case (SA).



Front casing (IN)

Filter case (SA)

[5] Hold the band of the heat exchanger and pull it out.


**Precaution**

The heat exchanger is heavy. Be careful not to remove the band.

(The heat exchanger may drop and cause an injury.)

**Assembly precaution**


When installing the heat exchanger, its label should come to this end and face up as shown in the picture.



Heat exchanger

**Assembly precaution**

Insert the heat exchanger to the mark line on the PCB plate.



PCB plate

Mark line

### (3) Remove the PCB cover

[1] Remove the heat exchanger. ... Refer to (2).

[2] Remove the bypass plate.

a. Remove the screw.

(1 screw: Spl screw PTT 4X14, indicated by ○)

**Tightening torque**

**○ :  $1.2 \pm 0.2$  N·m**

b. Unhook the bypass plate from the top hook (indicated by □).



Bypass plate

[3] Remove the PCB plate.

a. Remove the screws.

(2 screws: Spl screw PTT 4X14, indicated by ○)

**Tightening torque**


**○ :  $1.2 \pm 0.2$  N·m**




PCB plate

b. Raise this side of the PCB plate a little bit and pull it until the hook at the deepest location (indicated by ○) is unhooked to remove the PCB plate.

\* Remove the styrene part together.



PCB plate




[4] Remove the lead wires.

- a. Remove the lead wires from the styrene grooves (indicated by ○).

**Precaution**

Be careful not to damage the styrene.

- b. Pull out the lead wires stored in the outer side of the PCB cover (UP).



PCB cover (UP)

[5] Remove the PCB cover (UP).

- a. Remove the screws.  
(2 screws: Spl screw PTT 4X14, indicated by ○)

**Precaution**

Screws are located where it is not easy to see them.

**Tightening torque**


○ :  $1.2 \pm 0.2$  N·m



- b. Remove the PCB cover (UP).


**Assembly precaution**

Be sure to attach the PCB cover (LOW) before installing the PCB cover (UP).




PCB cover (UP)

[6] Remove the PCB cover (LOW).




■ Reference: Circuit board locations within the control box

< VL-250CZPVU-L type >




< VL-250CZPVU-R type >




## (4) Remove the thermistor

- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Unhook the thermistor lead from the hooks on the orifice (indicated by ○).
- [4] Remove the screws.  
(3 screws: Spl screw PTT 4X14, indicated by △)

Tightening torque  
△ :  $1.1 \pm 0.2$  N·m



<For thermistor (OA)>




<For thermistor (RA)>

- [5] Remove the orifice from the bottom groove (indicated by ○).



\*The picture shows the orifice (EA).


- [6] Remove the thermistor from the groove.
- [7] Remove the thermistor with the orifice.
- [8] Remove the thermistor from the hole of the orifice (indicated by ○).



\*The picture shows the orifice (EA).




- [9] Disconnect the thermistor relay connector.
- [10] Remove the thermistor lead from the lead clamber.
- [11] Remove the metal clip fixing screw.  
(1 screw: indicated by ○)




**Assembly precaution**  
When attaching the thermistor, align the insulok tie with the protrusion in the groove as shown in the picture.

**<For thermistor (OA)>**




**<For thermistor (RA)>**




**(5) Remove the damper assembly**

- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Remove the orifice (SA). ... Refer to (4).
- [4] Lower the circuit board (control circuit board) to provide a work space for disconnecting and connecting the connectors.
  - a. Remove the circuit board fixing screws from the bottom side of the product.  
(2 screws: Spl screw PT 4X10 (painted), indicated by ○)


**Tightening torque**  
○ :  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$



- b. Lower the circuit board.




[5] Remove the damper lead from the metal plate hook of the control box (indicated by ○).



Damper lead

[6] Disconnect the damper lead connector from the power circuit board.

Damper connector: CN7




Power circuit board

[7] Remove the damper assembly fixing screws.  
(2 screws: Spl screw PTT 4X14, indicated by ○)

**Tightening torque**  
○ :  $1.1 \pm 0.2 \text{ N}\cdot\text{m}$

Damper assembly




[8] Remove the damper assembly.

[9] Remove the damper lead from the bypass air duct.

Damper assembly

Bypass air duct



Damper lead

## (6) Remove the fan assembly

[1] Remove the heat exchanger. ... Refer to (2).

[2] Remove the PCB cover. ... Refer to (3).

[3] Remove the orifice and thermistor. ... Refer to (4).

[4] Lower the circuit board (control circuit board) to provide a work space for disconnecting and connecting the connectors. ... Refer to (5) [4].

[5] Remove the lead clip fixing screw to disconnect the connector.

(1 screw: PTT screw 4x12, indicated by ○)

**\* VL-250CZPVU-L type only**



Lead clip

[6] Disconnect the motor lead connectors from the power circuit board.

SA fan motor connector: CN10


EA fan motor connector: CN9

### Precaution

When disconnecting the motor connectors, make sure that the power supply is turned off. Even when the fan motor is stopped, disconnecting the live-line connectors will cause a motor malfunction.

[7] Remove the motor leads from the metal plate hook of the control box (indicated by ○).

SA fan motor connector: CN10      Motor lead




Power circuit board      EA fan motor connector: CN9

\* Steps [8] through [12] refers to the EA fan assembly. Disassemble the SA fan assembly in the similar manner.

[8] Remove the cover by sliding it.

Centrifugal fan





Cover

[9] Remove the special nut (M8) and spring washer.

**Tightening torque:**  
 $2.3 \pm 0.2 \text{ N}\cdot\text{m}$

[10] Remove the tab washer and centrifugal fan.



[11] Remove the special washer (8).



Special washer (8)


[12] Remove the DC motor (EA).

- a. Remove the lead clip fixing screw.  
(1 screw: PTT screw 4x8, indicated by ○)

**Tightening torque**  
○ :  $0.8 \pm 0.2 \text{ N}\cdot\text{m}$


- b. Remove the motor fixing screws.  
(4 screws: Spl screw PTT 4X14, indicated by △)

**Tightening torque**  
△ :  $1.2 \pm 0.2 \text{ N}\cdot\text{m}$



DC motor (EA)

Lead clip



DC motor (EA)

## (7) Remove the circuit board and power supply cord


- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Disconnect the relay connectors (indicated by O).



- [4] Remove the circuit board (control circuit board).
  - a. Remove the circuit board fixing screws. ... Refer to (5) [4] a.
  - b. Tilt the circuit board to this side and unhook the hook at the top of it.



Circuit board



Circuit board (X07DC-E2-C, VL-40S)

Insulating sheet

### Precaution for replacing the circuit board


- Refer to the leaflet supplied with the service circuit board, and set the DIP switches on the circuit board.
- When the circuit board is replaced, the controller settings will be initialized. Perform the controller settings according to the settings sheet included with the product. If the settings sheet is not available, keep a record of the settings before replacement so that you can restore them.

[5] Remove the control box (power circuit board).

- a. Disconnect the motor lead connectors from the power circuit board. ... Refer to (6) [6] and [7].
- b. Disconnect the damper lead connector from the power circuit board. ... Refer to (5) [5] and [6].
- c. Remove the screws from the bottom side of the product.

(3 screws: Spl screw PTT 4X12 (painted), indicated by ○)  
(2 screws: Spl screw PT 5X10 (painted), indicated by △)

**Tightening torque**  
○ :  $1.1 \pm 0.2 \text{ N}\cdot\text{m}$   
△ :  $2.7 \pm 0.5 \text{ N}\cdot\text{m}$




d. Remove the control box.



[6] Disconnect the power supply cord.


- a. Remove the earth screw and washer.  
(1 screw: PT screw 4x8 (BS), indicated by △)  
(1 washer: Spring washer)

**Tightening torque**  
△ :  $0.96 \pm 0.14 \text{ N}\cdot\text{m}$




- b. Use a ratchet to remove the screw.  
(1 screw: PT screw 4x10, indicated by ○).

**Tightening torque**  
○ :  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$



Power supply cord      Control box



Ratchet



**<When not using the ratchet>**

- b. Remove the screw and remove the lead fixing metal plate.  
(1 screw: PTT screw 4x12, indicated by  $\Delta$ )

**Tightening torque**  
 $\Delta$  :  $1.1 \pm 0.2$  N·m


- c. Remove the screw.  
(1 screw: PT screw 4x10, indicated by  $\circ$ )

**Tightening torque**  
 $\circ$  :  $1.5 \pm 0.2$  N·m




**[7] Remove the circuit board (power interface circuit board).**

- a. Disconnect the connectors (indicated by  $\circ$ ) from the circuit board.
- b. Remove the lead wire from the hook (indicated by  $\square$ ).



- c. Remove the circuit board fixing screws.  
(2 screws: PT screw 4x10, indicated by  $\circ$ )

**Tightening torque**  
 $\circ$  :  $1.5 \pm 0.2$  N·m



## (8) Remove the controller



\* The pictures show VL-250CZPVU-R-E.

- [1] Open the tabs in the slits at the bottom of the controller (at 2 locations indicated by ○) using a flat-head screwdriver and open the front cover.



- [2] Open the front cover and disconnect the bottom case connector.


**Assembly precaution**  
Be sure to connect the connectors when installing the front cover.



- [3] Remove the screws.  
(2 screws: PT screw 4x6, indicated by ○)

**Tightening torque**  
○:  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$

- [4] Disconnect the connector of controller cable.





## (9) Restoring wire connection



### ■ Wiring order inside the control box

#### Assembly precaution

If the lead wires are ordered in a wrong way, they cross each other and may affect the electrical characteristics.



#### [1] Thermistor connectors

- Connect the thermistor relay connectors.
- Bind the thermistor leads with the lead clamber. ... Refer to (4) [10].
- Tighten the screw (1 screw, indicated by ○) to fix the thermistor leads and controller cable with the metal clip.



#### [2] Damper connector

- Connect the damper connector to CN7 on the power circuit board.
- Fix the damper lead to the metal plate hook of the control box (indicated by ○).



[3] Motor connectors

- a. Connect the SA fan motor connector (white) to CN10 on the power circuit board.
- b. Connect the EA fan motor connector (red) to CN9 on the power circuit board.
- c. Fix the motor leads to the metal plate hook of the control box (indicated by O).
- d. Tighten the lead clip fixing screw. ... Refer to (6) [5].


\* VL-250CZPVU-L type only

SA fan motor connector      EA fan motor connector



< VL-250CZPVU-L type >

EA fan motor connector      SA fan motor connector




< VL-250CZPVU-R type >

- [4] Before attaching the PCB cover (LOW), put away the controller cable wires (indicated by O) so that they may not get pinched.

**Assembly precaution**

The plate metal of the PCB cover (LOW) may cut the controller cable wires.

Controller cable




## ■ How to arrange the lead wires after attaching the PCB covers (LOW and UP)


### Assembly precaution

Be careful not to damage the styrene when fitting the lead wires into the styrene grooves.

[1] Put the controller cable in the corner (indicated by ○).




< VL-250CZPVU-L type >




< VL-250CZPVU-R type >

[2] Fit the part of the thermistor (OA) lead wrapped with packing into the styrene groove (indicated by ○), and put the extra part of the lead in the corner.




< VL-250CZPVU-L type >




< VL-250CZPVU-R type >

[3] Fit the part of the thermistor (RA) lead wrapped with packing into the styrene groove (indicated by ○), and store the extra part of the lead in the outer side of the PCB cover (UP).




< VL-250CZPVU-L type >



< VL-250CZPVU-R type >

[4] Fit the part of the damper lead wrapped with packing into the styrene groove (indicated by ○).




< VL-250CZPVU-L type >




< VL-250CZPVU-R type >

[5] Fit the part of the SA fan motor lead wrapped with packing into the styrene groove (indicated by ○).




< VL-250CZPVU-L type >




< VL-250CZPVU-R type >

[6] Fit the part of the EA fan motor lead wrapped with packing into the styrene groove (indicated by ○).

\* Pass the lead over the PCB cover (UP).



< VL-250CZPVU-L type >



< VL-250CZPVU-R type >

### \* When reassembling

- Reassemble the unit in the reverse order of disassembly.
- After reassembly, always make a test run to make sure that the unit operates properly.

## 11-2 VL-350CZPVU-L type, VL-350CZPVU-R type


**Note:** The following procedure applies to the VL-350CZPVU-L type. For VL-350CZPVU-R type, the components are placed in the right-left opposite positions.

### (1) Turn off the power supply


- [1] Stop the operation.
- [2] Turn off the circuit breaker on the distribution board.

### (2) Remove the heat exchanger

- [1] Remove the filter cover (A) (1 pc.) and filter covers (B) (2 pcs.).  
**Note:** For VL-350CZPVU-R, remove the filter covers (A) (2 pcs.) and filter cover (B) (1 pc.).



- [2] Pull out the filter cases (OA), (RA), and (SA).



**Assembly precaution**

When installing the filter cases, be sure to return the filter cases to the original positions.  
(Check the position with the label attached to each filter case.)

[3] Remove the front casing (OUT).

- a. Remove the screws from the bottom side.  
(2 screws: Spl screw PT 4X10 (painted), indicated by ○)

**Tightening torque**  
○ :  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$

- b. Remove the screws and washers from the front side.  
(2 screws: Spl screw PT 4X10 (painted), indicated by △)  
(2 washers: Special washer (3))

**Tightening torque**  
△ :  $1.5 \pm 0.2 \text{ N}\cdot\text{m}$

- c. Open the bottom part of the front casing (OUT) a little bit, and raise it diagonally upward to unhook the top hook.

**Precaution**

Do not remove the screws (indicated by ○) on the top of the front casing (OUT).


Front casing (OUT)



Front casing (OUT)




Front casing (OUT)



[4] Remove the reinforcement.

- a. Remove the reinforcement fixing screw.  
(1 screw: Spl screw PT 5X10 (painted), indicated by ○)

**Tightening torque**  
○ :  $2.7 \pm 0.5 \text{ N}\cdot\text{m}$




Reinforcement



- b. Remove the reinforcement by sliding it upward.

**Precaution**  
Be careful not to drop the reinforcement due to reaction from the plate.  
(It may cause an injury or damage to properties.)




Reinforcement

[5] Hold the lower part of the front casing (IN) and open it a little bit, and then remove it by sliding it downward.

Front casing (IN)



Front casing (IN)




[6] Hold the band of the heat exchanger and pull it out.

**Precaution**

The heat exchanger is heavy. Be careful not to remove the band.  
(The heat exchanger may drop and cause an injury.)

**Assembly precaution**


When installing the heat exchanger, its label should come to this end and face up as shown in the picture.



**Assembly precaution**

Insert the heat exchanger to the position shown in the pictures.


< VL-350CZPVU-L type >



Heat exchanger

PCB plate

< VL-350CZPVU-R type >



PCB plate

Heat exchanger




### (3) Remove the PCB cover

[1] Remove the heat exchanger. ... Refer to (2).

[2] Remove the PCB plate.


#### For VL-350CZPVU-L type

Raise this side of the PCB plate a little bit and pull it until the hook at the deepest location (indicated by ○) is unhooked, and then remove the PCB plate by rotating it.



#### For VL-350CZPVU-R type

Raise the PCB plate a little bit and pull it so that it is not disturbed by the EA fan motor, and then remove the PCB plate by rotating it.




[3] Remove the lead wires.

- a. Remove the lead wires from the styrene grooves (indicated by ○).

**Precaution**

Be careful not to damage the styrene.

- b. Pull out the lead wires stored in the outer side of the PCB cover (UP).
- c. Remove the lead wire from the lead clamber (indicated by □).



PCB cover (UP)

[4] Remove the PCB cover (UP).


- a. Remove the screws.  
(2 screws: Spl screw PTT 4X12, indicated by ○)

**Precaution**

Screws are located where it is not easy to see them.

**Tightening torque**


○ :  $1.2 \pm 0.2$  N·m



- b. Remove the PCB cover (UP).


**Assembly precaution**

Be sure to attach the PCB cover (LOW) before installing the PCB cover (UP).



PCB cover (UP)

[5] Remove the PCB cover (LOW).



■ Reference: Circuit board locations within the control box ... Refer to 11-1 (page 55).

#### (4) Remove the fan assembly

[1] Remove the heat exchanger. ... Refer to (2).


[2] Remove the PCB cover. ... Refer to (3).

[3] Lower the circuit board (control circuit board) to provide a work space for disconnecting and connecting the connectors.

- a. Remove the circuit board fixing screws from the bottom side of the product.  
(2 screws: Spl screw PT 4X10 (painted), indicated by ○)

Tightening torque

○ :  $1.5 \pm 0.2$  N·m




Circuit board

- b. Lower the circuit board.



Circuit board

- [4] Remove the lead clip fixing screw to disconnect the connector.  
 (1 screw: PTT screw 4x12, indicated by ○)  
 \* VL-350CZPVU-L type only




Lead clip

- [5] Disconnect the motor lead connectors from the power circuit board.  
 SA fan motor connector: CN10  
 EA fan motor connector: CN9

**Precaution**  
 When disconnecting the motor connectors, make sure that the power supply is turned off. Even when the fan motor is stopped, disconnecting the live-line connectors will cause a motor malfunction.

- [6] Remove the motor leads from the metal plate hook of the control box (indicated by ○).



Power circuit board EA fan motor connector: CN9


### For the EA fan assembly

- [7] Remove the DC motor assembly (EA).  
 a. Unhook the thermistor (OA) lead from the hooks on the orifice (indicated by ○).  
 b. Remove the screws.  
 (4 screws: Spl screw PPT 4x30, indicated by △)

**Tightening torque**  
 $\Delta : 1.1 \pm 0.2 \text{ N}\cdot\text{m}$

- \* There are spacers (4 spacers: 6x15) behind the DC motor assembly (EA).

DC motor assembly (EA) Thermistor (OA) lead



- c. Remove the DC motor assembly (EA).

**Precaution**  
 Be careful not to catch the thermistor (OA) lead by the notch (Indicated by ○).

DC motor assembly (EA) Thermistor (OA) lead



## For the SA fan assembly

[7] Remove the DC motor assembly (SA).

- a. Remove the earth lead (green) fixing screw.  
(1 screw: PT screw 4x10, indicated by ○)

**Tightening torque**  
○ :  $1.5 \pm 0.2$  N·m

- b. Raise the cord clip fixing the earth lead (green).  
c. Remove the earth lead (black) fixing screw.  
(1 screw: PT screw 4x8 (BS) with washer, indicated by △)

**Tightening torque**  
△ :  $0.96 \pm 0.14$  N·m

- d. Unhook the thermistor (RA) lead from the hooks on the orifice (indicated by ○).  
e. Cut the insulok tie fixing the damper lead and earth lead (green).

**Precaution**  
Take care not to cut the lead wires.

**Assembly precaution**  
When installing the damper lead and earth lead (green), be sure to fix them with an insulok tie.




- f. Remove the screws.  
(4 screws: Spl screw PPT 4x30, indicated by △)

**Tightening torque**  
△ :  $1.1 \pm 0.2$  N·m

\*There are spacers (4 spacers: 6x15) behind the DC motor assembly (SA).

- g. Remove the DC motor assembly (SA).

**Precaution**  
Be careful not to catch the damper lead and thermistor (RA) lead by the notch (indicated by ○).



\* Steps [8] through [12] refers to the **DC motor assembly (EA)**. Remove the centrifugal fan for the **DC motor assembly (SA)** in the similar manner.



[8] Remove the special nut (M8).

Tightening torque:  
 $2.3 \pm 0.2 \text{ N}\cdot\text{m}$

[9] Remove the spring washer (8).

[10] Remove the tab washer.



[11] Remove the centrifugal fan.



DC motor assembly (EA)

Centrifugal fan

[12] Remove the washer (10).



DC motor assembly (EA)

## (5) Remove the thermistor


[1] Remove the heat exchanger. ... Refer to (2).

[2] Remove the PCB cover. ... Refer to (3).

### For the thermistor (OA)

[3] Remove the DC motor assembly (EA). ... Refer to (4).


[4] Remove the element guide (OA) by sliding it as shown in the pictures.




[5] Remove the thermistor (OA).

#### Assembly precaution

When attaching the thermistor, align the insulok tie with the groove and fix the thermistor as shown in the picture.




- Disconnect the thermistor (OA) relay connector.
- Remove the thermistor (OA) lead from the lead clamber.
- Remove the metal clip fixing screw.  
(1 screw: indicated by ○)



## For the thermistor (RA)


[3] Remove the DC motor assembly (SA). ... Refer to (4).

[4] Remove the element guide (RA) by sliding it as shown in the pictures.




[5] Remove the thermistor (RA).

**Assembly precaution**  
When attaching the thermistor, align the insulok tie with the groove and fix the thermistor as shown in the picture.




- Disconnect the thermistor (RA) relay connector.
- Remove the thermistor (RA) lead from the lead clamber.
- Remove the metal clip fixing screw.  
(1 screw: indicated by ○)





## (6) Remove the damper assembly


- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Remove the DC motor assembly (SA). ... Refer to (4).
- [4] Remove the thermistor (RA). ... Refer to (5).
- [5] Remove the damper lead from the metal plate hook of the control box (indicated by ○).



Damper lead


- [6] Disconnect the damper lead connector from the power circuit board.

Damper connector: CN7



Power circuit board

- [7] Slide the notch of the damper frame (indicated by ○) upward to unhook from the hook on the damper assembly.



- [8] Remove the damper lead from the groove and then remove the damper assembly.

Damper assembly



**(7) Remove the circuit board and power supply cord... Refer to 11-1 (7).**

**Note:** When removing the control box (power circuit board), be sure to remove the screws of the earth lead (green), (black). ... Refer to 11-2 (4) [7] (For the SA fan assembly).

**(8) Remove the controller... Refer to 11-1 (8).**

**(9) Restoring wire connection**

**■ Wiring order inside the control box**

**Assembly precaution**  
If the lead wires are ordered in a wrong way, they cross each other and may affect the electrical characteristics.

[1] Connect the connectors except for the EA fan motor connector.




[2] Connect the EA fan motor connector (red) to CN9 on the power circuit board.

**Assembly precaution**  
Pass the EA fan motor lead over the other lead wires.

[3] Fix the EA fan motor lead to the metal plate hook of the control box (indicated by O).

[4] Tighten the lead clip fixing screw. ... Refer to (4) [4].  
\* VL-350CZPVU-L type only



EA fan motor connector

EA fan motor lead

[5] Before attaching the PCB cover (LOW), put away the controller cable wires (indicated by O) so that they may not get pinched.


**Assembly precaution**  
The plate metal of the PCB cover (LOW) may cut the controller cable wires.

Controller cable



< VL-350CZPVU-L type >

Controller cable




< VL-350CZPVU-R type >

## ■ How to arrange the lead wires after attaching the PCB covers (LOW and UP)


### Assembly precaution

Be careful not to damage the styrene when fitting the lead wires into the styrene grooves.

[1] Put the controller cable in the corner (indicated by ○).




< VL-350CZPVU-L type >




< VL-350CZPVU-R type >

[2] Fit the part of the thermistor (OA) lead wrapped with packing into the styrene groove (indicated by ○), and put the extra part of the lead in the corner.




< VL-350CZPVU-L type >



< VL-350CZPVU-R type >

[3] Fit the part of the thermistor (RA) lead wrapped with packing into the styrene groove (indicated by ○).

\* Fit it into the same groove as the earth lead (green).




< VL-350CZPVU-L type >




< VL-350CZPVU-R type >

[4] Fit the part of the damper lead wrapped with packing into the styrene groove (indicated by ○).

[5] Fix the extra damper lead together with the earth lead (green) and thermistor (RA) lead using the cord clip.




< VL-350CZPVU-L type >




< VL-350CZPVU-R type >

[6] Fit the part of the SA fan motor lead wrapped with packing into the styrene groove (indicated by ○), and put the extra part of the lead in the corner.



< VL-350CZPVU-L type >




< VL-350CZPVU-R type >


[7] Fit the part of the EA fan motor lead wrapped with packing into the styrene groove (indicated by ○).

[8] Fix the EA fan motor lead with the lead clamper.

[9] Store the extra part of the lead in the outer side of the PCB cover (UP).



< VL-350CZPVU-L type >



< VL-350CZPVU-R type >

### \* When reassembling

- Reassemble the unit in the reverse order of disassembly.
- After reassembly, always make a test run to make sure that the unit operates properly.

### 11-3 VL-500CZPVU-L type, VL-500CZPVU-R type


**Note:** The following procedure applies to the VL-500CZPVU-L type. For VL-500CZPVU-R type, the components are placed in the right-left opposite positions.

#### (1) Turn off the power supply

- [1] Stop the operation.
- [2] Turn off the circuit breaker on the distribution board.

#### (2) Remove the heat exchanger... Refer to 11-1 (2).

**Assembly precaution**  
Insert the heat exchanger to the mark line on the PCB plate.




#### (3) Remove the PCB cover

- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the bypass plate.
  - a. Remove the screws.  
(2 screws: Spl screw PTT 4X14, indicated by ○)

**Tightening torque**  
○ : 1.2 ± 0.2 N·m

- b. Disengage the bypass plate from the boss part on the upper side.




**Assembly precaution**  
When installing the bypass plate, tighten the upper screw (to the boss part) before tightening the lower screw.

[3] Remove the PCB plate.

- a. Remove the screws.  
(4 screws: Spl screw PTT 4X14, indicated by ○)


**Tightening torque**  
○ :  $1.2 \pm 0.2 \text{ N}\cdot\text{m}$



PCB plate


- b. Raise this side of the PCB plate a little bit to disengage it from the back casing (indicated by □), and then pull out the PCB plate.

\* Remove the styrene part together.



PCB plate

Styrene part      PCB plate




[4] Remove the lead wires.

- a. Remove the lead wires from the styrene grooves (indicated by ○).

**Precaution**  
Be careful not to damage the styrene.

- b. Pull out the lead wires stored in the outer side of the PCB cover (UP).




PCB cover (UP)

[5] Remove the PCB cover (UP).

- a. Remove the screws.  
(2 screws: Spl screw PTT 4X14, indicated by ○)


**Precaution**  
Screws are located where it is not easy to see them.

**Tightening torque**  
○ :  $1.2 \pm 0.2$  N·m




- b. Remove the PCB cover (UP).

**Assembly precaution**  
Be sure to attach the PCB cover (LOW) before installing the PCB cover (UP).



[6] Remove the PCB cover (LOW).



■ **Reference: Circuit board locations within the control box** ... Refer to 11-1 (page 55).

## (4) Remove the thermistor

- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Remove the screws and remove the element guide.  
(3 screws: Spl screw PTT 4X14, indicated by ○)

**Tightening torque**  
○ :  $1.1 \pm 0.2$  N·m

Element guide (OA)      Thermistor (OA)



<For thermistor (OA)>


Thermistor (RA)      Element guide (SA)



<For thermistor (RA)>

**Assembly precaution**  
Attach the element guide to the original position.  
(Even though the element guides (OA, SA) have the same shape, another piece of packing is attached on the element guide (OA).)

Element guide (SA)      Packing



Packing      Element guide (OA)


- [4] Remove the thermistor lead from the groove.  
\* Pull out the thermistor (RA) from the hole (indicated by ○).

Thermistor (OA) lead



<For thermistor (OA)>

Thermistor (RA) lead



<For thermistor (RA)>



[5] Unhook the thermistor lead from the hooks on the orifice (indicated by ○).



<For thermistor (OA)>




<For thermistor (RA)>

[6] Disconnect the thermistor relay connector.

[7] Remove the thermistor lead from the lead clamber.

[8] Remove the metal clip fixing screw.  
(1 screw: indicated by ○)



**Assembly precaution**  
Attach the thermistor as shown in the picture.

<For thermistor (OA)>



<For thermistor (RA)>




## (5) Remove the damper assembly


- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Lower the circuit board (control circuit board) to provide a work space for disconnecting and connecting the connectors.
  - a. Remove the circuit board fixing screws from the bottom side of the product.  
(2 screws: Spl screw PT 4X10 (painted), indicated by ○)

**Tightening torque**  
○ :  $1.5 \pm 0.2$  N·m

- b. Lower the circuit board.




- [4] Remove the damper lead from the metal plate hook of the control box (indicated by ○).




- [5] Disconnect the damper lead connector from the power circuit board.

Damper connector: CN7    Power circuit board




- [6] Remove the element guide (SA). ... Refer to (4) [3].
- [7] Remove the damper assembly.
- [8] Remove the damper lead from the bypass air duct.

Damper assembly    Damper lead    Bypass air duct



## (6) Remove the fan assembly

- [1] Remove the heat exchanger. ... Refer to (2).
- [2] Remove the PCB cover. ... Refer to (3).
- [3] Remove the thermistor and element guide. ... Refer to (4).
- [4] Lower the circuit board (control circuit board) to provide a work space for disconnecting and connecting the connectors. ... Refer to (5) [3].
- [5] Remove the lead clip fixing screw to disconnect the connector.
  - (1 screw: PTT screw 4x12, indicated by ○)
  - \* VL-500CZPVU-L type only**




Lead clip

- [6] Disconnect the motor lead connectors from the power circuit board.
  - SA fan motor connector: CN10
  - EA fan motor connector: CN9

**Precaution**  
 When disconnecting the motor connectors, make sure that the power supply is turned off. Even when the fan motor is stopped, disconnecting the live-line connectors will cause a motor malfunction.


- [7] Remove the motor leads from the metal plate hook of the control box (indicated by ○).




Power circuit board EA fan motor connector: CN9

\* Steps [8] through [13] refers to the **EA fan assembly**. Disassemble the **SA fan assembly** in the similar manner.

- [8] Remove the orifice.
  - a. Remove the screw.
    - (1 screw: Spl screw PTT 4X14, indicated by ○)
  - Tightening torque**  
 $\bigcirc : 1.1 \pm 0.2 \text{ N}\cdot\text{m}$
  - b. Disengage the tabs (three locations, indicated by □) and remove the orifice.




[9] Remove the cover by sliding it.



[10] Remove the special nut (M8) and spring washer (8).

Tightening torque:  
 $2.3 \pm 0.2 \text{ N}\cdot\text{m}$

[11] Remove the tab washer and centrifugal fan.



[12] Remove the special washer (10).




[13] Remove the DC motor (EA).

- a. Remove the lead clip fixing screw.  
(1 screw: PTT screw 4x8, indicated by ○)

Tightening torque  
○ :  $0.8 \pm 0.2$  N·m

- b. Remove the motor fixing screws.  
(4 screws: Spl screw 4x16, indicated by △)

Tightening torque  
△ :  $1.5 \pm 0.2$  N·m




**(7) Remove the circuit board and power supply cord...** Refer to 11-1 (7).

**(8) Remove the controller...** Refer to 11-1 (8).

**(9) Restoring wire connection...** Refer to 11-1 (9).

Precautions when storing the controller cable after attaching the PCB cover (LOW and UP)  
(For VL-500CZPVU-L type)

- Tuck the controller cable into the deepest position until the cable touches the bottom metal plate.





- Tuck the controller cable with a long tool. (Do not use sharp tools including screwdrivers to avoid damaging the controller cable.)

### \* When reassembling


- Reassemble the unit in the reverse order of disassembly.
- After reassembly, always make a test run to make sure that the unit operates properly.

# 12. Parts catalog

## Please note the following when using the parts catalog.


1. When ordering parts, the part number, part name, and the number of parts are required.
2. It may take time for you to receive the parts. Make an inquiry about a rush order.
3. Specifications may be subject to change without notice.
4. Parts marked with  and  are critical for safety.
5. To maintain safety and performance, use the parts specified in the parts catalog.

### Description of screw abbreviations








Abbreviation	Description
PC screw	Cross recess flat head machine screw
PRC screw	Cross recess oval head machine screw
PP screw	Cross recess pan head machine screw
SW · PP screw	Cross recess pan head screw with spring washer
PPT screw	Cross recess tapping screw
PCT screw	Cross recess flat head tapping screw
PTT screw	Cross recess truss head tapping screw
PT screw	Cross recess truss head machine screw
SET screw	Slotted head stop screw
SQ · SET screw	Square head stop screw
P · SET screw	Pan head stop screw
PMT screw	Primer truss head screw
HS · SET screw	Hexagon head stop screw
P · R · W screw	Cross recess round wood screw
P · C · W screw	Cross recess flat head wood screw
P · R · C · W screw	Cross recess round and flat wood screw
R · W screw	Slotted round wood screw
PW · PP screw	Cross recess pan head screw with small washer
SW-PW · PP screw	Cross recess pan head machine screw with spring washer and flat washer

# VL-250CZPVU-L-E



15 \*


Drain hose fixture	Washer
	
2 pcs.	8 pcs.
Cable strap	
	
1 pc.	
Drain hose (250 mm)	
	
1 pc.	
Slim-Lossnay connection cable (100 mm)	
	
1 pc.	

\* shows accessory parts.

## VL-250CZPVU-L-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 008 719	1		
4	Filter case (RA)	W36 008 720	1		
5	Filter case (SA)	W36 008 721	1		
6	Front casing (OUT)	W36 008 830	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 008 831	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 008 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 008 380	1		
15	Parts in bag	W36 008 588	1		






## VL-250CZPVU-L-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (EA)	W36 008 453	1	△	
22	Spl screw PTT 4x14	W36 008 046	21		
23	Cover	W36 008 832	2		
24	Special washer (8)	W50 003 477	2		Dia. 40mm
25	Centrifugal fan	W36 008 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 008 167	1	△	OA
30	Orifice (EA)	W36 008 833	1		
31	Damper assembly	W36 008 715	1	△	
32	Bypass plate	W36 008 835	1		
33	Orifice (SA)	W36 008 834	1		
34	Thermistor	W36 008 168	1	△	RA
35	DC motor (SA)	W36 008 454	1	△	



Power interface circuit board



Power circuit board



50  
(3 pcs.)


51  
(2 pcs.)

Control circuit board

Signal interface circuit board

46

8  
(2 pcs.)



48

49


<Standard screws>

Symbol	Screw name
a	PT screw 4x10

## VL-250CZPVU-L-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 836	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	△	Power, Power interface
45	Circuit board	W36 008 236	1	△	Power interface
46	Insulating sheet	W36 008 226	1	△	
47	Circuit board	W36 008 237	1	△	Control, Signal interface
48	Power supply cord	W36 008 220	1	△	1850mm
49	Lead wire	W36 008 231	1	△	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		


# VL-250CZPVU-R-E



\* shows accessory parts.

## VL-250CZPVU-R-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (A)	W36 008 718	2		
2	Filter cover (B)	W36 008 717	1		
3	Filter case (RA)	W36 008 723	1		
4	Filter case (SA)	W36 008 724	1		
5	Filter case (OA)	W36 008 725	1		
6	Front casing (OUT)	W36 008 837	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 008 838	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 008 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 008 380	1		
15	Parts in bag	W36 008 588	1		



## VL-250CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (SA)	W36 008 454	1	△	
22	Spl screw PTT 4x14	W36 008 046	21		
23	Cover	W36 008 832	2		
24	Special washer (8)	W50 003 477	2		Dia. 40mm
25	Centrifugal fan	W36 008 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 008 169	1	△	RA
30	Damper assembly	W36 008 715	1	△	
31	Orifice (SA)	W36 008 834	1		
32	Bypass plate	W36 008 835	1		
33	Orifice (EA)	W36 008 833	1		
34	Thermistor	W36 008 167	1	△	OA
35	DC motor (EA)	W36 008 453	1	△	







<Standard screws>

Symbol	Screw name
a	PT screw 4x10

## VL-250CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 836	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 238	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 239	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 232	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		


# VL-350CZPVU-L-E



\* shows accessory parts.


VL-350CZPVU-L-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 008 726	1		
4	Filter case (RA)	W36 008 727	1		
5	Filter case (SA)	W36 008 728	1		
6	Spl screw PT 4x10	W36 008 045	6		
7	Special washer (3)	W00 000 167	2		
8	Front casing (OUT)	W36 008 839	1		
9	Bush	W36 008 225	6		
10	Front casing (IN)	W36 008 840	1		
11	Controller	W36 008 722	1	⚠	
12	Heat exchanger	W36 008 711	1	⚠	
13	Wiring diagram	W36 008 358	1		
14	Drain cap	W36 008 309	1		
15	Wall bracket	W36 008 381	1		
16	Parts in bag	W36 008 588	1		




## VL-350CZPVU-L-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	Special nut (M8)	W36 008 067	2		
22	Spring washer (8)	W00 000 126	2		
23	Tab washer	W00 000 134	2		
24	Centrifugal fan	W36 008 481	2	△	Dia. 210mm
25	Washer (10)	W36 008 071	2		
26	DC motor assy (EA)	W36 008 729	1	△	With fan casing
27	Spacer	W36 008 095	8		6X15
28	Spl screw PPT 4x30	W36 008 047	8		
29	Thermistor	W36 008 170	1	△	OA
30	Element guide (OA)	W36 008 841	1		
31	Damper frame	W36 008 716	1		
32	Damper assembly	W36 008 731	1	△	
33	Element guide (RA)	W36 008 842	1		
34	DC motor assy (SA)	W36 008 730	1	△	With fan casing
35	Thermistor	W36 008 171	1	△	RA



Power interface circuit board




Power circuit board



51  
(3 pcs.)


52  
(2 pcs.)



Control circuit board

Signal interface circuit board

6  
(2 pcs.)



<Standard screws>



Symbol	Screw name
a	PT screw 4x10

## VL-350CZPVU-L-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 843	1		
42	PCB cover (UP)	W36 008 704	1		
43	Spl screw PTT 4x12	W00 000 045	2		
44	PCB cover (LOW)	W36 008 705	1		
45	Control box	W36 008 235	1	⚠	Power, Power interface
46	Circuit board	W36 008 236	1	⚠	Power interface
47	Insulating sheet	W36 008 226	1	⚠	
48	Circuit board	W36 008 237	1	⚠	Control, Signal interface
49	Power supply cord	W36 008 220	1	⚠	1850mm
50	Lead wire	W36 008 231	1	⚠	Controller
51	Spl screw PTT 4x12	W36 008 049	3		
52	Spl screw PT 5x10	W36 008 048	2		




# VL-350CZPVU-R-E



\* shows accessory parts.


## VL-350CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (A)	W36 008 718	2		
2	Filter cover (B)	W36 008 717	1		
3	Filter case (RA)	W36 008 732	1		
4	Filter case (SA)	W36 008 733	1		
5	Filter case (OA)	W36 008 734	1		
6	Spl screw PT 4x10	W36 008 045	6		
7	Special washer (3)	W00 000 167	2		
8	Front casing (OUT)	W36 008 844	1		
9	Bush	W36 008 225	6		
10	Front casing (IN)	W36 008 845	1		
11	Controller	W36 008 722	1	⚠	
12	Heat exchanger	W36 008 711	1	⚠	
13	Wiring diagram	W36 008 358	1		
14	Drain cap	W36 008 309	1		
15	Wall bracket	W36 008 381	1		
16	Parts in bag	W36 008 588	1		



## VL-350CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	Special nut (M8)	W36 008 067	2		
22	Spring washer (8)	W00 000 126	2		
23	Tab washer	W00 000 134	2		
24	Centrifugal fan	W36 008 481	2	△	Dia. 210mm
25	Washer (10)	W36 008 071	2		
26	DC motor assy (SA)	W36 008 730	1	△	With fan casing
27	Spacer	W36 008 095	8		6X15
28	Spl screw PPT 4x30	W36 008 047	8		
29	Element guide (RA)	W36 008 842	1		
30	Damper assembly	W36 008 731	1	△	
31	Damper frame	W36 008 716	1		
32	Thermistor	W36 008 172	1	△	RA
33	Element guide (OA)	W36 008 841	1		
34	DC motor assy (EA)	W36 008 729	1	△	With fan casing
35	Thermistor	W36 008 170	1	△	OA




<Standard screws>

Symbol	Screw name
a	PT screw 4x10

## VL-350CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 843	1		
42	PCB cover (UP)	W36 008 704	1		
43	Spl screw PTT 4x12	W00 000 045	2		
44	PCB cover (LOW)	W36 008 705	1		
45	Control box	W36 008 238	1	⚠	Power, Power interface
46	Circuit board	W36 008 236	1	⚠	Power interface
47	Insulating sheet	W36 008 226	1	⚠	
48	Circuit board	W36 008 239	1	⚠	Control, Signal interface
49	Power supply cord	W36 008 220	1	⚠	1850mm
50	Lead wire	W36 008 232	1	⚠	Controller
51	Spl screw PTT 4x12	W36 008 049	3		
52	Spl screw PT 5x10	W36 008 048	2		


# VL-500CZPVU-L-E



## VL-500CZPVU-L-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 009 717	1		
4	Filter case (RA)	W36 009 718	1		
5	Filter case (SA)	W36 009 719	1		
6	Front casing (OUT)	W36 009 833	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 009 830	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 009 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 009 380	1		
15	Parts in bag	W36 008 588	1		





## VL-500CZPVU-L-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (EA)	W36 009 454	1	△	
22	Spl screw 4x16	W36 009 018	8		
23	Cover	W36 009 836	2		
24	Special washer (10)	W50 003 478	2		Dia. 40mm
25	Centrifugal fan	W36 009 480	2	△	Dia. 230mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 009 168	1	△	OA
30	Element guide (OA)	W36 009 837	1		
31	Spl screw PTT 4x14	W36 008 046	16		
32	Orifice	W36 009 834	2		
33	Damper assembly	W36 009 715	1	△	
34	Bypass plate	W36 009 832	1		
35	Element guide (SA)	W36 009 835	1		
36	Thermistor	W36 009 167	1	△	RA
37	DC motor (SA)	W36 009 453	1	△	




<Standard screws>

Symbol	Screw name
a	PT screw 4x10

VL-500CZPVU-L-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 009 831	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 237	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 231	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		

# VL-500CZPVU-R-E



## VL-500CZPVU-R-E








No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	1		
2	Filter cover (A)	W36 008 718	2		
3	Filter case (RA)	W36 009 720	1		
4	Filter case (SA)	W36 009 721	1		
5	Filter case (OA)	W36 009 722	1		
6	Front casing (OUT)	W36 009 839	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 009 838	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 009 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 009 380	1		
15	Parts in bag	W36 008 588	1		



## VL-500CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (SA)	W36 009 453	1	△	
22	Spl screw 4x16	W36 009 018	8		
23	Cover	W36 009 836	2		
24	Special washer (10)	W50 003 478	2		Dia. 40mm
25	Centrifugal fan	W36 009 480	2	△	Dia. 230
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 009 169	1	△	RA
30	Element guide (SA)	W36 009 835	1		
31	Spl screw PTT 4x14	W36 008 046	16		
32	Orifice	W36 009 834	2		
33	Damper assembly	W36 009 715	1	△	
34	Bypass plate	W36 009 832	1		
35	Element guide (OA)	W36 009 837	1		
36	Thermistor	W36 009 168	1	△	OA
37	DC motor (EA)	W36 009 454	1	△	






<Standard screws>

Symbol	Screw name
a	PT screw 4x10


## VL-500CZPVU-R-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 009 831	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 237	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 231	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		

# VL-250CZPVU-L-ERT




(Commercially available screw)  
(4 pcs.)



\* shows accessory parts.


## VL-250CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 008 719	1		
4	Filter case (RA)	W36 008 720	1		
5	Filter case (SA)	W36 008 721	1		
6	Front casing (OUT)	W36 008 830	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 008 831	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 008 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 008 380	1		
15	Parts in bag	W36 008 588	1		




## VL-250CZPVU-L-ERT


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (EA)	W36 008 453	1	△	
22	Spl screw PTT 4x14	W36 008 046	21		
23	Cover	W36 008 832	2		
24	Special washer (8)	W50 003 477	2		Dia. 40mm
25	Centrifugal fan	W36 008 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 008 167	1	△	OA
30	Orifice (EA)	W36 008 833	1		
31	Damper assembly	W36 008 715	1	△	
32	Bypass plate	W36 008 835	1		
33	Orifice (SA)	W36 008 834	1		
34	Thermistor	W36 008 168	1	△	RA
35	DC motor (SA)	W36 008 454	1	△	



Power interface circuit board



Power circuit board



50  
(3 pcs.)

51  
(2 pcs.)

Control circuit board

Signal interface circuit board


46

47

8  
(2 pcs.)

<Standard screws>

Symbol	Screw name
a	PT screw 4x10




## VL-250CZPVU-L-ERT


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 836	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 237	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 231	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		



# VL-250CZPVU-R-ERT




(Commercially available screw)  
(4 pcs.)



\* shows accessory parts.


## VL-250CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (A)	W36 008 718	2		
2	Filter cover (B)	W36 008 717	1		
3	Filter case (RA)	W36 008 723	1		
4	Filter case (SA)	W36 008 724	1		
5	Filter case (OA)	W36 008 725	1		
6	Front casing (OUT)	W36 008 837	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 008 838	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 008 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 008 380	1		
15	Parts in bag	W36 008 588	1		



## VL-250CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (SA)	W36 008 454	1	△	
22	Spl screw PTT 4x14	W36 008 046	21		
23	Cover	W36 008 832	2		
24	Special washer (8)	W50 003 477	2		Dia. 40mm
25	Centrifugal fan	W36 008 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 008 169	1	△	RA
30	Damper assembly	W36 008 715	1	△	
31	Orifice (SA)	W36 008 834	1		
32	Bypass plate	W36 008 835	1		
33	Orifice (EA)	W36 008 833	1		
34	Thermistor	W36 008 167	1	△	OA
35	DC motor (EA)	W36 008 453	1	△	





<Standard screws>

Symbol	Screw name
a	PT screw 4x10

## VL-250CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 836	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 238	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 239	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 232	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		

# VL-350CZPVU-L-ERT




\* shows accessory parts.

## VL-350CZPVU-L-ERT



No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 008 726	1		
4	Filter case (RA)	W36 008 727	1		
5	Filter case (SA)	W36 008 728	1		
6	Spl screw PT 4x10	W36 008 045	6		
7	Special washer (3)	W00 000 167	2		
8	Front casing (OUT)	W36 008 839	1		
9	Bush	W36 008 225	6		
10	Front casing (IN)	W36 008 840	1		
11	Controller	W36 008 722	1	⚠	
12	Heat exchanger	W36 008 711	1	⚠	
13	Wiring diagram	W36 008 358	1		
14	Drain cap	W36 008 309	1		
15	Wall bracket	W36 008 381	1		
16	Parts in bag	W36 008 588	1		






## VL-350CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	Special nut (M8)	W36 008 067	2		
22	Spring washer (8)	W00 000 126	2		
23	Tab washer	W00 000 134	2		
24	Centrifugal fan	W36 008 481	2	△	Dia. 210mm
25	Washer (10)	W36 008 071	2		
26	DC motor assy (EA)	W36 008 729	1	△	With fan casing
27	Spacer	W36 008 095	8		6X15
28	Spl screw PPT 4x30	W36 008 047	8		
29	Thermistor	W36 008 170	1	△	OA
30	Element guide (OA)	W36 008 841	1		
31	Damper frame	W36 008 716	1		
32	Damper assembly	W36 008 731	1	△	
33	Element guide (RA)	W36 008 842	1		
34	DC motor assy (SA)	W36 008 730	1	△	With fan casing
35	Thermistor	W36 008 171	1	△	RA



Power interface circuit board



Power circuit board

51  
(3 pcs.)

52  
(2 pcs.)

Control circuit board

Signal interface circuit board


47

48

6  
(2 pcs.)

<Standard screws>



Symbol	Screw name
a	PT screw 4x10



## VL-350CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 843	1		
42	PCB cover (UP)	W36 008 704	1		
43	Spl screw PTT 4x12	W00 000 045	2		
44	PCB cover (LOW)	W36 008 705	1		
45	Control box	W36 008 235	1	⚠	Power, Power interface
46	Circuit board	W36 008 236	1	⚠	Power interface
47	Insulating sheet	W36 008 226	1	⚠	
48	Circuit board	W36 008 237	1	⚠	Control, Signal interface
49	Power supply cord	W36 008 220	1	⚠	1850mm
50	Lead wire	W36 008 231	1	⚠	Controller
51	Spl screw PTT 4x12	W36 008 049	3		
52	Spl screw PT 5x10	W36 008 048	2		


# VL-350CZPVU-R-ERT



\* shows accessory parts.

## VL-350CZPVU-R-ERT


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (A)	W36 008 718	2		
2	Filter cover (B)	W36 008 717	1		
3	Filter case (RA)	W36 008 732	1		
4	Filter case (SA)	W36 008 733	1		
5	Filter case (OA)	W36 008 734	1		
6	Spl screw PT 4x10	W36 008 045	6		
7	Special washer (3)	W00 000 167	2		
8	Front casing (OUT)	W36 008 844	1		
9	Bush	W36 008 225	6		
10	Front casing (IN)	W36 008 845	1		
11	Controller	W36 008 722	1	⚠	
12	Heat exchanger	W36 008 711	1	⚠	
13	Wiring diagram	W36 008 358	1		
14	Drain cap	W36 008 309	1		
15	Wall bracket	W36 008 381	1		
16	Parts in bag	W36 008 588	1		



## VL-350CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	Special nut (M8)	W36 008 067	2		
22	Spring washer (8)	W00 000 126	2		
23	Tab washer	W00 000 134	2		
24	Centrifugal fan	W36 008 481	2	△	Dia. 210mm
25	Washer (10)	W36 008 071	2		
26	DC motor assy (SA)	W36 008 730	1	△	With fan casing
27	Spacer	W36 008 095	8		6X15
28	Spl screw PPT 4x30	W36 008 047	8		
29	Element guide (RA)	W36 008 842	1		
30	Damper assembly	W36 008 731	1	△	
31	Damper frame	W36 008 716	1		
32	Thermistor	W36 008 172	1	△	RA
33	Element guide (OA)	W36 008 841	1		
34	DC motor assy (EA)	W36 008 729	1	△	With fan casing
35	Thermistor	W36 008 170	1	△	OA






## VL-350CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 008 843	1		
42	PCB cover (UP)	W36 008 704	1		
43	Spl screw PTT 4x12	W00 000 045	2		
44	PCB cover (LOW)	W36 008 705	1		
45	Control box	W36 008 238	1	⚠	Power, Power interface
46	Circuit board	W36 008 236	1	⚠	Power interface
47	Insulating sheet	W36 008 226	1	⚠	
48	Circuit board	W36 008 239	1	⚠	Control, Signal interface
49	Power supply cord	W36 008 220	1	⚠	1850mm
50	Lead wire	W36 008 232	1	⚠	Controller
51	Spl screw PTT 4x12	W36 008 049	3		
52	Spl screw PT 5x10	W36 008 048	2		


# VL-500CZPVU-L-ERT



\* shows accessory parts.


## VL-500CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	2		
2	Filter cover (A)	W36 008 718	1		
3	Filter case (OA)	W36 009 717	1		
4	Filter case (RA)	W36 009 718	1		
5	Filter case (SA)	W36 009 719	1		
6	Front casing (OUT)	W36 009 833	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 009 830	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 009 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 009 380	1		
15	Parts in bag	W36 008 588	1		



## VL-500CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (EA)	W36 009 454	1	△	
22	Spl screw 4x16	W36 009 018	8		
23	Cover	W36 009 836	2		
24	Special washer (10)	W50 003 478	2		Dia. 40mm
25	Centrifugal fan	W36 009 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 009 168	1	△	OA
30	Element guide (OA)	W36 009 837	1		
31	Spl screw PTT 4x14	W36 008 046	16		
32	Orifice	W36 009 834	2		
33	Damper assembly	W36 009 715	1	△	
34	Bypass plate	W36 009 832	1		
35	Element guide (SA)	W36 009 835	1		
36	Thermistor	W36 009 167	1	△	RA
37	DC motor (SA)	W36 009 453	1	△	



<Standard screws>


Symbol	Screw name
a	PT screw 4x10

## VL-500CZPVU-L-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 009 831	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 237	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 231	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		




# VL-500CZPVU-R-ERT










## VL-500CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Filter cover (B)	W36 008 717	1		
2	Filter cover (A)	W36 008 718	2		
3	Filter case (RA)	W36 009 720	1		
4	Filter case (SA)	W36 009 721	1		
5	Filter case (OA)	W36 009 722	1		
6	Front casing (OUT)	W36 009 839	1		
7	Bush	W36 008 225	6		
8	Spl screw PT 4x10	W36 008 045	4		
9	Front casing (IN)	W36 009 838	1		
10	Controller	W36 008 722	1	⚠	
11	Heat exchanger	W36 009 710	1	⚠	
12	Wiring diagram	W36 008 358	1		
13	Drain cap	W36 008 309	1		
14	Wall bracket	W36 009 380	1		
15	Parts in bag	W36 008 588	1		



## VL-500CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
21	DC motor (SA)	W36 009 453	1	△	
22	Spl screw 4x16	W36 009 018	8		
23	Cover	W36 009 836	2		
24	Special washer (10)	W50 003 478	2		Dia. 40mm
25	Centrifugal fan	W36 009 480	2	△	Dia. 180mm
26	Tab washer	W36 008 077	2		
27	Spring washer (8)	W00 000 129	2		
28	Special nut (M8)	W00 000 067	2		Left-handed
29	Thermistor	W36 009 169	1	△	RA
30	Element guide (SA)	W36 009 835	1		
31	Spl screw PTT 4x14	W36 008 046	16		
32	Orifice	W36 009 834	2		
33	Damper assembly	W36 009 715	1	△	
34	Bypass plate	W36 009 832	1		
35	Element guide (OA)	W36 009 837	1		
36	Thermistor	W36 009 168	1	△	OA
37	DC motor (EA)	W36 009 454	1	△	



<Standard screws>

Symbol	Screw name
a	PT screw 4x10

## VL-500CZPVU-R-ERT

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	PCB plate	W36 009 831	1		
42	PCB cover (UP)	W36 008 704	1		
43	PCB cover (LOW)	W36 008 705	1		
44	Control box	W36 008 235	1	⚠	Power, Power interface
45	Circuit board	W36 008 236	1	⚠	Power interface
46	Insulating sheet	W36 008 226	1	⚠	
47	Circuit board	W36 008 237	1	⚠	Control, Signal interface
48	Power supply cord	W36 008 220	1	⚠	1850mm
49	Lead wire	W36 008 231	1	⚠	Controller
50	Spl screw PTT 4x12	W36 008 049	3		
51	Spl screw PT 5x10	W36 008 048	2		