

Air-Conditioners

PUMY-M200YKM

PUMY-M200YKM-BS

PUMY-M200YKM-ET

PUMY-M200YKM-ET-BS

For use with R32

INSTALLATION MANUAL	FOR INSTALLER	English
INSTALLATIONSHANDBUCH	FÜR INSTALLATEUR	Deutsch
MANUEL D'INSTALLATION	POUR L'INSTALLATEUR	Français
INSTALLATIEHANDLEIDING	VOOR DE INSTALLATEUR	Nederlands
MANUAL DE INSTALACIÓN	PARA EL INSTALADOR	Español
MANUALE DI INSTALLAZIONE	PER L'INSTALLATORE	Italiano
ΕΓΧΕΙΡΙΔΙΟ ΟΔΗΓΙΩΝ ΕΓΚΑΤΑΣΤΑΣΗΣ	ΓΙΑ ΑΥΤΟΝ ΠΟΥ ΚΑΝΕΙ ΤΗΝ ΕΓΚΑΤΑΣΤΑΣΗ	Ελληνικά
MANUAL DE INSTALAÇÃO	PARA O INSTALADOR	Português
INSTALLATIONS MANUAL	TIL INSTALLATØREN	Dansk
INSTALLATIONS MANUAL	FÖR INSTALLATÖREN	Svenska
MONTAJ EL KİTABI	MONTÖR İÇİN	Türkçe
ПОСІБНИК З УСТАНОВЛЕННЯ	ДЛЯ СПЕЦІАЛІСТА З МОНТАЖУ	Українська
РЪКОВОДСТВО ЗА МОНТАЖ	ЗА МОНТАЖНИКА	Български
INSTRUKCJA MONTAŻU	DLA INSTALATORA	Polski
INSTALLASJONSHÅNDBOK	FOR MONTØR	Norsk
ASENNUSOPAS	ASENTAJALLE	Suomi
INSTALAČNÍ PŘÍRUČKA	PRO MONTÁŽNÍ PRACOVNÍKY	Čeština
NÁVOD NA INŠTALÁCIU	PRE MONTÉRA	Slovenčina
TELEPÍTÉSI KÉZIKÖNYV	A TELEPÍTŐ RÉSZÉRE	Magyar
NAMESTITVENI PRIROČNIK	ZA MONTERJA	Slovenščina
MANUAL DE INSTALARE	PENTRU INSTALATOR	Română
PAIGALDUSJUHEND	PAIGALDAJALE	Eesti
MONTĀŽAS ROKASGRĀMATA	UZSTĀDĪŠANAS SPECIĀLISTAM	Latviski
MONTAVIMO VADOVAS	SKIRTA MONTUOTOJUI	Lietuviškai
PRIRUČNIK ZA POSTAVLJANJE	ZA INSTALATERA	Hrvatski
UPUTSTVO ZA UGRADNJU	ZA MONTERA	Srpski

1. Safety precautions.....	1	6. Electrical work	27
2. Installation location.....	4	7. Test run.....	53
3. Installing the outdoor unit	18	8. Special functions	54
4. Installing the refrigerant piping	18	9. Preventive maintenance for the unit.....	55
5. Drainage piping work.....	26	10. Specifications	55

Note: This symbol mark is for related countries only.

This symbol mark is according to the directive 2012/19/EU Article 14 Information for users and Annex IX.

Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and reused.

This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste. Please, dispose of this equipment at your local community waste collection/recycling centre.

In the European Union there are separate collection systems for used electrical and electronic product.

Please, help us to conserve the environment we live in!


Caution:

- Do not vent R32 into the atmosphere.

Confirmation of parts attached

In addition to this manual, the following part is supplied with the outdoor unit.

It is used for grounding the S terminal of transmission terminal block TB7. For details refer to “6. Electrical work”.



Grounding lead wire

1. Safety precautions

- ▶ Before installing the unit, make sure you read all the “Safety precautions”.
- ▶ The “Safety precautions” provide very important points regarding safety. Make sure you follow them.
- ▶ Please report to or take consent by the supply authority before connection to the system.

“This equipment complies with IEC 61000-3-12 provided that the short-circuit power S_{sc} is greater than or equal to $S_{sc}(*1)$ at the interface point between the user’s supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power S_{sc} greater than or equal to $S_{sc}(*1)$ ”

$S_{sc}(*1)$

Model	S_{sc} (MVA)
PUMY-M200YKM	1.56

- ▶ It is designed for use in the residential, commercial and light-industrial environment.

- Warning:**

Describes precautions that must be observed to prevent danger of injury or death to the user.
- Caution:**

Describes precautions that must be observed to prevent damage to the unit.

After installation work has been completed, explain the “Safety Precautions,” use, and maintenance of the unit to the customer according to the information in the Operation Manual and perform the test run to ensure normal operation. Both the Installation Manual and Operation Manual must be given to the user for keeping. These manuals must be passed on to subsequent users.
- : Indicates a part which must be grounded.
- Warning:**

Carefully read the labels affixed to the main unit.

MEANINGS OF SYMBOLS DISPLAYED ON THE UNIT

	WARNING (Risk of fire)	This mark is for R32 refrigerant only. Refrigerant type is written on nameplate of outdoor unit. In case that refrigerant type is R32, this unit uses a flammable refrigerant. If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.
	Read the OPERATION MANUAL carefully before operation.	
	Service personnel are required to carefully read the OPERATION MANUAL and INSTALLATION MANUAL before operation.	

- Warning:**

 - The unit must not be installed by the user. Ask a dealer or an authorized technician to install the unit. If the unit is installed incorrectly, water leakage, electric shock, or fire may result.
 - This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.
 - For installation work, follow the instructions in the Installation Manual and use tools and pipe components specifically made for use with R32 refrigerant. If pipe components not designed for R32 refrigerant are used and the unit is not installed correctly, the pipes may burst and cause damage or injuries. In addition, water leakage, electric shock, or fire may result.
- When installing the unit, use appropriate protective equipment and tools for safety. Failure to do so could cause injuries.
 - The unit must be installed according to the instructions in order to minimize the risk of damage from earthquakes, typhoons, or strong winds. An incorrectly installed unit may fall down and cause damage or injuries.
 - The unit must be securely installed on a structure that can sustain its weight. If the unit is mounted on an unstable structure, it may fall down and cause damage or injuries.

1. Safety precautions

- If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration in the room from exceeding the safety limit in the event of refrigerant leakage. Consult a dealer regarding the appropriate measures to prevent the allowable concentration from being exceeded. Should the refrigerant leak and cause the concentration limit to be exceeded, hazards due to lack of oxygen in the room may result.
- Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, it may ignite or poisonous gases will be released.
- All electric work must be performed by a qualified technician according to local regulations and the instructions given in this manual. The units must be powered by dedicated power lines and the correct voltage and circuit breakers must be used. Power lines with insufficient capacity or incorrect electrical work may result in electric shock or fire.
- Use C1220 copper phosphorus, for copper and copper alloy seamless pipes, to connect the refrigerant pipes. If the pipes are not connected correctly, the unit will not be properly grounded and electric shock may result.
- Use only specified cables for wiring. The wiring connections must be made securely with no tension applied on the terminal connections. Also, never splice the cables for wiring (unless otherwise indicated in this document). Failure to observe these instructions may result in overheating or a fire.
- The terminal block cover panel of the outdoor unit must be firmly attached. If the cover panel is mounted incorrectly and dust and moisture enter the unit, electric shock or fire may result.
- The appliance shall be installed in accordance with national wiring regulations.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- When installing or relocating, or servicing the air conditioner, use only the specified refrigerant (R32) to charge the refrigerant lines. Do not mix it with any other refrigerant and do not allow air to remain in the lines. If air is mixed with the refrigerant, then it can be the cause of abnormal high pressure in the refrigerant line, and may result in an explosion and other hazards. The use of any refrigerant other than that specified for the system will cause mechanical failure or system malfunction or unit breakdown. In the worst case, this could lead to a serious impediment to securing product safety.
- Do not perform pump down work when there is a gas leak. The intake of air or other gases causes abnormally high pressure in the refrigeration cycle, which may cause explosion or injury.
- Use only authorized accessories and ask a dealer or an authorized technician to install them. If accessories are incorrectly installed, water leakage, electric shock, or fire may result.
- Do not alter the unit. It may cause fire, electric shock, injury or water leakage.
- The user should never attempt to repair the unit or transfer it to another location. If the unit is installed incorrectly, water leakage, electric shock, or fire may result. If the air conditioner must be repaired or moved, ask a dealer or an authorized technician.
- After installation has been completed, check for refrigerant leaks. If refrigerant leaks into the room and comes into contact with the flame of a heater or portable cooking range, it may ignite or poisonous gases will be released.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- Pipe-work shall be protected from physical damage.
- The installation of pipe-work shall be kept to a minimum.
- Compliance with national gas regulations shall be observed.
- Keep any required ventilation openings clear of obstruction.
- Do not use low temperature solder alloy in case of brazing the refrigerant pipes.
- When performing brazing work, be sure to ventilate the room sufficiently. Make sure that there are no hazardous or flammable materials nearby. When performing the work in a closed room, small room, or similar location, make sure that there are no refrigerant leaks before performing the work. If refrigerant leaks and accumulates, it may ignite or poisonous gases may be released.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- Keep gas-burning appliances, electric heaters, and other fire sources (ignition sources) away from the location where installation, repair, and other air conditioner work will be performed. If refrigerant comes into contact with a flame, poisonous gases will be released.
- Do not smoke during work and transportation.
- When installing or removing the air conditioner, carry the refrigerant leak detector.
- For safety purposes, be sure always keep the power on, except during maintenance.
- Refrigerant pipes must be protected against external force.

en

1.1. Before installation

Caution:

- Do not use the unit in an unusual environment. If the air conditioner is installed in areas exposed to steam, volatile oil (including machine oil), or sulfuric gas, areas exposed to high salt content such as the seaside, or areas where the unit will be covered by snow, the performance can be significantly reduced and the internal parts can be damaged.
- Do not install the unit where combustible gases may leak, be produced, flow, or accumulate. If combustible gas accumulates around the unit, fire or explosion may result.
- The outdoor unit produces condensation during the heating operation. Make sure to provide drainage around the outdoor unit if such condensation is likely to cause damage.
- When installing the unit in a hospital or communications office, be prepared for noise and electronic interference. Inverters, home appliances, high-frequency medical equipment, and radio communications equipment can cause the air conditioner to malfunction or breakdown. The air conditioner may also affect medical equipment, disturbing medical care, and communications equipment, harming the screen display quality.
- Follow the instructions below to prevent abrasive components contained in sandpaper and cutting tools from entering the refrigerant circuit because those components can cause failures of the compressor and valves.
 - To deburr pipes, use a reamer or other deburring tools, not sandpaper.
 - To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
 - When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
 - If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

1. Safety precautions

1.2. Before installation (relocation)

-  **Caution:**
- Be extremely careful when transporting the units. Two or more persons are needed to handle the unit, as it weighs 20 kg or more. Do not grasp the packaging bands. Wear protective gloves to remove the unit from the packaging and to move it, as you can injure your hands on the fins or other parts.
 - Be sure to safely dispose of the packaging materials. Packaging materials, such as nails and other metal or wooden parts may cause stabs or other injuries.
 - The base and attachments of the outdoor unit must be periodically checked for looseness, cracks or other damage. If such defects are left uncorrected, the unit may fall down and cause damage or injuries.
- Do not clean the air conditioner unit with water. Electric shock may result.
 - Tighten all flare nuts to specification using a torque wrench. If tightened too much, the flare nut can break after an extended period and refrigerant can leak out.

1.3. Before electric work

-  **Caution:**
- Be sure to install circuit breakers. If not installed, electric shock may result.
 - For the power lines, use standard cables of sufficient capacity. Otherwise, a short circuit, overheating, or fire may result.
 - When installing the power lines, do not apply tension to the cables. If the connections are loosened, the cables can snap or break and overheating or fire may result.
- Be sure to ground the unit. Do not connect the ground wire to gas or water pipes, lightning rods, or telephone grounding lines. If the unit is not properly grounded, electric shock may result.
 - Use circuit breakers (ground fault interrupter, isolating switch (+B fuse), and molded case circuit breaker) with the specified capacity. If the circuit breaker capacity is larger than the specified capacity, breakdown or fire may result.

1.4. Before starting the test run

-  **Caution:**
- Turn on the main power switch more than 12 hours before starting operation. Starting operation just after turning on the power switch can severely damage the internal parts. Keep the main power switch turned on during the operation season.
 - Before starting operation, check that all panels, guards and other protective parts are correctly installed. Rotating, hot, or high voltage parts can cause injuries.
 - Do not touch any switch with wet hands. Electric shock may result.
- Do not touch the refrigerant pipes with bare hands during operation. The refrigerant pipes are hot or cold depending on the condition of the flowing refrigerant. If you touch the pipes, burns or frostbite may result.
 - After stopping operation, be sure to wait at least five minutes before turning off the main power switch. Otherwise, water leakage or breakdown may result.

1.5. Using R32 refrigerant air conditioners

-  **Caution:**
- Use C1220 copper phosphorus, for copper and copper alloy seamless pipes, to connect the refrigerant pipes. Make sure the insides of the pipes are clean and do not contain any harmful contaminants such as sulfuric compounds, oxidants, debris, or dust. Use pipes with the specified thickness. (Refer to 4.1.) Note the following if reusing existing pipes that carried R22 refrigerant.
 - Replace the existing flare nuts and flare the flared sections again.
 - Do not use thin pipes. (Refer to 4.1.)
 - Store the pipes to be used during installation indoors and keep both ends of the pipes sealed until just before brazing. (Leave elbow joints, etc. in their packaging.) If dust, debris, or moisture enters the refrigerant lines, oil deterioration or compressor breakdown may result.
 - Use ester oil, ether oil, alkylbenzene oil (small amount) as the refrigeration oil applied to the flared sections. If mineral oil is mixed in the refrigeration oil, oil deterioration may result.
- Do not use refrigerant other than R32 refrigerant. If another refrigerant is used, the chlorine will cause the oil to deteriorate.
 - Use the following tools specifically designed for use with R32 refrigerant. The following tools are necessary to use R32 refrigerant. Contact your nearest dealer for any questions.

Tools (for R32)	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adapter
Torque wrench	Electronic refrigerant charging scale

- Be sure to use the correct tools. If dust, debris, or moisture enters the refrigerant lines, refrigeration oil deterioration may result.

2. Installation location

2.1. Refrigerant pipe

Refer to Fig. 4-3, 4-4, 4-5.

2.2. Choosing the outdoor unit installation location

- R32 is heavier than air—as well as other refrigerants—so tends to accumulate at the base (in the vicinity of the floor). If R32 accumulates around base, it may reach a flammable concentration in case room is small. To avoid ignition, maintaining a safe work environment is required by ensuring appropriate ventilation. If a refrigerant leak is confirmed in a room or an area where there is insufficient ventilation, refrain from using of flames until the work environment can be improved by ensuring appropriate ventilation.
- Avoid locations exposed to direct sunlight or other sources of heat.
- Select a location from which noise emitted by the unit will not inconvenience neighbors.
- Select a location permitting easy wiring and pipe access to the power source and indoor unit.
- Avoid locations where combustible gases may leak, be produced, flow, or accumulate.
- Note that water may drain from the unit during operation.
- Select a level location that can bear the weight and vibration of the unit.
- Avoid locations where the unit can be covered by snow. In areas where heavy snow fall is anticipated, special precautions such as raising the installation location or installing a hood on the air intake must be taken to prevent the snow from blocking the air intake or blowing directly against it. This can reduce the airflow and a malfunction may result.
- Avoid locations exposed to oil, steam, or sulfuric gas.
- Use the transportation handles of the outdoor unit to transport the unit. If the unit is carried from the bottom, hands or fingers may be pinched.
- Refrigerant pipes connection shall be accessible for maintenance purposes.
- Install outdoor units in a place where at least one of the four sides is open, or in a sufficiently large space without depressions. (Fig. 2-1)
- Do not install the outdoor unit at the inside of building such as a basement or machinery room, where the refrigerant stagnates.




Fig. 2-1

2. Installation location




Fig. 2-2

2.3. Outline dimensions (Outdoor unit) (Fig. 2-2)

Constraints on indoor unit installation

You should note that indoor units that can be connected to this outdoor unit are the following models.

- Indoor units with model numbers 10-200 can be connected.
 - When using Branch box, Indoor units with model numbers 15-100 can be connected.
- Refer to the table 1 below for possible room, indoor unit combinations.

Verification

The rated capacity should be determined by observing the table below. The unit's quantities are limited as shown in the following table 2. For the next step, make sure that the total rated capacity selected will stay in a range of 50% – 130% of the outdoor unit capacity.

- PUMY-M200 11.2 – 29.1 kW

Table 1-1 City Multi indoor units

Indoor unit type	10	15	20	22	25	28	32	36	40	45	50	56	63
Rated capacity (Cooling) (kW)	1.2	1.7	2.2	2.5	2.8	3.2	3.6	4.0	4.5	5.0	5.6	6.3	7.1

Indoor unit type	71	80	100	125	140	200
Rated capacity (Cooling) (kW)	8.0	9.0	11.2	14.0	16.0	22.4

Table 1-2 M, S, P series

Indoor unit type	15	20	22	25	35	42	50	60	71	80	100
Rated capacity (Cooling) (kW)	1.5	2.0	2.2	2.5	3.5	4.2	5.0	6.0	7.1	8.0	10.0

Table 2 Connectable indoor units and Branch boxes quantities

Model	Only system									
	Only City Multi indoor units (Connection without Branch box)		Only M, S, P series indoor units (Connection with Branch box)							
			One Branch box		Two Branch boxes					
			4-Branch box × 1	6-Branch box × 1	4-Branch box × 2	4-Branch box × 1 6-Branch box × 1	6-Branch box × 2			
PUMY-M200	1-12		2-8						Not allowed	

Model	Mixed system									
	One Branch box				Two Branch boxes					
	4-Branch box × 1		6-Branch box × 1		4-Branch box × 2		4-Branch box × 1 6-Branch box × 1		6-Branch box × 2	
	M, S, P	City Multi	M, S, P	City Multi	M, S, P	City Multi	M, S, P	City Multi	M, S, P	City Multi
PUMY-M200	Max. 4	Max. 5	Max. 6	Max. 3	Max. 8	Max. 3	Max. 8	Max. 2	Not allowed	

Combinations in which the total capacity of indoor units exceeds the capacity of the outdoor unit will reduce the cooling capacity of each indoor unit below their rated cooling capacity.

Thus, combine indoor units with an outdoor unit within the outdoor unit's capacity, if possible.

2. Installation location

2.4. Ventilation and service space

Note:

The dimensions given along the arrows below are required to guarantee the air conditioner's performance. Install the unit in as wide a place as possible for later service or repairs.

2.4.1. When installing a single outdoor unit

Minimum dimensions are as follows, except for Max., meaning Maximum dimensions, indicated.

Refer to the figures for each case.

1 Obstacles at rear only (Fig. 2-3)

2 Obstacles at rear and above only (Fig. 2-4)

3 Obstacles at rear and sides only (Fig. 2-5)

4 Obstacles at front only (Fig. 2-6)

* When using an optional air outlet guide, the clearance is 500 mm or more.

5 Obstacles at front and rear only (Fig. 2-7)

* When using an optional air outlet guide, the clearance is 500 mm or more.

6 Obstacles at rear, sides, and above only (Fig. 2-8)

* Do not install the optional air outlet guides for upward airflow.

2.4.2. When installing multiple outdoor units

Leave 50 mm space or more between the units.

1 Obstacles at rear only (Fig. 2-9)

2 Obstacles at rear and above only (Fig. 2-10)

* No more than 3 units must be installed side by side. In addition, leave space as shown.

* Do not install the optional air outlet guides for upward airflow.

3 Obstacles at front only (Fig. 2-11)

* When using an optional air outlet guide, the clearance is 1000 mm or more.

4 Obstacles at front and rear only (Fig. 2-12)

* When using an optional air outlet guide, the clearance is 1000 mm or more.

5 Single parallel unit arrangement (Fig. 2-13)

* When using an optional air outlet guide installed for upward airflow, the clearance is 1000 mm or more.

6 Multiple parallel unit arrangement (Fig. 2-14)

* When using an optional air outlet guide installed for upward airflow, the clearance is 1500 mm or more.

7 Stacked unit arrangement (Fig. 2-15)

* The units can be stacked up to 2 units high.

* No more than 2 stacked units must be installed side by side. In addition, leave space as shown.

UNIT: mm

en




Fig. 2-3




Fig. 2-4




Fig. 2-5




Fig. 2-6




Fig. 2-7




Fig. 2-8




Fig. 2-9




Fig. 2-10




Fig. 2-11




Fig. 2-12




Fig. 2-13




Fig. 2-14




Fig. 2-15

2. Installation location




Fig. 2-16




Fig. 2-17

2.4.3. Windy location installation

When installing the outdoor unit on a rooftop or other location unprotected from the wind, situate the air outlet of the unit so that it is not directly exposed to strong winds. Strong wind entering the air outlet may impede the normal airflow and a malfunction may result.

The following shows two examples of precautions against strong winds.

- 1 Install an optional air protect guide if the unit is installed in a location where strong winds from a typhoon, etc. may directly enter the air outlet. (Fig. 2-16)
- 2 Position the unit so that the air outlet blows perpendicularly to the seasonal wind direction, if possible. (Fig. 2-17)

Ⓐ Air protect guide

Ⓑ Wind direction

2. Installation location

2.5. Minimum installation area

■ Indoor units

Install in a room with a floor area of $A_{\min}$ or more, corresponding to refrigerant quantity m (factory-charged refrigerant + locally added refrigerant).

* For the factory-charged refrigerant amount, refer to the spec nameplate or installation manual.

For the amount to be added locally, refer to the installation manual.

Install the indoor unit so that the height from the floor to the bottom of the indoor unit is h_0 .

For wall mounted: 1.8 m or more

For ceiling suspended, cassette and ceiling concealed: 2.2 m or more

* There are restrictions in installation height for each model, so read the installation manual for the particular unit.









Fig. 2-18

2. Installation location

2.6. Precautions for R32 system

This air conditioner unit uses a mildly flammable R32 refrigerant.

This system is supported by the safety standard complying with the Enhanced Tightness Refrigerant System of IEC60335-2-40.

Install the unit according to the following requirements so that the system can satisfy the standards.

- For piping connection, use the mechanical joint (brazing and flare connection, etc.) complying with the latest version of ISO14903.

Ensure that the piping installed in a room is securely protected from damage due to an external force.

- Be sure to install an indoor unit in a room where the conditions in Fig. 2-18 are satisfied.

Install an indoor unit with refrigerant sensor or the SENSOR AND ALARM KIT depending on the conditions. Refer to 2.7. for the detail.

<When the system requires the SENSOR ALARM KIT connection>

- For the Branch box system, be sure to install the SENSOR AND ALARM KIT for each indoor unit.
- Install the SENSOR AND ALARM KIT into the specified area within 30 cm above a floor. Refer to the installation manual of the SENSOR AND ALARM KIT for the detail.
- Never install the Branch box in a room.
- Ensure that the Branch box is installed above the ceiling of corridor, bath room, etc., where persons are not regularly there.
Do not provide any vent or mesh between the space where the Branch box will be installed and the room below it.
- Install the Supervisor Alarm based on the standards in IEC60335-2-40 when it is required such as in a hotel or a hospital.
The mode of the SENSOR AND ALARM KIT can be changed to the Sensor and alarm mode or Supervisor mode.
For the setting when the Supervisor Alarm is connected, refer to the installation manual of the Branch box and SENSOR AND ALARM KIT.
- When the sensor detects the refrigerant leakage, the system closes the shut-off valve and performs refrigerant recovery while the alarm sounds.
Take appropriate measures in a service because the air conditioner cannot be operated again after the refrigerant recovery operation.
- The sensor must be replaced after it detects a refrigerant leak. Refer to the installation manual of the SENSOR AND ALARM KIT for the detail.


Precautions for the system connection

- For the Branch box system, install the SENSOR AND ALARM KIT for each indoor unit.

Note:

For the Branch box system, the air conditioner does not operate if the SENSOR AND ALARM KIT is not installed for each indoor unit.


The CITY MULTI indoor unit without refrigerant sensor can be installed as long as the minimum installation area A_{min-1} is satisfied.



- The Supervisor Alarm is necessary for the environment required in IEC60335-2-40 such as in a place where the movement of people is limited (a hospital, etc.) or where there is a sleeping facility (a hotel, etc.).


The mode must be set to the Supervisor mode when the SENSOR AND ALARM KIT is used as the Supervisor Alarm.

Refer to the installation manual of the SENSOR AND ALARM KIT for the detail.




- If the Supervisor room also has an indoor unit with the same refrigerant system, set the Supervisor mode and Sensor and alarm mode and install the SENSOR AND ALARM KIT respectively.

Refer to the installation manual of the SENSOR AND ALARM KIT for the detail.




2. Installation location


- Be sure to install the SENSOR AND ALARM KIT for each indoor unit when the Branch box is connected in the system.
When multiple indoor units are installed in a room, install the SENSOR AND ALARM KIT for each indoor unit.




- Be sure to set the mode of the SENSOR AND ALARM KIT to the Supervisor mode when the Supervisor Alarm is connected.




- Be sure to install the SENSOR AND ALARM KIT in the room where an indoor unit is installed.



- Do not install the Branch box in a room.



- Do not install an indoor unit across a number of rooms.



2. Installation location


<When the system requires the connection of the CITY MULTI indoor unit with refrigerant sensor>

- For the CITY MULTI indoor unit with refrigerant sensor, be sure to connect the MA remote controller with alarm for each indoor unit.
- Install the Supervisor Alarm based on the standards in IEC60335-2-40 when it is required such as in a hotel or a hospital.
The mode of the MA remote controller with alarm can be changed to the Main Remote Controller mode or Supervisor Remote Controller mode.
For the setting when the MA remote controller in Supervisor Remote Controller mode is connected, refer to the installation manual of the CITY MULTI indoor unit with refrigerant sensor and the MA remote controller with alarm.
- When the sensor detects the refrigerant leakage, the system closes the shut-off valve and performs refrigerant recovery while the alarm sounds.
Take appropriate measures in a service because the air conditioner cannot be operated again after the refrigerant recovery operation.
- The sensor must be replaced after it detects a refrigerant leak. Refer to the installation manual of the CITY MULTI indoor unit with refrigerant sensor for the detail.


Note:

For the CITY MULTI indoor unit with refrigerant sensor, the air conditioner does not operate if the MA remote controller with alarm is not installed for each indoor unit.


The CITY MULTI indoor unit without refrigerant sensor can be installed as long as the minimum installation area $A_{\min-1}$ is satisfied.



- The Supervisor Alarm is necessary for the environment required in IEC60335-2-40 such as in a place where the movement of people is limited (a hospital, etc.) or where there is a sleeping facility (a hotel, etc.).
- The mode must be set to the Supervisor Remote Controller mode when the MA remote controller with alarm is used as the Supervisor Alarm.
Refer to the installation manual of the MA remote controller with alarm for the detail.




- If the Supervisor room also has an indoor unit with the same refrigerant system, set the Supervisor Remote Controller mode and Main Remote Controller mode and install the MA remote controller with alarm respectively.
Refer to the installation manual of the MA remote controller with alarm for the detail.




2. Installation location

- Be sure to install the MA remote controller with alarm for each indoor unit when the CITY MULTI indoor unit with refrigerant sensor is connected in the system. When multiple CITY MULTI indoor units with refrigerant sensor are installed in a room, install the MA remote controller with alarm for each indoor unit.




- Be sure to set the mode of the MA remote controller with alarm to the Supervisor Remote Controller mode when the Supervisor Alarm is connected.


en



- Be sure to install the MA remote controller with alarm in the room where an indoor unit is installed.



- Do not install an indoor unit across a number of rooms.



2. Installation location

2.7. Calculation of the minimum installation area

The maximum allowable refrigerant amount is calculated based on the floor area of each room where the system is connected so that the system can satisfy the safety standards.

Use Fig. 2-19 to calculate the maximum allowable refrigerant amount for the smallest room where the CITY MULTI indoor unit without refrigerant sensor or the CITY MULTI indoor unit with refrigerant sensor or the Branch box system (with the SENSOR AND ALARM KIT connection) is to be installed.


<Case 1: CITY MULTI indoor unit without refrigerant sensor>

1. Confirm the installation height of indoor units. Use the values of A_{min-1} (a) when the installation height is 1.8 m and those of A_{min-1} (b) when the height is 2.2 m.

Note:

The wall-mounted unit cannot be installed in the area lower than 1.8 m, and the other indoor units cannot be installed in the area lower than 2.2 m.

2. Calculate the maximum allowable refrigerant amount " m_{max} " for the smallest room.
3. Calculate the refrigerant amount in the system according to 4.8.
4. An indoor unit can be installed if the refrigerant amount in the system " m " is less than " m_{max} ".
Review the system if the condition is not satisfied.



en

2. Installation location

<Case 2: CITY MULTI indoor unit with refrigerant sensor or Branch box system (with the SENSOR AND ALARM KIT connection)>

For rooms on the lowest floor of the basement and rooms on the other floors, calculate each maximum allowable refrigerant amount for the minimum installation area and select the smallest value.


1. Confirm whether or not indoor units are installed in the rooms on the lowest floor of the basement.
2. Confirm the installation height of the indoor units when the indoor units are installed in the rooms on the lowest floor of the basement.

Use the values of $A_{\min-2}$ (c) when the installation height is 1.8 m and those of $A_{\min-2}$ (d) when the height is 2.2 m.


Note:

The wall-mounted unit cannot be installed in the area lower than 1.8 m and the other indoor units cannot be installed in the area lower than 2.2 m.

3. Calculate the maximum allowable refrigerant amount " $m_{\max 1}$ " for the smallest room.
4. Confirm whether or not indoor units are installed in the rooms other than on the lowest floor of the basement.
5. Confirm the installation height of indoor units when the indoor units are installed in the rooms other than on the lowest floor of the basement.
Use the values of $A_{\min-2}$ (a) when the installation height is 1.8 m and those of $A_{\min-2}$ (b) when the height is 2.2 m.
6. Calculate the maximum allowable refrigerant amount " $m_{\max 2}$ " for the smallest room.
7. When both of " $m_{\max 1}$ " and " $m_{\max 2}$ " have been obtained, regard a smaller value as " $m_{\max}$ ". When either one has been obtained, regard the value as " $m_{\max}$ ".
8. An indoor unit can be installed if the refrigerant amount in the system " m " is less than " $m_{\max}$ ".
Review the system if the condition is not satisfied.




2. Installation location



2. Installation location

<Case 3: Mixed system>
For the mixed system, use the smallest value of each maximum allowable refrigerant amount “m_{max}” obtained in Case 1 and Case 2.
An indoor unit can be installed if the refrigerant amount in the system “m” is less than the maximum allowable refrigerant amount “m_{max}”.
Review the system if the condition is not satisfied.



en

3. Installing the outdoor unit




Fig. 3-1

- Be sure to install the unit in a sturdy, level surface to prevent rattling noises during operation. (Fig. 3-1)

<Foundation specifications>

Foundation bolt	M10
Thickness of concrete	120 mm
Length of bolt	70 mm
Weight-bearing capacity	320 kg

- Make sure that the length of the foundation bolt is within 30 mm of the bottom surface of the base.
- Secure the base of the unit firmly with four-M10 foundation bolts in sturdy locations.

Installing the outdoor unit

- Do not block the vent. If the vent is blocked, operation will be hindered and breakdown may result.
- In addition to the unit base, use the installation holes on the back of the unit to attach wires, etc., if necessary to install the unit. Use self-tapping screws ($\phi 5 \times 15$ mm or less) and install on site.

Warning:

- The unit must be securely installed on a structure that can sustain its weight. If the unit is mounted on an unstable structure, it may fall down and cause damage or injuries.
- The unit must be installed according to the instructions in order to minimize the risk of damage from earthquakes, typhoons, or strong winds. An incorrectly installed unit may fall down and cause damage or injuries.

Caution:

- Install unit on a rigid structure to prevent excessive operation sound or vibration.

4. Installing the refrigerant piping

4.1. Precautions for devices that use R32 refrigerant

- Refer to page 3 for precautions not included below on using air conditioners with R32 refrigerant.
- Use ester oil, ether oil, alkylbenzene oil (small amount) as the refrigeration oil applied to the flared sections.
- Use C1220 copper phosphorus, for copper and copper alloy seamless pipes, to connect the refrigerant pipes. Use refrigerant pipes with the thicknesses specified in the table to the below. Make sure the insides of the pipes are clean and do not contain any harmful contaminants such as sulfuric compounds, oxidants, debris, or dust.

Warning:

When installing or relocating, or servicing the air conditioner, use only the specified refrigerant (R32) to charge the refrigerant lines. Do not mix it with any other refrigerant and do not allow air to remain in the lines.

If air is mixed with the refrigerant, then it can be the cause of abnormal high pressure in the refrigerant line, and may result in an explosion and other hazards. The use of any refrigerant other than that specified for the system will cause mechanical failure or system malfunction or unit breakdown. In the worst case, this could lead to a serious impediment to securing product safety.

$\phi 6.35$, $\phi 9.52$, $\phi 12.7$	Thickness 0.8 mm
$\phi 15.88$, $\phi 19.05$, $\phi 22.2$	Thickness 1.0 mm

- Do not use pipes thinner than those specified above.
- The thicknesses listed in the table above are based on Japanese standards. Use pipes with a maximum working pressure of 4.15 MPa [601 psig] or higher according to local standards.

Caution:

Follow the instructions below to prevent abrasive components contained in sandpaper and cutting tools from entering the refrigerant circuit because those components can cause failures of the compressor and valves.

- To deburr pipes, use a reamer or other deburring tools, not sandpaper.
- To cut pipes, use a pipe cutter, not a grinder or other tools that use abrasive materials.
- When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes.
- If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.

4. Installing the refrigerant piping

4.2. Selecting pipe size

Conversion formula

1/4 F	ø6.35 mm
3/8 F	ø9.52 mm
1/2 F	ø12.7 mm
5/8 F	ø15.88 mm
3/4 F	ø19.05 mm

4.2.1. Pipe size

A, B, C, D, E (Fig. 4-3, 4, 5)

	Liquid pipe	Gas pipe
PUMY-M200YKM	ø9.52 mm	ø19.05 mm

a, b, c-j (Fig. 4-3, 4, 5)

Indoor unit series	Model number	Liquid pipe		Gas pipe
CityMulti	10-50	a, b, c, d, e, f ≤ 30 m	ø6.35 mm	ø12.7 mm
		a, b, c, d, e, f > 30 m	ø9.52 mm *1	
M series or S series *3	63-200	ø9.52 mm		ø15.88 mm
	15-42	ø6.35 mm		ø9.52 mm
	50-60	ø6.35 mm		ø12.7 mm
	71-80	ø9.52 mm		ø15.88 mm
P series *3	35-60 *2	ø6.35 mm		ø12.7 mm
	71-100	ø9.52 mm		ø15.88 mm



*1 If the piping length after the first joint exceeds 30 m, use a pipe size of ø9.52 for the pipes of the system that exceeds 30 m.

*2 When using 35, 50 type indoor unit of P series, use the flare nut attached to the indoor unit.

Do not use the flare nut in the indoor unit accessory. If it is used, a gas leakage or even a pipe extraction may occur.

*3 If the pipe size of indoor unit is different, use a different-diameter joint.

4.2.2. Valve size of Branch box



(1) Valve size of Branch box for outdoor unit/other Branch box

Liquid pipe	ø9.52 mm
Gas pipe	ø15.88 mm

(2) Valve size of Branch box for indoor unit

4-branches model

Port A	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port B	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port C	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port D	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm

6-branches model

Port 1A	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port 1B	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port 1C	Liquid pipe	ø6.35 mm
	Gas pipe	ø12.7 mm
Port 2A	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port 2B	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
Port 2C	Liquid pipe	ø9.52 mm
	Gas pipe	ø15.88 mm

4.2.3. Different-diameter joint (optional parts)




Fig. 4-1



Fig. 4-2

Model name	Connected pipes diameter	Diameter A	Diameter B
	mm	mm	mm
PAC-SJ88RJ-E	ø9.52 → ø12.7	ø9.52	ø12.7
PAC-SK88RJ-E	ø12.7 → ø9.52	ø12.7	ø9.52
PAC-SK89RJ-E	ø12.7 → ø15.88	ø12.7	ø15.88
PAC-SJ87RJ-E	ø6.35 → ø9.52	ø6.35	ø9.52
PAC-SK90RJ-E	ø9.52 → ø15.88	ø9.52	ø15.88
PAC-SK87RJ-E	ø15.88 → ø19.05	ø15.88	ø19.05

4.2.4. Branch pipe (optional parts)

According to the connection method, you can choose the favorite one.

2-branch joint	CMY-Y62-G-E
4-branch header	CMY-Y64-G-E
8-branch header	CMY-Y68-G-E

2-branch pipe (Joint)

Model name	Connection method
MSDD-50AR2-E	flare
MSDD-50BR-E	brazing

■ Installation procedure (2 branches pipe (Joint))

Refer to the installation manuals of MSDD-50AR2-E and MSDD-50BR-E.

Model name	Connected pipes diameter	Outside Diameter A	Inside Diameter B
	mm	mm	mm
PAC-SG78RJB-E	ø9.52 → ø12.7	ø9.52	ø12.7
PAC-SG77RJB-E	ø6.35 → ø9.52	ø6.35	ø9.52
PAC-SG76RJB-E	ø9.52 → ø15.88	ø9.52	ø15.88
PAC-SK91RJ-E	ø9.52 → ø6.35	ø9.52	ø6.35
PAC-SK82RJ-E	ø15.88 → ø9.52	ø15.88	ø9.52
PAC-SK85RJ-E	ø15.88 → ø12.7	ø15.88	ø12.7
PAC-SG79RJB-E	ø12.7 → ø9.52	ø12.7	ø9.52
PAC-SG80RJB-E	ø12.7 → ø15.88	ø12.7	ø15.88
PAC-SJ72RJB-E	ø15.88 → ø19.05	ø15.88	ø19.05

4. Installing the refrigerant piping

4.3. Pipe length and height difference

4.3.1. Connection without Branch box (Fig. 4-3)




Fig. 4-3 (a)

Permissible length (one-way)	Total piping length	$A+B+C+D+a+b+c+d+e \leq 150 \text{ m}$
	Farthest piping length (L)	$L = A+B+C+D+e \leq 80 \text{ m}$
	Farthest piping length after the first branch (l)	$l = B+C+D+e \leq 50 \text{ m}$
Permissible height difference (one-way)	In indoor/outdoor section (H)	$H \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
	In each indoor unit (h)	$h \leq 15 \text{ m}$





Fig. 4-3 (b)

Permissible length (one-way)	Total piping length	$A+a+b+c+d+e+f \leq 150 \text{ m}$
	Farthest piping length (L)	$L = A+f \leq 80 \text{ m}, l = f \leq 50 \text{ m}$
	Farthest piping length after the first branch (l)	$l = B+C+D+e \leq 50 \text{ m}$
Permissible height difference (one-way)	In indoor/outdoor section (H)	$H \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
	In each indoor unit (h)	$h \leq 15 \text{ m}$



Permissible length (one-way)	Total piping length	$A+B+C+a+b+c+d+e \leq 150 \text{ m}$
	Farthest piping length (L)	$L = A+B+b \leq 80 \text{ m}$
	Farthest piping length after the first branch (l)	$B+b \leq 50 \text{ m}$
Permissible height difference (one-way)	In indoor/outdoor section (H)	$H \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
	In each indoor unit (h)	$h \leq 15 \text{ m}$

Fig. 4-3 (c)

4. Installing the refrigerant piping

4.3.2. Connection with Branch box (Fig. 4-4)

- This unit has flared connections on each indoor unit and Branch box and outdoor unit sides.
- Remove the valve cover of the outdoor unit, then connect the pipe.




Fig. 4-4

en	Permissible length (one-way)	Total piping length	$A + B + C + a + b + c + d + e + f + g + h \leq 150 \text{ m}$
		Farthest piping length (L)	$A + C + h \leq 80 \text{ m}$
		Piping length between outdoor unit and Branch boxes	$A + B + C \leq 55 \text{ m}$
		Farthest Branch box from the first joint	$C \leq 50 \text{ m}$
		Farthest piping length after Branch box (r)	$h \leq 25 \text{ m}$
		Total piping length between Branch boxes and indoor units	$a + b + c + d + e + f + g + h \leq 95 \text{ m}$
	Permissible height difference (one-way)	In indoor/outdoor section (H1)	$H1, H2 \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
		Branch box/outdoor unit section (H2)	$H1, H2 \leq 40 \text{ m}$ (In the case of outdoor unit is set lower than indoor unit)
		In Branch box/indoor unit section (h1)	$h1 + h2 \leq 15 \text{ m}$
		In each branch unit (h2)	$h2 \leq 15 \text{ m}$
		In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
	Number of bends	When using a branch joint	$ A + B + a , A + B + b , A + B + c , A + B + d , A + B + e , A + C + f , A + C + g , A + C + h \leq 15$
		When not using a branch joint	$ A + a , A + b , A + c , A + d , A + C + e , A + C + f , A + C + g , A + C + h \leq 15$

4. Installing the refrigerant piping

4.3.3. Mixed system (City Multi indoor units and M, S, P series indoor units via Branch box) (Fig. 4-5)

1. In case of using one Branch box




Fig. 4-5 (a)

Permissible length (One-way)	Total piping length	$A + B + C + D + E + a + b + c + d + e + f + g + h + i + j \leq 150 \text{ m}$
	Farthest piping length (L1)	$A + E + a \text{ or } A + B + C + e \leq 80 \text{ m}$
	Farthest piping length. Via Branch box (L2)	$A + B + C + D + j \leq 80 \text{ m}$
	Piping length between outdoor unit and Branch box	$A + B + C + D \leq 55 \text{ m}$
	Farthest piping length from the first joint	$B + C + D \text{ or } B + C + e \leq 50 \text{ m}$
	Farthest piping length after Branch box	$j \leq 25 \text{ m}$
	Total piping length between Branch boxes and indoor units	$f + g + h + i + j \leq 95 \text{ m}$
Permissible height difference (One-way)	In indoor/outdoor section (H1)	$H1, H2 \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
	Branch box/outdoor unit section (H2)	$H1, H2 \leq 40 \text{ m}$ (In the case of outdoor unit is set lower than indoor unit)
	In Branch box/indoor unit section (h1)	$h1 \leq 15 \text{ m}$
	In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
Number of bends	$ A + E + a , A + E + b , A + E + c , A + B + d , A + B + C + e ,$ $ A + B + C + D + f , A + B + C + D + g , A + B + C + D + h ,$ $ A + B + C + D + i , A + B + C + D + j \leq 15$	

2. In case of using two Branch boxes




Fig. 4-5 (b)

Permissible length (One-way)	Total piping length	$A + B + C + D + E + a + b + c + d + e + f + g + h + i + j + k \leq 150 \text{ m}$
	Farthest piping length (L1)	$A + E + a \leq 80 \text{ m}$
	Farthest piping length. Via Branch box (L2)	$A + B + C + k \leq 80 \text{ m}$
	Piping length between outdoor unit and Branch boxes	$A + B + C + D \leq 55 \text{ m}$
	Farthest piping length from the first joint	$B + C \text{ or } E + a \leq 50 \text{ m}$
	Farthest piping length after Branch box	$k \leq 25 \text{ m}$
	Farthest Branch box from outdoor unit	$A + B + C \leq 55 \text{ m}$
Permissible height difference (One-way)	Total piping length between Branch boxes and indoor units	$d + e + f + g + h + i + j + k \leq 95 \text{ m}$
	In indoor/outdoor section (H1)	$H1, H2 \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
	Branch box/outdoor unit section (H2)	$H1, H2 \leq 40 \text{ m}$ (In the case of outdoor unit is set lower than indoor unit)
	In Branch box/indoor unit section (h1+h2)	$h1 + h2 \leq 15 \text{ m}$
	In each branch unit (h1)	$h2 \leq 15 \text{ m}$
Number of bends	In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
	$ A + E + a , A + E + b , A + E + c , A + B + D + d , A + B + D + e , A + B + D + f ,$ $ A + B + D + g , A + B + D + h , A + B + C + i , A + B + C + j , A + B + C + k \leq 15$	

4. Installing the refrigerant piping




Fig. 4-6

A (Fig. 4-6)

Copper pipe O.D. (mm)	Flare dimensions øA dimensions (mm)
ø6.35	8.7 - 9.1
ø9.52	12.8 - 13.2
ø12.7	16.2 - 16.6
ø15.88	19.3 - 19.7
ø19.05	23.6 - 24.0

D (Fig. 4-6)

Copper pipe O.D. (mm)	Flare nut O.D. (mm)	Tightening torque (N·m)
ø6.35	17	14 - 18
ø6.35	22	34 - 42
ø9.52	22	34 - 42
ø12.7	26	49 - 61
ø12.7	29	68 - 82
ø15.88	29	68 - 82
ø15.88	36	100 - 120
ø19.05	36	100 - 120




Fig. 4-7

4.4. Connecting pipes (Fig. 4-6)

- Conduct sufficient anti-condensation and insulation work to prevent water dripping from the refrigerant piping. (liquid pipe/gas pipe)
- Increase insulation depending on the environment where the refrigerant piping is installed, or condensation may occur on the surface of the insulation material. (Insulation material Heat-resistant temperature: 120 °C, Thickness: 15 mm or more)
 - * When the refrigerant piping is used in locations subject to high temperature and humidity such as in the attic, further addition of insulation may be required.
- To insulate the refrigerant piping, apply heat-resistant polyethylene foam between the indoor unit and insulation material as well as to the net between the insulation material filling all gaps. (Condensation forming on the piping may result in condensation in the room or burns when contacting the piping.)
- The indoor parts of the drain pipe should be wrapped with polyethylene foam insulation materials (specific gravity of 0.03, thickness of 9 mm or more).
- Apply thin layer of refrigerant oil to pipe and joint seating surface before tightening flare nut. ①
- Apply refrigerating machine oil over the entire flare seat surface. ②
- Use the flare nuts for the following pipe size. ③
- For connection, first align the center, then tighten the first 3 to 4 turns of flare nut by hand.
- Use 2 wrenches to tighten piping connections. ④
- Use leak detector or soapy water to check for gas leaks after connections are completed.
- When bending the pipes, be careful not to break them. Bend radius of 100 mm to 150 mm is sufficient.
- Make sure the pipes do not contact the compressor. Abnormal noise or vibration may result.

1 Pipes must be connected starting from the indoor unit.

Flare nuts must be tightened with a torque wrench.

2 Flare the liquid pipes and gas pipes and apply a thin layer of refrigeration oil (Applied on site).

• When usual pipe sealing is used, refer to Table 4 for flaring of R32 refrigerant pipes. The size adjustment gauge can be used to confirm A measurements.

⚠ Warning:

When installing the unit, securely connect the refrigerant pipes before starting the compressor.

Table 4 (Fig. 4-7)

Copper pipe O.D. (mm)	A (mm)	
	Flare tool for R32	Flare tool for R22-R407C
	Clutch type	
ø6.35	0 - 0.5	1.0 - 1.5
ø9.52	0 - 0.5	1.0 - 1.5
ø12.7	0 - 0.5	1.0 - 1.5
ø15.88	0 - 0.5	1.0 - 1.5
ø19.05	0 - 0.5	1.0 - 1.5

4. Installing the refrigerant piping




Fig. 4-8




Fig. 4-9

4.5. Refrigerant piping (Fig. 4-8)

Remove the service panel ① (three screws) and the front piping cover ② (two screws) and rear piping cover ③ (five screws).

- 1 Perform refrigerant piping connections for the indoor/outdoor unit when the outdoor unit's stop valve is completely closed.
- 2 Vacuum-evacuate air from the indoor unit and the connection piping.
- 3 After connecting the refrigerant pipes, check the connected pipes and the indoor unit for gas leaks. (Refer to 4.6. Refrigerant pipe airtight testing method)
- 4 Vacuumize the refrigerant lines through the service port of the liquid and gas stop valves. And then open the stop valves completely (for both the liquid and gas stop valves). The outdoor unit has the shut-off valve, so the refrigerant line of the indoor and outdoor units are not connected until the air conditioner operates after being energized.
 - If the stop valves are left closed and the unit is operated, the compressor and control valves will be damaged.
 - Use a leak detector or soapy water to check for gas leaks at the pipe connection sections of the outdoor unit.
 - Do not use the refrigerant from the unit to evacuate air from the refrigerant lines.
 - After the valve work is completed, tighten the valve caps to the correct torque: 20 to 25 N·m (200 to 250 kgf·cm). Failure to replace and tighten the caps may result in refrigerant leakage. In addition, do not damage the insides of the valve caps as they act as a seal to prevent refrigerant leakage.
- 5 Use sealant to seal the ends of the thermal insulation around the pipe connection sections to prevent water from entering the thermal insulation.

4.6. Refrigerant pipe airtight testing method

- (1) Connect the testing tools.
 - Make sure the stop valves ① ② are closed and do not open them.
 - Add pressure to the refrigerant lines through the service port ③ of the liquid stop valve ① and the gas stop valve ②.
- (2) Do not add pressure to the specified pressure all at once; add pressure little by little.
 - 1 Pressurize to 0.5 MPa (5 kgf/cm²G), wait five minutes, and make sure the pressure does not decrease.
 - 2 Pressurize to 1.5 MPa (15 kgf/cm²G), wait five minutes, and make sure the pressure does not decrease.
 - 3 Pressurize to 4.15 MPa (41.5 kgf/cm²G) and measure the surrounding temperature and refrigerant pressure.
- (3) If the specified pressure holds for about one day and does not decrease, the pipes have passed the test and there are no leaks.
 - If the surrounding temperature changes by 1°C, the pressure will change by about 0.01 MPa (0.1 kgf/cm²G). Make the necessary corrections.
- (4) If the pressure decreases in steps (2) or (3), there is a gas leak. Look for the source of the gas leak.

⚠ Caution:

If an airtightness test was performed on the outdoor unit when it was relocated, vacuumize the refrigerant lines with the stop valves opened through both the check valves and the service ports.

en

4. Installing the refrigerant piping




Fig. 4-10




Fig. 4-11




Fig. 4-12

- * The figure to the left is an example only. The stop valve shape, service port position, etc., may vary according to the model.
- * Turn section ① only.
(Do not further tighten sections ① and ② together.)

③ Charge hose
④ Service port

4.7. Stop valve opening method

- The stop valve opening method varies according to the outdoor unit model. Use the appropriate method to open the stop valves.

(1) Gas side (Fig. 4-10)

- Remove the cap, pull the handle toward you and rotate 1/4 turn in a counterclockwise direction to open.

- Make sure that the stop valve is open completely, push in the handle and rotate the cap back to its original position.

(2) Liquid side (Fig. 4-11)

- Remove the cap and turn the valve rod counterclockwise as far as it will go with the use of a 4 mm hexagonal wrench. Stop turning when it hits the stopper. (ø9.52: Approximately 10 revolutions)

- Make sure that the stop valve is open completely and rotate the cap back to its original position.

① Valve body	⑥ Completely closed
② Unit side	⑦ Completely open
③ Service port	⑧ Refrigerant piping side (On-site installation)
④ Handle	⑨ Direction the refrigerant flows in
⑤ Cap	⑩ Valve stem

Refrigerant pipes are protectively wrapped

- The pipes can be protectively wrapped up to a diameter of ø90 before or after connecting the pipes. Cut out the knockout in the pipe cover following the groove and wrap the pipes.

Pipe inlet gap

- Use putty or sealant to seal the pipe inlet around the pipes so that no gaps remain. (If the gaps are not closed, noise may be emitted or water and dust will enter the unit and breakdown may result.)

Precautions when using the charge valve (Fig. 4-12)

Do not tighten the service port too much when installing it, otherwise, the valve core could be deformed and become loose, causing a gas leak.

After positioning section ② in the desired direction, turn section A only and tighten it. Do not further tighten sections ① and ② together after tightening section ①.

⚠ Warning:

- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

4. Installing the refrigerant piping

4.8. Additional refrigerant charge

Additional refrigerant charge

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

* When the unit is stopped, charge the unit with the additional refrigerant through the liquid stop valve after the pipe extensions and indoor units have been vacuumized.

When the unit is operating, add refrigerant to the gas check valve using a safety charger. Do not add liquid refrigerant directly to the check valve.

Calculation of additional refrigerant charge

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the below, and charge with the additional refrigerant.
- For amounts less than 0.1 kg, round up the calculated additional refrigerant charge.
(For example, if the calculated charge is 6.01 kg, round up the charge to 6.1 kg.)
- The amount of additional refrigerant which is calculated from the total capacity of indoor units and the combination of extended pipes must not be over 9.4 kg.

<Additional charge>

Calculation of refrigerant charge

Pipe size Liquid pipe ø6.35 (m) × 0.019(kg/m)	+	Pipe size Liquid pipe ø9.52 (m) × 0.051(kg/m)	+	Pipe size Liquid pipe ø12.7 (m) × 0.101(kg/m)	+	Total capacity of connected indoor units	Amount for the indoor units
						– 20.8 kW	3.2 kg
						20.9 – 28.0 kW	3.9 kg
						28.1 kW –	4.3 kg

Included refrigerant amount when shipped from the factory

Included refrigerant amount
3.0 kg

<Example>

Outdoor model: M200

Indoor 1: MS63 (7.1 kW)

2: MS40 (4.5 kW)

3: MS25 (2.8 kW)

4: MS20 (2.2 kW)

5: MS50 (5.6 kW)

A: ø12.7 35 m

a: ø9.52 15 m

b: ø6.35 10 m

c: ø6.35 10 m

d: ø6.35 30 m

e: ø6.35 10 m

At the conditions
below:

The total length of each liquid line is as follows:

ø12.7: A = 30 m

ø9.52: a = 15 m

ø6.35: b + c + d + e = 10 + 10 + 30 + 10 = 60 m

The total capacity of connected indoor units is as follows:

7.1 + 4.5 + 2.8 + 2.2 + 5.6 = 22.2

<Calculation example>

Additional refrigerant charge


$60 \times 0.019 + 15 \times 0.051 + 35 \times 0.101 + 3.9 = 9.4$ kg (rounded up)

- Do not vent R32 into the atmosphere:
R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP)=675.
- Make sure to indicate the followings with ineffaceable ink on the designated label / spec label.
 - On site additionally charge amount (kg)
 - Tonne of CO₂ equivalent (additionally charge amount)
 - Total refrigerant amount (1)+(3)
 - Total tonne of CO₂ equivalent (2)+(4)

- (1) Pre charge refrigerant amount (kg)

- (2) Tonne of CO₂ equivalent (Pre charge)

It is already written on the label and varies depending on the model.



□ Weight

▢ Tonne of CO₂ equivalent

▣ GWP

	□ kg	▢ = □ × ▣ / 1000
①	3.0	2.03
②		
③ = ① + ②		

5. Drainage piping work

Outdoor unit drainage pipe connection

When drain piping is necessary, use the drain socket or the drain pan (option).

Drain socket	PAC-SG61DS-E
Drain pan	PAC-SH97DP-E

6. Electrical work

6.1. Caution

- Follow ordinance of your governmental organization for technical standard related to electrical equipment, wiring regulations and guidance of each electric power company.
- Use self-extinguishing distribution cables for power supply wiring.
- Wiring for control (hereinafter referred to as transmission line) shall be (5 cm or more) apart from power source wiring so that it is not influenced by electric noise from power source wiring. (Do not insert transmission line and power source wire in the same conduit.)
- Be sure to provide designated grounding work to outdoor unit.
- Give some allowance to wiring for electrical part box of indoor and outdoor units, because the box is sometimes removed at the time of service work.
- Never connect the main power source to terminal block of transmission line. If connected, electrical parts will be burnt out.
- Use 2-core shield cable for transmission line. If transmission lines of different systems are wired with the same multicore cable, the resultant poor transmitting and receiving will cause erroneous operations.
- Only the transmission line specified should be connected to the terminal block for outdoor unit transmission.
(Transmission line to be connected with indoor unit : Terminal block TB3 for transmission line, Other : Terminal block TB7 for centralized control)
Erroneous connection does not allow the system to operate.

- In case to connect with the upper class controller or to conduct group operation in different refrigerant systems, the control line for transmission is required between the outdoor units each other.
Connect this control line between the terminal blocks for centralized control. (2-wire line with no polarity)
When conducting group operation in different refrigerant systems without connecting to the upper class controller, replace the insertion of the short circuit connector from CN41 of one outdoor unit to CN40.
- Group is set by operating the remote controller.
- Power on the indoor units and the Branch box side first, then the outdoor side.
- Make sure that the transmission line and power supply wiring do not contact the coil of the shut-off valve. The insulation of the wiring may tear.




Fig. 6-1

6.2. Control box and connecting position of wiring (Fig. 6-1)

- Connect the wiring between the outdoor unit and the indoor unit, interface kit or Branch box to the transmission terminal block (TB3) of the outdoor unit.
Connect the wiring between the outdoor unit and the centralized control system to the transmission terminal block (TB7) of the outdoor unit.
Connect the ground of the shielded wiring to the shield terminal (S) of the terminal block (TB3) or (TB7).
If the connection of the outdoor unit's transmission power supply connector has been changed from CN41 to CN40, connect the shield terminal (S) of the terminal block (TB7) to the screw (F) using the included lead wire.
* The shield (S) terminal of the transmission terminal block (TB3) is connected to the ground (E) when the unit is shipped from the factory.
- The terminal (B1) and (B2) on the terminal block (TB1B or TB1) is for supplying power to the Branch box (220 – 240 VAC).
- Remove the knock-out pieces from the piping cover, pass the power supply and transmission wires through the appropriate knock-out holes, and connect the wires to the terminal block.
- Fix power source wiring to terminal box by using buffer bushing for tensile force (PG connection or the like).

⚠ Caution:

Never connect the transmission line for the indoor unit or the centralized control system transmission line to this terminal block (TB1). If the transmission lines are connected, the indoor unit terminal block or centralized control terminal block could be damaged.

6.3. Wiring transmission cables

1 Types of control cables

1. Wiring transmission cables

Types of transmission cables	Shielding wire CVVS, CPEVS or MVVS
Cable diameter	More than 1.25 mm ²
Maximum wiring length	Within 200 m

2. M-NET Remote control cables

Types of remote control cables	Shielding wire CVVS, CPEVS or MVVS
Cable diameter	0.5 to 1.25 mm ²
Remarks	When 10 m is exceeded, use cable with the same specifications as transmission line wiring cables.

3. MA Remote control cable

Type of remote control cable	Sheathed 2-core cable (unshielded) CVV
Cable diameter	0.3 to 1.25 mm ² *
Remarks	Within 200 m *

* Cable diameter and length may differ depending on the remote controller. Refer to installation manual of each remote controller for details.

2 Wiring examples

- Controller name, symbol and allowable number of controllers.

Name	Symbol	Allowable number of controllers
Outdoor unit controller	OC	–
Indoor unit controller	CITY MULTI series	1 to 12 units per 1 OC *1
	M, S, P series	2 to 8 units per 1 OC *1
Branch box	BC	0 to 2 units per 1 OC *1
Remote controller	M-NET	M-NET RC *2
	MA	MA-RC
	Wireless	WL-RC

Note:

- The number of connectable units may be limited by some conditions such as an indoor unit's capacity or each unit's equivalent power consumption.
- Don't use the Lossnay controller (PZ-61DR-E, PZ-43SMF-E, PZ-52SF-E, PZ-60DR-E).

<Wiring Method and Address Setting: include Branch box system>
Please refer to the Branch box Installation Manual.

6. Electrical work


6.4. System control

Example of an M-NET remote controller system (Address setting is necessary.)

<Example for wiring control cables, wiring method and address setting, permissible lengths, and the constraint items are listed in the standard system with detailed explanation.>

Example for the standard operation

■ Example of wiring transmission cables



1 M-NET remote controller for each CITY MULTI series indoor unit
There is no need for setting the hundreds digit on the M-NET remote controller.

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.

For the system including the CITY MULTI indoor unit with refrigerant sensor, M-NET remote controller (M-NET RC) cannot be used.

■ Wiring Method and Address Settings

- Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
- Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
- Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block on M-NET the remote controller (M-NET RC).
- Set the address setting switch (on P.C.B) as shown below.


Unit	Range	Setting Method
M-IC	001 to 050	—
OC	051 to 100	Use the smallest address of all the indoor unit plus 50. * The address automatically becomes "100" if it is set as "01-50".
M-NET RC	101 to 150	Indoor unit address plus 100

- If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

- Indoor/Outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
- M-NET Remote controller cable length:
 $l1, l2 \leq 10 \text{ m}$ (0.5 to 1.25 mm²)
If the length exceeds 10 m, use a 1.25 mm² shielded wire. The section of the cable that exceeds 10 m must be included in the maximum length via outdoor units and maximum transmission cable length.

■ Constraint items



*1. M-NET remote controller (M-NET RC) and MA remote controller (MA RC) cannot be used together.


*2. Do not connect anything with TB15 of CITY MULTI series indoor unit (M-IC).

en

6. Electrical work

Example for the operation using 2 M-NET remote controllers

■ Example of wiring Transmission cables



Using 2 M-NET remote controllers for each CITY MULTI series indoor unit.

Note:
Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.
For the system including the CITY MULTI indoor unit with refrigerant sensor, M-NET remote controller (M-NET RC) cannot be used.

■ Wiring Method and Address Settings

- 1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
- 2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
- 3. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block on M-NET the remote controller (M-NET RC).
- 4. Set the address setting switch (on P.C.B) as shown below.

Unit	Range	Setting Method
M-IC	001 to 050	—
OC	051 to 100	Use the smallest address of all the indoor units plus 50. * The address automatically becomes "100" if it is set as "01-50".
M-NET RC (Main)	101 to 150	Indoor unit address plus 100
M-NET RC (Sub)	151 to 200	Indoor unit address plus 150


- 5. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

- 1. Indoor/Outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
- 2. M-NET Remote controller cable length:
 $l1 + l2 \leq 10 \text{ m}$ (0.5 to 1.25 mm²)

If the length exceeds 10 m, use a 1.25 mm² shielded wire. The section of the cable that exceeds 10 m must be included in the maximum length via outdoor units and maximum transmission cable length.

■ Constraint items




*1. Use the CITY MULTI series indoor unit (M-IC) address plus 150 as the sub M-NET remote controller address. In this case, it should be 152.
*2. 3 or more M-NET remote controllers (M-NET RC) cannot be connected to 1 CITY MULTI series indoor unit.

6. Electrical work

Example for the group operation

■ Example of wiring transmission cables



Multiple CITY MULTI series indoor units operated together by 1 M-NET remote controller.

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.

For the system including the CITY MULTI indoor unit with refrigerant sensor, M-NET remote controller (M-NET RC) cannot be used.

■ Wiring Method and Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
3. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the M-IC main unit with the most recent address within the same CITY MULTI series indoor unit (M-IC) group to terminal block on the M-NET remote controller.
4. Set the address setting switch (on P.C.B) as shown below.


Unit	Range	Setting Method
M-IC (Main)	001 to 050	Use the smallest address within the same group of CITY MULTI series indoor units.
M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).
OC	051 to 100	Use the smallest address of all the CITY MULTI series indoor units plus 50. * The address automatically becomes "100" if it is set as "01-50".
M-NET RC	101 to 150	Set at an M-IC (Main) address within the same group plus 100.

5. Use the CITY MULTI series indoor unit (M-IC) within the group with the most functions as the M-IC (Main) unit.
6. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

Same as that of standard operation

■ Constraint items




*1. The M-NET remote controller address is the CITY MULTI series indoor unit main address plus 100. In this case, it should be 101.

6. Electrical work

Example of a group operation system with 2 or more outdoor units and an M-NET remote controller.
(Address settings are necessary.)

■ Examples of wiring transmission cables



Note:
For the system including the CITY MULTI indoor unit with refrigerant sensor, M-NET remote controller (M-NET RC) cannot be used.

■ Wiring Method and Address Settings

- Always use shielded wire when making connections between the outdoor unit (OC) and the CITY MULTI series indoor unit (M-IC), as well as all OC-OC, and IC-IC wiring.
- Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC).
- Connect terminals M1 and M2 on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC) that has the most recent address within the same group to the terminal block on the M-NET remote controller (M-NET RC).
- Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
- Set the address setting switch as follows.

Unit	Range	Setting Method
M-IC (Main)	01 to 50	Use the smallest address within the same group of CITY MULTI series indoor units.
M-IC (Sub)	01 to 50	Use an address, other than the M-IC (Main) in the same group of CITY MULTI series indoor units. This must be in sequence with the M-IC (Main).
OC	51 to 100	Use the smallest address of all the CITY MULTI series indoor units plus 50. * The address automatically becomes "100" if it is set as "01-50".
M-NET RC (Main)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
M-NET RC (Sub)	151 to 200	Set at an M-IC (Main) address within the same group plus 150.
MA-RC	-	Address setting is not necessary. (Main/sub setting is necessary.)

- The group setting operations among the multiple CITY MULTI series indoor units are done by the M-NET remote controller (M-NET RC) after the electrical power has been turned on.
- When the system controller is connected to the system, set SW5-1 on all outdoor units to ON.
Also, set the power supply switching connectors (CN40, CN41) as follows.

Refrigerant system	Connection with system controller	Transmission line power supply unit	Group operation in different refrigerant systems	Power supply switching connector settings
Single refrigerant	—	—	—	Remains CN41 (default setting)
Multiple refrigerants	No	—	No	For one outdoor unit only, switch the power supply switching connector (CN41) to (CN40). * Short-circuit the S (shield) terminal and the ground terminal () of the terminal block (TB7) of one outdoor unit switched to CN40.
	Connection with indoor/outdoor transmission line	Not required	Yes/No	
	Connection with central control system transmission line	Required	Yes/No	Remains CN41 (default setting)


- If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

6. Electrical work

■ Permissible Lengths

- Maximum line length via outdoor unit:
 $L1+L2+L3+L4, L3+L4+L5+L6, L1+L2+L5+L6 \leq 500$ m (1.25 mm² or more)
- Indoor/outdoor transmission line Maximum length:
 $L1, L3+L4, L2+L5, L6 \leq 200$ m (1.25 mm² or more)
- M-NET Remote controller cable length:
 $\ell1, \ell2 + \ell3 \leq 10$ m (0.5 to 1.25 mm²)
 If the length exceeds 10 m, use a 1.25 mm² shielded wire.
 The section of the cable that exceeds 10 m must be included in the maximum length via outdoor units and maximum transmission cable length.

■ Constraint items



Set all addresses to ensure that they are not overlapped.

M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.

- *1. Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor units (M-IC) that have been connected to different outdoor units (OC).
- *2. If connected power supply unit, the earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit with the earth.


6. Electrical work

Example of an MA remote controller system (Address setting is not necessary.)

<In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit.>

Example for the standard operation

■ Example of wiring transmission cables



1 MA remote controller for each indoor unit

en

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible. For the system including the CITY MULTI indoor unit with refrigerant sensor, address settings are necessary.


■ Wiring Method and Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
3. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).
4. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

1. Indoor/outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
2. MA remote controller cable length:
 $l1, l2 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items




*1. The MA remote controller and the M-NET remote controller cannot be used together with the CITY MULTI series indoor unit of the same group.

6. Electrical work

Example for the operation using 2 remote controllers

■ Example of wiring transmission cables



Using 2 MA remote controllers for each CITY MULTI series indoor unit.

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.
For the system including the CITY MULTI indoor unit with refrigerant sensor, address settings are necessary.


■ Wiring Method and Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
3. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).
4. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 MA remote controllers.
 - Set either one of the MA remote controllers to "sub remote controller".
 - Refer to the installation manual of MA remote controller.
5. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

1. Indoor/outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
2. MA remote controller cable length:
 $\ell3 + \ell4, \ell5 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items



- *1. 3 MA remote controllers or more cannot be connected with the CITY MULTI series indoor unit of the same group.

en


6. Electrical work

Example for the group operation

Note:

The CITY MULTI indoor unit with refrigerant sensor cannot be included in the group.

■ Example of wiring transmission cables



Multiple indoor units operated together by 1 MA remote controller.

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.

For the system including the CITY MULTI indoor unit with refrigerant sensor, address settings are necessary.


■ Wiring Method and Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
3. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).
4. In the case of group operation using MA remote controller (MA-RC), connect terminals 1 and 2 on transmission cable terminal block (TB15) of each CITY MULTI series indoor unit. Use non-polarized 2-core wire.
5. In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit. Please set the smallest address within number 01–50 of the CITY MULTI series indoor unit with the most functions in the same group.
6. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

1. Indoor/outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
2. MA remote controller cable length:
 $l6 + l7 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items




- *1. The second MA remote controller is connected with the terminal block (TB15) for the MA remote controller of the same CITY MULTI series indoor unit (M-IC) as the first MA remote control.

6. Electrical work

Example for the operation using Supervisor Remote Controller mode (Address settings are necessary.)

■ Example of wiring transmission cables



Using 2 MA remote controllers with alarm for CITY MULTI series indoor unit.

Note:

Combinations of standard operation, operation using 2 M-NET remote controllers, and group operation are possible.


■ Wiring Method and Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the indoor unit (M-IC).
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on transmission cable terminal block (TB3) for the outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of each CITY MULTI series indoor unit (M-IC). Use nonpolarized 2-core wire.
3. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).
4. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 MA remote controllers.
 - Set either one of the MA remote controllers to "Supervisor Remote Controller".
 - Refer to the installation manual of MA remote controller.
5. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

■ Permissible Lengths

1. Indoor/outdoor transmission line Maximum length:
 $L1 + L2 \leq 200 \text{ m}$ (1.25 mm² or more)
2. MA remote controller cable length:
 $l8, l9 \leq 100 \text{ m}$, $l10 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items




*1. 3 MA remote controllers or more cannot be connected with the CITY MULTI series indoor unit of the same group.

6. Electrical work

Example of a group operation with 2 or more outdoor units and MA remote controllers. (Address settings are necessary.)

■ Examples of wiring transmission cables



■ Wiring Method Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the CITY MULTI series indoor unit (M-IC), as well for all OC-OC, and IC-IC wiring.
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block of the CITY MULTI series indoor unit (M-IC).
3. Connect terminals 1 and 2 on the terminal block for MA remote controller line (TB15) on the indoor unit (M-IC) to the terminal block on the MA remote controller (MA-RC). (Nonpolarized two-wire)
4. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
5. Set the address setting switch as follows.

Unit	Range	Setting Method
M-IC (Main)	01 to 50	Use the smallest address within the same group of indoor units.
M-IC (Sub)	01 to 50	Use an address, other than the M-IC (Main) in the same group of M-NET indoor units. This must be in sequence with the M-IC (Main).
OC	51 to 100	Use the smallest address of all the indoor units plus 50. * The address automatically becomes "100" if it is set as "01-50".
M-NET RC (Main)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
M-NET RC (Sub)	151 to 200	Set at an M-IC (Main) address within the same group plus 150.
MA-RC	-	Address setting is not necessary. (Main/sub setting is necessary.)

6. When the system controller is connected to the system, set SW5-1 on all outdoor units to ON.
Also, set the power supply switching connectors (CN40, CN41) as follows.

Refrigerant system	Connection with system controller	Transmission line power supply unit	Group operation in different refrigerant systems	Power supply switching connector settings
Single refrigerant	—	—	—	Remains CN41 (default setting)
Multiple refrigerants	No	—	No	For one outdoor unit only, switch the power supply switching connector (CN41) to (CN40). * Short-circuit the S (shield) terminal and the ground terminal (⏏) of the terminal block (TB7) of one outdoor unit switched to CN40.
			Yes	
	Connection with indoor/outdoor transmission line	Not required	Yes/No	Remains CN41 (default setting)
	Connection with central control system transmission line	Required	Yes/No	


7. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

6. Electrical work

■ Permissible Lengths

1. Maximum line length via outdoor unit (M-NET cable):
 $L1+L2+L3+L4, L3+L4+L5+L6, L1+L2+L5+L6 \leq 500 \text{ m}$ (1.25 mm² or more)
2. Indoor/outdoor transmission line Maximum length (M-NET cable):
 $L1 \text{ and } L3+L4 \text{ and } L2+L5 \text{ and } L6 \leq 200 \text{ m}$ (1.25 mm² or more)
3. MA Remote controller cable length:
 $m1 \text{ and } m1+m2+m3 \text{ and } m1+m2+m3+m4 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items




M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.

- *1. Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor units (M-IC) that have been connected to different outdoor units (OC).
- *2. If connected Power Supply Unit, the earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit with the earth.


6. Electrical work

Example of a system using Branch box and A-Control indoor unit

■ Examples of wiring transmission cables



■ Example of SENSOR AND ALARM KIT Wiring



6. Electrical work

■ Wiring Method Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC) and the Branch box, as well for all OC-OC and BC-BC wiring.
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1, M2 and S on the terminal S on the transmission cable terminal block (TB5) of the Branch box.
3. Connect terminals 1 and 2 on the transmission cable terminal block (TB5/TB15) of the A-control indoor unit (A-IC), to the terminal block on the MA remote controller (MA-RC).
4. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
5. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit to the earth.
6. Set the address setting switch as follows.

Unit	Range	Setting Method
A-IC	01 to 50	According to the set address of connected Branch box, set the A-IC addresses sequentially by SW1 on Branch box. (For example, when setting the Branch box address to 01, A-IC addresses set 01, 02, 03 and 04.)
Branch box	01 to 50	Use a number within the range 1–50, but it should not make the highest address of connected A-IC exceed 50.
OC	51 to 100	Use the smallest address of all the Branch box plus 50. * The address automatically becomes "100" if it is set as "01–50".
MA-RC	-	Address setting is not necessary.

7. When the system controller is connected to the system, set SW5-1 on all outdoor units to ON.
Also, set the power supply switching connectors (CN40, CN41) as follows.

Refrigerant system	Connection with system controller	Transmission line power supply unit	Group operation in different refrigerant systems	Power supply switching connector settings
Single refrigerant	–	–	–	Remains CN41 (default setting)
Multiple refrigerants	No	–	No	
	Connection with indoor/outdoor transmission line	Not required	Yes	For one outdoor unit only, switch the power supply switching connector (CN41) to (CN40). * Short-circuit the S (shield) terminal and the ground terminal () of the terminal block (TB7) of one outdoor unit switched to CN40.
			Yes/No	
	Connection with central control system transmission line	Required	Yes/No	Remains CN41 (default setting)

8. If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.


■ Permissible Lengths

1. Maximum line length via outdoor unit (M-NET cable):
 $L1+L2+L3+L4+L5 \leq 500 \text{ m}$ (1.25 mm² or more)
2. Branch box/outdoor transmission line Maximum length (M-NET cable):
 $L1+L2, L3+L4, L5 \leq 200 \text{ m}$ (1.25 mm² or more)
3. Indoor/Branch box transmission line Maximum length (A-Control cable) :
 $L6 \leq 25 \text{ m}$ (1.5 mm²)
4. MA Remote controller cable length:
 $m1 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

en

6. Electrical work

■ Constraint items



Different refrigerant systems cannot be connected together.


*1. Plural indoor units cannot be operated by a single remote controller.

*2. M-NET remote controller cannot be connected.

6. Electrical work


Example of a system using Branch box, A-Control indoor unit, and CITY MULTI series indoor unit.

■ Examples of wiring transmission cables



6. Electrical work

■ Example of SENSOR AND ALARM KIT Wiring



■ Wiring Method Address Settings

- Always use shielded wire when making connections between the outdoor unit (OC) and the Branch box or CITY MULTI series indoor unit (M-IC), as well for all OC-OC, IC-IC, BC-BC and IC-BC wiring.
- Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of the Branch box or CITY MULTI series indoor unit (M-IC).
- Connect terminals 1 and 2 on the transmission cable terminal block (TB5/TB15) of the A-control indoor unit (A-IC) or CITY MULTI series indoor unit (M-IC), to the terminal block on the MA remote controller (MA-RC).
- Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
- The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit to the earth.
- Set the address setting switch as follows.

Unit	Range	Setting Method
M-IC	01 to 50	-
A-IC	01 to 50	According to the set address of connected Branch box, set the A-IC addresses sequentially by SW1, SW11, SW12 on Branch box. (For example, when the Branch box address is set to 01, set the A-IC addresses to 01, 02, 03 and 04.)
Branch box	01 to 50	Use a number within the range 1-50, but it should not make the highest address of connected A-IC exceed 50.
OC	51 to 100	Use the smallest address of all the Branch box plus 50. * The address automatically becomes "100" if it is set as "01-50".
MA-RC	-	Address setting is not necessary.

- When the system controller is connected to the system, set SW5-1 on all outdoor units to ON.
Also, set the power supply switching connectors (CN40, CN41) as follows.

Refrigerant system	Connection with system controller	Transmission line power supply unit	Group operation in different refrigerant systems	Power supply switching connector settings
Single refrigerant	-	-	-	Remains CN41 (default setting)
Multiple refrigerants	No	-	No	For one outdoor unit only, switch the power supply switching connector (CN41) to (CN40). * Short-circuit the S (shield) terminal and the ground terminal (⏏) of the terminal block (TB7) of one outdoor unit switched to CN40.
	No	-	Yes	
	Connection with indoor/outdoor transmission line	Not required	Yes/No	Remains CN41 (default setting)
	Connection with central control system transmission line	Required	Yes/No	


- If the interface kit is not connected, set SW5-7 on all outdoor units to OFF.

6. Electrical work

■ Permissible Lengths

- Maximum line length via outdoor unit (M-NET cable):
 $L1+L2+L3+L4+L5+L6+L7 \leq 500 \text{ m}$ (1.25 mm² or more)
- Indoor/Branch box/outdoor transmission line Maximum length (M-NET cable):
 $L1+L2+L3+L4, L5+L6 \text{ and } L7 \leq 200 \text{ m}$ (1.25 mm² or more)
- Indoor/Branch box transmission line Maximum length (A-Control cable):
 $L8 \leq 25 \text{ m}$ (1.5 mm²)
- Remote controller cable length:
 $m1 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)

■ Constraint items



Different refrigerant systems cannot be connected together.


*1. Plural indoor units cannot be operated by a single remote controller.

*2. M-NET remote controller cannot be connected.

6. Electrical work

Example of a system using Branch box and A-Control indoor unit with interface kit

■ Example of wiring transmission cables



■ Wiring Method Address Settings

1. Always use shielded wire when making connections between the outdoor unit (OC), Interface kit and the Branch box, as well as for all OC-OC, BC-BC, OC-IF and IF-BC wiring.
2. Use feed wiring to connect terminals M1, M2 and S (Connected to ground) on the transmission cable terminal block (TB3) of each outdoor unit (OC) to terminals M1, M2 and S on the transmission cable terminal block (TB5) of Interface kit. Also connect terminals M1, M2 and S on the transmission cable terminal block (TB3) of Interface Kit to terminals M1, M2 and S on the transmission cable terminal block (TB5) of Branch box.
3. Connect terminals 1 and 2 on the transmission cable terminal block (TB5/TB15) of the A-control indoor unit (A-IC) or CITY MULTI series indoor unit (M-IC), to the terminal block on the MA remote controller (MA-RC).
4. Connect together terminals M1, M2 and terminal S on the terminal block for centralized control (TB7) for the outdoor unit (OC).
5. The earth processing of S terminal for the centralized control terminal block (TB7) is unnecessary. Connect the terminal S on the power supply unit to the earth.
6. Set the address setting switch as follows.

Unit	Range	Setting Method
M-IC	01 to 50	-
A-IC	01 to 50	According to the set address of connected Branch box, set the A-IC addresses sequentially by SW1, SW11, SW12 on Branch box. (For example, when the Branch box address is set to 01, set the A-IC addresses to 01, 02, 03 and 04.)
Branch box	01 to 50	Use a number within the range 1-50, but it should not make the highest address of connected A-IC exceed 50.
OC	51 to 100	Use the smallest address of all the Branch box plus 50. * The address automatically becomes "100" if it is set as "01-50".
MA-RC	-	Address setting is not necessary.
Interface kit	151 to 200	Use a number within the range 151-200. (If it is set as "200", switch setting is "00")

6. Electrical work

7. When the system controller is connected to the system, set SW5-1 on all outdoor units to ON.
Also, set the power supply switching connectors (CN40, CN41) as follows.

Refrigerant system	Connection with system controller	Transmission line power supply unit	Group operation in different refrigerant systems	Power supply switching connector settings
Single refrigerant	—	—	—	Remains CN41 (default setting)
Multiple refrigerants	No	—	No	For one outdoor unit only, switch the power supply switching connector (CN41) to (CN40). * Short-circuit the S (shield) terminal and the ground terminal () of the terminal block (TB7) of one outdoor unit switched to CN40.
			Yes	
	Connection with indoor/outdoor transmission line	Not required	Yes/No	
	Connection with central control system transmission line	Required	Yes/No	Remains CN41 (default setting)

8. For systems with interface kit connected, turn SW5-7 ON.
* Branch box also needs to be set up. For details, refer to the installation manual for the Branch box.
If the SW setting is incorrect, an system error (e.g. error 7130) may occur and the system may not start up.

• Permissible Lengths

- Maximum line length via outdoor unit (M-NET cable):
 $L1+L2+L3+L4+L5+L6 \leq 500 \text{ m}$ (1.25 mm² or more)
- Indoor/Branch box/outdoor transmission line Maximum length (M-NET cable):
 $L1+L2+L3, L4+L5 \text{ and } L6 \leq 200 \text{ m}$ (1.25 mm² or more)
- Indoor/Branch box transmission line Maximum length (A-Control cable):
 $L7 \leq 25 \text{ m}$ (1.5 mm²)
- MA Remote controller cable length:
 $m1 \leq 200 \text{ m}$ (0.3 to 1.25 mm²)
- Sensor and alarm kit - Branch box connection cable length:
 $L8 \leq 40 \text{ m}$, (0.5 mm²)


en

6. Electrical work

Example of a system using Branch box and A-Control indoor unit with interface kit

■ Constraint items

() : Address



*1. When connecting interface kit, it is not possible to connect a Branch box without through the interface kit.

*2. When connecting interface kit, mixed system is not possible (Cannot connect M-IC).

*3. Sensor and alarm kit must be connected to the interface kit.

6. Electrical work

6.5. Wiring of main power supply and equipment capacity


Schematic Drawing of Wiring: When Not Using a Branch box (Example) (Fig. 6-2)



Fig. 6-2

Schematic Drawing of Wiring: When using a Branch box (Example) (Fig. 6-3)

<When Power Is Supplied from the Outdoor Unit>



* The M-NET Control Indoor unit cannot receive power supplied from an outdoor unit, so provide it with power separately.

<When Power Is Supplied Separately>




Fig. 6-3

Note:

The interface kit must be a power supply separately . For details, refer to the installation manual of interface kit.

6. Electrical work

Cross-sectional area of Wire for Main Power Supply and On/Off Capacities

<When power is supplied separately>

Model		Power Supply	Minimum Wire Cross-sectional area (mm ²)		Breaker for Wiring *1	Breaker for Current Leakage
			Main Cable	Ground		
Outdoor Unit	M200YKM	3N~ 380-400-415 V 50 Hz *2	2.5	2.5	25 A	25 A 30 mA 0.1 sec. or less

<When power is supplied from the outdoor unit>

Model		Power Supply	Minimum Wire Cross-sectional area (mm ²)		Breaker for Wiring *1	Breaker for Current Leakage
			Main Cable	Ground		
Outdoor Unit	M200YKM	3N~ 380-400-415 V 50 Hz *2	4.0	4.0	32 A	32 A 30 mA 0.1 sec. or less

*1 A breaker with at least 3.0 mm contact separation in each poles shall be provided. Use non-fuse breaker (NF) or earth leakage breaker (NV).

*2 In multi-phase appliances, the colour of the neutral conductor of the supply cord, if any, shall be blue.

<Indoor units> When power is supplied separately

Total operating current of the indoor unit	Minimum wire thickness (mm ²)			Ground-fault interrupter *1	Local switch (A)		Breaker for wiring (NFB)
	Main Cable	Branch	Ground		Capacity	Fuse	
F0 = 16 A or less *2	1.5	1.5	1.5	20 A current sensitivity *3	16	16	20
F0 = 25 A or less *2	2.5	2.5	2.5	30 A current sensitivity *3	25	25	30
F0 = 32 A or less *2	4.0	4.0	4.0	40 A current sensitivity *3	32	32	40

Apply to IEC61000-3-3 about max. permissive system impedance.

*1 The Ground-fault interrupter should support inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

*2 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = {V1 × (Quantity of Type 1)/C} + {V1 × (Quantity of Type 2)/C} + {V1 × (Quantity of Type 3)/C} + ... + {V1 × (Quantity of Type 12)/C}

Connect to Branch box (PAC-MMK-BC)

Indoor unit		V1	V2
Type 1	PCA-M·KA2, PCA-M·KA3	19.8	2.4
	SEZ-M·DA(L)2, SEZ-M·DA3		
Type 2	PEAD-M·JA(L)2, PEAD-M·JA(L)3	18.6	3.0
Type 3	PLA-M·EA2, PLA-M·EA3	17.1	2.4
	SLZ-M·FA2, SLZ-M·FA3		
Type 4	MLZ-KP·VF	9.9	
	MLZ-KP·VG		
Type 5	MLZ-KY·VG	7.4	
	MSZ-AP·VG(K)		
	MSZ-AY·VG(K)(P)2, MSZ-AP·VG(K)(P)		
	MSZ-EF·VG-E2/ER2/ET2, MSZ-EF·VGK-E1/ER1/ET1, MSZ-EF·VG(K)2		
	MSZ-LN·VG2, MSZ-LN·VG3		
	MSZ-RW·VG, MSZ-RW·VG2		
Type 6	MSZ-EF·VG-E1/ER1/ET1	6.8	
Type 7	MSZ-BT·VG(K), MSZ-BT·VG(K)2	6.1	
Type 8	Branch box (PAC-MMK40BC)	5.1	3.0
Type 9	Branch box (PAC-MMK60BC)	10.2	6.0

Connect to City Multi

Indoor unit		V1	V2
Type 10	PCFY-MS·VKM, PCFY-MS·VKM2	19.8	2.4
	PKFY-MS·VLM, PKFY-MS·VLM2		
	PKFY-MS·VKM, PKFY-MS·VKM2		
	PMFY-MS·VCM-E		
Type 11	PEFY-M·VMA(L)-A1	18.6	3.0
	PEFY-MS·VMA(L)-A		
Type 12	PLFY-M·VEM6	17.1	2.4
	PLFY-MS·VEM, PLFY-MS·VEM2		
	PLFY-MS·VFM, PLFY-MS·VFM2		
Type 13	PEFY-MS·VMS(L)-A	18.6	
Type 14	PEFY-MS40-140VMHS-A	26.8	1.6
Type 15	PEFY-MS200VMHS-A	23.0	4.8

C : Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.

6. Electrical work

<Example of "F2" calculation>

Condition PLFY-M·VEM6-E × 4 + PEFY-M·VMA(L)-A1 × 1, C = 8 (refer to right sample chart)

$$F2 = 17.1 \times 4/8 + 18.6 \times 1/8$$

$$= 10.875$$

→ 16 A breaker (Tripping current = 8 × 16 A at 0.01s)


*3 Current sensitivity is calculated using the following formula.

$$G1 = V2 \times (\text{Quantity of Type1}) + V2 \times (\text{Quantity of Type2}) + V2 \times (\text{Quantity of Type3}) + \dots + V2 \times (\text{Quantity of Type12}) + V3 \times (\text{Wire length[km]})$$

G1	Current sensitivity
30 or less	30 mA 0.1 sec. or less
100 or less	100 mA 0.1 sec. or less

Wire thickness	V3
1.5 mm ²	48
2.5 mm ²	56
4.0 mm ²	66

Sample chart




1. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
2. The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10%.
3. Specific wiring requirements should adhere to the wiring regulations of the region.
4. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
5. Install an earth longer than other cables.

⚠ Warning:

- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.
- Be sure to attach the terminal block covers/panel of the outdoor unit securely. If it is not attached correctly, it could result in a fire or an electric shock due to dust, water, etc.

⚠ Caution:

- Be careful not to make mis-wiring.
- Firmly tighten the terminal screws to prevent them from loosening.
- After tightening, pull the wires lightly to confirm that they not move.
- If the connecting wire is incorrectly connected to the terminal block, the unit does not operate normally.
- Some installation site may require attachment of an earth leakage breaker. If no earth leakage breaker is installed, it may cause an electric shock.
- Do not use anything other than breaker and fuse with correct capacity. Using fuse and wire or copper wire with too large capacity may cause a malfunction of unit or fire.
- Properly route wiring so as not to contact the sheet metal edge or a screw tip.



IMPORTANT

Make sure that the current leakage breaker is one compatible with higher harmonics.


Always use a current leakage breaker that is compatible with higher harmonics as this unit is equipped with an inverter.

The use of an inadequate breaker can cause the incorrect operation of inverter.

Never splice the power cable or the indoor-outdoor-Branch box-Interface Kit connection cable, otherwise it may result in a smoke, a fire or communication failure.

⚠ Warning:

- Please turn off the main power supply when servicing. And do not touch the B1, B2 terminals when the power is energized. If isolator should be used between outdoor unit and Branch box, please use 2 pole type. (Please refer to figure below.)



⚠ Caution:

After using the isolator, be sure to turn off and on the main power supply to reset the system. Otherwise, the outdoor unit may not be able to detect the Branch box(es) or indoor units.

Be sure to connect the outdoor-Branch box/indoor-Branch box connecting cables directly to the units (no intermediate connections).

Intermediate connections can lead to communication errors if water enters the cables and causes insufficient insulation to ground or a poor electrical contact at the intermediate connection point.

6. Electrical work

6.6. Address setting

Switch address setting

	Outdoor	Branch box * The 6-Branch box model is equipped with two control boards. For detailed settings, refer to the Branch box Installation Manual.		M, S, P series Indoor	CITY MULTI series	Interface kit																														
		Address	Connection Setting																																	
Switch	 tens digit SWU2  ones digit SWU1	 tens digit SW12  ones digit SW11	<table><tr><td>ON</td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td>OFF</td><td></td><td></td><td></td><td></td><td></td><td></td></tr><tr><td></td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr></table> SW1	ON							OFF								1	2	3	4	5	6	None	 tens digit SW12  ones digit SW11	 tens digit SW12  ones digit SW11									
ON																																				
OFF																																				
	1	2	3	4	5	6																														
Range	51 - 100	1 - 50	—	—	1 - 50	151 - 200																														
Setting	CITY MULTI series Indoor or Branch box address +50	- According to the set address (for example, 01), the addresses for the connected indoor units are set sequentially (for example, 02, 03, and 04). - The 6-Branch box model is equipped with two control boards, so settings are required for each of the control boards. <table><tr><td>SW1</td><td>1</td><td>2</td><td>3</td><td>4</td><td></td></tr><tr><td></td><td>ON</td><td>ON</td><td>ON</td><td>ON</td><td></td></tr><tr><td>Port</td><td>A</td><td>B</td><td>C</td><td>D</td><td></td></tr><tr><td>Address</td><td>01</td><td></td><td></td><td></td><td>(SW11, 12)</td></tr><tr><td></td><td></td><td>02</td><td>03</td><td>04</td><td>(sequential numbers)</td></tr></table>	SW1	1	2	3	4			ON	ON	ON	ON		Port	A	B	C	D		Address	01				(SW11, 12)			02	03	04	(sequential numbers)	Refer to the following table.	There are no address settings for the indoor units.	—	—
SW1	1	2	3	4																																
	ON	ON	ON	ON																																
Port	A	B	C	D																																
Address	01				(SW11, 12)																															
		02	03	04	(sequential numbers)																															

• Specify whether indoor units are connected to each port.


SW1	4-Branch model			6-Branch model					
	Port	OFF	ON	Control board-1			Control board-2		
				Port	OFF	ON	Port	OFF	ON
1	A	Not connected	Connected	1-A	Not connected	Connected	2-A	Not connected	Connected
2	B	Not connected	Connected	1-B	Not connected	Connected	2-B	Not connected	Connected
3	C	Not connected	Connected	1-C	Not connected	Connected	2-C	Not connected	Connected
4	D	Not connected	Connected	Not used			Not used		
5	Not used			Not used			Not used		
6	Supervisor alarm	Not connected	Connected	Supervisor alarm	Not connected	Connected	Not used		

Note: 1. Branch box address


When setting the address, use a number within the range 1–50.

6. Electrical work

Ex1. Outdoor + Branch-1 <6-Branch> (M, S, P series Indoor 1-A, 1-B, 1-C, 2-A, 2-B, 2-C) + Branch-2 <4-Branch> (M, S, P series Indoor A, C)



Ex2. Outdoor + Branch-1 <4-Branch> (M, S, P series Indoor A, B, C, D) + Branch-2 <4-Branch> (M, S, P series Indoor A, B, C) + CITY MULTI series Indoor-1 + CITY MULTI series Indoor-2



7. Test run

7.1. Before test run

- ▶ After completing installation and the wiring and piping of the indoor and outdoor units, check for refrigerant leakage, looseness in the power supply or control wiring, wrong polarity, and no disconnection of one phase in the supply.

- ▶ Use a 500-volt M-ohm tester to check that the resistance between the power supply terminals and ground is at least 1 MΩ.

- ▶ Do not carry out this test on the control wiring (low voltage circuit) terminals.

⚠ **Warning:**

Do not use the air conditioner if the insulation resistance is less than 1 MΩ.

Insulation resistance

After installation or after the power source to the unit has been cut for an extended period, the insulation resistance will drop below 1 MΩ due to refrigerant accumulation in the compressor. This is not a malfunction. Perform the following procedures.

1. Remove the wires from the compressor and measure the insulation resistance of the compressor.
2. If the insulation resistance is below 1 MΩ, the compressor is faulty or the resistance dropped due to the accumulation of refrigerant in the compressor.

3. After connecting the wires to the compressor, the compressor will start to warm up after power is supplied. After supplying power for the times indicated below, measure the insulation resistance again.

- The insulation resistance drops due to accumulation of refrigerant in the compressor. The resistance will rise above 1 MΩ after the compressor is warmed up for 12 hours.
(The time necessary to warm up the compressor varies according to atmospheric conditions and refrigerant accumulation.)
- To operate the compressor with refrigerant accumulated in the compressor, the compressor must be warmed up at least 12 hours to prevent breakdown.

4. If the insulation resistance rises above 1 MΩ, the compressor is not faulty.

⚠ **Caution:**

- **The compressor will not operate unless the power supply phase connection is correct.**

- **Turn on the power at least 12 hours before starting operation.**

- Starting operation immediately after turning on the main power switch can result in severe damage to internal parts. Keep the power switch turned on during the operational season.

- ▶ **The followings must be checked as well.**

- The outdoor unit is not faulty. LED on the control board of the outdoor unit flash when the outdoor unit is faulty.
- Both the gas and liquid stop valves are completely open.

7.2. Test run

7.2.1. Using remote controller

Refer to the indoor unit installation manual.

- Be sure to perform the test run for each indoor unit. Make sure each indoor unit operates properly following the installation manual attached to the unit.
- If you perform the test run for all indoor units at once, you cannot detect any erroneous connection, if any, of the refrigerant pipes and the connecting wires.
- The compressor operation is not available for 3 minutes at least after the power is supplied.
- The compressor can emit noise just after turn on the power supply or in case of low outside air temperature.
- Depending on the operating conditions, the outdoor unit fan may stop while the compressor is operating, but this is not a malfunction.

About the restart protective mechanism

Once the compressor stops, the restart preventive device operates so the compressor will not operate for 3 minutes to protect the air conditioner.

7.2.2. Using SW6 in outdoor unit

Note:

In case of the test run from outdoor unit, all indoor units operate. Therefore, you can not detect any erroneous connection of refrigerant pipes and the connecting wires. If it aims at detection of any erroneous connection, be sure to carry out the test run from remote controller with reference to “7.2.1. Using remote controller.”

■ Test run (from the outdoor unit)

- 1 Set SW6-2 to select the operation mode.

SW6-2	ON	Heating operation
	OFF	Cooling operation

- 2 After setting SW6-2, set SW6-1 from OFF to ON. The test run starts.
 - * Before setting SW6-1, make sure that the circuit breaker is turned on.
 - * Stop the air conditioner operation (SW6-1: OFF). Set the operation mode will not change.
 - * Set SW6-1 to OFF to finish the test run.
- A few seconds after the compressor starts, a clanging noise may be heard from the inside of the outdoor unit. The noise is coming from the check valve due to the small difference in pressure in the pipes. The unit is not faulty.

7.3. Refrigerant collecting (Pump down)

Perform the following procedures to collect the refrigerant when moving the indoor unit or the outdoor unit.

- 1 Turn off the circuit breaker.
- 2 Connect the low pressure side of the gauge manifold to the service port of the gas side stop valve.
- 3 Close the liquid stop valve.
- 4 Supply power (circuit breaker).
 - * Start-up of the indoor-outdoor communication takes about 3 minutes after the power (circuit breaker) is turned on. Start the pump-down operation 3 to 4 minutes after the power (circuit breaker) is turned ON.
- 5 Perform the test run for cooling operation (SW6-1: ON and SW6-2: OFF). The compressor (outdoor unit) and ventilators (indoor and outdoor units) start operating and test run for cooling operation begins. Immediately after performing the test run for cooling operation, set the outdoor service switch SW6-5 (pump down switch) from OFF to ON.
 - * Do not continue to operate for a long time with the switch SW6-5 set to ON. Make sure to switch it to OFF after pump down is completed.
 - * Only set the SW6-1 to ON if the unit is stopped. However, even if the unit is stopped and the SW6-1 is set to ON less than 3 minutes after the compressor stops, refrigerant collecting operation cannot be performed. Wait until the compressor has been stopped for 3 minutes and then set the SW6-1 to ON again.

- 6 Fully close the gas stop valve when the pressure reading on the gauge drops 0.05 - 0.00 MPa (approximately 0.5 - 0.0 kgf/cm²)
- 7 Stop the air conditioner operation (SW6-1: OFF). Set the outdoor service switch SW6-5 from ON to OFF.
- 8 Turn off the power supply (circuit breaker).
 - * If too much refrigerant has been added to the air conditioner system, the pressure may not drop to 0.05 MPa (0.5 kgf/cm²). If this occurs, use a refrigerant collecting device to collect all of the refrigerant in the system, and then recharge the system with the correct amount of refrigerant after the indoor and outdoor units have been relocated.

⚠ **Warning:**

- **When pumping down the refrigerant, stop the compressor before disconnecting the refrigerant pipes. The compressor may burst and cause injury if any foreign substance, such as air, enters the system.**
- **Do not perform pump down work when there is a gas leak. The intake of air or other gases causes abnormally high pressure in the refrigeration cycle, which may cause explosion or injury.**

8. Special functions

8.1. Function setting

Make function settings by setting the dipswitches SW4, SW6, and SWP3 on the main board.

Write down the switch settings on the electrical wiring diagram label on the control box front panel for future reference when the control box needs to be replaced.


- Take the following steps to make function settings.
 - Set the SW6-10 to ON.
 - Set SW4 as shown in the table below to select the setting item number. (The setting item No. will be displayed on LED1.)
 - Press SWP3 for 2 seconds or longer to change the settings. (The setting item No. and the setting condition (enable [ON] / normal [OFF]) are displayed alternately by the second.)
 - Set the SW6-10 and SW4 to OFF.

Function	Setting item No.	SW4 0: OFF, 1: ON ^{*1}										Setting (LED1 display)	
		1	2	3	4	5	6	7	8	9	10	ON	OFF
Switching the Silent / Demand mode	0010	0	1	0	1	0	0	0	0	0	0	Demand control	Silent mode

^{*1} Make the SW4 setting after the unit is energized.

8.2. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR

• State (CN51)




A Distant control board
B Relay circuit
C External output adapter (PAC-SA88HA-E)
D Outdoor unit control board

E Lamp power supply
F Procure locally
G Max. 10 m

L1: Error display lamp
L2: Compressor operation lamp
X, Y: Relay (coil rating: ≤ 0.9 W, 12 VDC)

• Silent Mode / Demand Control (CN3D)



A Remote control panel
B Relay circuit
C External input adapter (PAC-SC36NA-E)
D Outdoor unit control board

E Relay power supply
F Procure locally
G Max. 10 m

SW1: Switch
SW2: Switch
X, Y: Relay (contact rating: ≥ 0.1 A, 15 VDC)
(min. applicable load: ≤ 1 mA)

The silent mode and the demand control are selected by switching function setting No.10 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1, 2.

	Outdoor controller board function setting No.10	SW1	SW2	Function
Silent mode	OFF	OFF	OFF	Normal
		ON	OFF	Silent mode *
		OFF	ON	Normal
		ON	ON	Silent mode *
Demand control	ON	OFF	OFF	100% (Normal)
		ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)

* Cooling only

9. Preventive maintenance for the unit

The maintenance cycle does not indicate the guarantee period.

The list below is applicable under the following conditions:

- The unit is used normally: it does not start and stop frequently. (The number of start/stop is 6 times or less per hour in normal use though it depends on the model.)
- The operating time is assumed to be 10 hours a day and 2,500 hours a year. (It can be longer for the unit which operates during the night.)

Additionally, the “maintenance cycle” and “replacement cycle” need to be reviewed to be shortened when the following conditions are satisfied:

- The unit is used under high temperature or high humidity, or in the place where the temperature or humidity changes severely.
- The unit is used in the place where the power (voltage, frequency, or waveform) fluctuates a lot. (The unit cannot be used if the power is out of the allowable range.)
- The unit is used in the place where a lot of vibration or impacts are applied.
- The unit is used in a bad environment such as in the dusty area, the high-salt area, or the area where noxious gas (sulfur dioxide or hydrogen sulfide) or oil-mist exists.
- The unit starts and stops frequently or the operating time is long (such as under 24-hour air conditioning).

List of “inspection cycle” and “maintenance cycle”

Part name	Inspection cycle	Maintenance cycle (Replacement or repairing)
Compressor	1 year	20,000 hours
Motor		20,000 hours
Electronic boards		25,000 hours
Heat exchanger		5 years
Expansion valve		20,000 hours
Valve (solenoid valve, 4-way valve)		20,000 hours
Sensor		5 years
Drain pan		8 years

10. Specifications

PUMY-M200YKM(-BS) PUMY-M200YKM-ET(-BS)		Cooling [D.B.*1]	Heating [W.B.*2]
Maximum operating temperature	°C	52	15
Minimum operating temperature	°C	-5	-20

*1 D.B. : Dry Bulb Temperature

*2 W.B. : Wet Bulb Temperature

<ENGLISH>

English is original. The other languages versions are translation of the original.

 CAUTION

- Refrigerant leakage may cause suffocation. Provide ventilation in accordance with EN378-1.
- Be sure to wrap insulation around the piping. Direct contact with the bare piping may result in burns or frostbite.
- Never put batteries in your mouth for any reason to avoid accidental ingestion.
- Battery ingestion may cause choking and/or poisoning.
- Install the unit on a rigid structure to prevent excessive operation sound or vibration.
- The A-weighted sound pressure level is below 70dB.
- This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

<DEUTSCH>

Das Original ist in Englisch. Die anderen Sprachversionen sind vom Original übersetzt.

 VORSICHT

- Wenn Kältemittel austritt, kann dies zu Ersticken führen. Sorgen Sie in Übereinstimmung mit EN378-1 für Durchlüftung.
- Die Leitungen müssen isoliert werden. Direkter Kontakt mit nicht isolierten Leitungen kann zu Verbrennungen oder Erfrierungen führen.
- Nehmen Sie niemals Batterien in den Mund, um ein versehentliches Verschlucken zu vermeiden.
- Durch das Verschlucken von Batterien kann es zu Erstickungen und/oder Vergiftungen kommen.
- Installieren Sie das Gerät auf einem stabilen Untergrund, um übermäßige Betriebsgeräusche oder -schwingungen zu vermeiden.
- Der A-gewichtete Schalldruckpegel ist niedriger als 70dB.
- Dieses Gerät ist vorgesehen für die Nutzung durch Fachleute oder geschultes Personal in Werkstätten, in der Leichtindustrie und in landwirtschaftlichen Betrieben oder für die kommerzielle Nutzung durch Laien.

<FRANÇAIS>

L'anglais est l'original. Les versions fournies dans d'autres langues sont des traductions de l'original.

 PRECAUTION

- Une fuite de réfrigérant peut entraîner une asphyxie. Fournissez une ventilation adéquate en accord avec la norme EN378-1.
- Assurez-vous que la tuyauterie est enveloppée d'isolant. Un contact direct avec la tuyauterie nue peut entraîner des brûlures ou des engelures.
- Ne mettez jamais des piles dans la bouche pour quelque raison que ce soit pour éviter de les avaler par accident.
- Le fait d'ingérer des piles peut entraîner un étouffement et/ou un empoisonnement.
- Installez l'appareil sur une structure rigide pour prévenir un bruit de fonctionnement et une vibration excessifs.
- Le niveau de pression acoustique pondéré est en dessous de 70 dB.
- Cet appareil est conçu pour un utilisateur expert ou les utilisateurs formés en magasin, dans l'industrie légère et dans l'agriculture ou dans le commerce par le profane.

<NEDERLANDS>

Het Engels is het origineel. De andere taalversies zijn vertalingen van het origineel.

 VOORZICHTIG

- Het lekken van koelvloeistof kan verstikking veroorzaken. Zorg voor ventilatie in overeenstemming met EN378-1.
- isoleer de leidingen met isolatiemateriaal. Direct contact met de onbedekte leidingen kan leiden tot brandwonden of bevriezing.
- Stop nooit batterijen in uw mond om inslikking te voorkomen.
- Het inslikken van batterijen kan verstikking of vergiftiging veroorzaken.
- Installeer het apparaat op een stabiele structuur om overmatig lawaai of trillingen te voorkomen.
- Het niveau van de geluidsdruk ligt onder 70 dB(A).
- Dit apparaat is bedoeld voor gebruik door ervaren of opgeleide gebruikers in werkplaatsen, in de lichte industrie en op boerderijen, of voor commercieel gebruik door leken.

<ESPAÑOL>

El idioma original del documento es el inglés. Las versiones en los demás idiomas son traducciones del original.

 CUIDADO

- Las pérdidas de refrigerante pueden causar asfixia. Se debe proporcionar la ventilación determinada en EN378-1.
- Asegúrese de colocar el aislante alrededor de las tuberías. El contacto directo con la tubería puede ocasionar quemaduras o congelación.
- Para evitar una ingestión accidental, no coloque las pilas en su boca bajo ningún concepto.
- La ingestión de las pilas puede causar asfixia y/o envenenamiento.
- Coloque la unidad en una estructura rígida para evitar que se produzcan sonidos o vibraciones excesivos debidos a su funcionamiento.
- El nivel de presión acústica ponderado A es inferior a 70 dB.
- Este aparato está destinado a su uso por parte de usuarios expertos o capacitados en talleres, industrias ligeras y granjas, o a su uso comercial por parte de personas no expertas.

<ITALIANO>

Il testo originale è redatto in lingua Inglese. Le altre versioni linguistiche rappresentano traduzioni dell'originale.

 ATTENZIONE

- Le perdite di refrigerante possono causare asfissia. Prevedere una ventilazione adeguata in conformità con la norma EN378-1.
- Accertarsi di applicare materiale isolante intorno alle tubature. Il contatto diretto con le tubature non schermate può provocare ustioni o congelamento.
- Non introdurre in nessun caso le batterie in bocca onde evitare ingestioni accidentali.
- L'ingestione delle batterie può provocare soffocamento e/o avvelenamento.
- Installare l'unità su una struttura rigida in modo da evitare rumore o vibrazioni eccessivi durante il funzionamento.
- Il livello di pressione del suono ponderato A è inferiore a 70dB.
- Questa apparecchiatura è destinata all'utilizzo da parte di utenti esperti o addestrati in negozi, industria leggera o fattorie oppure a un uso commerciale da parte di persone non esperte.

<ΕΛΛΗΝΙΚΑ>

Η γλώσσα του πρωτοτύπου είναι η αγγλική. Οι εκδόσεις άλλων γλωσσών είναι μεταφράσεις του πρωτοτύπου.

 ΠΡΟΣΟΧΗ

- Η διαρροή του ψυκτικού ενδέχεται να προκαλέσει ασφυξία. Φροντίστε για τον εξερισμό σύμφωνα με το πρότυπο EN378-1.
- Φροντίστε να τυλίξετε με μονωτικό υλικό τη σωλήνωση. Η απευθείας επαφή με τη γυμνή σωλήνωση ενδέχεται να προκαλέσει εγκαύματα ή κρυοπαγήματα.
- Μη βάζετε ποτέ τις μπαταρίες στο στόμα σας για κανένα λόγο ώστε να αποφύγετε την κατά λάθος κατάποσή τους.
- Η κατάποση μπαταριών μπορεί να προκαλέσει πνιγμό ή/και δηλητηρίαση.
- Εγκαταστήστε τη μονάδα σε σταθερή κατασκευή ώστε να αποφύγετε τον έντονο ήχο λειτουργίας ή τους κραδασμούς.
- Η Α-σταθμισμένη στάθμη ηχητικής πίεσης είναι κάτω των 70dB.
- Η συσκευή αυτή προορίζεται για χρήση από έμπειρους ή εκπαιδευμένους χρήστες σε καταστήματα, στην ελαφριά βιομηχανία και σε αγροκτήματα, ή για εμπορική χρήση από άτομα τα οποία δεν είναι ειδήμονες.

<PORTUGUÊS>

O idioma original é o inglês. As versões em outros idiomas são traduções do idioma original.

 CUIDADO

- A fuga de refrigerante pode causar asfixia. Garanta a ventilação em conformidade com a norma EN378-1.
- Certifique-se de que envolve as tubagens com material de isolamento. O contacto directo com tubagens não isoladas pode resultar em queimaduras ou ulcerações provocadas pelo frio.
- Nunca coloque pilhas na boca, por nenhum motivo, para evitar a ingestão accidental.
- A ingestão de uma pilha pode causar obstrução das vias respiratórias e/ou envenenamento.
- Instale a unidade numa estrutura robusta, de forma a evitar ruídos ou vibrações excessivos durante o funcionamento.
- O nível de pressão sonora ponderado A é inferior a 70 dB.
- Este equipamento destina-se a ser utilizado por especialistas ou utilizadores com formação em lojas, na indústria ligeira e em quintas, ou para utilização comercial por leigos.

<DANSK>

Engelsk er originalen. De andre sprogversioner er oversættelser af originalen.

 FORSIGTIG

- Lækage af kølemiddel kan forårsage kvælning. Sørg for udluftning i overensstemmelse med EN378-1.
- Sørg for at pakke rørene ind i isolering. Direkte kontakt med ubeklædte rør kan forårsage forbrændinger eller forfrysninger.
- Batterier må under ingen omstændigheder tages i munden for at forhindre utilsigtet indtagelse.
- Indtagelse af batterier kan forårsage kvælning og/eller forgiftning.
- Installer enheden på en fast struktur for at forhindre for høje driftslyde eller vibrationer.
- Det A-vægtede lydtrykniveau er under 70dB.
- Dette apparat er beregnet til at blive brugt af eksperter eller udlærte brugere i butikker, inden for let industri og på gårde eller til kommerciel anvendelse af lægmænd.

<SVENSKA>

Engelska är originalspråket. De övriga språkversionerna är översättningar av originalet.

 FÖRSIKTIGHET

- Köldmedelsläckage kan leda till kvävning. Tillhandahåll ventilation i enlighet med EN378-1.
- Kom ihåg att linda isolering runt rören. Direktkontakt med bara rör kan leda till brännskador eller köldskador.
- Stoppa aldrig batterier i munnen, de kan sväljas av misstag.
- Om ett batteri sväljs kan det leda till kvävning och/eller förgiftning.
- Montera enheten på ett stadigt underlag för att förhindra höga driftljud och vibrationer.
- Den A-vägda ljudtrycksnivån är under 70dB.
- Denna apparat är ämnad för användning av experter eller utbildade användare i affärer, inom lätt industri och på lantbruk, eller för kommersiell användning av lekmän.

<TÜRKÇE>

Aslı İngilizcedir. Diğer dillerdeki sürümler aslının çevirisidir.

 DİKKAT

- Soğutucu kaçağı boğulmaya neden olabilir. EN378-1 uyarınca uygun havalandırma sağlayın.
- Borular etrafına yalıtım yapıldığından emin olun. Borulara doğrudan çıplak elle dokunulması yanıklara veya soğuk ısırıklarına neden olabilir.
- Kazara yutmamak için, pilleri kesinlikle hiçbir amaçla ağzınızda tutmayın.
- Pillerin yutulması boğulmaya ve/veya zehirlenmeye yol açabilir.
- Açgınlıkta ses seslerini veya titreşimi önlemek için, üniteyi sağlam bir yapı üzerine monte edin.
- A ağırlıklı ses gücü seviyesi 70dB'nin altındadır.
- Bu cihaz atölyelerde, hafif endüstriyel tesislerde ve çiftliklerde uzman veya eğitilmiş kullanıcılar tarafından kullanılmak üzere veya normal kullanıcılar tarafından ticari kullanım için tasarlanmıştır.

<УКРАЇНСЬКА>

Переклад оригіналу. Текст іншими мовами є перекладом оригіналу.

 ОБЕРЕЖНО

- Виток холодоагенту може призвести до удущення. Необхідно забезпечити вентиляцію відповідно до стандарту EN 378-1.
- Труби необхідно обмотати ізоляційним матеріалом. Прямий контакт із непокритою трубою може призвести до опіку або обмороження.
- Забороняється класти елементи живлення в рот із будь-яких причин, оскільки є ризик випадково їх проковтнути.
- Попадання елемента живлення в травну систему може стати причиною задухи та/або отруєння.
- Встановлюйте блок на міцній конструкції, щоб уникнути надмірного рівня звуку роботи або вібрації.
- Рівень амплітудно зваженого акустичного тиску становить нижче 70 дБ.
- Цей прилад призначається для використання спеціалістами або особами, що пройшли відповідне навчання, у крамницях, легкій промисловості та сільськогосподарських підприємствах, а також для комерційного використання неспеціалістами.

<БЪЛГАРСКИ>

Оригиналът е текстът на английски език. Версиите на други езици са преводи на оригинала.

 ВНИМАНИЕ

- Изтичането на хладилен агент може да причини задушаване. Осигурете вентилация съобразно с EN378-1.
- Не забравяйте да увиете изолация около тръбите. Директният контакт с оголени тръби може да причини изгаряне или измръзване.
- При никакви обстоятелства не поставяйте батериите в устата си, за да не ги погълнете по невнимание.
- Това може да доведе до задушаване и/или натравяне.
- Монтирайте тялото върху твърда конструкция, за да предотвратите прекомерен шум или вибрации по време на работа.
- А-претегленото ниво на звуково налягане е под 70 dB.
- Този уред е предназначен за използване от експерти или обучени потребители в магазини, в леката промишленост и във ферми, или за търговска употреба от неспециалисти.

<POLSKI>

Językiem oryginału jest język angielski. Inne wersje językowe stanowią tłumaczenie oryginalu.

 UWAGA

- Wyciek czynnika chłodniczego może spowodować uduszenie. Należy zapewnić wentylację zgodnie z normą EN378-1.
- Należy pamiętać, aby owinać izolację wokół przewodów rurowych. Bezpośredni kontakt z niebezpiecznymi przewodami rurowymi może doprowadzić do poparzeń lub odmrożeń.
- Nie wolno wkładać baterii do ust z jakiegokolwiek powodu, aby uniknąć przypadkowego połknięcia.
- Połknięcie baterii może spowodować zadławienie i/lub zatrucie.
- Zainstalować urządzenie na sztywnej konstrukcji, aby zapobiec nadmiernemu hałasowi i wibracjom.
- Poziom dźwięku A nie przekracza 70 dB.
- W sklepach, w przemyśle lekkim i w gospodarstwach rolnych urządzenie powinni obsługiwać profesjonaliści lub przeszkoleni użytkownicy, a w środowisku handlowym mogą to być osoby nieposiadające fachowej wiedzy.

<NORSK>
Originalspråket er engelsk. De andre språkversjonene er oversettelser av originalen.



FORSIKTIG

- Kjølemiddellekkasje kan forårsake kvelning. Sørg for ventilering i samsvar med EN378-1.
- Pass på at isoleringen pakkes godt rundt røret. Direkte kontakt med ukledte rør kan forårsake brannskader eller forfrysninger.
- Aldri plasser batteri i munnen, da dette kan medføre en risiko for at du svelger batteriet ved et uhell.
- Hvis du svelger et batteri, kan du risikere kvelning og/eller forgiftning.
- Installer enheten på en stabil struktur for å forhindre unødvendig mye driftsstøy eller vibrering.
- Det A-vektede lydtrykknivået er under 70 dB.
- Dette apparatet er ment for bruk av eksperter eller faglært personell i butikker, lettindustri og på gårder, eller for kommersielt bruk av ikke-fagmenn.

<SUOMI>
Englanti on alkuperäinen. Muut kieliversiot ovat alkuperäiskappaleen käännöksiä.



HUOMIO

- Vuotava kylmäaine voi aiheuttaa tukehtumisen. Ilmanvaihdon on oltava EN378-1-standardin mukainen.
- Kääri putken ympärille eristysmateriaalia. Paljaan putken koskettamisesta voi seurata palotai paleltumavammoja.
- Älä koskaan laita paristoja suuhun, jotta et vahingossa nielaisisi niitä.
- Paristojen nieleminen voi aiheuttaa tukehtumisen ja/tai myrkytyksen.
- Asenna yksikkö tukeviin rakenteisiin, jotta sen käytöstä ei syntyisi ylimääräistä ääntä tai värinää.
- A-painotettu äänenpainetaso on alle 70 dB.
- Laite on tarkoitettu asiantuntijoiden tai laitteelle koulutuksen saaneiden käyttöön kauppoissa, pienteollisuudessa ja maailloilla tai maailloille kaupalliseen käyttöön.

<ČEŠTINA>
Originál je v angličtině. Ostatní jazykové verze jsou překladem originálu.



POZOR

- Únik chladicího média může způsobit udušení. Zajistěte větrání v souladu s normou EN 378-1.
- Okolo potrubí vždy omotejte izolaci. Přímý kontakt s obnaženým potrubím může způsobit popálení nebo omrzliny.
- Nikdy nevykládejte baterie do úst, aby nedošlo k jejich polknutí.
- Polknutí baterie může způsobit zadušení a/nebo otrávu.
- Jednotku nainstalujte na pevnou konstrukci, aby nedocházelo ke vzniku nadměrného provozního hluku a vibrací.
- Hladina akustického tlaku A je nižší než 70 dB.
- Toto zařízení je určeno pro prodejní, lehký průmysl a farmy, kde je musí obsluhovat odborníci a školení uživatelé, a pro komerční použití, kde je mohou obsluhovat laici.

<SLOVENČINA>
Preklad anglického originálu. Všetky jazykové verzie sú preložené z angličtiny.



UPOZORNENIE

- Únik chladiva môže spôsobiť udusenie. Zabezpečte vetranie podľa normy EN 378-1.
- Nezabudnite potrubie obaliť izoláciou. Priamy kontakt s nezabaleným potrubím môže spôsobiť popáleniny alebo omrzliny.
- Batérie si nikdy z akéhokoľvek dôvodu nekladte do úst, aby nedošlo k ich náhodnému požitiu.
- Požitie batérií môže vyvolať dusenie a/alebo otrávu.
- Nainštalujte jednotku na pevný konštrukčný prvok, aby ste obmedzili nadmerný prevádzkový hluč a vibrácie.
- Hladina akustického tlaku vážená podľa krivky A je nižšia ako 70 dB.
- Toto zariadenie je určené na používanie odborníkmi alebo zaškolenými používateľmi v komerčných priestoroch, v prostredí ľahkého priemyslu, na farmách, alebo na komerčné použitie bežnými používateľmi.

<MAGYAR>
Az angol változat az eredeti. A többi nyelvi változat az eredeti fordítása.



VIGYÁZAT

- A hűtőközeg szivárgása fulladást okozhat. Gondoskodjon az EN378-1 szabvány előírásai szerinti szellőzéstől.
- Feltétlenül szigetelje körbe a csöveket. A csupasz cső megérintése égési vagy fagyási sérülést okozhat.
- Ne vegyen a szájába elemet semmilyen célból, mert véletlenül lenyelheti!
- A lenyelt elem fulladást és/vagy mérgezést okozhat.
- A készüléket merev szerkezetre szerelje fel, hogy megakadályozza a túlzott üzemi zajt és vibrációt.
- Az A-súlyozott hangnyomásszint 70 dB alatt van.
- A készülék üzemel, a könnyűipar és gazdaságok szakértő vagy képzett felhasználói, valamint laikus felhasználók általi kereskedelmi használatra készült.

<SLOVENŠČINA>
Izvirnik je v angleščini. Druge jezikovne različice so prevodi izvirnika.



POZOR

- Puščanje hladiva lahko povzroči zadušitev. Zagotovite prezračevanje po standardu EN378-1.
- Cevi ovijte z izolacijo. Neposredni stik z golimi cevmi lahko povzroči opekline ali ozeblino.
- Nikoli in iz nobenega razloga ne vstavljajte baterij v usta, da jih po nesreči ne pogoltnete.
- Če baterije pogoltnete, se lahko zadušite in/ali zastrupite.
- Enoto namestite na togo konstrukcijo, da preprečite pretrzan zvok ali tresljaje med delovanjem.
- A-utežena raven zvočnega tlaka je pod 70 dB.
- Naprava je namenjena za uporabo s strani strokovnih ali ustrezno usposobljenih uporabnikov v trgovinah, lahki industriji in na kmetijah ter za komercialno uporabo s strani nestrokovnih uporabnikov.

<ROMÂNĂ>
Textul original este în limba engleză. Versiunile pentru celelalte limbi sunt traduceri ale originalului.



ATENȚIE

- Scurgerea de agent frigorific poate cauza asfixierea. Asigurați o ventilație corespunzătoare, conform standardului EN378-1.
- Asigurați-vă că înfășurați materialul izolator în jurul conductelor. Contactul direct cu conductele neizolate se poate solda cu arsuri sau degerături.
- Nu introduceți niciodată și pentru niciun motiv bateriile în gură, pentru a evita ingerarea accidentală a acestora.
- Ingerarea bateriilor poate cauza sufocarea și/sau intoxicația.
- Instalați unitatea pe o structură rigidă pentru a preveni producerea unui nivel excesiv de sunete sau vibrații.
- Nivelul de presiune acustică ponderată în A este mai mic de 70 dB.
- Acest aparat este destinat utilizării de către utilizatori specializați sau instruiți în cadrul spațiilor comerciale, spațiilor din cadrul industriei ușoare și al fermelor sau în scopuri comerciale de către nespecialiști.

<EESTI>
Originaaljuhend on ingliskeelne. Muudes keeltes versioonid on originaali tõlked.



ETTEVAATUST!

- Külmaaine leke võib põhjustada lämbumist. Tuulutamine standardi EN378-1 kohaselt.
- Mähkige torude ümber kindlasti isolatsiooni. Vahetu kontakt paljaste torudega võib põhjustada põletusi või külmakahjustusi.
- Hoiduge patareide tahtmatust allaneelamisest, ärge kunagi pange ühelgi põhjusel patareisid suhu.
- Patarei allaneelamine võib põhjustada lämbumist ja/või mürgitust.
- Paigaldage seade jäigale struktuurile, et vältida ülemäära stööheli ja vibreerimist.
- A-filtriga helirõhu tase on madalam kui 70 dB.
- Seade on mõeldud kasutamiseks asjatundjatele ja väljaõppe läbinud kasutajatele poodides, kergtööstuses ja taludes ning kommertskasutuseks tavaisikute poolt.

<LATVISKI>
Oriģināls ir angļu valodā. Versijas citās valodās ir oriģināla tulkojums.



UZMANĪBU

- Aukstumaģenta noplūdes gadījumā pastāv nosmakšanas risks. Ir jānodrošina standartam EN378-1 atbilstoša ventilāšana.
- Aptiniet caurules ar izolējošu materiālu. Pieskaroties neaptītām caurulēm, var gūt apdegumus vai apsaldējumus.
- Aizliegts ievietot baterijas mutē; pastāv norīšanas risks.
- Bateriju norīšana var izraisīt aizrīšanas un/vai saindēšanas.
- Uzstādiet iekārtu uz izturīgas struktūras, lai izvairītos no pārlieku liela darbības trokšņa vai vibrācijas.
- A — izsvartotais skaņas spiediena līmenis ir mazāks par 70 dB.
- Šo iekārtu paredzēts lietot speciālistiem vai apmācītiem lietotājiem veikalos, vieglās rūpniecības telpās un lauksaimniecības fermās, kā arī to var lietot nespeciālisti komerciālām vajadzībām.

<LIETUVIŠKAI>
Originalas yra anglų k. Versijos kitomis kalbomis yra originalo vertimas.



ATSARGIAI

- Dėl šaltnešio nuotėkio galima uždegti. Išvėdinkite patalpą pagal EN378-1.
- Būtinai vamzdelius apvyniokite izoliacija. Prisilietus prie plikų vamzdelių galima nusideginti arba nušalti.
- Siekdami išvengti atsitiktinio prarijimo, niekada nedėkite baterijų į burną.
- Prarijus bateriją galima užspringti ir / arba apsinuodyti.
- Įrenginį sumontuokite ant tvirtos struktūros, kad nesigirdėtų pernelyg didelio veikimo triukšmo ar vibracijos.
- A svertinis garso slėgio lygis nesiekia 70 dB;
- Šis prietaisas skirtas naudoti specialistui ar išmokytiems naudotojams dirbtuvėse, lengvojoje pramonėje ar ūkiuose arba komerciniams naudojimui nespecialistams.

<HRVATSKI>
Tekst je izvorno napisan na engleskom jeziku. Tekst na ostalim jezicima predstavlja prijevod izvorno napisanog teksta.



OPREZ

- Čurenje rashladnog sredstva može uzrokovati gušenje. Osigurajte ventilaciju u skladu s normom HR EN378-1.
- Obavezno stavite izolaciju oko položenih cijevi. Izravni doticaj s golim cijevima može dovesti do opekline ili smrzavanja.
- Nikada ne stavljajte baterije u usta ni zbog kojeg razloga kako biste izbjegli slučajno gutanje.
- Gutanje baterija može prouzročiti gušenje i/ili trovanje.
- Postavite jedinicu na čvrstu površinu kako biste izbjegli prebučan zvuk tijekom rada ili pojavu vibracija.
- Razina zvučnog tlaka A niža je od 70dB.
- Ovak uređaj mogu upotrebljavati stručnjaci ili osposobljeni korisnici u trgovinama, lakoj industriji i na poljoprivrednim gospodarstvima ili laici u komercijalne svrhe.

<SRPSKI>
Prevod originala. Verzije na drugim jezicima su prevodi originala.



OPREZ

- Čurenje rashladne tečnosti može da dovede do gušenja. Obezbedite ventilaciju u skladu sa EN378-1.
- Obavezno obmotajte izolaciju oko cevi. Direktna kontakt sa golom cevi može izazvati opekotine ili promrzline.
- Nikada nemojte stavljati baterije u usta iz bilo kog razloga, kako bi se sprečilo slučajno gutanje.
- Gutanje baterija može da izazove gušenje i/ili trovanje.
- Ugradite jedinicu na čvrstu strukturu kako biste sprečili previše jak zvuk rada ili vibracije.
- A-ponderisani nivo jačine pritiska zvuka je ispod 70 dB.
- Ovak uređaj je namenjen za upotrebu od strane stručnih ili obučenih korisnika u prodavnicama, u lakoj industriji i na farmama ili za komercijalnu upotrebu od strane ne kvalifikovanih lica.

This product is designed and intended for use in the residential, commercial, and light-industrial environment.

Manufacturer

MITSUBISHI ELECTRIC CONSUMER PRODUCTS (THAILAND) CO., LTD.

700/406 MOO 7, TAMBON DON HUA ROH, AMPHUR MUANG, CHONBURI 20000, THAILAND

Contact.LES@mcp.meap.com

Importer within the EU / Authorised representative within the EU

Mitsubishi Electric Europe B.V.

Living Environment Systems Business Unit

2, Rue de l'Union, 92565 Rueil-Malmaison Cedex, France

Contact.LES@fra.mee.com

Please be sure to put the contact address/telephone number on
this manual before handing it to the customer.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN