



IF YOU ARE TOO HOT PRESS



IF YOU ARE TOO COLD PRESS



**Operation Buttons**

- |   |  |
|---|--|
| 1 | TURN UNIT ON/OFF   |
| 2 | <b>MODE KEY:</b><br>☪ Fan only - DO NOT USE<br>⚙ Heating (Ideal Temp 20°C)<br>❄ Cooling (Ideal Temp 23°C)<br>💧 Dry Mode - DO NOT USE<br>☑ Auto (Ideal Temp 21°C) |
| 3 | <b>SET IDEAL TEMPERATURE:</b><br>Heating 20°C<br>Cooling 23°C  |
| 4 | TIMER - already fixed (do not adjust)  |
| 5 | FAN SPEED - Leave in low speed   |
| 6 | CASSETTE UNITS ONLY - Fix swing position   |