



### Initial Settings

1. Press "FILTER" and "LOUVRE" to enter (press filter slightly before)
2. Press "GROUP ▲" or "▼" to select group
3. Press "TEMP ▲" or "▼" to select unit
4. Press "FAN SPEED" to store unit in group (ic will appear if successful, 88 if not)
5. Press "FILTER" x2 to delete a unit from a group
6. Press "MODE LOCK" to display all units in a group
7. Press "FILTER" and "LOUVRE" to exit

### Deleting a unit from a group

1. Use steps 1 to 3 above to locate the unit to be removed
2. When the address is displayed press "FILTER" x2 to delete

### Searching for registered units

1. Use steps 1 to 3 above to identify group
2. Press "MODE LOCK" to show units registered in that group

### Interlocking units

1. Press "COL/GROUP" button to open up
2. Select the group with "▲" or "▼"
3. Select the interlocked unit address using temp "▲" or "▼"
4. Press "FAN SPEED" to store (ic and lc will display alternatively if successful 88 if unsuccessful)
5. To remove an interlocked address press "FILTER" x2 when the address is displayed
6. Press "COL/GROUP" button to exit

### Collective deletion

1. Press "FILTER" and "LOUVRE" to access group settings
2. Press and hold "AIR DIRECTION" button for 3 seconds
3. When deleted the controller will flash "HO"