

Wi-Fi INTERFACE


SETUP QUICK REFERENCE GUIDE

Before setting up, read the Safety precautions on the INSTALLATION MANUAL and INSTRUCTION BOOK.











For SETUP MANUAL and MELCloud User Manual, please go to the website below.
<http://www.melcloud.com/Support>

SETUP

 ON  Flashing



Troubleshooting

<p>ERR: OFF NET: OFF</p> 		<p>Try pairing the Wi-Fi interface with the Router.</p>
<p>ERR: Flash (Every 0.5-sec)</p> 	 <p>IP address</p>	<p>Check DHCP settings of the Router. or Check IP address settings of the Wi-Fi interface.</p>
<p>ERR: Flash (Every 1 sec)</p> 	 <p>DNS</p>	<p>Check DNS settings of the Router. or Check DNS address settings of the Wi-Fi interface.</p>
<p>ERR: Flash (Twice every 5 sec)</p> 	 <p>Internet</p>	<p>Check if the Router is connected to the Internet.</p>
<p>MODE: Flash (Once every 5 sec)</p> 	 <p>The Wi-Fi interface is set to Access point mode</p>	<p>Push MODE switch of the Wi-Fi interface for 7 seconds. Try pairing the Router again if the Wi-Fi interface is not connected.</p>