



# Air Conditioning Remote Controller

# User Guide

## PAR-40MAA



### 1 Unit On / Off

 Switches unit on or off

### 2 Mode Selection

Selects desired operation

 Cooling Mode

 Heating Mode

### 3 Temperature Setting

Sets the room temperature

 Temperature Decreases

 Temperature Increases

### 4 Fan Speed Settings

Adjust fan speed as required. Selecting 'Auto' will allow the fan to automatically increase or decrease dependent on current room temperature.

Fan Speed 1  Up to Fan Speed 4  Fan Speed Auto Mode 