

June 2008

 No. OC355
 REVISED EDITION-D



TECHNICAL & SERVICE MANUAL

| [Model name] | [Service Ref.] |
|--------------------------------|---------------------------------|
| <Outdoor unit> PUMY-P100YHM | PUMY-P100YHM |
| PUMY-P100YHMA | PUMY-P100YHM₁ |
| PUMY-P125YHM | PUMY-P100YHMA |
| PUMY-P125YHMA | PUMY-P125YHM |
| PUMY-P140YHM | PUMY-P125YHM₁ |
| PUMY-P140YHMA | PUMY-P125YHMA |
| PUMY-P100YHMA-BS | PUMY-P140YHM |
| PUMY-P125YHMA-BS | PUMY-P140YHM₁ |
| PUMY-P140YHMA-BS | PUMY-P140YHMA |
| | PUMY-P100YHMA-BS |
| | PUMY-P125YHMA-BS |
| | PUMY-P140YHMA-BS |

Revision:

- PUMY-P100/125/140YHMA-BS are added in REVISED EDITION-D.
- Some descriptions have been modified.

- Please void OC355 REVISED EDITION-C.



CONTENTS

| | |
|--|----|
| 1. TECHNICAL CHANGES..... | 2 |
| 2. SAFETY PRECAUTION..... | 2 |
| 3. OVERVIEW OF UNITS..... | 5 |
| 4. SPECIFICATIONS..... | 7 |
| 5. DATA..... | 8 |
| 6. OUTLINES AND DIMENSIONS..... | 18 |
| 7. WIRING DIAGRAM..... | 20 |
| 8. NECESSARY CONDITIONS FOR SYSTEM CONSTRUCTION..... | 22 |
| 9. TROUBLESHOOTING..... | 32 |
| 10. ELECTRICAL WIRING..... | 74 |
| 11. REFRIGERANT PIPING TASKS..... | 77 |
| 12. DISASSEMBLY PROCEDURE..... | 81 |
| 13. PARTS LIST..... | 87 |
| 14. RoHS PARTS LIST..... | 90 |
| 15. OPTIONAL PARTS..... | 93 |

NOTE :

- This service manual describes technical data of outdoor unit. As for indoor units, refer to its service manual.
- RoHS compliant products have <G> mark on spec name plate.
- For servicing of RoHS compliant products, refer to RoHS PARTS LIST.

1

TECHNICAL CHANGES

PUMY-P100YHM₁ → PUMY-P100YHMA
 PUMY-P125YHM₁ → PUMY-P125YHMA
 PUMY-P140YHM₁ → PUMY-P140YHMA

- Compressor and oil have been changed.
 ANB33FDEMT → ANB33FDKMT
 Ester oil → Ether oil
- Electrical parts below have been changed.
 ①Controller board (MULTI.B.) ②Noise filter (N.F.)
- PEFY-P15 can be connected.

PUMY-P100YHM → PUMY-P100YHM₁
 PUMY-P125YHM → PUMY-P125YHM₁
 PUMY-P140YHM → PUMY-P140YHM₁

- The parts below have been changed.
 ①4-way valve and coil (21S4) ②Fan motor (MF1,MF2)
 ③Noise filter circuit board (N.F.) ④Multi controller circuit board (MULTI.B.)

2

SAFETY PRECAUTION

2-1. CAUTIONS RELATED TO NEW REFRIGERANT

Caution for units utilizing refrigerant R410A

Use new refrigerant pipes.

Avoid using thin pipes.

Make sure that the inside and outside of refrigerant piping is clean and it has no contamination such as sulfur hazardous for use, oxides, dirt, shaving particles, etc. In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil etc.

Store the piping to be used during installation indoors and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Use ester oil, ether oil or alkylbenzene oil (small amount) as the refrigerant oil applied to flares and flange connections.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil etc.

Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

Do not use refrigerant other than R410A.

If other refrigerant (R22 etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil etc.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil etc.

Use the following tools specifically designed for use with R410A refrigerant.

The following tools are necessary to use R410A refrigerant.

| Tools for R410A | |
|-------------------|---------------------------------------|
| Gauge manifold | Flare tool |
| Charge hose | Size adjustment gauge |
| Gas leak detector | Vacuum pump adaptor |
| Torque wrench | Electronic refrigerant charging scale |

Keep the tools with care.

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.


[1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) When performing service, install a filter drier simultaneously.
Be sure to use a filter drier for new refrigerant.

[2] Additional refrigerant charge

When charging directly from cylinder

- Check that cylinder for R410A on the market is syphon type.
- Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



[3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

| No. | Tool name | Specifications |
|-----|--------------------------------|--|
| ① | Gauge manifold | ·Only for R410A |
| | | ·Use the existing fitting specifications. (UNF1/2) |
| | | ·Use high-tension side pressure of 5.3MPa·G or over. |
| ② | Charge hose | ·Only for R410A |
| | | ·Use pressure performance of 5.09MPa·G or over. |
| ③ | Electronic scale | — |
| ④ | Gas leak detector | ·Use the detector for R134a, R407C or R410A. |
| ⑤ | Adaptor for reverse flow check | ·Attach on vacuum pump. |
| ⑥ | Refrigerant charge base | — |
| ⑦ | Refrigerant cylinder | ·Only for R410A ·Top of cylinder (Pink) |
| | | ·Cylinder with syphon |
| ⑧ | Refrigerant recovery equipment | — |

2-2. PRECAUTIONS FOR SALT PROOF TYPE "-BS" MODEL

Although "-BS" model has been designed to be resistant to salt damage, observe the following precautions to maintain the performance of the unit.

1. Avoid installing the unit in a location where it will be exposed directly to seawater or sea breeze.
2. If the cover panel may become covered with salt, be sure to install the unit in a location where the salt will be washed away by rainwater. (If a sunshade is installed, rainwater may not clean the panel.)
3. To ensure that water does not collect in the base of the outdoor unit, make sure that the base is level, not at angle. Water collecting in the base of the outdoor unit could cause rust.
4. If the unit is installed in a coastal area, clean the unit with water regularly to remove any salt build-up.
5. If the unit is damaged during installation or maintenance, be sure to repair it.
6. Be sure to check the condition of the unit regularly.
7. Be sure to install the unit in a location with good drainage.

Cautions for refrigerant piping work

New refrigerant R410A is adopted for replacement inverter series. Although the refrigerant piping work for R410A is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R410A is 1.6 time higher than that of R22, their sizes of flared sections and flare nuts are different.

① Thickness of pipes



Because the working pressure of R410A is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 0.7mm or below.)

Diagram below: Piping diameter and thickness

| Nominal dimensions(inch) | Outside diameter (mm) | Thickness (mm) | |
|--------------------------|-----------------------|----------------|-----|
| | | R410A | R22 |
| 1/4 | 6.35 | 0.8 | 0.8 |
| 3/8 | 9.52 | 0.8 | 0.8 |
| 1/2 | 12.70 | 0.8 | 0.8 |
| 5/8 | 15.88 | 1.0 | 1.0 |
| 3/4 | 19.05 | — | 1.0 |

② Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R410A is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants. Therefore, to enhance airtightness and intensity, flare cutting dimension of copper pipe for R410A have been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R410A also have partly been changed to increase intensity as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R410A below. For 1/2 and 5/8 inch, the dimension B changes. Use torque wrench corresponding to each dimension.



Flare cutting dimensions (mm)

| Nominal dimensions(inch) | Outside diameter | Dimension A (mm) | |
|--------------------------|------------------|------------------|------|
| | | R410A | R22 |
| 1/4 | 6.35 | 9.1 | 9.0 |
| 3/8 | 9.52 | 13.2 | 13.0 |
| 1/2 | 12.70 | 16.6 | 16.2 |
| 5/8 | 15.88 | 19.7 | 19.4 |
| 3/4 | 19.05 | — | 23.3 |

Flare nut dimensions (mm)

| Nominal dimensions(inch) | Outside diameter | Dimension B | |
|--------------------------|------------------|-------------|------|
| | | R410A | R22 |
| 1/4 | 6.35 | 17.0 | 17.0 |
| 3/8 | 9.52 | 22.0 | 22.0 |
| 1/2 | 12.70 | 26.0 | 24.0 |
| 5/8 | 15.88 | 29.0 | 27.0 |
| 3/4 | 19.05 | — | 36.0 |

③ Tools for R410A (The following table shows whether conventional tools can be used or not.)

| Tools and materials | Use | R410A tools | Can R22 tools be used? | Can R407C tools be used? |
|--|---|--|--|---|
| Gauge manifold | Air purge, refrigerant charge and operation check | Tool exclusive for R410A | × | × |
| Charge hose | Gas leak check | Tool exclusive for R410A | × | × |
| Gas leak detector | Refrigerant recovery | Tool for HFC refrigerant | × | ○ |
| Refrigerant recovery equipment | Refrigerant charge | Tool exclusive for R410A | × | × |
| Refrigerant cylinder | Apply to flared section | Tool exclusive for R410A | × | × |
| Applied oil | Prevent compressor malfunction when charging refrigerant by spraying liquid refrigerant | Ester oil, ether oil and alkylbenzene oil (minimum amount) | × | Ester oil, ether oil: ○ Alkylbenzene oil: minimum amount |
| Safety charger | Prevent gas from blowing out when detaching charge hose | Tool exclusive for R410A | × | × |
| Charge valve | Vacuum drying and air purge | Tools for other refrigerants can be used if equipped with adopter for reverse flow check | △ (Usable if equipped with adopter for reverse flow) | △ (Usable if equipped with adopter for reverse flow) |
| Vacuum pump | Flaring work of piping | Tools for other refrigerants can be used by adjusting flaring dimension | △ (Usable by adjusting flaring dimension) | △ (Usable by adjusting flaring dimension) |
| Flare tool | Bend the pipes | Tools for other refrigerants can be used | ○ | ○ |
| Bender | Cut the pipes | Tools for other refrigerants can be used | ○ | ○ |
| Pipe cutter | Weld the pipes | Tools for other refrigerants can be used | ○ | ○ |
| Welder and nitrogen gas cylinder | Refrigerant charging | Tools for other refrigerants can be used | ○ | ○ |
| Refrigerant charging scale | Check the degree of vacuum. (Vacuum valve prevents back flow of oil and refrigerant to thermistor vacuum gauge) | Tools for other refrigerants can be used | ○ | ○ |
| Vacuum gauge or thermistor vacuum gauge and vacuum valve | Refrigerant charge | Tool exclusive for R410A | × | — |
| Charging cylinder | | | | |

× : Prepare a new tool. (Use the new tool as the tool exclusive for R410A.)

△ : Tools for other refrigerants can be used under certain conditions.

○ : Tools for other refrigerants can be used.

3


OVERVIEW OF UNITS

3-1. UNIT CONSTRUCTION

| | | | | |
|-----------------------------------|----------------------------|--|--|--|
| Outdoor unit | | 4HP | 5HP | 6HP |
| | | PUMY-P100YHM PUMY-P100YHM ₁ PUMY-P100YHMA (-BS) | PUMY-P125YHM PUMY-P125YHM ₁ PUMY-P125YHMA (-BS) | PUMY-P140YHM PUMY-P140YHM ₁ PUMY-P140YHMA (-BS) |
| Indoor unit that can be connected | Capacity | Type 15(YHMA) / 20(YHM ₍₁₎)~Type 125 | | Type 15(YHMA) / 20(YHM ₍₁₎)~Type 140 |
| | Number of units | 1~ 6 unit | | 1~ 8 unit |
| | Total system wide capacity | 50% ~130% of outdoor unit capacity *2 | | |

| | | | |
|---------------------------|----------------------------|----------------------------|----------------------------|
| | CMY-Y62-G-E | CMY-Y64-G-E | CMY-Y68-G-E |
| Branching pipe components | Branch header (2 branches) | Branch header (4 branches) | Branch header (8 branches) |

| Model | Cassette Ceiling | | | Ceiling Concealed | Ceiling mounted built-in | Wall Mounted | Ceiling Suspended | Floor standing | | Ceiling Concealed (Fresh Air) *1 |
|----------|------------------|------------|------------|-------------------|--------------------------|--------------|-------------------|----------------|-----------|----------------------------------|
| | 4-way flow | 2-way flow | 1-way flow | | | | | Exposed | Concealed | |
| Capacity | PLFY-P | PLFY-P | PMFY-P | PEFY-P | PDFY-P | PKFY-P | PCFY-P | PFFY-P | PFFY-P | PEFY-P |
| 15 | - | - | - | 15VMS(L)-E | - | - | - | - | - | - |
| 20 | 20VCM-E | 20VLM-D-E | 20VBM-E | 20VML-E / VMM-E | 20VM-E | 20VBM-E | - | 20VLEM-E | 20VLRM-E | - |
| 25 | 25VCM-E | 25VLM-D-E | 25VBM-E | 25VML-E / VMM-E | 25VM-E | 25VBM-E | - | 25VLEM-E | 25VLRM-E | - |
| 32 | 32VCM-E/32VBM-E | 32VLM-D-E | 32VBM-E | 32VML-E / VMM-E | 32VM-E | 32VGM-E | - | 32VLEM-E | 32VLRM-E | - |
| 40 | 40VCM-E/40VBM-E | 40VLM-D-E | 40VBM-E | 40VMH-E / VMM-E | 40VM-E | 40VGM-E | 40VGM-E | 40VLEM-E | 40VLRM-E | - |
| 50 | 50VBM-E | 50VLM-D-E | - | 50VMH-E / VMM-E | 50VM-E | 50VGM-E | - | 50VLEM-E | 50VLRM-E | - |
| 63 | 63VBM-E | 63VLM-D-E | - | 63VMH-E / VMM-E | 63VM-E | - | 63VGM-E | 63VLEM-E | 63VLRM-E | - |
| 71 | - | - | - | 71VMH-E / VMM-E | 71VM-E | - | - | - | - | - |
| 80 | 80VBM-E | 80VLM-D-E | - | 80VMH-E / VMM-E | 80VM-E | - | - | - | - | 80VMH-E-F |
| 100 | 100VBM-E | 100VLM-D-E | - | 100VMH-E / VMM-E | 100VM-E | - | 100VGM-E | - | - | - |
| 125 | 125VBM-E | 125VLM-D-E | - | 125VMH-E / VMM-E | 125VM-E | - | 125VGM-E | - | - | - |
| 140 | - | - | - | 140VMM-E | - | - | - | - | - | 140VMH-E-F |



| | | | |
|-------------------|--------------|---|---|
| Remote controller | Name | M-NET remote controller | MA remote controller |
| | Model number | PAR-F27MEA-E | PAR-21MAA |
| | Functions | <ul style="list-style-type: none"> • A handy remote controller for use in conjunction with the Melans centralized management system. • Addresses must be set. | <ul style="list-style-type: none"> • Addresses setting is not necessary. |

*1. PUMY-P·YHM₁/YHMA can connect Fresh Air type indoor unit. (PUMY-P·YHM can NOT connect.)
It is possible only by 1:1 system.

(1 indoor unit of Fresh Air type is connected with 1 outdoor unit.)
Operating temperature range(outdoor temperature) for fresh air type indoor units differ from other indoor units.
Refer to 3-2(3).

*2. When the indoor unit of Fresh Air type is connected with the outdoor unit, the maximum connectable total indoor unit capacity is 110% (100% in case of heating below -5°C [23°F]).

3-2. UNIT SPECIFICATIONS

(1) Outdoor Unit


| Service Ref. | | PUMY-P100YHM PUMY-P100YHM ₁ PUMY-P100YHMA(-BS) | PUMY-P125YHM PUMY-P125YHM ₁ PUMY-P125YHMA (-BS) | PUMY-P140YHM PUMY-P140YHM ₁ PUMY-P140YHMA (-BS) |
|---------------------------|--------------|---|--|--|
| Capacity | Cooling (kW) | 11.2 | 14.0 | 16.0 |
| | Heating (kW) | 12.5 | 16.0 | 18.0 |
| Motor for compressor (kW) | | 1.9 | 2.4 | 2.9 |

Cooling / Heating capacity indicates the maximum value at operation under the following condition.


- *. Cooling Indoor : D.B. 27°C / W.B. 19.0°C
- Outdoor : D.B. 35°C
- Heating Indoor : D.B. 20°C
- Outdoor : D.B. 7°C / W.B. 6°C

(2) Method for identifying MULTI-S model

■ Indoor unit < When using Model 80 >



■ Outdoor unit <When using model 125 >



(3) Operating temperature range

| | Cooling | Heating |
|-------------------------------------|----------------|--------------|
| Indoor-side intake air temperature | W.B. 15~24C | D.B. 15~27C |
| Outdoor-side intake air temperature | D.B. -5~46C *1 | W.B. -15~15C |

Notes D.B. : Dry Bulb Temperature
W.B. : Wet Bulb Temperature

*1. 10~46°C DB : In case of connecting PKFY-P20/P25 type indoor unit.

■ In case of connecting fresh air type indoor unit (Only PUMY-P-YHM₁/YHMA can connect Fresh air type indoor unit.)

| | Capacity of Fresh air type indoor | Cooling | Heating |
|---|-----------------------------------|---------------------------------|-----------------|
| Indoor-side and Outdoor-side intake air temperature | P80 | D.B.21~43°C *2 W.B.15.5~35°C | D.B.-10~20°C *3 |
| | P140 | D.B.21~43°C *2 W.B.15.5~35°C | D.B.-5~20°C *3 |

*2. Thermo-off (FAN-mode) automatically starts if the outdoor temp. is lower than 21°C D.B..

*3. Thermo-off (FAN-mode) automatically starts if the outdoor temp. is higher than 20°C D.B..

4

SPECIFICATIONS

| Service Ref. | | PUMY-P100YHM ₍₁₎ PUMY-P100YHMA PUMY-P100YHMA-BS | PUMY-P125YHM ₍₁₎ PUMY-P125YHMA PUMY-P125YHMA-BS | PUMY-P140YHM ₍₁₎ PUMY-P140YHMA PUMY-P140YHMA-BS |
|---------------------------------|--------------------------|--|--|--|
| Cooling Capacity | kW | 11.2 | 14.0 | 15.5 |
| Heating Capacity | kW | 12.5 | 16.0 | 18.0 |
| Input (Cool) | *3 kW | 3.3 | 4.27 | 5.32 |
| Input Current (Cool) | *3 A | 5.28/5.02/4.84 | 6.83/6.49/6.26 | 8.51/8.09/7.80 |
| Input (Heat) | *3 kW | 3.63 | 4.29 | 5.32 |
| Input Current (Heat) | *3 A | 5.81/5.52/5.32 | 6.87/6.52/6.29 | 8.51/8.09/7.80 |
| EER (Cool) | *3 | 3.39 | 3.28 | 2.91 |
| COP (Heat) | *3 | 3.44 | 3.73 | 3.38 |
| Connectable indoor units (Max.) | | 6 | 8 | 8 |
| Max. Connectable Capacity | kW | 14.5 (130%) | 18.2 (130%) | 20.2 (130%) |
| Power Supply | | 3 phase , 50Hz , 380/400/415V | | |
| Breaker Size | | 16A | 16A | 16A |
| Sound level (Cool/Heat) | dB | 49 / 51 | 50 / 52 | 51 / 53 |
| External finish | | Munsell 3Y 7.8/1.1 | | |
| Refrigerant control | | Linear Expansion Valve | | |
| Compressor | | Hermetic | | |
| Model | | YHM ₍₁₎ :ANB33FDEMT, YHMA:ANB33FDKMT | | |
| Motor output | kW | 1.9 | 2.4 | 2.9 |
| Starting method | | Inverter | | |
| Crankcase heater | W | — | | |
| Heat exchanger | | Plate fin coil (Anti corrosion fin treatment) | | |
| Fan | Fan(drive) × No. | Propeller fan × 2 | | |
| | Fa motor output | kW | | |
| | Airflow | m ³ /min(CFM) | | |
| Dimensions (HxWxD) | W | mm(in.) | | |
| | D | mm(in.) | | |
| | H | mm(in.) | | |
| Weight | kg(lbs) | 140 (309) | | |
| Refrigerant | | R410A | | |
| | Charge | kg(lbs) | | |
| | Oil (Model) | L | | |
| Protection devices | High pressure protection | HP switch | | |
| | Compressor protection | Discharge thermo, Over current detection | | |
| | Fan motor protection | Overheating/Voltage protection | | |
| Total Piping length (Max.) | m | 120 | | |
| Farthest | m | 80 | | |
| Max. Height difference | m | 30 *1 | | |
| Chargeless length | m | 50 | | |
| Piping diameter | Gas | φmm(in.) | | |
| | Liquid | φmm(in.) | | |
| Guranteed operation range | (cool) | -5~ 46°C DB *2 | | |
| | (heat) | -15~ 15°C WB | | |

Rating conditions (JIS B 8616)

Cooling Indoor : D.B. 27°C / W.B. 19°C

Outdoor : D.B. 35°C / W.B. 20°C

Heating Indoor : D.B. 20°C

Outdoor : D.B. 7°C / W.B. 6°C

Note.*1. 20m:

In case of installing outdoor unit lower than indoor unit.

*2. 10~46°C DB: In case of connecting PKFY-P20/P25 type indoor unit.

*3. Electrical data is for only outdoor unit.

5-1. COOLING AND HEATING CAPACITY AND CHARACTERISTICS

5-1-1. Method for obtaining system cooling and heating capacity:

To obtain the system cooling and heating capacity and the electrical characteristics of the outdoor unit, first add up the ratings of all the indoor units connected to the outdoor unit (see table below), and then use this total to find the standard capacity with the help of the tables on 5-2.STANDARD CAPACITY DIAGRAM.

(1) Capacity of indoor unit

| Model Number for indoor unit | Model 15 | Model 20 | Model 25 | Model 32 | Model 40 | Model 50 | Model 63 | Model 71 | Model 80 | Model 100 | Model 125 | Model 140 |
|------------------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|-----------|-----------|-----------|
| Model Capacity | 17 | 22 | 28 | 36 | 45 | 56 | 71 | 80 | 90 | 112 | 140 | 160 |

(2) Sample calculation

① System assembled from indoor and outdoor unit (in this example the total capacity of the indoor units is greater than that of the outdoor unit)

- Outdoor unit PUMY-P125YHM PUMY-P125YHM₁
- Indoor unit PKFY-P25VAM-E × 2 , PLFY-P50VLMD-E × 2

② According to the conditions in ①, the total capacity of the indoor unit will be: $28 \times 2 + 56 \times 2 = 168$

③ The following figures are obtained from the 168 total capacity row of the standard capacity diagram (5-2.):

| Capacity (kW) | | Outdoor unit power consumption (kW) | | Outdoor unit current (A)/400V | |
|---------------|---------|-------------------------------------|---------|-------------------------------|---------|
| Cooling | Heating | Cooling | Heating | Cooling | Heating |
| Ⓐ 14.60 | Ⓑ 16.33 | 4.34 | 3.95 | 6.59 | 6.01 |

5-1-2. Method for obtaining the heating and cooling capacity of an indoor unit:

(1) The capacity of each indoor unit (kW) = the capacity Ⓐ (or Ⓑ) × $\frac{\text{model capacity}}{\text{total model capacity of all indoor units}}$

(2) Sample calculation (using the system described above in 5-1-1. (2)):

During cooling:

- The total model capacity of the indoor unit is:
 $2.8 \times 2 + 5.6 \times 2 = 16.8 \text{ kW}$
 Therefore, the capacity of PKFY-P25VAM-E and PLFY-P50VLMD-E will be calculated as follows by using the formula in 5-1-2. (1):

$$\text{Model 25} = 14.6 \times \frac{2.8}{16.8} = 2.43 \text{ kW}$$

$$\text{Model 50} = 14.6 \times \frac{5.6}{16.8} = 4.87 \text{ kW}$$

During heating:

- The total model capacity of indoor unit is:
 $3.2 \times 2 + 6.3 \times 2 = 19.0$
 Therefore, the capacity of PKFY-P25VAM-E and PLFY-P50VLMD-E will be calculated as follows by using the formula in 5-1-2. (1):

$$\text{Model 25} = 16.33 \times \frac{3.2}{19.0} = 2.75 \text{ kW}$$

$$\text{Model 50} = 16.33 \times \frac{6.3}{19.0} = 5.41 \text{ kW}$$

5-2. STANDARD CAPACITY DIAGRAM

5-2-1.PUMY-P100YHM PUMY-P100YHM₁ PUMY-P100YHMA (-BS)

*Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on 5-1-1.

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 56 | 5.60 | 6.30 | 1.57 | 1.87 | 2.52 | 3.00 | 2.39 | 2.85 | 2.31 | 2.75 |
| 57 | 5.70 | 6.41 | 1.59 | 1.90 | 2.55 | 3.05 | 2.42 | 2.89 | 2.34 | 2.79 |
| 58 | 5.80 | 6.53 | 1.62 | 1.92 | 2.60 | 3.08 | 2.47 | 2.93 | 2.38 | 2.82 |
| 59 | 5.90 | 6.64 | 1.64 | 1.95 | 2.63 | 3.13 | 2.50 | 2.97 | 2.41 | 2.86 |
| 60 | 6.00 | 6.75 | 1.66 | 1.98 | 2.66 | 3.17 | 2.53 | 3.02 | 2.44 | 2.91 |
| 61 | 6.10 | 6.87 | 1.69 | 2.00 | 2.71 | 3.21 | 2.58 | 3.05 | 2.48 | 2.94 |
| 62 | 6.20 | 6.98 | 1.71 | 2.03 | 2.74 | 3.26 | 2.61 | 3.09 | 2.51 | 2.98 |
| 63 | 6.30 | 7.09 | 1.74 | 2.06 | 2.79 | 3.30 | 2.65 | 3.14 | 2.56 | 3.02 |
| 64 | 6.40 | 7.20 | 1.76 | 2.08 | 2.82 | 3.34 | 2.68 | 3.17 | 2.59 | 3.05 |
| 65 | 6.50 | 7.32 | 1.78 | 2.11 | 2.85 | 3.38 | 2.71 | 3.21 | 2.61 | 3.10 |
| 66 | 6.60 | 7.43 | 1.81 | 2.14 | 2.90 | 3.43 | 2.76 | 3.26 | 2.66 | 3.14 |
| 67 | 6.70 | 7.54 | 1.83 | 2.17 | 2.93 | 3.48 | 2.79 | 3.31 | 2.69 | 3.19 |
| 68 | 6.80 | 7.66 | 1.86 | 2.20 | 2.98 | 3.53 | 2.83 | 3.35 | 2.73 | 3.23 |
| 69 | 6.90 | 7.77 | 1.89 | 2.22 | 3.03 | 3.56 | 2.88 | 3.38 | 2.78 | 3.26 |
| 70 | 7.00 | 7.88 | 1.91 | 2.25 | 3.06 | 3.61 | 2.91 | 3.43 | 2.81 | 3.30 |
| 71 | 7.10 | 8.00 | 1.94 | 2.28 | 3.11 | 3.66 | 2.96 | 3.47 | 2.85 | 3.35 |
| 72 | 7.20 | 8.11 | 1.97 | 2.31 | 3.16 | 3.70 | 3.00 | 3.52 | 2.89 | 3.39 |
| 73 | 7.30 | 8.22 | 1.99 | 2.34 | 3.19 | 3.75 | 3.03 | 3.56 | 2.92 | 3.44 |
| 74 | 7.40 | 8.33 | 2.02 | 2.37 | 3.24 | 3.80 | 3.08 | 3.61 | 2.97 | 3.48 |
| 75 | 7.50 | 8.44 | 2.05 | 2.40 | 3.28 | 3.85 | 3.12 | 3.66 | 3.01 | 3.52 |
| 76 | 7.60 | 8.56 | 2.08 | 2.43 | 3.33 | 3.90 | 3.17 | 3.70 | 3.05 | 3.57 |
| 77 | 7.70 | 8.67 | 2.11 | 2.46 | 3.38 | 3.94 | 3.21 | 3.75 | 3.10 | 3.61 |
| 78 | 7.80 | 8.78 | 2.13 | 2.49 | 3.41 | 3.99 | 3.24 | 3.79 | 3.13 | 3.66 |
| 79 | 7.90 | 8.89 | 2.16 | 2.52 | 3.46 | 4.04 | 3.29 | 3.84 | 3.17 | 3.70 |
| 80 | 8.00 | 9.00 | 2.19 | 2.55 | 3.51 | 4.09 | 3.34 | 3.88 | 3.22 | 3.74 |
| 81 | 8.10 | 9.10 | 2.22 | 2.58 | 3.56 | 4.14 | 3.38 | 3.93 | 3.26 | 3.79 |
| 82 | 8.20 | 9.20 | 2.25 | 2.61 | 3.60 | 4.18 | 3.43 | 3.97 | 3.30 | 3.83 |
| 83 | 8.30 | 9.30 | 2.28 | 2.64 | 3.65 | 4.23 | 3.47 | 4.02 | 3.35 | 3.88 |
| 84 | 8.40 | 9.40 | 2.31 | 2.67 | 3.70 | 4.28 | 3.52 | 4.07 | 3.39 | 3.92 |
| 85 | 8.50 | 9.50 | 2.35 | 2.70 | 3.76 | 4.33 | 3.58 | 4.11 | 3.45 | 3.96 |
| 86 | 8.60 | 9.60 | 2.38 | 2.74 | 3.81 | 4.39 | 3.62 | 4.17 | 3.49 | 4.02 |
| 87 | 8.70 | 9.70 | 2.41 | 2.77 | 3.86 | 4.44 | 3.67 | 4.22 | 3.54 | 4.07 |
| 88 | 8.80 | 9.80 | 2.44 | 2.80 | 3.91 | 4.49 | 3.72 | 4.26 | 3.58 | 4.11 |
| 89 | 8.90 | 9.90 | 2.47 | 2.83 | 3.96 | 4.54 | 3.76 | 4.31 | 3.63 | 4.15 |
| 90 | 9.00 | 10.00 | 2.51 | 2.86 | 4.02 | 4.58 | 3.82 | 4.35 | 3.68 | 4.20 |
| 91 | 9.10 | 10.10 | 2.54 | 2.90 | 4.07 | 4.65 | 3.87 | 4.42 | 3.73 | 4.26 |
| 92 | 9.20 | 10.22 | 2.57 | 2.93 | 4.12 | 4.70 | 3.91 | 4.46 | 3.77 | 4.30 |
| 93 | 9.30 | 10.33 | 2.60 | 2.96 | 4.16 | 4.74 | 3.96 | 4.51 | 3.82 | 4.34 |
| 94 | 9.40 | 10.45 | 2.64 | 3.00 | 4.23 | 4.81 | 4.02 | 4.57 | 3.88 | 4.40 |
| 95 | 9.50 | 10.56 | 2.67 | 3.03 | 4.28 | 4.86 | 4.07 | 4.61 | 3.92 | 4.45 |
| 96 | 9.60 | 10.67 | 2.71 | 3.06 | 4.34 | 4.90 | 4.13 | 4.66 | 3.98 | 4.49 |
| 97 | 9.70 | 10.79 | 2.74 | 3.10 | 4.39 | 4.97 | 4.17 | 4.72 | 4.02 | 4.55 |
| 98 | 9.80 | 10.90 | 2.78 | 3.13 | 4.45 | 5.02 | 4.23 | 4.77 | 4.08 | 4.59 |
| 99 | 9.90 | 11.02 | 2.81 | 3.17 | 4.50 | 5.08 | 4.28 | 4.83 | 4.12 | 4.65 |
| 100 | 10.00 | 11.13 | 2.85 | 3.20 | 4.56 | 5.13 | 4.34 | 4.87 | 4.18 | 4.70 |
| 101 | 10.10 | 11.24 | 2.88 | 3.24 | 4.61 | 5.19 | 4.39 | 4.93 | 4.23 | 4.75 |
| 102 | 10.20 | 11.36 | 2.92 | 3.27 | 4.67 | 5.24 | 4.45 | 4.98 | 4.29 | 4.80 |
| 103 | 10.30 | 11.47 | 2.96 | 3.31 | 4.74 | 5.30 | 4.51 | 5.04 | 4.34 | 4.86 |
| 104 | 10.40 | 11.59 | 2.99 | 3.34 | 4.79 | 5.35 | 4.55 | 5.08 | 4.39 | 4.90 |
| 105 | 10.50 | 11.70 | 3.03 | 3.38 | 4.85 | 5.42 | 4.61 | 5.15 | 4.45 | 4.96 |
| 106 | 10.60 | 11.81 | 3.07 | 3.41 | 4.91 | 5.46 | 4.67 | 5.19 | 4.51 | 5.00 |
| 107 | 10.70 | 11.93 | 3.11 | 3.45 | 4.98 | 5.53 | 4.74 | 5.25 | 4.56 | 5.06 |
| 108 | 10.80 | 12.04 | 3.14 | 3.48 | 5.03 | 5.58 | 4.78 | 5.30 | 4.61 | 5.11 |
| 109 | 10.90 | 12.16 | 3.18 | 3.52 | 5.09 | 5.64 | 4.84 | 5.36 | 4.67 | 5.17 |
| 110 | 11.00 | 12.27 | 3.22 | 3.56 | 5.15 | 5.70 | 4.90 | 5.42 | 4.73 | 5.22 |
| 111 | 11.10 | 12.38 | 3.26 | 3.59 | 5.22 | 5.75 | 4.96 | 5.47 | 4.78 | 5.27 |
| 112 | 11.20 | 12.50 | 3.30 | 3.63 | 5.28 | 5.81 | 5.02 | 5.52 | 4.84 | 5.32 |
| 113 | 11.22 | 12.51 | 3.31 | 3.62 | 5.30 | 5.80 | 5.04 | 5.51 | 4.86 | 5.31 |
| 114 | 11.24 | 12.53 | 3.31 | 3.61 | 5.30 | 5.78 | 5.04 | 5.50 | 4.86 | 5.30 |
| 115 | 11.26 | 12.54 | 3.32 | 3.60 | 5.31 | 5.77 | 5.05 | 5.48 | 4.87 | 5.28 |
| 116 | 11.28 | 12.55 | 3.32 | 3.59 | 5.31 | 5.75 | 5.05 | 5.47 | 4.87 | 5.27 |
| 117 | 11.30 | 12.56 | 3.32 | 3.58 | 5.31 | 5.74 | 5.05 | 5.45 | 4.87 | 5.25 |
| 118 | 11.32 | 12.57 | 3.33 | 3.56 | 5.33 | 5.70 | 5.07 | 5.42 | 4.89 | 5.22 |
| 119 | 11.34 | 12.58 | 3.33 | 3.55 | 5.33 | 5.69 | 5.07 | 5.40 | 4.89 | 5.21 |
| 120 | 11.36 | 12.60 | 3.34 | 3.54 | 5.35 | 5.67 | 5.08 | 5.39 | 4.90 | 5.19 |

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 121 | 11.38 | 12.61 | 3.34 | 3.53 | 5.35 | 5.66 | 5.08 | 5.37 | 4.90 | 5.18 |
| 122 | 11.40 | 12.62 | 3.34 | 3.52 | 5.35 | 5.64 | 5.08 | 5.36 | 4.90 | 5.17 |
| 123 | 11.42 | 12.63 | 3.35 | 3.51 | 5.36 | 5.62 | 5.10 | 5.34 | 4.92 | 5.15 |
| 124 | 11.44 | 12.64 | 3.35 | 3.50 | 5.36 | 5.61 | 5.10 | 5.33 | 4.92 | 5.14 |
| 125 | 11.47 | 12.66 | 3.36 | 3.48 | 5.38 | 5.58 | 5.12 | 5.30 | 4.93 | 5.11 |
| 126 | 11.49 | 12.67 | 3.36 | 3.47 | 5.38 | 5.56 | 5.12 | 5.28 | 4.93 | 5.09 |
| 127 | 11.51 | 12.68 | 3.36 | 3.46 | 5.38 | 5.54 | 5.12 | 5.27 | 4.93 | 5.08 |
| 128 | 11.53 | 12.69 | 3.37 | 3.45 | 5.39 | 5.53 | 5.13 | 5.25 | 4.95 | 5.06 |
| 129 | 11.55 | 12.70 | 3.37 | 3.44 | 5.39 | 5.51 | 5.13 | 5.24 | 4.95 | 5.05 |
| 130 | 11.57 | 12.71 | 3.38 | 3.43 | 5.41 | 5.50 | 5.15 | 5.22 | 4.96 | 5.03 |
| 131 | 11.59 | 12.73 | 3.38 | 3.41 | 5.41 | 5.46 | 5.15 | 5.19 | 4.96 | 5.00 |
| 132 | 11.61 | 12.74 | 3.38 | 3.40 | 5.41 | 5.45 | 5.15 | 5.18 | 4.96 | 4.99 |
| 133 | 11.63 | 12.75 | 3.39 | 3.39 | 5.43 | 5.43 | 5.16 | 5.16 | 4.97 | 4.97 |
| 134 | 11.65 | 12.76 | 3.39 | 3.38 | 5.43 | 5.42 | 5.16 | 5.15 | 4.97 | 4.96 |
| 135 | 11.67 | 12.77 | 3.40 | 3.37 | 5.44 | 5.40 | 5.18 | 5.13 | 4.99 | 4.95 |
| 136 | 11.69 | 12.78 | 3.40 | 3.36 | 5.44 | 5.38 | 5.18 | 5.12 | 4.99 | 4.93 |
| 137 | 11.71 | 12.80 | 3.40 | 3.34 | 5.44 | 5.35 | 5.18 | 5.08 | 4.99 | 4.90 |
| 138 | 11.73 | 12.81 | 3.41 | 3.33 | 5.46 | 5.34 | 5.19 | 5.07 | 5.00 | 4.89 |
| 139 | 11.75 | 12.82 | 3.41 | 3.32 | 5.46 | 5.32 | 5.19 | 5.05 | 5.00 | 4.87 |
| 140 | 11.77 | 12.83 | 3.42 | 3.31 | 5.47 | 5.30 | 5.21 | 5.04 | 5.02 | 4.86 |
| 141 | 11.79 | 12.84 | 3.42 | 3.30 | 5.47 | 5.29 | 5.21 | 5.02 | 5.02 | 4.84 |
| 142 | 11.82 | 12.86 | 3.42 | 3.29 | 5.47 | 5.27 | 5.21 | 5.01 | 5.02 | 4.83 |
| 143 | 11.84 | 12.87 | 3.43 | 3.27 | 5.49 | 5.24 | 5.22 | 4.98 | 5.03 | 4.80 |
| 144 | 11.86 | 12.88 | 3.43 | 3.26 | 5.49 | 5.22 | 5.22 | 4.96 | 5.03 | 4.78 |
| 145 | 11.88 | 12.89 | 3.44 | 3.25 | 5.51 | 5.21 | 5.24 | 4.95 | 5.05 | 4.77 |

5-2-2.PUMY-P125YHM PUMY-P125YHM: PUMY-P125YHMA (-BS)

*Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on 5-1-1.

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 70 | 7.00 | 7.88 | 1.80 | 2.04 | 2.88 | 3.27 | 2.74 | 3.10 | 2.64 | 3.00 |
| 71 | 7.10 | 8.00 | 1.83 | 2.06 | 2.93 | 3.30 | 2.79 | 3.13 | 2.69 | 3.02 |
| 72 | 7.20 | 8.11 | 1.85 | 2.09 | 2.96 | 3.35 | 2.82 | 3.18 | 2.72 | 3.07 |
| 73 | 7.30 | 8.22 | 1.88 | 2.11 | 3.01 | 3.38 | 2.86 | 3.21 | 2.76 | 3.10 |
| 74 | 7.40 | 8.33 | 1.91 | 2.14 | 3.06 | 3.43 | 2.91 | 3.26 | 2.81 | 3.14 |
| 75 | 7.50 | 8.44 | 1.93 | 2.17 | 3.09 | 3.48 | 2.94 | 3.30 | 2.83 | 3.19 |
| 76 | 7.60 | 8.56 | 1.96 | 2.19 | 3.14 | 3.51 | 2.98 | 3.33 | 2.88 | 3.22 |
| 77 | 7.70 | 8.67 | 1.99 | 2.22 | 3.19 | 3.56 | 3.03 | 3.38 | 2.92 | 3.26 |
| 78 | 7.80 | 8.78 | 2.01 | 2.25 | 3.22 | 3.61 | 3.06 | 3.42 | 2.95 | 3.30 |
| 79 | 7.90 | 8.89 | 2.04 | 2.28 | 3.27 | 3.66 | 3.10 | 3.47 | 3.00 | 3.35 |
| 80 | 8.00 | 9.00 | 2.07 | 2.30 | 3.32 | 3.69 | 3.15 | 3.50 | 3.04 | 3.38 |
| 81 | 8.10 | 9.10 | 2.10 | 2.33 | 3.36 | 3.74 | 3.20 | 3.55 | 3.08 | 3.42 |
| 82 | 8.20 | 9.20 | 2.12 | 2.36 | 3.40 | 3.78 | 3.23 | 3.59 | 3.11 | 3.46 |
| 83 | 8.30 | 9.30 | 2.15 | 2.39 | 3.44 | 3.83 | 3.27 | 3.64 | 3.16 | 3.51 |
| 84 | 8.40 | 9.40 | 2.18 | 2.42 | 3.49 | 3.88 | 3.32 | 3.68 | 3.20 | 3.55 |
| 85 | 8.50 | 9.50 | 2.21 | 2.44 | 3.54 | 3.91 | 3.36 | 3.71 | 3.24 | 3.58 |
| 86 | 8.60 | 9.60 | 2.24 | 2.47 | 3.59 | 3.96 | 3.41 | 3.76 | 3.29 | 3.63 |
| 87 | 8.70 | 9.70 | 2.27 | 2.50 | 3.64 | 4.01 | 3.45 | 3.80 | 3.33 | 3.67 |
| 88 | 8.80 | 9.80 | 2.30 | 2.53 | 3.68 | 4.06 | 3.50 | 3.85 | 3.38 | 3.71 |
| 89 | 8.90 | 9.90 | 2.33 | 2.56 | 3.73 | 4.10 | 3.55 | 3.89 | 3.42 | 3.76 |
| 90 | 9.00 | 10.00 | 2.36 | 2.59 | 3.78 | 4.15 | 3.59 | 3.94 | 3.46 | 3.80 |
| 91 | 9.10 | 10.10 | 2.39 | 2.62 | 3.83 | 4.20 | 3.64 | 3.99 | 3.51 | 3.85 |
| 92 | 9.20 | 10.22 | 2.42 | 2.65 | 3.88 | 4.25 | 3.68 | 4.03 | 3.55 | 3.89 |
| 93 | 9.30 | 10.33 | 2.45 | 2.68 | 3.92 | 4.30 | 3.73 | 4.08 | 3.60 | 3.93 |
| 94 | 9.40 | 10.45 | 2.49 | 2.71 | 3.99 | 4.34 | 3.79 | 4.12 | 3.66 | 3.98 |
| 95 | 9.50 | 10.56 | 2.52 | 2.74 | 4.04 | 4.39 | 3.83 | 4.17 | 3.70 | 4.02 |
| 96 | 9.60 | 10.67 | 2.55 | 2.77 | 4.08 | 4.44 | 3.88 | 4.21 | 3.74 | 4.07 |
| 97 | 9.70 | 10.79 | 2.58 | 2.80 | 4.13 | 4.49 | 3.92 | 4.26 | 3.79 | 4.11 |
| 98 | 9.80 | 10.90 | 2.62 | 2.83 | 4.20 | 4.54 | 3.99 | 4.30 | 3.85 | 4.15 |
| 99 | 9.90 | 11.02 | 2.65 | 2.86 | 4.24 | 4.58 | 4.03 | 4.35 | 3.89 | 4.20 |
| 100 | 10.00 | 11.13 | 2.68 | 2.89 | 4.29 | 4.63 | 4.08 | 4.40 | 3.93 | 4.24 |
| 101 | 10.10 | 11.24 | 2.72 | 2.92 | 4.36 | 4.68 | 4.14 | 4.44 | 3.99 | 4.29 |
| 102 | 10.20 | 11.36 | 2.75 | 2.96 | 4.40 | 4.74 | 4.18 | 4.50 | 4.04 | 4.34 |
| 103 | 10.30 | 11.47 | 2.79 | 2.99 | 4.47 | 4.79 | 4.24 | 4.55 | 4.10 | 4.39 |
| 104 | 10.40 | 11.59 | 2.82 | 3.02 | 4.52 | 4.84 | 4.29 | 4.59 | 4.14 | 4.43 |
| 105 | 10.50 | 11.70 | 2.86 | 3.05 | 4.58 | 4.89 | 4.35 | 4.64 | 4.20 | 4.48 |
| 106 | 10.60 | 11.81 | 2.89 | 3.08 | 4.63 | 4.94 | 4.40 | 4.68 | 4.24 | 4.52 |
| 107 | 10.70 | 11.93 | 2.93 | 3.12 | 4.69 | 5.00 | 4.46 | 4.75 | 4.30 | 4.58 |
| 108 | 10.80 | 12.04 | 2.96 | 3.15 | 4.74 | 5.05 | 4.50 | 4.79 | 4.34 | 4.62 |
| 109 | 10.90 | 12.16 | 3.00 | 3.18 | 4.80 | 5.10 | 4.56 | 4.84 | 4.40 | 4.67 |
| 110 | 11.00 | 12.27 | 3.04 | 3.21 | 4.87 | 5.14 | 4.62 | 4.88 | 4.46 | 4.71 |
| 111 | 11.10 | 12.38 | 3.07 | 3.25 | 4.91 | 5.21 | 4.67 | 4.94 | 4.51 | 4.77 |
| 112 | 11.20 | 12.50 | 3.11 | 3.28 | 4.98 | 5.26 | 4.73 | 4.99 | 4.56 | 4.81 |
| 113 | 11.30 | 12.63 | 3.15 | 3.31 | 5.04 | 5.30 | 4.79 | 5.03 | 4.62 | 4.86 |
| 114 | 11.40 | 12.75 | 3.19 | 3.35 | 5.11 | 5.37 | 4.85 | 5.09 | 4.68 | 4.92 |
| 115 | 11.50 | 12.88 | 3.22 | 3.38 | 5.15 | 5.42 | 4.90 | 5.14 | 4.73 | 4.96 |
| 116 | 11.60 | 13.00 | 3.26 | 3.42 | 5.22 | 5.48 | 4.96 | 5.20 | 4.78 | 5.02 |
| 117 | 11.70 | 13.13 | 3.30 | 3.45 | 5.28 | 5.53 | 5.02 | 5.25 | 4.84 | 5.06 |
| 118 | 11.80 | 13.25 | 3.34 | 3.49 | 5.35 | 5.59 | 5.08 | 5.31 | 4.90 | 5.12 |
| 119 | 11.90 | 13.38 | 3.38 | 3.52 | 5.41 | 5.64 | 5.14 | 5.35 | 4.96 | 5.17 |
| 120 | 12.00 | 13.50 | 3.42 | 3.55 | 5.47 | 5.69 | 5.20 | 5.40 | 5.02 | 5.21 |
| 121 | 12.10 | 13.63 | 3.46 | 3.59 | 5.54 | 5.75 | 5.26 | 5.46 | 5.08 | 5.27 |
| 122 | 12.20 | 13.75 | 3.50 | 3.62 | 5.60 | 5.80 | 5.32 | 5.51 | 5.14 | 5.31 |
| 123 | 12.30 | 13.88 | 3.54 | 3.66 | 5.67 | 5.86 | 5.38 | 5.57 | 5.19 | 5.37 |
| 124 | 12.40 | 14.00 | 3.58 | 3.70 | 5.73 | 5.93 | 5.44 | 5.63 | 5.25 | 5.43 |
| 125 | 12.50 | 14.13 | 3.62 | 3.73 | 5.79 | 5.98 | 5.51 | 5.67 | 5.31 | 5.47 |
| 126 | 12.60 | 14.25 | 3.66 | 3.77 | 5.86 | 6.04 | 5.57 | 5.73 | 5.37 | 5.53 |
| 127 | 12.70 | 14.38 | 3.70 | 3.80 | 5.92 | 6.09 | 5.63 | 5.78 | 5.43 | 5.58 |
| 128 | 12.80 | 14.50 | 3.74 | 3.84 | 5.99 | 6.15 | 5.69 | 5.84 | 5.49 | 5.63 |
| 129 | 12.90 | 14.63 | 3.79 | 3.88 | 6.07 | 6.22 | 5.76 | 5.90 | 5.56 | 5.69 |
| 130 | 13.00 | 14.75 | 3.83 | 3.91 | 6.13 | 6.26 | 5.82 | 5.95 | 5.62 | 5.74 |

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 131 | 13.10 | 14.88 | 3.87 | 3.95 | 6.19 | 6.33 | 5.88 | 6.01 | 5.68 | 5.80 |
| 132 | 13.20 | 15.00 | 3.91 | 3.99 | 6.26 | 6.39 | 5.95 | 6.07 | 5.74 | 5.85 |
| 133 | 13.30 | 15.13 | 3.96 | 4.02 | 6.34 | 6.44 | 6.02 | 6.11 | 5.81 | 5.90 |
| 134 | 13.40 | 15.25 | 4.00 | 4.06 | 6.40 | 6.51 | 6.08 | 6.17 | 5.87 | 5.96 |
| 135 | 13.50 | 15.38 | 4.04 | 4.10 | 6.47 | 6.57 | 6.14 | 6.23 | 5.93 | 6.02 |
| 136 | 13.60 | 15.50 | 4.09 | 4.14 | 6.55 | 6.63 | 6.22 | 6.30 | 6.00 | 6.07 |
| 137 | 13.70 | 15.63 | 4.13 | 4.17 | 6.61 | 6.68 | 6.28 | 6.34 | 6.06 | 6.12 |
| 138 | 13.80 | 15.75 | 4.18 | 4.21 | 6.69 | 6.75 | 6.36 | 6.40 | 6.13 | 6.18 |
| 139 | 13.90 | 15.88 | 4.22 | 4.25 | 6.75 | 6.81 | 6.42 | 6.46 | 6.19 | 6.24 |
| 140 | 14.00 | 16.00 | 4.27 | 4.29 | 6.83 | 6.87 | 6.49 | 6.52 | 6.26 | 6.29 |
| 141 | 14.02 | 16.01 | 4.28 | 4.28 | 6.84 | 6.86 | 6.50 | 6.51 | 6.27 | 6.28 |
| 142 | 14.04 | 16.02 | 4.28 | 4.27 | 6.85 | 6.84 | 6.50 | 6.49 | 6.28 | 6.26 |
| 143 | 14.06 | 16.03 | 4.28 | 4.26 | 6.85 | 6.82 | 6.51 | 6.47 | 6.28 | 6.24 |
| 144 | 14.08 | 16.04 | 4.28 | 4.24 | 6.85 | 6.80 | 6.51 | 6.45 | 6.28 | 6.23 |
| 145 | 14.10 | 16.06 | 4.28 | 4.23 | 6.86 | 6.78 | 6.51 | 6.43 | 6.29 | 6.21 |
| 146 | 14.12 | 16.07 | 4.29 | 4.22 | 6.86 | 6.76 | 6.52 | 6.42 | 6.29 | 6.19 |
| 147 | 14.15 | 16.08 | 4.29 | 4.21 | 6.86 | 6.74 | 6.52 | 6.40 | 6.29 | 6.17 |
| 148 | 14.17 | 16.09 | 4.29 | 4.19 | 6.87 | 6.72 | 6.52 | 6.38 | 6.29 | 6.15 |
| 149 | 14.19 | 16.10 | 4.29 | 4.18 | 6.87 | 6.70 | 6.53 | 6.36 | 6.30 | 6.14 |
| 150 | 14.21 | 16.12 | 4.30 | 4.17 | 6.87 | 6.68 | 6.53 | 6.34 | 6.30 | 6.12 |
| 151 | 14.23 | 16.13 | 4.30 | 4.16 | 6.88 | 6.66 | 6.53 | 6.32 | 6.30 | 6.10 |
| 152 | 14.25 | 16.14 | 4.30 | 4.15 | 6.88 | 6.64 | 6.54 | 6.31 | 6.31 | 6.08 |
| 153 | 14.27 | 16.15 | 4.30 | 4.13 | 6.88 | 6.62 | 6.54 | 6.29 | 6.31 | 6.07 |
| 154 | 14.30 | 16.16 | 4.30 | 4.12 | 6.89 | 6.61 | 6.54 | 6.27 | 6.31 | 6.05 |
| 155 | 14.32 | 16.17 | 4.31 | 4.11 | 6.89 | 6.59 | 6.55 | 6.25 | 6.32 | 6.03 |
| 156 | 14.34 | 16.19 | 4.31 | 4.10 | 6.90 | 6.57 | 6.55 | 6.23 | 6.32 | 6.01 |
| 157 | 14.36 | 16.20 | 4.31 | 4.09 | 6.90 | 6.55 | 6.55 | 6.21 | 6.32 | 6.00 |
| 158 | 14.38 | 16.21 | 4.31 | 4.07 | 6.90 | 6.53 | 6.56 | 6.20 | 6.33 | 5.98 |
| 159 | 14.40 | 16.22 | 4.32 | 4.06 | 6.91 | 6.51 | 6.56 | 6.18 | 6.33 | 5.96 |
| 160 | 14.42 | 16.23 | 4.32 | 4.05 | 6.91 | 6.49 | 6.56 | 6.16 | 6.33 | 5.94 |
| 161 | 14.45 | 16.25 | 4.32 | 4.04 | 6.91 | 6.47 | 6.57 | 6.14 | 6.34 | 5.92 |
| 162 | 14.47 | 16.26 | 4.32 | 4.03 | 6.92 | 6.45 | 6.57 | 6.12 | 6.34 | 5.91 |
| 163 | 14.49 | 16.27 | 4.32 | 4.01 | 6.92 | 6.43 | 6.57 | 6.10 | 6.34 | 5.89 |
| 164 | 14.51 | 16.28 | 4.33 | 4.00 | 6.92 | 6.41 | 6.58 | 6.09 | 6.35 | 5.87 |
| 165 | 14.53 | 16.29 | 4.33 | 3.99 | 6.93 | 6.39 | 6.58 | 6.07 | 6.35 | 5.85 |
| 166 | 14.55 | 16.31 | 4.33 | 3.98 | 6.93 | 6.37 | 6.58 | 6.05 | 6.35 | 5.84 |
| 167 | 14.57 | 16.32 | 4.33 | 3.97 | 6.93 | 6.35 | 6.59 | 6.03 | 6.36 | 5.82 |
| 168 | 14.60 | 16.33 | 4.34 | 3.95 | 6.94 | 6.33 | 6.59 | 6.01 | 6.36 | 5.80 |
| 169 | 14.62 | 16.34 | 4.34 | 3.94 | 6.94 | 6.32 | 6.59 | 5.99 | 6.36 | 5.78 |
| 170 | 14.64 | 16.35 | 4.34 | 3.93 | 6.95 | 6.30 | 6.60 | 5.98 | 6.37 | 5.77 |
| 171 | 14.66 | 16.36 | 4.34 | 3.92 | 6.95 | 6.28 | 6.60 | 5.96 | 6.37 | 5.75 |
| 172 | 14.68 | 16.38 | 4.34 | 3.91 | 6.95 | 6.26 | 6.61 | 5.94 | 6.37 | 5.73 |
| 173 | 14.70 | 16.39 | 4.35 | 3.89 | 6.96 | 6.24 | 6.61 | 5.92 | 6.38 | 5.71 |
| 174 | 14.72 | 16.40 | 4.35 | 3.88 | 6.96 | 6.22 | 6.61 | 5.90 | 6.38 | 5.69 |
| 175 | 14.75 | 16.41 | 4.35 | 3.87 | 6.96 | 6.20 | 6.62 | 5.88 | 6.38 | 5.68 |
| 176 | 14.77 | 16.42 | 4.35 | 3.86 | 6.97 | 6.18 | 6.62 | 5.87 | 6.39 | 5.66 |
| 177 | 14.79 | 16.44 | 4.36 | 3.84 | 6.97 | 6.16 | 6.62 | 5.85 | 6.39 | 5.64 |
| 178 | 14.81 | 16.45 | 4.36 | 3.83 | 6.97 | 6.14 | 6.63 | 5.83 | 6.39 | 5.62 |
| 179 | 14.83 | 16.46 | 4.36 | 3.82 | 6.98 | 6.12 | 6.63 | 5.81 | 6.40 | 5.61 |
| 180 | 14.85 | 16.47 | 4.36 | 3.81 | 6.98 | 6.10 | 6.63 | 5.79 | 6.40 | 5.59 |
| 181 | 14.87 | 16.48 | 4.36 | 3.80 | 6.98 | 6.08 | 6.64 | 5.77 | 6.40 | 5.57 |
| 182 | 14.89 | 16.50 | 4.37 | 3.78 | 6.99 | 6.06 | 6.64 | 5.76 | 6.41 | 5.55 |

5-2-3.PUMY-P140YHM PUMY-P140YHM; PUMY-P140YHMA (-BS)

*Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on 5-1-1.

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 80 | 8.00 | 9.00 | 2.34 | 2.73 | 3.75 | 4.37 | 3.56 | 4.16 | 3.44 | 4.01 |
| 81 | 8.10 | 9.10 | 2.37 | 2.76 | 3.80 | 4.42 | 3.61 | 4.20 | 3.48 | 4.05 |
| 82 | 8.20 | 9.20 | 2.40 | 2.79 | 3.84 | 4.47 | 3.66 | 4.25 | 3.52 | 4.10 |
| 83 | 8.30 | 9.30 | 2.43 | 2.82 | 3.89 | 4.52 | 3.70 | 4.29 | 3.57 | 4.14 |
| 84 | 8.40 | 9.40 | 2.46 | 2.86 | 3.94 | 4.58 | 3.75 | 4.35 | 3.61 | 4.20 |
| 85 | 8.50 | 9.50 | 2.49 | 2.89 | 3.99 | 4.63 | 3.79 | 4.40 | 3.66 | 4.24 |
| 86 | 8.60 | 9.60 | 2.53 | 2.92 | 4.05 | 4.67 | 3.85 | 4.45 | 3.71 | 4.29 |
| 87 | 8.70 | 9.70 | 2.56 | 2.95 | 4.10 | 4.72 | 3.90 | 4.49 | 3.76 | 4.33 |
| 88 | 8.80 | 9.80 | 2.59 | 2.98 | 4.15 | 4.77 | 3.94 | 4.54 | 3.80 | 4.37 |
| 89 | 8.90 | 9.90 | 2.62 | 3.01 | 4.20 | 4.82 | 3.99 | 4.58 | 3.85 | 4.42 |
| 90 | 9.00 | 10.00 | 2.66 | 3.04 | 4.26 | 4.87 | 4.05 | 4.63 | 3.90 | 4.46 |
| 91 | 9.10 | 10.11 | 2.69 | 3.08 | 4.31 | 4.93 | 4.10 | 4.69 | 3.95 | 4.52 |
| 92 | 9.20 | 10.23 | 2.72 | 3.11 | 4.36 | 4.98 | 4.14 | 4.74 | 3.99 | 4.56 |
| 93 | 9.30 | 10.34 | 2.76 | 3.14 | 4.42 | 5.03 | 4.20 | 4.78 | 4.05 | 4.61 |
| 94 | 9.40 | 10.46 | 2.79 | 3.17 | 4.47 | 5.07 | 4.25 | 4.83 | 4.10 | 4.65 |
| 95 | 9.50 | 10.57 | 2.83 | 3.21 | 4.53 | 5.14 | 4.31 | 4.89 | 4.15 | 4.71 |
| 96 | 9.60 | 10.68 | 2.86 | 3.24 | 4.58 | 5.19 | 4.35 | 4.93 | 4.20 | 4.75 |
| 97 | 9.70 | 10.80 | 2.89 | 3.27 | 4.63 | 5.23 | 4.40 | 4.98 | 4.24 | 4.80 |
| 98 | 9.80 | 10.91 | 2.93 | 3.30 | 4.69 | 5.28 | 4.46 | 5.02 | 4.30 | 4.84 |
| 99 | 9.90 | 11.03 | 2.97 | 3.34 | 4.75 | 5.35 | 4.52 | 5.08 | 4.36 | 4.90 |
| 100 | 10.00 | 11.14 | 3.00 | 3.37 | 4.80 | 5.39 | 4.57 | 5.13 | 4.40 | 4.95 |
| 101 | 10.10 | 11.25 | 3.04 | 3.40 | 4.87 | 5.44 | 4.63 | 5.18 | 4.46 | 4.99 |
| 102 | 10.20 | 11.37 | 3.07 | 3.43 | 4.91 | 5.49 | 4.67 | 5.22 | 4.51 | 5.03 |
| 103 | 10.30 | 11.48 | 3.11 | 3.47 | 4.98 | 5.55 | 4.74 | 5.28 | 4.56 | 5.09 |
| 104 | 10.40 | 11.60 | 3.14 | 3.50 | 5.03 | 5.60 | 4.78 | 5.33 | 4.61 | 5.14 |
| 105 | 10.50 | 11.71 | 3.18 | 3.53 | 5.09 | 5.65 | 4.84 | 5.37 | 4.67 | 5.18 |
| 106 | 10.60 | 11.82 | 3.22 | 3.57 | 5.15 | 5.71 | 4.90 | 5.43 | 4.73 | 5.24 |
| 107 | 10.70 | 11.94 | 3.26 | 3.60 | 5.22 | 5.76 | 4.96 | 5.48 | 4.78 | 5.28 |
| 108 | 10.80 | 12.05 | 3.29 | 3.63 | 5.27 | 5.81 | 5.01 | 5.53 | 4.83 | 5.33 |
| 109 | 10.90 | 12.17 | 3.33 | 3.67 | 5.33 | 5.87 | 5.07 | 5.59 | 4.89 | 5.39 |
| 110 | 11.00 | 12.28 | 3.37 | 3.70 | 5.39 | 5.92 | 5.13 | 5.63 | 4.95 | 5.43 |
| 111 | 11.10 | 12.39 | 3.41 | 3.74 | 5.46 | 5.99 | 5.19 | 5.69 | 5.00 | 5.49 |
| 112 | 11.20 | 12.51 | 3.45 | 3.77 | 5.52 | 6.03 | 5.25 | 5.74 | 5.06 | 5.53 |
| 113 | 11.30 | 12.63 | 3.48 | 3.80 | 5.57 | 6.08 | 5.30 | 5.78 | 5.11 | 5.58 |
| 114 | 11.40 | 12.75 | 3.52 | 3.84 | 5.63 | 6.15 | 5.36 | 5.85 | 5.17 | 5.63 |
| 115 | 11.50 | 12.88 | 3.56 | 3.87 | 5.70 | 6.19 | 5.42 | 5.89 | 5.22 | 5.68 |
| 116 | 11.60 | 13.00 | 3.60 | 3.91 | 5.76 | 6.26 | 5.48 | 5.95 | 5.28 | 5.74 |
| 117 | 11.70 | 13.13 | 3.64 | 3.94 | 5.83 | 6.31 | 5.54 | 6.00 | 5.34 | 5.78 |
| 118 | 11.80 | 13.25 | 3.68 | 3.98 | 5.89 | 6.37 | 5.60 | 6.06 | 5.40 | 5.84 |
| 119 | 11.90 | 13.38 | 3.72 | 4.01 | 5.95 | 6.42 | 5.66 | 6.10 | 5.46 | 5.88 |
| 120 | 12.00 | 13.50 | 3.76 | 4.05 | 6.02 | 6.48 | 5.72 | 6.16 | 5.52 | 5.94 |
| 121 | 12.10 | 13.63 | 3.80 | 4.08 | 6.08 | 6.53 | 5.78 | 6.21 | 5.58 | 5.99 |
| 122 | 12.20 | 13.75 | 3.84 | 4.12 | 6.15 | 6.59 | 5.85 | 6.27 | 5.63 | 6.04 |
| 123 | 12.30 | 13.88 | 3.88 | 4.15 | 6.21 | 6.64 | 5.91 | 6.32 | 5.69 | 6.09 |
| 124 | 12.40 | 14.00 | 3.92 | 4.19 | 6.27 | 6.71 | 5.97 | 6.38 | 5.75 | 6.15 |
| 125 | 12.50 | 14.13 | 3.97 | 4.22 | 6.35 | 6.75 | 6.04 | 6.42 | 5.82 | 6.19 |
| 126 | 12.60 | 14.25 | 4.01 | 4.26 | 6.42 | 6.82 | 6.10 | 6.48 | 5.88 | 6.25 |
| 127 | 12.70 | 14.38 | 4.05 | 4.29 | 6.48 | 6.87 | 6.16 | 6.53 | 5.94 | 6.29 |
| 128 | 12.80 | 14.50 | 4.09 | 4.33 | 6.55 | 6.93 | 6.23 | 6.59 | 6.00 | 6.35 |
| 129 | 12.90 | 14.63 | 4.13 | 4.36 | 6.61 | 6.98 | 6.29 | 6.64 | 6.06 | 6.40 |
| 130 | 13.00 | 14.75 | 4.18 | 4.40 | 6.69 | 7.04 | 6.36 | 6.70 | 6.13 | 6.46 |
| 131 | 13.10 | 14.88 | 4.22 | 4.44 | 6.75 | 7.11 | 6.42 | 6.76 | 6.19 | 6.51 |
| 132 | 13.20 | 15.00 | 4.26 | 4.47 | 6.82 | 7.15 | 6.48 | 6.80 | 6.25 | 6.56 |
| 133 | 13.30 | 15.13 | 4.31 | 4.51 | 6.90 | 7.22 | 6.56 | 6.86 | 6.32 | 6.62 |
| 134 | 13.40 | 15.25 | 4.35 | 4.54 | 6.96 | 7.27 | 6.62 | 6.91 | 6.38 | 6.66 |
| 135 | 13.50 | 15.38 | 4.39 | 4.58 | 7.03 | 7.33 | 6.68 | 6.97 | 6.44 | 6.72 |
| 136 | 13.60 | 15.50 | 4.44 | 4.62 | 7.11 | 7.39 | 6.76 | 7.03 | 6.51 | 6.78 |
| 137 | 13.70 | 15.63 | 4.48 | 4.65 | 7.17 | 7.44 | 6.82 | 7.08 | 6.57 | 6.82 |
| 138 | 13.80 | 15.75 | 4.53 | 4.69 | 7.25 | 7.51 | 6.89 | 7.14 | 6.65 | 6.88 |
| 139 | 13.90 | 15.88 | 4.57 | 4.73 | 7.31 | 7.57 | 6.96 | 7.20 | 6.70 | 6.94 |
| 140 | 14.00 | 16.00 | 4.62 | 4.76 | 7.39 | 7.62 | 7.03 | 7.24 | 6.78 | 6.98 |
| 141 | 14.10 | 16.13 | 4.66 | 4.80 | 7.46 | 7.68 | 7.09 | 7.31 | 6.84 | 7.04 |
| 142 | 14.20 | 16.26 | 4.71 | 4.84 | 7.54 | 7.75 | 7.17 | 7.37 | 6.91 | 7.10 |
| 143 | 14.30 | 16.40 | 4.76 | 4.87 | 7.62 | 7.79 | 7.24 | 7.41 | 6.98 | 7.14 |

| Total capacity of indoor units * | Capacity(kW) | | Power Consumption(kW) | | Current(A)/380V | | Current(A)/400V | | Current(A)/415V | |
|----------------------------------|--------------|---------|-----------------------|---------|-----------------|---------|-----------------|---------|-----------------|---------|
| | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating | Cooling | Heating |
| 144 | 14.40 | 16.53 | 4.80 | 4.91 | 7.68 | 7.86 | 7.31 | 7.47 | 7.04 | 7.20 |
| 145 | 14.50 | 16.66 | 4.85 | 4.95 | 7.76 | 7.92 | 7.38 | 7.53 | 7.11 | 7.26 |
| 146 | 14.60 | 16.80 | 4.89 | 4.99 | 7.83 | 7.99 | 7.44 | 7.59 | 7.17 | 7.32 |
| 147 | 14.70 | 16.93 | 4.94 | 5.02 | 7.91 | 8.03 | 7.52 | 7.64 | 7.25 | 7.36 |
| 148 | 14.80 | 17.06 | 4.99 | 5.06 | 7.99 | 8.10 | 7.59 | 7.70 | 7.32 | 7.42 |
| 149 | 14.90 | 17.20 | 5.04 | 5.10 | 8.07 | 8.16 | 7.67 | 7.76 | 7.39 | 7.48 |
| 150 | 15.00 | 17.33 | 5.08 | 5.14 | 8.13 | 8.23 | 7.73 | 7.82 | 7.45 | 7.54 |
| 151 | 15.10 | 17.46 | 5.13 | 5.17 | 8.21 | 8.27 | 7.81 | 7.87 | 7.53 | 7.58 |
| 152 | 15.20 | 17.60 | 5.18 | 5.21 | 8.29 | 8.34 | 7.88 | 7.93 | 7.60 | 7.64 |
| 153 | 15.30 | 17.73 | 5.23 | 5.25 | 8.37 | 8.40 | 7.96 | 7.99 | 7.67 | 7.70 |
| 154 | 15.40 | 17.86 | 5.28 | 5.29 | 8.45 | 8.47 | 8.04 | 8.05 | 7.75 | 7.76 |
| 155 | 15.50 | 18.00 | 5.32 | 5.32 | 8.51 | 8.51 | 8.09 | 8.09 | 7.80 | 7.80 |
| 156 | 15.51 | 18.01 | 5.32 | 5.31 | 8.52 | 8.49 | 8.10 | 8.08 | 7.81 | 7.79 |
| 157 | 15.52 | 18.02 | 5.32 | 5.29 | 8.52 | 8.47 | 8.10 | 8.06 | 7.81 | 7.77 |
| 158 | 15.54 | 18.04 | 5.33 | 5.28 | 8.52 | 8.45 | 8.11 | 8.04 | 7.81 | 7.74 |
| 159 | 15.55 | 18.05 | 5.33 | 5.27 | 8.53 | 8.43 | 8.11 | 8.01 | 7.82 | 7.72 |
| 160 | 15.57 | 18.06 | 5.33 | 5.25 | 8.53 | 8.40 | 8.12 | 7.99 | 7.82 | 7.70 |
| 161 | 15.58 | 18.07 | 5.34 | 5.24 | 8.54 | 8.38 | 8.12 | 7.97 | 7.83 | 7.68 |
| 162 | 15.60 | 18.09 | 5.34 | 5.22 | 8.54 | 8.36 | 8.12 | 7.95 | 7.83 | 7.66 |
| 163 | 15.61 | 18.10 | 5.34 | 5.21 | 8.55 | 8.34 | 8.13 | 7.93 | 7.83 | 7.64 |
| 164 | 15.62 | 18.11 | 5.34 | 5.20 | 8.55 | 8.32 | 8.13 | 7.91 | 7.84 | 7.62 |
| 165 | 15.64 | 18.12 | 5.35 | 5.18 | 8.56 | 8.29 | 8.14 | 7.89 | 7.84 | 7.60 |
| 166 | 15.65 | 18.14 | 5.35 | 5.17 | 8.56 | 8.27 | 8.14 | 7.87 | 7.85 | 7.58 |
| 167 | 15.67 | 18.15 | 5.35 | 5.16 | 8.56 | 8.25 | 8.14 | 7.85 | 7.85 | 7.56 |
| 168 | 15.68 | 18.16 | 5.35 | 5.14 | 8.57 | 8.23 | 8.15 | 7.83 | 7.85 | 7.54 |
| 169 | 15.70 | 18.17 | 5.36 | 5.13 | 8.57 | 8.21 | 8.15 | 7.80 | 7.86 | 7.52 |
| 170 | 15.71 | 18.19 | 5.36 | 5.11 | 8.58 | 8.18 | 8.16 | 7.78 | 7.86 | 7.50 |
| 171 | 15.73 | 18.20 | 5.36 | 5.10 | 8.58 | 8.16 | 8.16 | 7.76 | 7.87 | 7.48 |
| 172 | 15.74 | 18.21 | 5.37 | 5.09 | 8.59 | 8.14 | 8.17 | 7.74 | 7.87 | 7.46 |
| 173 | 15.76 | 18.22 | 5.37 | 5.07 | 8.59 | 8.12 | 8.17 | 7.72 | 7.87 | 7.44 |
| 174 | 15.77 | 18.24 | 5.37 | 5.06 | 8.59 | 8.10 | 8.17 | 7.70 | 7.88 | 7.42 |
| 175 | 15.79 | 18.25 | 5.37 | 5.05 | 8.60 | 8.07 | 8.18 | 7.68 | 7.88 | 7.40 |
| 176 | 15.80 | 18.26 | 5.38 | 5.03 | 8.60 | 8.05 | 8.18 | 7.66 | 7.89 | 7.38 |
| 177 | 15.81 | 18.27 | 5.38 | 5.02 | 8.61 | 8.03 | 8.19 | 7.64 | 7.89 | 7.36 |
| 178 | 15.83 | 18.29 | 5.38 | 5.00 | 8.61 | 8.01 | 8.19 | 7.62 | 7.89 | 7.34 |
| 179 | 15.84 | 18.30 | 5.38 | 4.99 | 8.62 | 7.99 | 8.19 | 7.59 | 7.90 | 7.32 |
| 180 | 15.86 | 18.31 | 5.39 | 4.98 | 8.62 | 7.96 | 8.20 | 7.57 | 7.90 | 7.30 |
| 181 | 15.87 | 18.32 | 5.39 | 4.96 | 8.63 | 7.94 | 8.20 | 7.55 | 7.91 | 7.28 |
| 182 | 15.89 | 18.34 | 5.39 | 4.95 | 8.63 | 7.92 | 8.21 | 7.53 | 7.91 | 7.26 |
| 183 | 15.90 | 18.35 | 5.40 | 4.94 | 8.63 | 7.90 | 8.21 | 7.51 | 7.91 | 7.24 |
| 184 | 15.92 | 18.36 | 5.40 | 4.92 | 8.64 | 7.88 | 8.22 | 7.49 | 7.92 | 7.22 |
| 185 | 15.93 | 18.37 | 5.40 | 4.91 | 8.64 | 7.85 | 8.22 | 7.47 | 7.92 | 7.20 |
| 186 | 15.95 | 18.39 | 5.40 | 4.89 | 8.65 | 7.83 | 8.22 | 7.45 | 7.93 | 7.18 |
| 187 | 15.96 | 18.40 | 5.41 | 4.88 | 8.65 | 7.81 | 8.23 | 7.43 | 7.93 | 7.16 |
| 188 | 15.97 | 18.41 | 5.41 | 4.87 | 8.66 | 7.79 | 8.23 | 7.41 | 7.93 | 7.14 |
| 189 | 15.99 | 18.42 | 5.41 | 4.85 | 8.66 | 7.77 | 8.24 | 7.39 | 7.94 | 7.12 |
| 190 | 16.00 | 18.44 | 5.41 | 4.84 | 8.66 | 7.74 | 8.24 | 7.36 | 7.94 | 7.10 |
| 191 | 16.02 | 18.45 | 5.42 | 4.82 | 8.67 | 7.72 | 8.24 | 7.34 | 7.95 | 7.08 |
| 192 | 16.03 | 18.46 | 5.42 | 4.81 | 8.67 | 7.70 | 8.25 | 7.32 | 7.95 | 7.06 |
| 193 | 16.05 | 18.47 | 5.42 | 4.80 | 8.68 | 7.68 | 8.25 | 7.30 | 7.95 | 7.04 |
| 194 | 16.06 | 18.49 | 5.43 | 4.78 | 8.68 | 7.66 | 8.26 | 7.28 | 7.96 | 7.02 |
| 195 | 16.08 | 18.50 | 5.43 | 4.77 | 8.69 | 7.63 | 8.26 | 7.26 | 7.96 | 7.00 |
| 196 | 16.09 | 18.51 | 5.43 | 4.76 | 8.69 | 7.61 | 8.27 | 7.24 | 7.97 | 6.98 |
| 197 | 16.11 | 18.52 | 5.43 | 4.74 | 8.70 | 7.59 | 8.27 | 7.22 | 7.97 | 6.96 |
| 198 | 16.12 | 18.54 | 5.44 | 4.73 | 8.70 | 7.57 | 8.27 | 7.20 | 7.97 | 6.94 |
| 199 | 16.14 | 18.55 | 5.44 | 4.71 | 8.70 | 7.54 | 8.28 | 7.18 | 7.98 | 6.92 |
| 200 | 16.15 | 18.56 | 5.44 | 4.70 | 8.71 | 7.52 | 8.28 | 7.15 | 7.98 | 6.90 |
| 201 | 16.16 | 18.57 | 5.44 | 4.69 | 8.71 | 7.50 | 8.29 | 7.13 | 7.99 | 6.88 |
| 202 | 16.18 | 18.59 | 5.45 | 4.67 | 8.72 | 7.48 | 8.29 | 7.11 | 7.99 | 6.86 |
| 203 | 16.19 | 18.60 | 5.45 | 4.66 | 8.72 | 7.46 | 8.29 | 7.09 | 7.99 | 6.84 |
| 204 | 16.21 | 18.61 | 5.45 | 4.65 | 8.73 | 7.43 | 8.30 | 7.07 | 8.00 | 6.82 |
| 205 | 16.22 | 18.62 | 5.46 | 4.63 | 8.73 | 7.41 | 8.30 | 7.05 | 8.00 | 6.79 |
| 206 | 16.24 | 18.64 | 5.46 | 4.62 | 8.73 | 7.39 | 8.31 | 7.03 | 8.01 | 6.77 |
| 207 | 16.25 | 18.65 | 5.46 | 4.60 | 8.74 | 7.37 | 8.31 | 7.01 | 8.01 | 6.75 |
| 208 | 16.27 | 18.66 | 5.46 | 4.59 | 8.74 | 7.35 | 8.31 | 6.99 | 8.01 | 6.73 |

5-3. CORRECTING COOLING AND HEATING CAPACITY

5-3-1. Correcting Changes in Air Conditions

(1) The performance curve charts (Figure 1, 2) show the change ratio of capacity and input (power consumption) according to the indoor and outdoor temperature condition when defining the rated capacity (total capacity) and rated input under the standard condition in standard piping length (5m) as "1.0".

• Standard conditions:

| | |
|------------------------|---|
| Rated cooling capacity | Indoor D.B. 27°C / W.B. 19°C Outdoor D.B. 35°C |
| Rated heating capacity | Indoor D.B. 20°C Outdoor D.B. 7°C / W.B. 6°C |

• Use the rated capacity and rated input given in "5-2".

• The input is the single value on the side of the outdoor unit; the input on the sides of each indoor unit must be added to obtain the total input.

(2) The capacity of each indoor unit may be obtained by multiplying the total capacity obtained in (1) by the ratio between the individual capacity at the rated time and the total capacity at the rated time.

$$\text{Individual capacity under stated conditions} = \text{total capacity under the stated conditions} \times \frac{\text{individual capacity at the rated time}}{\text{total capacity at the rated time}}$$



(3) Capacity correction factor curve

Figure 1.

PUMY-P100YHM PUMY-P100YHM₁ PUMY-P100YHMA(-BS)
PUMY-P125YHM PUMY-P125YHM₁ PUMY-P125YHMA(-BS)
PUMY-P140YHM PUMY-P140YHM₁ PUMY-P140YHMA(-BS)

Figure 2.


PUMY-P100YHM PUMY-P100YHM₁ PUMY-P100YHMA(-BS)
PUMY-P125YHM PUMY-P125YHM₁ PUMY-P125YHMA(-BS)
PUMY-P140YHM PUMY-P140YHM₁ PUMY-P140YHMA(-BS)



5-3-2. Correcting Capacity for Changes in the Length of Refrigerant Piping

- (1) During cooling, obtain the ratio (and the equivalent piping length) of the outdoor units rated capacity and the total in-use indoor capacity, and find the capacity ratio corresponding to the standard piping length from Figure 3. Then multiply by the cooling capacity from Figure 1 to obtain the actual capacity.
- (2) During heating, find the equivalent piping length, and find the capacity ratio corresponding to standard piping length from Figure 3. Then multiply by the heating capacity from Figure 2 to obtain the actual capacity.

(1) Capacity CORRECTION CURVE (Figure.3)



(2) Method for Obtaining the Equivalent Piping Length

Equivalent length for type P100-125-140 = (length of piping to farthest indoor unit) + (0.3 × number of bends in the piping) (m)
 Length of piping to farthest indoor unit: type P100~P140.....80m

5-3-3. Correction of Heating Capacity for Frost and Defrosting

If heating capacity has been reduced due to frost formation or defrosting, multiply the capacity by the appropriate correction factor from the following table to obtain the actual heating capacity.


Correction factor diagram

| | | | | | | | | | |
|--------------------------------------|-----|------|------|------|------|-----|------|------|------|
| Outdoor Intake temperature (W.B. °C) | 6 | 4 | 2 | 0 | -2 | -4 | -6 | -8 | -10 |
| Correction factor | 1.0 | 0.98 | 0.89 | 0.88 | 0.89 | 0.9 | 0.95 | 0.95 | 0.95 |

5-4.NOISE CRITERION CURVES


PUMY-P100YHM
PUMY-P100YHM₁
PUMY-P100YHMA(-BS)

| MODE | SPL(dB) | LINE |
|---------|---------|------|
| COOLING | 49 | ○—○ |
| HEATING | 51 | ●—● |





PUMY-P125YHM
PUMY-P125YHM₁
PUMY-P125YHMA(-BS)

| MODE | SPL(dB) | LINE |
|---------|---------|------|
| COOLING | 50 | ○—○ |
| HEATING | 52 | ●—● |




PUMY-P140YHM
PUMY-P140YHM₁
PUMY-P140YHMA(-BS)

| MODE | SPL(dB) | LINE |
|---------|---------|------|
| COOLING | 51 | ○—○ |
| HEATING | 53 | ●—● |



PUMY-P100YHM PUMY-P100YHM₁
 PUMY-P125YHM PUMY-P125YHM₁
 PUMY-P140YHM PUMY-P140YHM₁

Unit : mm



1 FREE SPACE (Around the unit)
 The diagram below shows a basic example. Explanation of particular details is given in the installation manuals etc.

Over 10mm
Over 100mm
Over 150mm
Over 500mm

2 SERVICE SPACE
 Dimensions of space needed for service access are shown in the below diagram.

Over 10
Over 500
Over 500


3 FOUNDATION BOLTS
 Please secure the unit firmly with 4 foundation (M10) bolts. (Bolts and washers must be purchased locally.)

<Foundation bolt height>
Less than 30

4 PIPING-WIRING DIRECTIONS
 Piping and wiring connections can be made from 4 directions: front, right, rear and below.




Example of Notes

①...Refrigerant GAS pipe connection (FLARE)φ15.88 (5/8 inch)
 ②...Refrigerant LIQUID pipe connection (FLARE)φ9.52 (3/8 inch)
 *1...Indication of STOP VALVE connection location.




PUMY-P100YHMA(-BS) PUMY-P125YHMA(-BS) PUMY-P140YHMA(-BS)

Unit : mm



Example of Notes
 Ⓛ Refrigerant GAS pipe connection (FLARE) φ15.88(5/8 inch)
 Ⓜ Refrigerant LIQUID pipe connection (FLARE) φ 9.52(3/8 inch)
 *1.....Indication of STOP VALVE connection location.



Piping Knockout Hole Details


PUMY-P100YHM PUMY-P100YHM₁
PUMY-P125YHM PUMY-P125YHM₁
PUMY-P140YHM PUMY-P140YHM₁

| SYMBOL | NAME | SYMBOL | NAME | SYMBOL | NAME |
|-----------|--|-------------|--------------------------------------|----------------|--|
| TB1 | Terminal Block <Power Supply> | SV1 | Connector<Bypass Valve> | N.F. | Noise Filter Circuit Board |
| TB3 | Terminal Block <Transmission> | SS | Connector<For Option> | L1/L12/L13/NI | Connection Terminal<L1/L2/L3/N-Power Supply> |
| TB7 | Terminal Block <Centralized Control> | CN3D | Connector<For Option> | L01/L02/L03/NO | Connection Terminal<L1/L2/L3/N-Power Supply> |
| MC | Motor for Compressor | CN3S | Connector<For Option> | CNAC1 | Connector<To Transmission Power Board> |
| MF1,MF2 | Fan Motor | CN3N | Connector<For Option> | CNAC2 | Connector<To Multi Controller Board> |
| 21S4 | Solenoid Valve<Four way valve> | CN51 | Connector<For Option> | CNCT | Connector<To Power Circuit Board> |
| SV1 | Solenoid Valve<Bypass valve> | X501-505 | Relay | CNL | Connector<To Reactor> |
| TH3 | Thermistor<Outdoor Pipe Temperature> | CONVB. | Converter Circuit Board | FUSE | Fuse<6.3A> |
| TH4 | Thermistor<Discharge Temperature> | L1-A1,L1-IN | Connection Terminal<L1-Power Supply> | M-P.B. | Transmission Power Board |
| TH6 | Thermistor<Low Pressure Saturated Temperature> | L1-A2,L1-OU | Connection Terminal<L1-Power Supply> | CN1 | Connector<To Noise Filter Circuit Board> |
| TH7 | Thermistor<Outdoor Temperature> | L2-A2,L2-OU | Connection Terminal<L2-Power Supply> | CN2 | Connector<To Multi Controller Board> |
| 63HS | High Pressure Sensor<Discharge Pressure> | L3-A2,L3-OU | Connection Terminal<L3-Power Supply> | | |
| 63H | High Pressure Switch | N-IN | Connection Terminal | | |
| 63L | Low Pressure Switch | CK-OU | Connection Terminal | | |
| CB1,CB2 | Main Smoothing Capacitor | CN7 | Connector<To Power Circuit Board> | | |
| CK | Capacitor | | | | |
| RS | Rush Current Protect Resistor | | | | |
| ACL1-ACL4 | Reactor | | | | |
| P.B | Power Circuit Board | | | | |

| | |
|-------------|---|
| TB-U/V/W | Connection Terminal<U/V/W-Phase> |
| TB-L1/L2/L3 | Connection Terminal<L1/L2/L3-Power Supply> |
| TB-P2 | Connection Terminal |
| TB-C1 | Connection Terminal |
| TB-N1 | Connection Terminal |
| CN2 | Connection <To Multi Controller Board> |
| CN4 | Connection <To Multi Controller Board> |
| CN5 | Connection <To Noise Filter Circuit Board> |
| CNDC | Connection <To Multi Controller Board> |
| MULTI.B. | Multi Controller Board |
| F1,F2 | Fuse<6.3A> |
| F500 | Fuse<3A> |
| SW1 | Switch<Display Selection> |
| SW2 | Switch<Function Selection> |
| SW3 | Switch<Test Run> |
| SW4 | Switch<Model Selection> |
| SW5 | Switch<Function Selection> |
| SW6 | Switch<Function Selection> |
| SW7 | Switch<Function Selection> |
| SW8 | Switch<Function Selection> |
| SWU1 | Switch<Unit Address Selection, 1st digit> |
| SWU2 | Switch<Unit Address Selection, 2nd digit> |
| TRANS | Transformer |
| LED1,2 | Digital Indicator<Operation Inspection Display> |
| LED3 | LED<Power Supply to Main Microcomputer> |
| CNS1 | Connector<Multi System> |
| CNS2 | Connector<Centralized Control> |
| CNAC | Connector<To Noise Filter Circuit Board> |
| CNDC | Connector<To Noise Filter Circuit> |
| CN2 | Connector<To Power Circuit Board> |
| CN4 | Connector<To Power Circuit Board> |
| CN40 | Connector<Centralized Control Power Supply> |
| CN41 | Connector<For shorting Jumper Connector> |
| TH3 | Connector<Thermistor> |
| TH4 | Connector<Thermistor> |
| TH7/6 | Connector<Thermistor> |
| 63HS | Connector<High Pressure Sensor> |
| 63H | Connector<High Pressure Switch> |
| 63L | Connector<Low Pressure Switch> |
| CNF1,CNF2 | Connector<Fan Motor> |
| 21S4 | Connector<Four-way Valve> |

*1 MODEL SELECT 1:ON 0:OFF

| MODELS | 1 | 2 | 3 | 4 | 5 | 6 |
|--------------|---|---|---|---|---|---|
| PUMY-P100YHM | 1 | 1 | 0 | 0 | 1 | 0 |
| PUMY-P125YHM | 1 | 1 | 0 | 0 | 0 | 1 |
| PUMY-P140YHM | 1 | 1 | 0 | 0 | 1 | 1 |




Cautions when Servicing

⚠ **WARNING:** When the main supply is turned off, the voltage [540 V] in the main capacitor will drop to 20 V in approx. 5 minutes (input voltage: 380 V). When servicing, make sure that LED1 and LED2 on the outdoor circuit board goes out, and then wait for at least 5 minute. Components other than the outdoor board may be faulty: Check and take corrective action, referring to the service manual. Do not replace the outdoor board without checking.

NOTES:

- Refer to the wiring diagrams of the indoor units for details on wiring of each indoor unit.
 Self-diagnosis function
 The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1), LED1 and LED2 (LED indication) found on the multi-controller of the outdoor unit.
 LED indication : Set all contacts of SW1 to OFF.
 During normal operation
 The LED indicates the drive state of the controller in the outdoor unit.

[Example]
 When the compressor and SV1 are turned on during cooling operation.




| Bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|---------------------|-----|------|-----|-------|---|---|------------|
| Indication | Compressor operated | 52C | 21S4 | SV1 | (SV2) | — | — | Always lit |

When fault requiring inspection has occurred, the LED alternately indicates the inspection code and the location of the unit in which the fault has occurred.

PUMY-P100YHMA(-BS) PUMY-P125YHMA(-BS) PUMY-P140YHMA(-BS)

| SYMBOL | NAME |
|----------------|--|
| TB1 | Terminal Block <Power Supply> |
| TB3 | Terminal Block <Communication Line> |
| TB7 | Terminal Block <Centralized Control Line> |
| MC | Motor For Compressor |
| MF1, MF2 | Fan Motor |
| 21S4 | Solenoid Valve<Four-Way Valve> |
| 63H | High Pressure Switch |
| 63L | Low Pressure Switch |
| 63HS | High Pressure Sensor |
| SV1 | Solenoid Valve<Bypass Valve> |
| TH3 | Thermistor<Outdoor Pipe> |
| TH4 | Thermistor<Discharge> |
| TH6 | Thermistor<Low Pressure Saturated> |
| TH7 | Thermistor<Outdoor> |
| RS | Rush Current Protect Resistor |
| ACL1~ACL4 | Reactor |
| CB1, CB2 | Main Smoothing Capacitor |
| CK | Capacitor |
| P.B. | Power Circuit Board |
| TB-U/V/W | Connection Terminal<U/V/W-Phase> |
| TB-L1/L2/L3 | Connection Terminal<L1/L2/L3-Power Supply> |
| TB-P2 | Connection Terminal |
| TB-C1 | Connection Terminal |
| TB-N1 | Connection Terminal |
| X52A | Relay |
| N.F. | Noise Filter Circuit Board |
| L01/L02/L03/NO | Connection Terminal<L1/L2/L3-Power Supply> |
| L1/L2/L3/NI | Connection Terminal<L1/L2/L3-Power Supply> |
| GD1, GD3 | Connection Terminal<Ground> |
| CONV.B. | Converter Circuit Board |
| L1-A1/IN | Connection Terminal<L1-Power Supply> |
| L1-A2/OU | Connection Terminal<L1-Power Supply> |
| L2-A2/OU | Connection Terminal<L2-Power Supply> |
| L3-A2/OU | Connection Terminal<L3-Power Supply> |
| N-IN | Connection Terminal |
| CK-OU | Connection Terminal |
| C.B. | Controller Circuit Board |
| SW1 | Switch<Display Selection> |
| SW2 | Switch<Function Selection> |
| SW3 | Switch<Test Run> |
| SW4 | Switch<Model Selection> |
| SW5 | Switch<Function Selection> |
| SW6 | Switch<Function Selection> |
| SW7 | Switch<Function Selection> |
| SW8 | Switch<Function Selection> |
| SWU1 | Switch<Unit Address Selection, 1st digit> |
| SWU2 | Switch<Unit Address Selection, 2nd digit> |
| SS | Connector<Connection For Option> |
| CN3D | Connector<Connection For Option> |
| CN3S | Connector<Connection For Option> |
| CN3N | Connector<Connection For Option> |
| CN51 | Connector<Connection For Option> |
| LED1, LED2 | LED<Operation Inspection Display> |
| LED3 | LED<Power Supply to Main Microcomputer> |
| F1, F2 | Fuse<T6.3AL250V> |
| X501~X505 | Relay |
| M-NET P.B. | M-NET Power Circuit Board |
| TP1 | Connection Terminal<Ground> |



*1 MODEL SELECT 1:ON 0:OFF

| MODELS | SW4 |
|---------------|-------------|
| | 1 2 3 4 5 6 |
| PUMY-P100YHMA | 1 1 0 0 1 0 |
| PUMY-P125YHMA | 1 1 0 0 0 1 |
| PUMY-P140YHMA | 1 1 0 0 1 1 |

Cautions when Servicing

- ⚠ WARNING: When the main supply is turned off, the voltage [570 V] in the main capacitor will drop to 20 V in approx. 5 minutes (input voltage: 400 V). When servicing, make sure that LED1 and LED2 on the outdoor circuit board goes out, and then wait for at least 5 minute.
- Components other than the outdoor board may be faulty: Check and take corrective action, referring to the service manual. Do not replace the outdoor board without checking.

NOTES:

- Refer to the wiring diagrams of the indoor units for details on wiring of each indoor unit.
 - Self-diagnosis function
 - The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1), LED1 and LED2 (LED indication) found on the multi-controller of the outdoor unit.
 - LED indication : Set all contacts of SW1 to OFF.
 - During normal operation
 - The LED indicates the drive state of the controller in the outdoor unit.

| Bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|---------------------|-----|------|-----|-------|---|---|------------|
| Indication | Compressor operated | 52C | 21S4 | SV1 | (SV2) | — | — | Always lit |


- When fault requiring inspection has occurred, the LED alternately indicates the inspection code and the location of the unit in which the fault has occurred.

[Example]

When the compressor and SV1 are turned on during cooling operation.



8-1. TRANSMISSION SYSTEM SETUP






8-2. REFRIGERANT SYSTEM DIAGRAM

Unit:mm<inch>

PUMY-P100YHM PUMY-P100YHM₁ PUMY-P100YHMA(-BS)
PUMY-P125YHM PUMY-P125YHM₁ PUMY-P125YHMA(-BS)
PUMY-P140YHM PUMY-P140YHM₁ PUMY-P140YHMA(-BS)



Capillary tube for oil separator : $\phi 2.5 \times \phi 0.8 \times L1000$

Refrigerant piping specifications <dimensions of flared connector>

| Capacity | | Item | Liquid piping | Gas piping |
|--------------|------------------------------|------|-------------------|--------------------|
| Indoor unit | P15, P20, P25, P32, P40, P50 | | $\phi 6.35 <1/4>$ | $\phi 12.7 <1/2>$ |
| | P63, P80, P100 | | $\phi 9.52 <3/8>$ | $\phi 15.88 <5/8>$ |
| | P125, P140 | | $\phi 9.52 <3/8>$ | $\phi 15.88 <5/8>$ |
| Outdoor unit | P100, P125, P140 | | $\phi 9.52 <3/8>$ | $\phi 15.88 <5/8>$ |

8-3. SYSTEM CONTROL




8-3-1. Example for the System

- Example for wiring control cables, wiring method and address setting, permissible lengths, and the prohibited items are listed in the standard system with detailed explanation.

The explanation for the system in this section : Use 1 single outdoor unit and multiple outdoor units for M-NET remote control system.




Use 1 single outdoor unit and multiple indoor units in the multiple outdoor units for the M-NET remote control system.

A. Example of a M-NET remote controller system (address setting is necessary.)


| Example of wiring control cables | Wiring Method and Address Setting | | | | | | | | | | | | | | | | | | |
|---|--|---|-------|----------------|------------------|------------|---|-------------------|------------|---|-----------------------------|------------|---|----------------------------|------------|---|-----------------------|------------|---|
| <p>1. Standard operation</p>  <ul style="list-style-type: none"> • 1 remote controller for each indoor unit. • There is no need for setting the 100 position on the remote controller. | <p>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each indoor unit (IC). Use non-polarized 2 wire.</p> <p>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block (TB6) for the remote controller (RC).</p> <p>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</p> <table border="1" data-bbox="839 851 1441 1064"> <thead> <tr> <th>Unit</th> <th>Range</th> <th>Setting Method</th> </tr> </thead> <tbody> <tr> <td>Indoor unit (IC)</td> <td>001 to 050</td> <td>—</td> </tr> <tr> <td>Outdoor unit (OC)</td> <td>051 to 100</td> <td>Use the smallest address of all the indoor unit plus 50.</td> </tr> <tr> <td>Remote controller (RC)</td> <td>101 to 150</td> <td>Indoor unit address plus 100.</td> </tr> </tbody> </table> | Unit | Range | Setting Method | Indoor unit (IC) | 001 to 050 | — | Outdoor unit (OC) | 051 to 100 | Use the smallest address of all the indoor unit plus 50. | Remote controller (RC) | 101 to 150 | Indoor unit address plus 100. | | | | | | |
| Unit | Range | Setting Method | | | | | | | | | | | | | | | | | |
| Indoor unit (IC) | 001 to 050 | — | | | | | | | | | | | | | | | | | |
| Outdoor unit (OC) | 051 to 100 | Use the smallest address of all the indoor unit plus 50. | | | | | | | | | | | | | | | | | |
| Remote controller (RC) | 101 to 150 | Indoor unit address plus 100. | | | | | | | | | | | | | | | | | |
| <p>2. Operation using 2 remote controllers</p>  <ul style="list-style-type: none"> • Using 2 remote controllers for each indoor unit. | <p>a. Same as above.</p> <p>b. Same as above.</p> <p>c. Set address switch (on outdoor unit P.C.B) as shown below.</p> <table border="1" data-bbox="839 1187 1441 1467"> <thead> <tr> <th>Unit</th> <th>Range</th> <th>Setting Method</th> </tr> </thead> <tbody> <tr> <td>Indoor Unit (IC)</td> <td>001 to 050</td> <td>—</td> </tr> <tr> <td>Outdoor unit (OC)</td> <td>051 to 100</td> <td>Use the smallest address of all the indoor units plus 50.</td> </tr> <tr> <td>Main Remote Controller (RC)</td> <td>101 to 150</td> <td>Indoor unit address plus 100.</td> </tr> <tr> <td>Sub Remote Controller (RC)</td> <td>151 to 200</td> <td>Indoor unit address plus 150.</td> </tr> </tbody> </table> | Unit | Range | Setting Method | Indoor Unit (IC) | 001 to 050 | — | Outdoor unit (OC) | 051 to 100 | Use the smallest address of all the indoor units plus 50. | Main Remote Controller (RC) | 101 to 150 | Indoor unit address plus 100. | Sub Remote Controller (RC) | 151 to 200 | Indoor unit address plus 150. | | | |
| Unit | Range | Setting Method | | | | | | | | | | | | | | | | | |
| Indoor Unit (IC) | 001 to 050 | — | | | | | | | | | | | | | | | | | |
| Outdoor unit (OC) | 051 to 100 | Use the smallest address of all the indoor units plus 50. | | | | | | | | | | | | | | | | | |
| Main Remote Controller (RC) | 101 to 150 | Indoor unit address plus 100. | | | | | | | | | | | | | | | | | |
| Sub Remote Controller (RC) | 151 to 200 | Indoor unit address plus 150. | | | | | | | | | | | | | | | | | |
| <p>3. Group operation</p>  <ul style="list-style-type: none"> • Multiple indoor units operated together by 1 remote controller | <p>a. Same as above.</p> <p>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the IC main unit with the most recent address within the same indoor unit (IC) group to terminal block (TB6) on the remote controller.</p> <p>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</p> <table border="1" data-bbox="839 1680 1441 1993"> <thead> <tr> <th>Unit</th> <th>Range</th> <th>Setting Method</th> </tr> </thead> <tbody> <tr> <td>IC (Main)</td> <td>001 to 050</td> <td>Use the smallest address within the same group of indoor units.</td> </tr> <tr> <td>IC (Sub)</td> <td>001 to 050</td> <td>Use an address, other than that of the IC (Main) from among the units within the same group of indoor units. This must be in sequence with the IC (Main).</td> </tr> <tr> <td>Outdoor Unit</td> <td>051 to 100</td> <td>Use the smallest address of all the indoor units plus 50.</td> </tr> <tr> <td>Main Remote Controller</td> <td>101 to 150</td> <td>Set at an IC (Main) address within the same group plus 100.</td> </tr> <tr> <td>Sub Remote Controller</td> <td>151 to 200</td> <td>Set at an IC (Main) address within the same group plus 150.</td> </tr> </tbody> </table> <p>d. Use the indoor unit (IC) within the group with the most functions as the IC (Main) unit.</p> | Unit | Range | Setting Method | IC (Main) | 001 to 050 | Use the smallest address within the same group of indoor units. | IC (Sub) | 001 to 050 | Use an address, other than that of the IC (Main) from among the units within the same group of indoor units. This must be in sequence with the IC (Main). | Outdoor Unit | 051 to 100 | Use the smallest address of all the indoor units plus 50. | Main Remote Controller | 101 to 150 | Set at an IC (Main) address within the same group plus 100. | Sub Remote Controller | 151 to 200 | Set at an IC (Main) address within the same group plus 150. |
| Unit | Range | Setting Method | | | | | | | | | | | | | | | | | |
| IC (Main) | 001 to 050 | Use the smallest address within the same group of indoor units. | | | | | | | | | | | | | | | | | |
| IC (Sub) | 001 to 050 | Use an address, other than that of the IC (Main) from among the units within the same group of indoor units. This must be in sequence with the IC (Main). | | | | | | | | | | | | | | | | | |
| Outdoor Unit | 051 to 100 | Use the smallest address of all the indoor units plus 50. | | | | | | | | | | | | | | | | | |
| Main Remote Controller | 101 to 150 | Set at an IC (Main) address within the same group plus 100. | | | | | | | | | | | | | | | | | |
| Sub Remote Controller | 151 to 200 | Set at an IC (Main) address within the same group plus 150. | | | | | | | | | | | | | | | | | |
| <p>Combinations of 1 through 3 above are possible.</p> | | | | | | | | | | | | | | | | | | | |

• Name, Symbol and the Maximum Remote controller Units for Connection

| Name | Symbol | Maximum units for connection |
|-------------------------|--------|--|
| Outdoor unit | OC | — |
| Indoor unit | IC | 1 OC unit can be connected to 1-8 IC units (P100 : 1-6 IC units) |
| M-NET remote controller | RC | Maximum 2 RC for 1 indoor unit, Maximum 16 RC for 1 OC |

| Permissible Lengths | Prohibited items |
|--|---|
| <p>Longest transmission cable length (1.25 mm²) $L_1 + L_2, L_2 + L_3, L_3 + L_1 \leq 200m$ Remote controller cable length 1. If 0.5 to 1.25 mm² $l_1, l_2 \leq 10m$ 2. If the length exceeds 10 meters, the exceeding section should be 1.25 mm² and that section should be a value within the total extension length of the transmission cable and maximum transmission cable length. (L₃)</p> | <ul style="list-style-type: none"> • M-NET remote controller(RC) and MA remote controller(MA) cannot be used together. • Do not connect anything with TB15 of indoor unit(IC).  |
| Same as above |  <ul style="list-style-type: none"> • Use the indoor unit(IC) address plus 150 as the sub remote controller address. In this case, it should be 152. • 3 or more remote controller (RC) cannot be connected to 1 indoor unit. |
| Same as above |  <ul style="list-style-type: none"> • The remote controller address is the indoor unit main address plus 100. In this case, it should be 101. |

B. Example of a group operation system with 2 or more outdoor units and a M-NET remote controller.
(Address settings are necessary.)




• Name, Symbol, and the Maximum Units for Connection

Permissible Length




- Longest length via outdoor units : $L_1+L_2+L_3+L_4, L_1+L_2+L_3+L_5, L_1+L_2+L_6+L_7 \leq 500$ meters (1.25mm²)
- Longest transmission cable length : $L_1, L_3+L_4, L_3+L_5, L_6, L_2+L_6, L_7 \leq 200$ meters (1.25mm²)
- Remote controller cable length : $l_1, l_2, l_2+l_3, l_4 \leq 10$ meters (0.5 to 1.25mm²)

If the length exceeds 10 meters, use a 1.25 mm² shielded wire. The length of this section (L₈) should be included in the calculation of the maximum length and overall length.






C. Example of a MA remote controller system (address setting is not necessary.)


NOTE : In the case of same group operation, need to set the address that is only main indoor unit.

| Example of wiring control cables | Wiring Method and Address Setting |
|---|---|
| <p>1. Standard operation</p>  <p>• 1 remote controller for each indoor unit.</p> | <p>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each indoor unit (IC). Use non-polarized 2 wire.</p> <p>b. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for the MA remote controller (MA).</p> |
| <p>2. Operation using two remote controllers</p>  <p>• Using 2 remote controllers for each indoor unit.</p> | <p>a. The same as above.</p> <p>b. The same as above.</p> <p>c. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 remote controllers.</p> <p>· Set the sub remote controller position for one of MA remote controller's main switch. Refer to the installation manual of MA remote controller</p> |
| <p>3. Group operation</p>  <p>• Multiple indoor units operated together by 1 remote controller</p> | <p>a. The same as above.</p> <p>b. The same as above.</p> <p>c. Connect terminals 1 and 2 on transmission cable terminal block (TB15) of each indoor unit, which is doing group operation with the terminal block the MA remote controller. Use non-polarized 2 wire.</p> <p>d. In the case of same group operation, need to set the address that is only main indoor unit. Please set the smallest address within number 01-50 of the indoor unit with the most functions in the same group.</p> |
| <p>Combinations of 1 through 3 above are possible.</p> | |




| Permissible Lengths | Prohibited items |
|--|--|
| <p>Longest transmission cable length $L_1 + L_2 \leq 200\text{m}$ (1.25 mm²) MA remote controller cable length $l_1, l_2 \leq 200\text{m}$ (0.3 ~ 1.25 mm²)</p> | <p>The MA remote controller and the M-NET remote controller cannot be used together with the indoor unit of the same group.</p>  |
| <p>Longest transmission cable length The same as above. MA remote controller cable length $l_3 + l_4, l_5 + l_6 \leq 200\text{m}$ (0.3 ~ 1.25 mm²)</p> | <p>3 MA remote controller or more cannot be connected with the indoor unit of the same group.</p>  |
| <p>Longest transmission cable length The same as above. MA remote controller cable length $l_7 + l_8 \leq 200\text{m}$ (0.3 ~ 1.25 mm²)</p> | <p>The second MA remote controller is connected with the terminal block (TB15) for the MA remote controller of the same indoor unit (IC) as the first remote control.</p>  |

D. Example of a group operation with 2 or more outdoor units and a MA remote controller.
 (Address settings are necessary.)




• Name, Symbol, and the Maximum Units for Connection

| | |
|--------------------|---|
| Permissible Length | <p>Longest length via outdoor unit (M-NET cable): $L_1+L_2+L_3+L_4$ and $L_1+L_2+L_6+L_7 \leq 500$ m (1.25 mm² or more) Longest transmission cable length (M-NET cable): L_1 and L_3+L_4 and L_6 and L_2+L_6 and $L_7 \leq 200$ m (1.25 mm² or more) Remote controller cable length: m_1 and $m_1+m_2+m_3$ and $m_1+m_2+m_3+m_4 \leq 200$ m (0.3 to 1.25 mm²)</p> |
| Prohibited items |  <p>(A) : Group 1 (B) : Group 3 (C) : Group 5 (D) : Shielded Wire (E) : Sub Remote Controller () : Address</p> <ul style="list-style-type: none"> • Never connect together the terminal blocks (TB5) for transmission wires for indoor units (IC) that have been connected to different outdoor units (OC). • M-NET remote controller and MA remote controller cannot be connected with the indoor unit of the same group wiring together. |

9-1. CHECK POINTS FOR TEST RUN

9-1-1. Procedures of test run

- (1) Before test run, make sure that following work is completed.
 - Installation related :
Make sure that the panel of cassette type and electrical wiring are done.
Otherwise electrical functions like auto vane will not operate normally.
 - Piping related :
Perform leakage test of refrigerant and drain piping.
Make sure that all joints are perfectly insulated.
Check stop valves on both liquid and gas side for full open.
 - Electrical wiring related :
Check ground wire, transmission cable, remote controller cable, and power supply cable for secure connection.
Make sure that all switch settings of address or adjustments for special specification systems are correctly settled.
- (2) Safety check :
With the insulation tester of 500V, inspect the insulation resistance.
Do not touch the transmission cable and remote controller cable with the tester.
The resistance should be over 1.0 MΩ. Do not proceed inspection if the resistance is under 1.0 MΩ.
Inspect between the outdoor unit power supply terminal block and ground first, metallic parts like refrigerant pipes or the electrical box next, then inspect all electrical wiring of outdoor unit, indoor unit, and all linked equipment .
- (3) Before operation :
 - a) Turn the power supply switch of the outdoor unit to on for compressor protection. For a test run, wait at least 12 hours from this point.
 - b) Register control systems into remote controller(s). Never touch the on/ off switch of the remote controller(s). Refer to “9-1-2. Special Function Operation and Settings (for M-NET Remote Controller)” as for settings. In MA remote controller(s), this registration is unnecessary.
- (4) More than 12 hours later from power supply to the outdoor unit, turn all power switch to on for test run. Perform test run according to the “Operation procedure” table of the bottom of this page. While test running, make test run reports .
- (5) When you deliver the unit after test run, instruct the end user for proper usage of the system using owners' manual and the test run report you made to certificate normal operation. If abnormalities are detected during test run, refer to “9-1-3 Countermeasures for Error During Test Run”. As for DIP switch setting of outdoor unit, refer to” 9-5. INTERNAL SWITCH FUNCTION TABLE”.



Operation procedure

| | |
|---|--|
| ① | Turn on the main power supply of all units at least 12 hours before test run. "HO" appears on display panel for 3 min. |
| ② | 12 hours later, press TEST RUN button twice to perform test run. "TEST RUN " appears on display panel. |
| ③ | Press OPERATION SWITCH button to make sure that air blows out. |
| ④ | Select Cooling (or Heating) by OPERATION SWITCH button to make sure that cool (or warm) air blows out. |
| ⑤ | Press Fan speed button to make sure that fan speed in changed by the button. |
| ⑥ | Press AIR DIRECTION button or LOUVER button to make sure that air direction is adjustable(horizontal, downward, upward, and each angle). |
| ⑦ | Check outdoor fans for normal operation. |
| ⑧ | Check interlocked devices (like ventilator) for normal operation, if any. This is the end of test run operation. |
| ⑨ | Press ON/OFF button to stop and cancel test run. |

NOTE 1 : If error code appears on remote controller or remote controller malfunctions, refer to “9-1-3 Countermeasures for Error During Run”.

NOTE 2 : During test run operation, 2-hour off timer activates automatically and remaining time is on remote controller and test run stops 2 hours later.

NOTE 3 : During test run, the indoor liquid pipe temperature is displayed on remote controller instead of room temperature.

NOTE 4 : Depending on a model, “This function is not available” appears when air direction button is pressed. However, this is not malfunction.

9-1-2. Special Function Operation and Settings (for M-NET Remote Controller)

- It is necessary to perform "group settings" and "paired settings" at making group settings of different refrigerant systems (multiple outdoor unit).
- (A) Group settings: Enter the indoor unit controlled by the remote controller, check the content of entries, and clear entries, etc.
- (B) Paired settings: Used to set the linked operation of a Lossnay unit.

(1) Entering address: Follow the steps below to enter the addresses of the indoor unit using the remote controller.

a) Group settings





- Turning off the remote controller: Press the ON/OFF button to stop operation (the indicator light will go off).
- Changing to indoor unit address display mode: If the FILTER and  buttons on the remote controller are pressed simultaneously and held for 2 seconds, the display shown in Figure 1 will appear.
- Changing address: Press the temperature adjustment   buttons to change the displayed address to the address to be entered.
- Entering the displayed address: Press the TEST RUN button to enter the indoor unit with the displayed address. The type of the unit will be displayed as shown in Figure 2 if entry is completed normally. If a selected indoor unit does not exist, an error signal will be displayed as shown in Figure 3. When this happens, check whether the indoor unit actually exists and perform entry again.
- Returning to the normal mode after completing entry: Press the FILTER and  buttons simultaneously and hold for 2 seconds to return to the normal mode.

Figure 1. (A) Group setting display






Figure 2. Normal completion of entry



Type of unit is displayed.

Figure 3. Entry error signal



Flashing "88" indicates entry error.

b) Paired Settings










- Turn off the remote controller: Press the remote controller's ON/OFF button to turn it off (the indicator light will go off).
- Put in indoor unit address display mode: Press the FILTER and  buttons on the remote controller simultaneously and hold for 2 seconds.
- The above steps are the same as when making group settings (A).
- Changing to the linked operation unit address display state: The display shown in Figure 4 will appear when the  button on the remote control is pressed.
- Displaying the address of the Lossnay unit and linked indoor unit: In this situation, the indoor unit number will be the lowest address of the group. The Lossnay unit will not operate if this setting is incorrect.
- If the temperature adjustment   buttons are pressed, the address may be changed to the indoor unit that are to be linked.
- If the time setting   buttons are pressed, the address of the linked units may be changed to the address where it is desired to enter the Lossnay .
- Linking the Lossnay and the indoor unit: The display shown in Figure 5 will appear when the TEST RUN button is pressed. The indoor unit whose address is displayed and the Lossnay unit with a linked address will operate in a linked manner.
- If it is desired to display the address of the Lossnay in the indoor unit address, display the indoor unit address in the linked unit address, and the above content will also be recorded.
- Apart from the indoor unit with the lowest address in the group, display and enter the addresses of the other indoor unit that are to be linked with the Lossnay unit.
- Returning to the normal mode after completing entry: Press the FILTER and  buttons on the remote controller simultaneously and hold for 2 seconds to return to the normal mode.

Figure 4. (B) Making paired settings



The addresses of indoor unit and linked units are displayed simultaneously.

Figure 5. Completing normal entry





These alternating IC or LC displays will appear when entry is completed normally.





A flashing "88" will appear if there is a problem with the entry (indicating that the unit does not exist).

(2) Address check: Refer to section (1) regarding address entry.

a) In making group settings:

- Turn off the remote controller: Press the remote controller's ON/OFF button to stop operation (the indicator light will go off).
- Locate the indoor unit address display mode: Press the FILTER and  buttons on the remote controller simultaneously and hold for 2 seconds.
- Display indoor unit address: The entered indoor units address and type will be displayed each time the button is pressed.
* When 1 entry is made, only 1 address will be displayed no matter how many times the ⊖ button is pressed.
- Returning to the normal mode after completing check: Simultaneously press the FILTER and  buttons on the remote controller and hold for 2 seconds to return to the normal mode.

b) In making paired settings:

- Turn off the remote controller: Press the remote controller's ON/OFF button to stop operation (the indicator light will go off).
- Put in indoor unit address display mode: Press the FILTER and  buttons on the remote controller simultaneously and hold for 2 seconds.
- Changing to the linked operation unit address display state: Press the  button on the remote control.
- Displaying the address of the indoor unit to be checked: Change the address to that of the indoor unit to be checked by pressing the temperature adjustment buttons .
- Displaying the address of the linked Lossnay unit: Press the ⊖ button to display the addresses of the linked Lossnay and indoor unit in alternation.
- Displaying the addresses of other entered units: The addresses of the other entered units will be displayed in alternating fashion after resting the ⊖ button again.
- Returning to the normal mode after completing the check: Simultaneously press the FILTER and  buttons on the remote controller and hold for 2 seconds to return to the normal mode.

(3) Clearing an address: Refer to section (1) regarding the address entry and section (2) regarding checking addresses.

a) In making group settings:




- Turn off the remote controller: The procedure is same as **a)** in (2) Address check.
- Put in the indoor unit address display mode: The procedure is same as **a)** in (2) Address check.
- Displaying the indoor unit address to be cleared: The procedure is same as **a)** in (2) Address check.
- Clearing indoor unit address :Pressing the  button on the remote controller twice will clear the address entry of the displayed indoor unit, resulting in the display shown in Figure 6.
The display shown in Figure 7 will appear if an abnormality occurs and the entry is not cleared.
Please repeat the clearing procedure.
- Returning to the normal mode after clearing an address: The procedure is same as **a)** in (2) Address check.

Figure 6. Display after address has been cleared normally



"011" will appear in the room temperature display location.

Figure 7. Display when an abnormality has occurred during clearing



"88" will appear in the room temperature display location.

b) In making paired settings:



- Turn off the remote controller: The procedure is same as **b)** in (2) Address check.
- Put into the indoor unit address display mode: The procedure is same as **b)** in (2) Address check.
- Put into the linked unit address display mode: The procedure is same as **b)** in (2) Address check.
- Display the address of the Lossnay unit or the indoor unit to be cleared.
- Deleting the address of a linked indoor unit: Pressing the  button on the remote controller twice will clear the address entry of the displayed indoor unit, resulting in the display shown in Figure 8.
- Returning to the normal mode after clearing an address: The procedure is same as **b)** in (2) Address check.

Figure 8. Display after address has been cleared normally



"011" will appear in the unit type display location when an address has been cleared normally.

"88" will appear in the unit type display location when an abnormality has occurred during clearing.

9-1-3. Countermeasures for Error During Test Run

- If a problem occurs during test run, a code number will appear in the temperature display area on the remote controller (or LED on the outdoor unit), and the air conditioning system will automatically cease operating.

Determine the nature of the abnormality and apply corrective measures.

| Check code | Trouble | Detected unit | | | Remarks |
|------------|---|---------------|---------|-------------------|--|
| | | Indoor | Outdoor | Remote controller | |
| 0403 | Serial transmission trouble | | ○ | | Outdoor unit Multi controller board ~ Power board communication trouble |
| 1102 | Discharge temperature trouble | | ○ | | Check delay code 1202 |
| 1300 | Low Pressure trouble | | ○ | | Check delay code 1400 |
| 1302 | High pressure trouble | | ○ | | Check delay code 1402 |
| 1500 | Excessive refrigerant replenishment | | ○ | | Check delay code 1600 |
| 1501 | Insufficient refrigerant trouble | | ○ | | Check delay code 1601 |
| 1505 | Vacuum operation protection | | ○ | | |
| 2500 | Water leakage | ○ | | | |
| 2502 | Drain pump trouble | ○ | ○ | | |
| 2503 | Drain sensor trouble (THd) | ○ | | | |
| 4100 | Overcurrent trouble (Overload, compressor lock) | | ○ | | Check delay code 4350 |
| 4115 | Power synchronization signal trouble | | ○ | | Check delay code 4165 |
| 4220 | Inverter trouble | | ○ | | Check delay code 4320 |
| 4230 | Overheat protection of radiator panel | | ○ | | Check delay code 4330 |
| 4250 | Power module trouble or Overcurrent trouble | | ○ | | Check delay code 4350 |
| 4400 | Fan controller trouble (Outdoor) | | ○ | | Check delay code 4500 |
| 5101 | Air inlet sensor trouble (TH21) or Discharge temperature sensor trouble (TH4) | ○ | ○ | | Check delay code 1202 |
| | Liquid pipe temp.sensor trouble (TH22) or Low pressure saturated temp.sensor trouble (TH6) | ○ | ○ | | Check delay code 1211 |
| 5102 | Gas pipe temperature sensor trouble (TH23) | ○ | | | |
| 5105 | Piping temperature sensor trouble (TH3) | | ○ | | Check delay code 1205 |
| 5106 | Outdoor temperature sensor trouble (TH7) | | ○ | | Check delay code 1221 |
| 5110 | Heatsink temperature sensor trouble (TH8) | | ○ | | Check delay code 1214 |
| 5201 | Pressure sensor trouble (63HS) | | ○ | | Check delay code 1402 |
| 5300 | Current sensor trouble | | ○ | | Check delay code 4310 |
| 5701 | Contact failure of drain float switch | ○ | | | |
| 6600 | Duplicated unit address setting | ○ | ○ | ○ | Only M-NET Remote controller is detected. |
| 6602 | Transmission error (Transmission processor hardware error) | ○ | ○ | ○ | Only M-NET Remote controller is detected. |
| 6603 | Transmission error (Transmission route BUSY) | ○ | ○ | ○ | Only M-NET Remote controller is detected. |
| 6606 | Transmission and reception error (Communication trouble with transmission processor) | ○ | ○ | ○ | Only M-NET Remote controller is detected. |
| 6607 | Transmission and reception error (No ACK error) | ○ | | ○ | Only M-NET Remote controller is detected. * |
| 6608 | Transmission and reception error (No responsive frame error) | ○ | | ○ | Only M-NET Remote controller is detected. * |
| 6831 | MA communication receive signal error (no receive signal) | ○ | | ○ | Only MA Remote controller is detected. |
| 6832 | MA communication send signal error (starting bit detection error) | ○ | | ○ | Only MA Remote controller is detected. |
| 6833 | MA communication send error (H/W error) | ○ | | ○ | Only MA Remote controller is detected. |
| 6834 | MA communication receive error (Synchronous recovery error) | ○ | | ○ | Only MA Remote controller is detected. |
| 7100 | Total capacity error | | ○ | | |
| 7101 | Capacity code error | ○ | ○ | | |
| 7102 | Connecting unit number error | | ○ | | |
| 7105 | Address set error | | ○ | | |
| 7111 | Remote controller sensor trouble | | | ○ | |

NOTE)

When the outdoor unit detects No ACK error/ No responsive frame error, an object indoor unit is treated as a stop, and not assumed to be abnormal.

Self-diagnosis function

The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED1, LED2 (LED indication) found on the multi-controller of the outdoor unit.

LED indication : Set all contacts of SW1 to OFF.


During normal operation

The LED indicates the drive state of the controller in the outdoor unit.

| Bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|------------|---------------------|-----|------|-----|-------|---|---|------------|
| Indication | Compressor operated | 52C | 21S4 | SV1 | (SV2) | — | — | Always lit |

[Example]

When the compressor and SV1 are turned during cooling operation.




| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|---|
| 1102 | High discharging temperature Abnormal if discharge temperature thermistor (TH4) exceeds 125°C or 110°C continuously for 5 minutes. Abnormal if pressure detected by high-pressure sensor and converted to saturation temperature exceeds 40°C during defrosting and discharge temperature thermistor (TH4) exceeds 110°C. | ① Over-heated compressor operation caused by shortage of refrigerant ② Defective operation of stop valve ③ Defective thermistor ④ Defective outdoor controller board ⑤ Defective action of linear expansion valve | ① Check intake super heat. Check leakage of refrigerant. Charge additional refrigerant. ② Check if stop valve is full open. ③④ Turn the power off and check if 5101 is displayed when the power is put again. When 5101 is displayed, refer to "Check points" for 5101. |
| 1300 | Low pressure (63L worked) Abnormal if 63L is worked (under- 0.03MPa) during compressor operation. 63L: Low-pressure switch | ① Stop valve of outdoor unit is closed during operation. ② Disconnection or loose connection of connector (63L) on outdoor controller board ③ Disconnection or loose connection of 63L ④ Defective outdoor controller board ⑤ Leakage or shortage of refrigerant ⑥ Malfunction of linear expansion valve | ⑤ Check linear expansion valve. ① Check stop valve. ②~④ Check the connector (63L) on outdoor controller board. ⑤ Correct to proper amount of refrigerant. |
| 1302 | (1) High pressure (High-pressure switch 63H worked) Abnormal if high-pressure switch 63H worked (*) during compressor operation. * 4.15 MPa 63H: High-pressure switch (2) High pressure (High - pressure sensor 63HS detect) Abnormal if high-pressure sensor detects 4.31MPa or more (or over 4.15MPa for 3 minutes) during the compressor operation. | ① Short cycle of indoor unit ② Clogged filter of indoor unit ③ Decreased airflow caused by dirt of indoor fan ④ Dirt of indoor heat exchanger ⑤ Locked indoor fan motor ⑥ Malfunction of indoor fan motor ⑦ Defective operation of stop valve (Not fully open) ⑧ Clogged or broken pipe ⑨ Locked outdoor fan motor ⑩ Malfunction of outdoor fan motor ⑪ Short cycle of outdoor unit ⑫ Dirt of outdoor heat exchanger ⑬ Decreased airflow caused by defective inspection of outside temperature thermistor (It detects lower temperature than actual temperature.) ⑭ Disconnection or contact failure of connector (63H) on outdoor controller board ⑮ Disconnection or contact failure of 63H connection ⑯ Defective outdoor controller board ⑰ Defective action of linear expansion valve ⑱ Malfunction of fan driving circuit ⑲ Solenoid valve (SV1) performance failure (High-pressure pressure cannot be controlled by SV1.) ⑳ High-pressure sensor defective ㉑ High-pressure sensor input circuit defective in multi controller board | ⑥ Check linear expansion valve. ①~⑥ Check indoor unit and repair defectives. ⑦ Check if stop valve is fully open. ⑧ Check piping and repair defectives. ⑨~⑫ Check outdoor unit and repair defectives. ⑬ Check the inspected temperature of outside temperature thermistor on LED display. ⑭~⑯ Check the connector (63H) on outdoor controller board. ⑰ Check linear expansion valve. ⑱ Replace outdoor controller board. ⑲ Check the solenoid valve performance. ㉑ Check the high-pressure sensor. ㉒ Check the high-pressure sensor. |
| 1500 | Superheat due to low discharge temperature Abnormal if discharge superheat is continuously detected less than or equal to -15°C even though linear expansion valve has minimum open pulse after compressor starts operating for 10 minutes. | ① Disconnection or loose connection of discharge temperature thermistor (TH4) ② Defective holder of discharge temperature thermistor | ①② Check the installation conditions of discharge temperature thermistor (TH4). |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|---|
| 1501 | <p>Refrigerant shortage</p> <p>When the conditions of below detecting mode I or II are satisfied during the compressor operation.</p> <p><Detecting mode I ></p> <p>When the below conditions are satisfied completely.</p> <ol style="list-style-type: none"> 1. Compressor is operating in HEAT mode. 2. Discharge super heat is 80°C or more. 3. Difference of outer temperature thermistor (TH7) and outdoor piping temp. thermistor (TH3) applies to the formula of (TH7-TH3)<5°C. 4. High-pressure sensor is below about 2.04MPa. <p><Detecting mode II ></p> <p>When the below conditions are satisfied completely.</p> <ol style="list-style-type: none"> 1. Compressor is operating. 2. When cooling, discharge superheat is 80°C or more. When heating, discharge superheat is 90°C or more. <p>High pressure sensor is below about 2.32MPa.</p> | <ol style="list-style-type: none"> ① Gas leakage, Gas shortage ② When heating operation, refrigerant shortage feeling operation (When heating, airflow or thermo OFF are mixed-operation, it cause a refrigerant shortage operation.) ③ Ball valve performance failure (not fully opened.) ④ Error detection of discharge super heat <ol style="list-style-type: none"> 1) High-pressure sensor defective 2) Discharge temperature thermistor defective 3) Thermistor input circuit defective and high-pressure sensor defective in multi controller board ⑤ Error detection of TH7/TH3 <ol style="list-style-type: none"> 1) Thermistor defective 2) Thermistor input circuit defective in multi controller board | <ol style="list-style-type: none"> ① Check the refrigerant amount. ② Check the operation condition and refrigerant amount. ③ Check the ball valve is fully opened. ④ <ol style="list-style-type: none"> 1) Check the ball valve is fully opened. 2) Check the resistance of discharge temperature thermistor. 3) According to "Outdoor unit functions", set the SW2 and check the high-pressure sensor level. <p>According to "Outdoor unit functions", check the discharge temp. thermistor level.</p> <p>When the high-pressure pressure sensor and discharge temp. thermistor are normal, if the above mentioned detecting pressure level and temp. are very different from the actual pressure and temp., replace the multi controller board.</p> ⑤ <ol style="list-style-type: none"> 1) Check the resistance of thermistor. 2) According to "Outdoor unit functions", check the outdoor pipe temp. thermistor level. 3) According to "Outdoor unit functions", check the outer temp. thermistor level. |

| | | | |
|------------------------------|--|--|--|
| 2500 (Float switch model) | <p>Water leakage</p> <ol style="list-style-type: none"> 1. Suspensive Abnormality when float switch detects to be in the water and drain pump turns on and off except during cooling or dry mode. 2. Abnormal when detecting that the drain pump turns on and off again within 1 hour after the detection of water leakage suspensive abnormality, and repeats the detection twice. <2500> is displayed. 3. The unit continues to detect abnormality while turned off. 4. To release water leakage suspensive abnormality <ul style="list-style-type: none"> · When not detecting that the drain pump turns off and on within 1 hour after detecting suspensive abnormality. · When turning to cooling operation or dry operation. · Detected that [liquid pipe temperature – room temperature] ≤ -10deg[-18°F] | <ol style="list-style-type: none"> ① Defective drain Clogged drain pump Clogged drain pipe Adverse flow of drain in other units ② Defective moving part of float switch Foreign matter on the moving part of float switch(ex. sludge etc.) ③ Defective float switch | <ol style="list-style-type: none"> ① Check the drain function. ② Check moving part of float switch. ③ Check the value of resistance with the float switch ON/OFF. |
|------------------------------|--|--|--|

Operation mode: When drain pump turns on as float switch detects to be in the water except during cooling/dry mode





| Display | Abnormal point and detecting method | Causes | Check points |
|------------------------------|---|--|---|
| 2502 (Drain sensor model) | <p>Drain pump (DP)</p> <p>① Let drain sensor self-heated, and if temperature rises slightly, as suspensive abnormality operation stops and changes to protect mode of restarting in 3 minutes.</p> <p>② Drain pump is abnormal if the condition above is detected during suspensive abnormality. <2502> is displayed.</p> <p>③ Malfunction of drain pipe is constantly detected during drain pump operation.</p> | <p>① Malfunction of drain pump</p> <p>② Defective drain Clogged drain pump Clogged drain pipe</p> <p>③ Water drops on drain sensor • Drops of drain trickles from lead wire. • Clogged filter is causing wave of drain.</p> <p>④ Defective indoor controller board</p> | <p>① Check if drain-up machine works.</p> <p>② Check drain function.</p> <p>③ Check the setting of lead wire of drain sensor and check clogs of the filter.</p> <p>④ Replace indoor controller board when there is no problem in the above mentioned ①~③.</p> |
| | <p>④ The unit enters to forced outdoor unit stop when following conditions, a) and b), are satisfied (while the above mentioned detection is performed).</p> <p>a) The drain sensor detects to be soaked in the water 10 times in a row.</p> <p>b) Detected that [liquid pipe temperature – room temperature] ≤ -10deg[-18°F] for 30 minutes constantly.</p> <p>(When the drain sensor detects to be NOT soaked in the water, the detection record of a) and b) will be cleared.)</p> <p>* Drain pump abnormality (above ①~③) is detected before it becomes an outdoor unit forced stop condition.</p> <p>⑤ When indoor unit detects above ④ condition, outdoor unit in same refrigerant sytem stops. Also, indoor unit except for Fan or OFF mode unit stop. 2502 is displayed on stopped unit.</p> <p>⑥ Detection timing of forced outdoor unit stop Constantly detected during unit operation and stop</p> <p>⑦ Releasing of forced outdoor unit stop Reset power supply of both abnormal indoor unit and its outdoor unit in same refrigerant system. Forced outdoor unit stop cannot be released by remote controller OFF.</p> <p>NOTE) Above-mentioned ①~③ and ④~⑦ are detected independently.</p> | <p>⑤ Both of above mentioned ①~④ and the indoor linear expansion valve full-closed failure (leakage) happens synchronistically.</p> <div data-bbox="627 768 1018 857" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>(Note) Address/Attribute displayed on the remote controller shows the indoor unit which is cause of trouble.</p> </div> | <p>Check whether the indoor linear expansion valve leaks or not.</p> |




| Display | Abnormal point and detecting method | Causes | Check points |
|------------------------------|--|--|--|
| 2502 (Float switch model) | <p>Drain pump (DP)</p> <p>① Judge whether the sensor is in the water or in the air by turning the float switch ON/OFF. In the water: Detected that the float switch is ON for 15 seconds. In the air: Detected that the float switch is OFF for 15 seconds.</p> <p>② When the float switch remains to be turned ON for 3 minutes after detected to be in the water, the drain pump is judged to be abnormal and <2502> will be displayed. *It takes 3 minutes and 15 seconds to detect abnormality including the time to judge to be in the water.</p> <p>③ The unit continue to detect abnormality while turned off.</p> <p>④ When the conditions below 1, 2 and Forced outdoor unit stop condition are met 1. Detected that [liquid pipe temperature – room temperature] ≤ -10deg[-18°F] for 30 minutes constantly. 2. Float switch detects to be in the water for 15 minutes constantly. *Before Forced outdoor unit stop Condition is met, the unit always detects ①-③ above.</p> <p>⑤ The indoor unit detecting ④ above stops due to detecting abnormality the outdoor unit in same refrigerant system (compressor is inhibited to operate). The unit which stops due to detecting abnormality displays <2502>.</p> <p>⑥ Detection timing of forced outdoor unit stop Constantly detected during unit operation and stop</p> <p>⑦ Releasing of forced outdoor unit stop Reset power supply of both abnormal indoor unit and its outdoor unit in same refrigerant system. Forced outdoor unit stop cannot be released by remote controller OFF.</p> <p>NOTE) Above-mentioned ①~③ and ④~⑦ are detected independently.</p> | <p>① Malfunction of drain pump</p> <p>② Defective drain Clogged drain pump Clogged drain pipe</p> <p>③ Defective moving part of float switch Foreign matter on the moving part of float switch(ex. sludge etc.)</p> <p>④ Defective float switch</p> <p>⑤ Defective indoor controller board Defective driving circuit of drain pump Defective input circuit of float switch</p> <p>⑥ Both of above mentioned ①~⑤ and the indoor linear expansion valve full-closed failure (leakage) happens synchronistically.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>(Note) Address/Attribute displayed on the remote controller shows the indoor unit which is cause of trouble.</p> </div> | <p>① Check if drain-up machine works.</p> <p>② Check drain function.</p> <p>③ Check moving part of float switch.</p> <p>④ Check the value of resistance with the float switch ON/OFF.</p> <p>⑤ Change the indoor controller board.</p> <p>⑥ Check whether the indoor linear expansion valve leaks or not.</p> |
| 2503 | <p>Drain sensor (THd, DS) abnormality When the drain sensor detects short/open while the operation.</p> | <p>① Connector (CN31) contact failure (insertion failure)</p> <p>② Thermistor wiring disconnection or half disconnection</p> <p>③ Thermistor defective</p> <p>④ Indoor controller board (detecting circuit) failure</p> | <p>① Check whether the indoor controller board connector (CN31) is disconnected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor.</p> <p>④ If abnormality is not found in the method of the above-mentioned from ① to ③, it is defective of the indoor controller board.</p> |
| 4100 | <p>Compressor overcurrent interruption (When compressor locked) Abnormal if overcurrent of DC bus or compressor is detected within 30 seconds after compressor starts operating.</p> <p>Over current level : 18.0A</p> | <p>① Stop valve is closed.</p> <p>② Decrease of power supply voltage</p> <p>③ Looseness, disconnection or converse of compressor wiring connection</p> <p>④ Defective compressor</p> <p>⑤ Defective outdoor power board</p> | <p>① Open stop valve.</p> <p>② Check facility of power supply.</p> <p>③ Correct the wiring (U·V·W phase) to compressor.</p> <p>④ Check compressor.</p> <p>⑤ Replace outdoor power circuit board.</p> |




| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|---|--|
| 4220 | <p>Overvoltage or voltage shortage Abnormal if any of followings are detected during compressor operation;</p> <ul style="list-style-type: none"> • Decrease of DC bus voltage to 310V • Instantaneous decrease of DC bus voltage to 350V. • Increase of DC bus voltage to 760V. • Decrease of input current of outdoor unit to 0.1A only if operation frequency is more than or equal to 40Hz or compressor current is more than or equal to 6A. | <ul style="list-style-type: none"> ① Decrease of power supply voltage ② Disconnection of compressor wiring ③ Defective 52C ④ Defective outdoor converter circuit board ⑤ Disconnection or loose connection of CN5 on the outdoor power circuit board ⑥ Defective 52C drive circuit of outdoor power circuit board ⑦ Disconnection or loose connection of CN2 on the outdoor power circuit board. | <ul style="list-style-type: none"> ① Check the facility of power supply. ② Correct the wiring (U·V·W phase) to compressor. (Outdoor power circuit board) ③ Replace 52C. ④ Replace outdoor converter circuit board. ⑤ Check CN5 wiring on the outdoor power circuit board. ⑥ Replace outdoor power circuit board. ⑦ Check CN2 wiring on the outdoor power circuit board. |
| 4230 | <p>Temperature of heatsink If heatsink thermistor(TH8) detects temperature indicated below 95°C</p> <p>NOTE) TH8 is internal thermistor of power module on power board.</p> | <ul style="list-style-type: none"> ① The outdoor fan motor is locked. ② Failure of outdoor fan motor ③ Airflow path is clogged. ④ Rise of ambient temperature ⑤ Defective thermistor ⑥ Defective input circuit of outdoor power circuit board ⑦ Failure of outdoor fan drive circuit | <ul style="list-style-type: none"> ①② Check outdoor fan. ③ Check air flow path for cooling. ④ Check if there is something which causes temperature rise around outdoor unit. (Upper limit of ambient temperature is 46°C.) Turn off power, and on again to check if 4230 is displayed within 30 minutes. ⑤ Check thermistor <TH8> temperature by micro computer. ⑥ Replace outdoor power circuit board. ⑦ Replace outdoor controller circuit board. |
| 4250 | <p>(1) Power module Check abnormality by driving power module in case overcurrent is detected.</p> | <ul style="list-style-type: none"> ① Outdoor stop valve is closed. ② Decrease of power supply voltage ③ Looseness, disconnection or converse of compressor wiring connection ④ Defective compressor ⑤ Defective outdoor power circuit board | <ul style="list-style-type: none"> ① Open stop valve. ② Check facility of power supply. ③ Correct the wiring (U·V·W phase) to compressor. (Outdoor power circuit board). ④ Check compressor. ⑤ Replace outdoor power circuit board. |
| | <p>(2) Compressor overcurrent interruption Abnormal if overcurrent DC bus or compressor is detected after compressor starts operating for 30 seconds.</p> <p>Over current level : 18.0A</p> | <ul style="list-style-type: none"> ① Stop valve of outdoor unit is closed. ② Decrease of power supply voltage ③ Looseness, disconnection or converse of compressor wiring connection ④ Defective fan of indoor/outdoor units ⑤ Short cycle of indoor/outdoor units ⑥ Defective input circuit of outdoor controller board ⑦ Defective compressor | <ul style="list-style-type: none"> ① Open stop valve. ② Check facility of power supply. ③ Correct the wiring (U·V·W phase) to compressor. (Outdoor power circuit board). ④ Check indoor/outdoor fan. ⑤ Solve short cycle. ⑥ Replace outdoor controller circuit board. ⑦ Check compressor. * Before the replacement of the outdoor controller circuit board, disconnect the wiring to compressor from the outdoor power circuit board and check the output voltage among phases, U, V, W, during test run (SW7-1 ON). No defect on board if voltage among phases (U-V, V-W and W-U) is same. Make sure to perform the voltage check with same performing frequency. |
| 4400 | <p>Outdoor fan motor The outdoor fan motor is considered to be abnormal if the rotational frequency of fan motor is abnormal when detected during operation. Fan motor rotational frequency is abnormal if;</p> <ul style="list-style-type: none"> • 100 rpm or below detected continuously for 15 seconds at 20: or more outside air temperature • 50 rpm or below or 1500 rpm or more detected continuously for 1 minute. | <ul style="list-style-type: none"> ① Failure in the operation of the DC fan motor ② Failure in the outdoor circuit controller board | <ul style="list-style-type: none"> ① Check or replace the DC fan motor. ② Check the voltage of the outdoor circuit controller board during operation. ③ Replace the outdoor circuit controller board. (when the failure is still indicated even after performing the remedy 1 above.) |




| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|---|
| 5101 | <p>Room temperature thermistor (TH21)</p> <p>When controller detects short (high temp.)/open (low temp.) in thermistor during the operation, the operation stops and the operation changes to protect mode of restarting in 3 minutes. If the thermistor does not recover in 3 minutes, the operation stops due to detecting abnormality. In this time, <5101> is displayed. Then, if the thermistor recover in 3 minutes, it operates normally.</p> <p>Short: Detected 90°C or more Open: Detected -40°C or less</p> | <p>① Connector (CN20) contact failure</p> <p>② Thermistor wiring disconnection or half disconnection</p> <p>③ Thermistor failure</p> <p>④ Detecting circuit failure in the indoor controller board</p> | <p>① Check whether the connector (CN20) in the indoor controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor; 0°C...15kΩ 10°C...9.6kΩ 20°C...6.3kΩ 30°C...4.3kΩ 40°C...3.0kΩ</p> <p>④ When there is no problem in above mentioned ①②③, replace the indoor controller board.</p> |
| | <p>Discharge temperature thermistor (TH4)</p> <p>① When controller detects short/open in thermistor during the operation, the outdoor unit stops once and restarts operation in 3 minutes. When the detected temperature is normal at just before of restarting, the outdoor unit restarts.</p> <p>② When controller detects short/open in thermistor at just before of restarting, the unit stops due to detecting abnormality. In this time, <5101> is displayed.</p> <p>③ For 10 minutes after starting compressor, for defrosting or for 3 minutes after recover of defrosting, above-mentioned short/open are not detected. Short: 216°C or more (1kΩ) Open: 0°C or less (700kΩ) Note) When outer temperature thermistor (TH7) is 5°C or less on cooling, open detecting is not determined as abnormality.</p> | <p>① Connector (TH4) contact failure</p> <p>② Thermistor wiring disconnection or half disconnection</p> <p>③ Thermistor failure</p> <p>④ Multi controller board input circuit failure</p> | <p>① Check whether the connector (TH4) in the multi controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor; When the resistance is not below value, replace the thermistor. 0°C... about 700kΩ 10°C... about 410kΩ 20°C... about 250kΩ 30°C... about 160kΩ 40°C... about 104kΩ</p> <p>④ Set the SW1 to  on</p> <p>When the temperature in multi controller board is not an actual temperature, replace the multi controller board.</p> <p>1.3: Open 219.4: Short</p> |





| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|--|
| 5102 | <p>Liquid pipe temperature thermistor (TH22)</p> <p>When the thermistor detects short/open during the operation, the operation stops and the operation changes to protect mode of restarting in 3 minutes. If the thermistor does not recover in 3 minutes, the operation stops due to detecting abnormality. In this time, <5102> is displayed. Then, if the thermistor recovers in 3 minutes, it operates normally.</p> <p>Short: Detected 90°C or more</p> <p>Open: Detected -40°C or less</p> | <p>1) Connector (CN21) contact failure</p> <p>2) Thermistor wiring disconnection or half disconnection</p> <p>3) Thermistor failure</p> <p>4) Detecting circuit failure in the indoor controller board</p> | <p>① Check whether the connector (CN21) in the indoor controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor;</p> <p>0°C...15kΩ 10°C...9.6kΩ 20°C...6.3kΩ 30°C...4.3kΩ 40°C...3.0kΩ</p> <p>④ When there is no problem in above mentioned ①②③, replace the indoor controller board.</p> |
| | <p>Low pressure saturation temperature thermistor (TH6)</p> <p>① When controller detects short/open in thermistor during the operation, the outdoor unit stops once and restarts operation in 3 minutes. When the detected temperature is normal at just before of restarting, the outdoor unit restarts.</p> <p>② When controller detects short/open in thermistor at just before of restarting, the unit stops due to detecting abnormality. In this time, <5102> is displayed.</p> <p>③ For 10 minutes after starting compressor, heating mode, above-mentioned short/open are not detected.</p> <p>Short: 90°C or more</p> <p>Open: -40°C or less</p> | <p>1) Connector (TH6) contact failure</p> <p>2) Thermistor wiring disconnection or half disconnection</p> <p>3) Thermistor failure</p> <p>4) Multi controller board input circuit failure</p> | <p>① Check whether the connector (TH6) in the multi controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor;</p> <p>0°C...15kΩ 10°C...9.6kΩ 20°C...6.3kΩ 30°C...4.3kΩ 40°C...3.0kΩ</p> <p>④ Set the SW1 to  on</p> <p>When the temperature in multi controller board is not an actual temperature, replace the multi controller board.</p> <p>-42.5: Open</p> <p>91.9: Short</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|---|--|--|
| 5103 | <p>Gas pipe temperature thermistor (TH23)</p> <p>When the thermistor detects short/open after 3 minutes-continuous thermo ON during cooling or dry operation, the operation stops and the operation changes to protect mode of restarting in 3 minutes. If the thermistor does not recover in 3 minutes, the operation stops due to detecting abnormality. In this time, <5103> is displayed. Then, if the thermistor recover in 3 minutes, it operates normally.</p> <p>Short: Detected 90°C or more</p> <p>Open: Detected -40°C or less</p> | <p>1) Connector (CN29) contact failure</p> <p>2) Thermistor wiring disconnection or half disconnection</p> <p>3) Thermistor failure</p> <p>4) Detecting circuit failure in the indoor controller board</p> | <p>① Check whether the connector (CN29) in the indoor controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor;</p> <p>0°C...15kΩ 10°C...9.6kΩ 20°C...6.3kΩ 30°C...4.3kΩ 40°C...3.0kΩ</p> <p>④ When there is no problem in above mentioned ①②③, replace the indoor controller board.</p> |
| 5105 | <p>Pipe temperature / judging defrost thermistor (TH3)</p> <p>① When controller detects short/open in thermistor during the operation, the outdoor unit stops once and restarts operation in 3 minutes. When the detected temperature is normal at just before of restarting, the outdoor unit restarts.</p> <p>② When controller detects short/open in thermistor at just before of restarting, the unit stops due to detecting abnormality. In this time, <5105> is displayed.</p> <p>③ For 10 minutes after starting compressor, for defrosting or for 3 minutes after recover of defrosting, above-mentioned short/open are not detected.</p> <p>Short: 88°C or more (0.4kΩ) Open: -39°C or less (115kΩ)</p> | <p>1) Connector (TH3) contact failure</p> <p>2) Thermistor wiring disconnection or half disconnection</p> <p>3) Thermistor failure</p> <p>4) Multi controller board input circuit failure</p> | <p>① Check whether the connector (TH3) in the multi controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor; When the resistance is not below value, replace the thermistor.</p> <p>0°C...15kΩ 10°C...9.6kΩ 20°C...6.3kΩ 30°C...4.3kΩ 40°C...3.0kΩ</p> <p>④ Set the SW1 to  on</p> <p>When the temperature in multi controller board is not an actual temperature, replace the multi controller board.</p> <p>-42.5: Open</p> <p>91.9: Short</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|---|---|---|
| 5106 | <p>Outdoor temperature thermistor (TH7)</p> <p>① When controller detects short/open in thermistor during the operation, the outdoor unit stops once and restarts operation in 3 minutes. When the detected temperature is normal at just before of restarting, the outdoor unit restarts.</p> <p>② When controller detects short/open in thermistor at just before of restarting, the unit stops due to detecting abnormality. In this time, <5106> is displayed.</p> <p>③ For 10 minutes after starting compressor, for defrosting or for 3 minutes after recover of defrosting, above-mentioned short/open are not detected.</p> <p>Short: 90°C or more Open: -40°C or less</p> | <p>1) Connector (TH7) contact failure</p> <p>2) Thermistor wiring disconnection or half disconnection</p> <p>3) Thermistor failure</p> <p>4) Multi controller board input circuit failure</p> | <p>① Check whether the connector (TH7) in the multi controller board is connected or not.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor; When the resistance is not below value, replace the thermistor.</p> <p>0°C····15kΩ 10°C···9.6kΩ 20°C···6.3kΩ 30°C···4.3kΩ 40°C···3.0kΩ</p> <p>④ Set the SW1 to on  When the temperature in multi controller board is not an actual temperature, replace the multi controller board.</p> <p>-42.5: Open 91.9: Short</p> |
| 5110 | <p>Heatsink temperature thermistor (TH8) (internal thermistor of power module)</p> <p>① When controller detects short/open in thermistor during the operation, the outdoor unit stops once and restarts operation in 3 minutes. When the detected temperature is normal at just before of restarting, the outdoor unit restarts.</p> <p>② When controller detects short/open in thermistor at just before of restarting, the unit stops due to detecting abnormality. In this time, <5110> is displayed.</p> <p>③ For 10 minutes after starting compressor, for defrosting or for 3 minutes after recover of defrosting, above-mentioned short/open are not detected.</p> <p>Short:170°C or more Open: -35°C or less</p> | <p>1) Connector (TH8) contact failure.</p> <p>2) Thermistor wiring disconnection or half disconnection.</p> <p>3) Thermistor failure</p> <p>4) Power board input circuit failure</p> | <p>① Check whether the connector (TH8) in the power circuit board.</p> <p>② Check whether the thermistor wiring is disconnected or not.</p> <p>③ Check the resistance of thermistor; When the resistance is not below value, replace the thermistor.</p> <p>0°C ·····180kΩ 10°C ·····105kΩ 20°C ·····63kΩ 30°C ·····39kΩ 40°C ·····25kΩ</p> <p>④ Set the SW1 to on  When the temperature in multi controller board is not an actual temperature, replace the power board.</p> <p>-81.0: Open 999.9: Short</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|---|--|---|
| 5201 | <p>Pressure sensor (63HS)</p> <p>① When detected pressure in high-pressure sensor is 1 MPa or less during the operation, the compressor stops and restarts operation in 3 minutes.</p> <p>② When the detected pressure is 1 MPa or less at just before of restarting, the compressor stops due to detecting abnormality. In this time, <5201> is displayed.</p> <p>③ For 3 minutes after starting compressor, for defrosting or for 3 minutes after recover of defrosting, abnormality is not determined as abnormality.</p> | <p>1) High-pressure sensor failure</p> <p>2) Internal pressure decrease by gas leakage</p> <p>3) Connector contact failure, disconnection</p> <p>4) Multi controller board input circuit failure</p> | <p>① Check the high-pressure sensor.</p> <p>② Check the internal pressure.</p> <p>③ Check the high-pressure sensor.</p> <p>④ Check the high-pressure sensor.</p> |
| 5701 | <p>Connection failure of float switch connector</p> <p>Abnormal if detected that the float switch connector is disconnected(open) during operation</p> | <p>1) Connection failure of connector(CN4F)</p> | <p>① Check the connection failure of connector(CN4F) on the indoor controller board.</p> |
| 5300 | <p>Current sensor error</p> <p>Abnormal if current sensor detects -1.5A to 1.5A during compressor operation. (This error is ignored in case of SW7-1 ON.)</p> | <p>1) Disconnection of compressor wiring</p> <p>2) Defective circuit of current sensor on outdoor power circuit board</p> | <p>① Correct the wiring (U·V·W phase) to compressor. (Outdoor power circuit board).</p> <p>② Replace outdoor power circuit board.</p> |
| 6600 | <p>Duplex address error</p> <p>Detected error when transmission of unit with the same address is confirmed,</p> <p>Note) Address/Attribute displayed on the remote controller shows the controller detecting abnormality.</p> | <p>1) There are 2 units or more with the same address among the outdoor unit or indoor unit or lossnay controller, remote controller.</p> <p>2) When noise has occurred in the transmission signal, and the signal has changed.</p> | <p>① Look for the unit, which is source of abnormality with the same address. When the same address is found, correct the address and turn off power supply of outdoor unit, indoor unit, and lossnay for 2 minutes or more as the same time. Then, turn on power supply.</p> <p>② Check the transmitted wave and the noise on the transmission line.</p> |
| 6602 | <p>Transmission processor H/W error</p> <p>" 1 " shows on the transmission line though the transmission processor transmitted " 0".</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>Note) Address/Attribute displayed on the remote controller shows the controller detecting abnormality.</p> </div> | <p>1) When the wiring for either of the indoor unit, the outdoor unit or lossnay transmission line is constructed or polarity is changed with the power supply turned on, the transmission waves change in case that the transmission data collides mutually. It causes to detect error.</p> <p>2) Transmission processor circuit failure</p> <p>3) When the transmission data has changed by the noise.</p> | <p>① When the transmission wire is constructed with the current flowed, turn off power supply of outdoor unit, indoor unit and lossnay for 2 minutes or more as the same time. Then, turn on power supply.</p> <p>② Check the transmitted wave and the noise on the transmission line.</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|---|--|--|
| 6603 | <p>Transmission bus busy error</p> <p>① Over error by collision Abnormality when the state, which cannot be transmitted by collision of transmission, is consecutive for 8 to 10minutes.</p> <p>② The state that data cannot to be output to the transmission line by the noise happens for 8 to 10 minutes consecutively.</p> <p>Note) Address/Attribute displayed on the remote controller shows the controller detecting abnormality.</p> | <p>1) The transmission processor cannot be transmitted since a short cycle voltage of the noise etc. mixes on the transmission line consecutively.</p> <p>2) The transmission volume increases and cannot be transmitted since the wiring method is mistaken and the routing technique to the terminal board (TB3) for the transmission line of the outdoor unit and the terminal board (TB7) for centralized control cannot be transmitted.</p> <p>3) The share becomes high since the data exists together to other transmitted data by a defective repeater (function which connects and intercepts the transmission of controlling system and centralized control system), and it causes abnormal detection.</p> | <p>① Check whether the transmission line of the indoor unit, fresh master, lossnay and remote controller is connected to the outdoor unit terminal board (TB7) for centralized controller or not.</p> <p>② Check whether the transmission line with the other refrigerant system of the indoor unit and lossnay is connected to the outdoor unit terminal board (TB3) for transmission or not.</p> <p>③ Check whether the outdoor unit terminal board for transmission line (TB3) and for centralized controller (TB7) are connected or not.</p> <p>④ Check the transmitted wave and the noise on the transmission line.</p> |
| 6606 | <p>Signal communication error with transmission processor</p> <p>Signal communication error between unit processor and transmission processor</p> <p>Note) Address/Attribute displayed on the remote controller shows the controller detecting abnormality.</p> | <p>1) The data of the unit/transmission processor was not normally transmitted due to accidental disturbance such as noise and lightening surge.</p> <p>2) The address transmission from the unit processor was not normally transmitted by the hardware of transmission processor defective.</p> | <p>Turn off power supply of outdoor unit, indoor unit, and lossnay for 2minutes or more at the same time. Then, turn on power supply. It normally recovers from the malfunction that happens by chance. When same abnormality occurs again, it is defective of the controller.</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|---|--|
| 6607 | <p>No ACK (Acknowledgement)</p> <p>① Abnormality which controller of the sending side detects when there is no answer (ACK) from other side though data was transmitted once. It is detected 6 times every 30 seconds continuously.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note) Address/Attribute displayed on the remote controller shows the controller, which did not send back replay (ACK).</p> </div> | <p>Factor that does not related to origin</p> <p>1) Since the address switch was changed with the current passed, the unit in the last address does not exist.</p> <p>2) Decline of transmission voltage and signal by transmission line tolerance over · The furthest point...200m · Remote controller line...(12m) (Refer to 8-3.)</p> <p>3) Decline of transmission line voltage and signal by unmatched kind of line. · Shield line-CVVS,CPEVS Line diameter...1.25 mm² or more</p> <p>4) Decline of transmission line voltage and signal by a number of over-connected units.</p> <p>5) Mis-operation of origin controller, which happens by chance.</p> <p>6) Original controller defective</p> | <p>① Turn off power supply of outdoor unit, indoor unit fresh master and lossnay for 2 minutes or more at the same time. Then, turn on power supply. It recovers normally from the malfunction that happens by chance.</p> <p>② Check the address switch of the address which causes abnormality.</p> <p>③ Check whether the transmission line is connected / loosen or not at origin. (Terminal board or connector)</p> <p>④ Check whether the transmission line tolerance is over or not.</p> <p>⑤ Check whether the kind of transmission line is mistaken or not.</p> <p>When there is any trouble from above ①-⑤, turn off power supply of outdoor unit, indoor unit and lossnay for 2 minutes or more at the same time. Then, turn on power supply.</p> <p>= When there is not any trouble in single refrigerant system (1 outdoor unit) from above①-⑤, controller defective in displayed address and attribute.</p> <p>= When there is not any trouble in different refrigerant system (2 outdoor unit or more) from above ①-⑤, determine it after ⑥.</p> <p>⑥ When the address which should not exist is an origin, since there is the indoor unit which memorizes the address data, cancel the unnecessary address data by the manual setting function of remote controller. However, they are limited to the system, which sets the group between different refrigerant systems, or which fresh master /lossnay are connected.</p> <p>When there is not any trouble from above ①-⑥, replace the displayed address/attribute controller board.</p> <p>In this time, when the error does not recover to normal, the outdoor unit multi controller board (repeater circuit) defective is expected.</p> <p>Check the recovery by replacing the multi controller board one by one.</p> |
| | <p>1) When the cause of displayed address and attribute is on the outdoor unit side (The indoor unit detects when there is no reply (ACK) on transmitting from the indoor unit to the outdoor unit.)</p> | <p>1) Contact failure of outdoor unit or indoor unit transmission line</p> <p>2) Indoor unit transmission connector (CN2M) disconnection</p> <p>3) Sending/receiving signal circuit failure in the indoor/outdoor unit</p> | |
| | <p>2) When the cause of displayed address and attribute is on the indoor unit side</p> <p>(The remote controller detects when there is no reply (ACK) on transmitting from the remote controller to the indoor unit.)</p> | <p>1) When operating with multi refrigerant system indoor units, the remote controller transmits the signal to the indoor unit after the other refrigerant system outdoor unit is turned off or turned on again in 2 minutes, and detects abnormality.</p> <p>2) Contact failure of remote controller or indoor unit transmission line</p> <p>3) Indoor unit transmission connector (CN2M) disconnection</p> <p>4) Sending/receiving signal circuit failure in the indoor unit or remote controller.</p> | |

Continued to the next page.

From the previous page.

| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|--------------|
| 6607 | <p>3) When the cause of displayed address and attribute is on the remote controller side</p> <p>(The indoor unit detects when there is no reply (ACK) on transmitting from the indoor unit to the remote controller unit.)</p> | <p>1) When operating with multi refrigerant system indoor units, the indoor units transmits the signal to the remote controller after the other refrigerant system outdoor unit is turned off or turned on again in 2 minutes, and detects abnormality.</p> <p>2) Contact failure of remote controller or indoor unit transmission line</p> <p>3) Indoor unit transmission connector (CN2M) disconnection</p> <p>4) Sending/receiving signal circuit failure in the indoor unit or remote controller</p> | |
| | <p>4) When the cause of displayed address and attribute is on the fresh master side</p> <p>(The indoor unit detects when there is no reply (ACK) on transmitting from the indoor unit to the fresh master.)</p> | <p>1) When synchronized operating with other refrigerant system fresh master, the indoor units transmits the signal to the fresh master after the fresh master and same refrigerant system outdoor unit is turned off or turned on again in 2 minutes, and detects abnormality.</p> <p>2) Contact failure of fresh master or indoor unit transmission line</p> <p>3) Indoor unit or fresh master transmission connector (CN2M) disconnection</p> <p>4) Sending/receiving signal circuit failure in the indoor unit or fresh master</p> | |
| | <p>5) When the cause of displayed address and attribute is on the lossnay side</p> <p>(The indoor unit detects when there is no reply (ACK) on transmitting from the indoor unit to the lossnay.)</p> | <p>1) When the lossnay power supply is Off, the indoor unit detects abnormality at signal transmitting to the lossnay.</p> | |

Continued to the next page.









From the previous page.

| Display | Abnormal point and detecting method | Causes | Check points |
|---------|--|--|---|
| 6607 | | <p>2) When synchronized operating with other refrigerant system lossnay, the indoor units transmits the signal to the lossnay after the lossnay and same refrigerant system outdoor unit is turned off or turned on again in 2 minutes, and detects abnormality</p> <p>3) Contact failure of lossnay or indoor unit transmission line</p> <p>4) Indoor unit transmission connector (CN2M) disconnection</p> <p>5) Sending/receiving signal circuit failure in the indoor unit or lossnay</p> | |
| | 6) When the controller of displayed address and attribute is not recognized | <p>1) Since the address switch was changed with the current passed, the unit in the last address does not exist.</p> <p>2) Since the fresh master/lossnay address are changed after synchronized setting of fresh master / lossnay by the remote controller, abnormality is detected at transmitting from the indoor unit.</p> | |
| 6608 | <p>No response Though there was a replay (ACK) of having received signal from the other side, it is the abnormality when the response command does not return. The sending side detects the abnormality continuously six times every 30 seconds. Note) Address/Attribute displayed on the remote controller shows the controller, which did not response.</p> | <p>1) Transmission repeats the failure by the noise etc.</p> <p>2) Decline of transmission voltage and signal by transmission line tolerance over · The furthest point··200m · Remote controller line··(12m) (Refer to 8-3.)</p> <p>3) Decline of transmission line voltage and signal by unmatched kind of line · Shield wire-CVVS,CPEVS Wire diameter··1.25mm²or more</p> <p>4) Mis-operation of origin controller, which happens by chance.</p> | <p>① Check the transmission wave and noise on the transmission line.</p> <p>② Turn off power supply of outdoor unit, indoor unit and lossnay for 2minutes or more at the same time. Then, turn on power supply again. It normally recovers from the malfunction that happens by chance. When same abnormality occurs again, it is defective of displayed address and attribute.</p> |



| Display | Abnormal point and detecting method | Causes | Check points |
|--------------|---|---|---|
| 6831 6834 | <p>Signal reception(Remote controller) Following symptoms are regarded as abnormality.</p> <p>1) When the remote controller cannot receive the signal from indoor controller normally even once for 3 minutes</p> <p>2) When the remote controller cannot receive the signal even once for 2 minutes</p> | <p>① Defect of the transmission and reception circuit of the remote controller.</p> <p>② Defect of the transmission and reception circuit of the indoor controller board</p> <p>③ Noise occurs on the transmission line of the remote controller</p> <p>④ All remote controllers are set as sub-remote controller.</p> | <p>①~③ Check the remote controller. According to the results, perform the following disposals.</p> <ul style="list-style-type: none"> • When "RC OK" is displayed, the remote controller is normal. Turn off the power supply and turn it on again. • If "HO" or "PLEASE WAIT" is displayed for 4 minutes or more, replace the indoor controller board. • When "RC NG" is displayed, replace the remote controller. • When "RC 6832 or 6833" or "ERC 00-66" is displayed, these displays may be due to noise, etc. <p>④ Set one remote controller to main remote controller and the other to sub-remote controller.</p> |
| 6832 6833 | <p>Signal transmission(Remote controller) Following symptoms are regarded as abnormality.</p> <p>1) When sub-remote controller cannot transmit the signal to the transmission path for 6 minutes</p> <p>2) When the remote controller cannot finish transmitting the signal for 30 times on end</p> | <p>① Defect of the transmission and reception circuit of the remote controller</p> <p>② Noise occurs on the transmission line of the remote controller</p> <p>③ There are 2 main remote controllers.</p> | <p>④ Set one remote controller to main remote controller and the other to sub-remote controller.</p> |
| 7100 | <p>When connected total models of the indoor units exceed the specified level (130% of the outdoor unit models), error code <7100> is displayed.</p> | <p>1) Connecting total models of the indoor unit exceed the specified level.</p> <ul style="list-style-type: none"> · PUMY-P100 (~ code 26) · PUMY-P125 (~ code 33) · PUMY-P140 (~ code 38) <p>-----</p> <p>2) There is a mistake in the registration of model name code of the outdoor unit.</p> | <p>① Check the total models of connected indoor unit.</p> <p>② Check the model code registration switch (indoor controller board SW2) of connected indoor unit.</p> <p>-----</p> <p>Check the model code registration switch (outdoor multi controller board SW4) of the outdoor unit.</p> |




| Display | Abnormal point and detecting method | Causes | Check points |
|---------|---|--|--|
| 7101 | <p>Capacity code error</p> <p>When the connected indoor unit models cannot be connected, <7101> is displayed.</p> | <p>The indoor unit models is not possible to connect. [PUMY-100/125/140YHM_(r1)] The indoor unit of 20-140(code 4-28) is possible to connect. [PUMY-100/125/140YHMA(-BS)] The indoor unit of 15-40(Code 3-28) is possible to connect.</p> | <p>① Check the model code registration switch (indoor controller board SW2) in the connected indoor unit.</p> <p>② The outdoor unit SW1 operation can check model code of the connected indoor units.</p> <p>Code of indoor unit No.1 on </p> <p>Code of indoor unit No.2 on </p> <p>Code of indoor unit No.3 on </p> <p>Code of indoor unit No.4 on </p> <p>Code of indoor unit No.5 on </p> <p>Code of indoor unit No.6 on </p> <p>Code of indoor unit No.7 on </p> <p>Code of indoor unit No.8 on </p> |
| 7102 | <p>Number of connecting unit over</p> <p>When the connecting unit exceeds a number of limitations, error code <7102> is displayed.</p> <p>(Even if the indoor unit is not connected, <7102> is display.)</p> | <p>Connecting unit exceeds a number of limitations. It is assumed abnormal excluding the following cases;</p> <p>1) The indoor unit can be totally connected up to 6(P100)/8(P125, 140) units. The indoor unit can be connected up to 6(P100)/8(P125, 140) units</p> <p>2) Ventilation unit connecting is only 1 unit.</p> | <p>Check whether the connecting unit exceeds a number of limitations or not.</p> |
| 7105 | <p>Address setting error</p> <p>Address setting of the outdoor unit is wrong.</p> | <p>Addresses mis-setting of the outdoor unit</p> <p>The outdoor unit is not set in 000 or in the range of 51-100.</p> | <p>Check the address setting of the outdoor unit. The address should be set in 000 or 51-100.</p> <p>When the setting is out of the range, reset it, turn off power supply of the outdoor unit, indoor unit and lossnay for 2 minutes or more at the same time, and turn on power supply again.</p> |
| 7111 | <p>Remote controller sensor</p> <p>In the case of network remote controller, it is an abnormality when incapable response returns from the network remote controller during the operation.</p> | <p>When an old type remote controller for M-NET is used, and the remote controller sensor is specified (SW1-1 is ON).</p> | <p>Replace the remote controller to network remote controller.</p> |
| 0403 | <p>Serial communication error</p> <p>Abnormal if serial communication between outdoor multi board and outdoor power board is defective.</p> | <p>① Breaking of wire or contact failure of connector CN2 ② Breaking of wire or contact failure of connector CN4 ③ Defective communication circuit of outdoor power board ④ Defective communication circuit of outdoor multi board for power board</p> | <p>①② Check connection of each connector CN2, CN4.</p> <p>③ Replace outdoor power board.</p> <p>④ Replace outdoor multi board.</p> |

9-2. REMOTE CONTROLLER DIAGNOSIS

· MA remote controller is equipped with the diagnosis function

If the air conditioner cannot be operated from the remote controller, diagnose the remote controller as explained below.


- ① First, check that the power-on indicator is lit.
If the correct voltage (DC12 V) is not supplied to the remote controller, the indicator will not light.
If this occurs, check the remote controller's wiring and the indoor unit.



Power on indicator


- ② Switch to the remote controller self-diagnosis mode.
Press the **CHECK** button for 5 seconds or more. The display content will change as shown below.

Press the **FILTER** button to start self-diagnosis.



- ③ Remote controller self-diagnosis result


[When the remote controller is functioning correctly]



Check for other possible causes, as there is no problem with the remote controller.

[When the remote controller malfunctions]

(Error display 1) "NG" flashes. → The remote controller's transmitting-receiving circuit is defective.




The remote controller must be replaced with a new one.

[Where the remote controller is not defective, but cannot be operated.]
(Error display 2) [E3], [6833] or [6832] flashes. → Transmission is not possible.





There might be noise or interference on the transmission path, or the indoor unit or other remote controllers are defective. Check the transmission path and other controllers.

(Error display 3) "ERC" and the number of data errors are displayed.
→ Data error has occurred.



The number of data errors is the difference between the number of bits sent from the remote controller and the number actually transmitted through the transmission path. If such a problem is occurring, the transmitted data is affected by noise, etc. Check the transmission path.


When the number of data errors is "02":

Transmission data from remote controller 
Transmission data on transmission path 

- ④ To cancel remote controller diagnosis

Press the **CHECK** button for 5 seconds or more. Remote controller diagnosis will be cancelled, "PLEASE WAIT" and operation lamp will flash. After approximately 30 seconds, the state in effect before the diagnosis will be restored.

9-3. REMOTE CONTROLLER TROUBLE



“●” Indicator: appears when current is carried.

(M-NET Remote controller)

(1) For M-NET remote controller systems

| Symptom or inspection code | Cause | Inspection method and solution |
|---|--|--|
| Though the content of operation is displayed on the remote controller, some indoor units do not operate. | <ul style="list-style-type: none"> The power supply of the indoor unit is not on. The address of the indoor units in same group or the remote controller is not set correctly. The group setting between outdoor units is not registered to the remote controller. The fuse on the indoor unit controller board is blown. | <ul style="list-style-type: none"> Check the part where the abnormality occurs. ① The entire system ② In the entire refrigerant system ③ In same group only ④ 1 indoor unit only |
| Though the indoor unit operates, the display of the remote controller goes out soon. | <ul style="list-style-type: none"> The power supply of the indoor unit is not on. The fuse on the indoor unit controller board is blown. | <p><In case of the entire system or in the entire refrigerant system></p> <ul style="list-style-type: none"> Check the self-diagnosis LED of the outdoor unit. Check the items shown in the left that are related to the outdoor unit. <p><In case of in same group only or 1 indoor unit only></p> <ul style="list-style-type: none"> Check the items shown in the left that are related to the indoor unit. |
| “●” is not displayed on the remote controller. (M-NET remote controller is not fed.) | <ul style="list-style-type: none"> The power supply of the outdoor unit is not on. The connector of transmission outdoor power board is not connected. The number of connected indoor unit in the refrigeration system is over the limit or the number of connected remote controller is over the limit. M-NET remote controller is connected to MA remote controller cable. The transmission line of the indoor/outdoor unit is shorted or down. M-NET remote controller cable is shorted or down. Transmission outdoor power board failure. | |
| "HO" keeps being displayed or it is displayed periodically. ("HO" is usually displayed about 3 minutes after the power supply of the outdoor unit is on.) | <ul style="list-style-type: none"> The power supply for the feeding expansion unit for the transmission line is not on. The address of the outdoor unit remains "00". The address of the indoor unit or the remote controller is not set correctly. MA remote controller is connected to the transmission line of the indoor/outdoor unit. | |
| The remote controller does not operate though “●” is displayed. | <ul style="list-style-type: none"> The transmission line of the indoor/outdoor unit is connected to TB15. The transmission line of the indoor/outdoor unit is shorted, down or badly contacted. | |

(2) For MA remote controller systems

| Symptom or inspection code | Cause | Inspection method and solution |
|---|--|--|
| Though the content of operation is displayed on the remote controller, some indoor units do not operate. | <ul style="list-style-type: none"> The power supply of the indoor unit is not on. Wiring between indoor units in same group is not finished. The indoor unit and Slim model are connected to same group. The fuse on the indoor unit controller board is blown. | <ul style="list-style-type: none"> Check the part where the abnormality occurs. ① The entire system ② In the entire refrigerant system ③ In same group only ④ 1 indoor unit only |
| Though the indoor unit operates, the display of the remote controller goes out soon. | <ul style="list-style-type: none"> The power supply of the indoor unit (Master) is not on. In case of connecting the system controller, the setting of the system controller does not correspond to that of MA remote controller. The fuse on the indoor unit (Master) controller board is blown. | <p><In case of the entire system or in the entire refrigerant system></p> <ul style="list-style-type: none"> Check the self-diagnosis LED of the outdoor unit. Check the items shown in the left that are related to the outdoor unit. <p><In case of in same group only or 1 indoor unit only></p> <ul style="list-style-type: none"> Check the items shown in the left that are related to the indoor unit. |
| “●” is not displayed on the remote controller. (MA remote controller is not fed.) | <ul style="list-style-type: none"> The remote controller is not fed until the power supply of both indoor unit and outdoor unit is on and the start-up of both units is finished normally. The power supply of the indoor unit is not on. The power supply of the outdoor unit is not on. The number of connected remote controller is over the limit (Maximum: 2 units) or the number of connected indoor unit that is over the limit (Maximum: 16 units). The address of the indoor unit is "00" and the address for the outdoor unit is the one other than "00". The transmission line of the indoor/outdoor unit is connected to TB15. MA remote controller is connected to the transmission line of the indoor/outdoor unit. The remote controller cable is shorted or down. The power supply cable or the transmission line is shorted or down. The fuse on the indoor unit controller board is blown. | |
| "PLEASE WAIT" keeps being displayed or it is displayed periodically. ("PLEASE WAIT" is usually displayed about 3 minutes after the power supply of the outdoor unit is on.) | <ul style="list-style-type: none"> The power supply of the outdoor unit is not on. The power supply of the feeding expansion unit for the transmission line is not on. The setting of MA remote controller is not main remote controller, but sub-remote controller. MA remote controller is connected to the transmission line of the indoor/outdoor unit. | |
| The remote controller does not operate though “●” is displayed. | <ul style="list-style-type: none"> The power supply of the indoor unit (Master) is not on. The transmission line of the indoor/outdoor unit is connected to TB15. The transmission line of the indoor/outdoor unit is shorted, down or badly contacted. The fuse on the indoor unit controller board is blown. | |

9-4. THE FOLLOWING SYMPTOM DO NOT REPRESENT TROUBLE (EMERGENCY)

| Symptom | Display of remote controller | CAUSE |
|---|-------------------------------------|--|
| Even the cooling (heating) operation selection button is pressed, the indoor unit cannot be operated. | "Cooling (Heating)" blinks | The indoor unit can not cool (heat) if other indoor units are heating (cooling). |
| The auto vane runs freely. | Normal display | Because of the control operation of auto vane, it may change over to horizontal blow automatically from the downward blow in cooling in cause the downward blow operation has been continued for 1 hour. At defrosting in heating, hot adjusting and thermostat OFF, it automatically changes over to horizontal blow. |
| Fan setting changes during heating. | Normal display | Ultra-low speed operation is commenced at thermostat OFF. Light air automatically change over to set value by time or piping temperature at thermostat ON. |
| Fan stops during heating operation. | "Defrost ❄" | The fan is to stop during defrosting. |
| Fan does not stop while operation has been stopped. | Light out | Fan is to run for 1 minute after stopping to exhaust residual heat (only in heating). |
| No setting of fan while start SW has been turned on. | STAND BY ❄ | Ultra-low speed operation for 5 minutes after SW ON or until piping temperature becomes 35C. There low speed operate for 2 minutes, and then set notch is commenced. (Hot adjust control) |
| Indoor unit remote controller shows "HO" or "PLEASE WAIT" indicator for about two minutes when turning ON power supply. | "HO" blinks "PLEASE WAIT" blinks | System is being driven. Operate remote controller again after "HO" or "PLEASE WAIT" disappears. |
| Drain pump does not stop while unit has been stopped. | Light out | After a stop of cooling operation, unit continues to operate drain pump for 3 minutes and then stops it. |
| Drain pump continues to operate while unit has been stopped. | — | Unit continues to operate drain pump if drainage is generated, even during a stop. |

9-5. INTERNAL SWITCH FUNCTION TABLE

PUMY-P100YHM

PUMY-P125YHM

PUMY-P140YHM

PUMY-P100YHM1

PUMY-P125YHM1

PUMY-P140YHM1

PUMY-P100YHMA















PUMY-P125YHMA

PUMY-P140YHMA

PUMY-P100YHMA-BS

PUMY-P125YHMA-BS

PUMY-P140YHMA-BS

| Switch | Step | Function | Operation in Each Switch Setting | | | Remarks | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---------------|--|----------------------------------|--------------------------------|--|---|--|--|--|---|---|---|---|---|---|-----------|---|---|---|---|---|---|-----------|---|---|---|---|---|---|-----------|---|---|---|---|---|---|--|--|--------------------------------|--|
| | | | ON | OFF | When to Set | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW U1 1st digit SW U2 2nd digit | Rotary switch |  SWU2 (2nd digit)  SWU1 (1st digit) | | | Before turning the power on | <Initial settings>  SWU2 (2nd digit)  SWU1 (1st digit) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW1 Digital Display Switching | 1~8 | ON  OFF  1 2 3 4 5 6 7 8 | | | Can be set either during operation or not. | <Initial settings> ON  OFF  1 2 3 4 5 6 7 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW2 Function Switching | 1 | Selects operating system startup | With centralized controller | Without centralized controller | Before turning the power on | <Initial settings> ON  OFF  1 2 3 4 5 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Connection Information Clear Switch | Clear | Do not clear | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | Abnormal data clear switch input | Clear abnormal data | Normal | OFF to ON any time after the power is turned on. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4 | Pump down | Run adjustment mode | Normal | During compressor running | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 5 | Auto change over from Remote controller | Enable | Disable | Before turning the power on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 6 | — | — | — | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW3 Trial operation | 1 | ON/ OFF from outdoor unit | ON | OFF | Any time after the power is turned on. | <Initial settings> ON  OFF  1 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Mode setting | Heating | Cooling | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW4 Model Switching | 1~6 | ※1 MODEL SELECT 1:ON 0:OFF <table border="1" data-bbox="448 1189 804 1323"> <thead> <tr> <th rowspan="2">MODELS</th> <th colspan="6">SW4</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> <th>5</th> <th>6</th> </tr> </thead> <tbody> <tr> <td>PUMY-P100</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td>0</td> </tr> <tr> <td>PUMY-P125</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>PUMY-P140</td> <td>1</td> <td>1</td> <td>0</td> <td>0</td> <td>1</td> <td>1</td> </tr> </tbody> </table> | MODELS | SW4 | | | | | | 1 | 2 | 3 | 4 | 5 | 6 | PUMY-P100 | 1 | 1 | 0 | 0 | 1 | 0 | PUMY-P125 | 1 | 1 | 0 | 0 | 0 | 1 | PUMY-P140 | 1 | 1 | 0 | 0 | 1 | 1 | | | Before the power is turned on. | <Initial settings> Set for each capacity. |
| MODELS | SW4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | 2 | 3 | 4 | 5 | 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PUMY-P100 | 1 | 1 | 0 | 0 | 1 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PUMY-P125 | 1 | 1 | 0 | 0 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PUMY-P140 | 1 | 1 | 0 | 0 | 1 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SW5 Function switching | 1 | Pressure limitation value change | Enable | Normal | Can be set when off or during operation OFF to ON during compressor running. Can be set when off or during operation | <Initial settings> ON  OFF  1 2 3 4 5 6 7 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Change the indoor unit's LEV opening at start | Enable | Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | Fixing the indoor units linear expansion valve opening | Fix | Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4 | Fix the operation frequency | Fix | Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 5 | Change the indoor unit's LEV opening at defrost | Enable | Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 6 | Switching the target sub cool. | Enable | Normal | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 7 | During the FAN or COOL mode, and thermo-OFF or OFF in heating operation, set the opening of linear expansion valve on indoor unit ※1 | Active | Inactive | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 8 | During the FAN or COOL mode, and thermo-OFF in heating operation, set the opening of linear expansion valve on indoor unit ※2 | Active | Inactive | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

※1 SW5-7 Refrigerant amount shortage measure during heating operation
(Refrigerant piping is long etc.)


※2 SW5-8 Countermeasure against room temperature rise for indoor unit in FAN, COOL, and thermo-OFF (heating) mode.



| | Switch | Step | Function | Operation in Each Switch Setting | | | Remarks | | | | | | | | | | | | | | | | |
|--------------|------------------------------|--|---|----------------------------------|--|---|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | | | ON | OFF | When to Set | | | | | | | | | | | | | | | | | |
| Outdoor unit | SW6 function switching | 1 | — | — | — | — | <Initial settings> ON <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table> OFF <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table> 1 2 3 4 5 6 7 8 | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2 | Switch of current limitation reading in a different way | Enable | Normal | Before turning the power on. | | | | | | | | | | | | | | | | | |
| | | 3 | — | — | — | — | | | | | | | | | | | | | | | | | |
| | | 4 | Restriction of maximum frequency | Enable | Normal | Can be set when off or during operation | | | | | | | | | | | | | | | | | |
| | | 5 | Ignore refrigerant filling abnormality | Enable | Normal | | | | | | | | | | | | | | | | | | |
| | | 6 | Switching the target discharge pressure (Pdm) | Enable | Normal | | | | | | | | | | | | | | | | | | |
| | 7 | Switching (1) the target evaporation temperature (ETm) | Enable | Normal | | | | | | | | | | | | | | | | | | | |
| | 8 | Switching (2) the target evaporation temperature (ETm) | Enable | Normal | | | | | | | | | | | | | | | | | | | |
| | SW7 function switching | 1 | Ignore current sensor abnormality | Enable | Normal | Before turning the power on. | <Initial settings> ON <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table> OFF <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td><td> </td><td> </td><td> </td><td> </td></tr></table> 1 2 3 4 5 6 | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2 | — | — | — | — | | | | | | | | | | | | | | | | | |
| | | 3 | — | — | — | | | | | | | | | | | | | | | | | | |
| | | 4 | — | — | — | | | | | | | | | | | | | | | | | | |
| | 5 | — | — | — | | | | | | | | | | | | | | | | | | | |
| | 6 | Forced defrost | Forced defrost | Normal | During compressor running in heating mode. | | | | | | | | | | | | | | | | | | |
| | SW8 function switching | 1 | Silent mode/ Demand Control Selection (see next page) | Demand Control | Silent mode | Can be set when off or during operation | <Initial settings> ON <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td></tr></table> OFF <table border="1" style="display: inline-table; vertical-align: middle;"><tr><td> </td><td> </td></tr></table> 1 2 | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Change of defrosting control | Enable (For high humidity) | Normal | | | | | | | | | | | | | | | | | | | |

9-6. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR


• State (CN51)



- Ⓐ Distant control board
- Ⓑ Relay circuit
- Ⓒ External output adapter (PAC-SA88HA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Lamp power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

L1 : Error display lamp
 L2 : Compressor operation lamp
 X, Y : Relay (Coil standard of 0.9W or less for DC 12V)
 X, Y : Relay (DC1mA)


• Auto change over (CN3N)



- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

| | ON | OFF |
|-----|-----------------|-------------------|
| SW1 | Heating | Cooling |
| SW2 | Validity of SW1 | Invalidity of SW1 |

• Silent Mode / Demand Control (CN3D)



- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

| | ON | OFF |
|-----|-----------------|-------------------|
| SW1 | Heating | Cooling |
| SW2 | Validity of SW1 | Invalidity of SW1 |

The silent mode and the demand control are selected by switching the Dip switch 8-1 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1,2.

| | Outdoor controller board DIP SW8-1 | SW1 | SW2 | Function |
|----------------|------------------------------------|-----|-----|-----------------------|
| Silent mode | OFF | ON | — | Silent mode operation |
| Demand control | ON | OFF | OFF | 100% (Normal) |
| | | ON | OFF | 75% |
| | | ON | ON | 50% |
| | | OFF | ON | 0% (Stop) |


9-7. HOW TO CHECK THE PARTS

PUMY-P100YHM
PUMY-P125YHM
PUMY-P140YHM

PUMY-P100YHM₁
PUMY-P125YHM₁
PUMY-P140YHM₁

PUMY-P100YHMA
PUMY-P125YHMA
PUMY-P140YHMA

PUMY-P100YHMA-BS
PUMY-P125YHMA-BS
PUMY-P140YHMA-BS

| Parts name | Check points | | | | | | | | | | | | | |
|--|---|---------------|----------|----------|-----------------------------------|--------------------------------------|---------------|------------|-------------|-----|-----|--------|------------|--|
| Thermistor (TH3) <Outdoor pipe> Thermistor (TH4) <Discharge> Thermistor (TH6) <Low pressure saturated temperature> Thermistor (TH7) <Outdoor> Thermistor (TH8) <Heatsink> | Disconnect the connector then measure the resistance with a tester. (At the ambient temperature 10°C~30°C) <table border="1" style="margin-top: 10px;"> <thead> <tr> <th></th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>TH4</td> <td>160kΩ~410kΩ</td> <td rowspan="4">Open or short</td> </tr> <tr> <td>TH3</td> <td rowspan="2">4.3kΩ~9.6kΩ</td> </tr> <tr> <td>TH6</td> </tr> <tr> <td>TH7</td> </tr> <tr> <td>TH8 ※1</td> <td>39kΩ~105kΩ</td> <td></td> </tr> </tbody> </table> <p style="text-align: right;">※1 TH8 is internal thermistor of power module.</p> | | Normal | Abnormal | TH4 | 160kΩ~410kΩ | Open or short | TH3 | 4.3kΩ~9.6kΩ | TH6 | TH7 | TH8 ※1 | 39kΩ~105kΩ | |
| | Normal | Abnormal | | | | | | | | | | | | |
| TH4 | 160kΩ~410kΩ | Open or short | | | | | | | | | | | | |
| TH3 | 4.3kΩ~9.6kΩ | | | | | | | | | | | | | |
| TH6 | | | | | | | | | | | | | | |
| TH7 | | | | | | | | | | | | | | |
| TH8 ※1 | 39kΩ~105kΩ | | | | | | | | | | | | | |
| Fan motor(MF1,MF2) | Refer to next page. | | | | | | | | | | | | | |
| Solenoid valve coil <Four-way valve> (21S4) | Measure the resistance between the terminals with a tester. (At the ambient temperature 20°C) <table border="1" style="margin-top: 10px;"> <thead> <tr> <th colspan="2">Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>P100, P125,P140YHM</td> <td>P100,P125,P140YHM₁/YHMA</td> <td rowspan="2">Open or short</td> </tr> <tr> <td>1370 ±100Ω</td> <td>1435 ±150Ω</td> </tr> </tbody> </table> | Normal | | Abnormal | P100, P125,P140YHM | P100,P125,P140YHM ₁ /YHMA | Open or short | 1370 ±100Ω | 1435 ±150Ω | | | | | |
| Normal | | Abnormal | | | | | | | | | | | | |
| P100, P125,P140YHM | P100,P125,P140YHM ₁ /YHMA | Open or short | | | | | | | | | | | | |
| 1370 ±100Ω | 1435 ±150Ω | | | | | | | | | | | | | |
| Motor for compressor (MC)  | Measure the resistance between the terminals with a tester. (Winding temperature 20°C) <table border="1" style="margin-top: 10px;"> <thead> <tr> <th colspan="2">Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>P100, P125,P140YHM₍₁₎</td> <td>P100,P125,P140YHMA</td> <td rowspan="2">Open or short</td> </tr> <tr> <td>0.302Ω</td> <td>0.330Ω</td> </tr> </tbody> </table> | Normal | | Abnormal | P100, P125,P140YHM ₍₁₎ | P100,P125,P140YHMA | Open or short | 0.302Ω | 0.330Ω | | | | | |
| Normal | | Abnormal | | | | | | | | | | | | |
| P100, P125,P140YHM ₍₁₎ | P100,P125,P140YHMA | Open or short | | | | | | | | | | | | |
| 0.302Ω | 0.330Ω | | | | | | | | | | | | | |
| Solenoid valve coil <Bypass valve> (SV1) | Measure the resistance between the terminals with a tester. (At the ambient temperature 20°C) <table border="1" style="margin-top: 10px;"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>1197±10Ω</td> <td>Open or short</td> </tr> </tbody> </table> | Normal | Abnormal | 1197±10Ω | Open or short | | | | | | | | | |
| Normal | Abnormal | | | | | | | | | | | | | |
| 1197±10Ω | Open or short | | | | | | | | | | | | | |


Check method of DC fan motor (fan motor / outdoor controller circuit board)

① Notes

- High voltage is applied to the connector (CNF1, 2) for the fan motor. Give attention to the service.
- Do not pull out the connector (CNF1, 2) for the motor with the power supply on.
(It causes trouble of the outdoor controller circuit board and fan motor.)

② Self check

Symptom : The outdoor fan cannot turn around.



9-8. HOW TO CHECK THE COMPONENTS

<Thermistor feature chart>

Low temperature thermistors


- Thermistor <Outdoor pipe> (TH3)
- Thermistor <Low pressure saturated temperature> (TH6)
- Thermistor <Outdoor> (TH7)

Thermistor R0 = 15kΩ ± 3%

B constant = 3480 ± 2%

$$R_t = 15 \exp\left\{3480 \left(\frac{1}{273+t} - \frac{1}{273} \right)\right\}$$

| | | | |
|------|-------|------|-------|
| 0°C | 15kΩ | 30°C | 4.3kΩ |
| 10°C | 9.6kΩ | 40°C | 3.0kΩ |
| 20°C | 6.3kΩ | | |
| 25°C | 5.2kΩ | | |



High temperature thermistor


- Thermistor <Discharge> (TH4)

Thermistor R120 = 7.465kΩ ± 2%



B constant = 4057 ± 2%

$$R_t = 7.465 \exp\left\{4057 \left(\frac{1}{273+t} - \frac{1}{393} \right)\right\}$$

| | | | |
|------|-------|-------|--------|
| 20°C | 250kΩ | 70°C | 34kΩ |
| 30°C | 160kΩ | 80°C | 24kΩ |
| 40°C | 104kΩ | 90°C | 17.5kΩ |
| 50°C | 70kΩ | 100°C | 13.0kΩ |
| 60°C | 48kΩ | 110°C | 9.8kΩ |



<HIGH PRESSURE SENSOR>



- ③-① : 5V (DC)
- ②-① : Output Vout (DC)

9-9. TEST POINT DIAGRAM


Outdoor multi controller board

PUMY-P100YHM
PUMY-P125YHM
PUMY-P140YHM

PUMY-P100YHM₁
PUMY-P125YHM₁
PUMY-P140YHM₁

PUMY-P100YHMA
PUMY-P125YHMA
PUMY-P140YHMA

PUMY-P100YHMA-BS
PUMY-P125YHMA-BS
PUMY-P140YHMA-BS



Outdoor power circuit board
PUMY-P100YHM PUMY-P100YHM₁
PUMY-P125YHM PUMY-P125YHM₁
PUMY-P140YHM PUMY-P140YHM₁
PUMY-P100YHMA(-BS)
PUMY-P125YHMA(-BS)
PUMY-P140YHMA(-BS)

Brief check of POWER MODULE

* Usually, each point is in a state of being short-circuited if they are broken. Measure the resistance in the following points (connectors, etc.). If they are short-circuited, it means that they are broken.

1. Check of POWER MODULE


①. Check of DIODE circuit

L1]-[P1], [L2]-[P1], [L3]-[P1], [L1]-[N1], [L2]-[N1], [L3]-[N1]

②. Check of IGBT circuit

[P2]-[U], [P2]-[V], [P2]-[W], [N2]-[U], [N2]-[V], [N2]-[W]

Note: The marks, **L1, L2, L3, N1, N2, P1, P2, U, V** and **W** shown in the diagram are not actually printed on the board.




Outdoor converter circuit board

PUMY-P100YHM
PUMY-P125YHM
PUMY-P140YHM


PUMY-P100YHM₁
PUMY-P125YHM₁
PUMY-P140YHM₁

PUMY-P100YHMA
PUMY-P125YHMA
PUMY-P140YHMA

PUMY-P100YHMA-BS
PUMY-P125YHMA-BS
PUMY-P140YHMA-BS



Outdoor noise filter circuit board
PUMY-P100YHM PUMY-P100YHM₁
PUMY-P125YHM PUMY-P125YHM₁
PUMY-P140YHM PUMY-P140YHM₁




Outdoor noise filter circuit board

PUMY-P100YHMA
PUMY-P125YHMA
PUMY-P140YHMA


PUMY-P100YHMA-BS
PUMY-P125YHMA-BS
PUMY-P140YHMA-BS

※ The noise filter circuit board of PUMY-P-YHMA has been changed from support type to lead wire type(GD3).
 This circuit board can be applied to PUMY-P-YHM₍₁₎ (Convertible).



Transmission power board

- PUMY-P100YHM
- PUMY-P125YHM
- PUMY-P140YHM
- PUMY-P100YHM₁
- PUMY-P125YHM₁
- PUMY-P140YHM₁
- PUMY-P100YHMA
- PUMY-P125YHMA
- PUMY-P140YHMA
- PUMY-P100YHMA-BS
- PUMY-P125YHMA-BS
- PUMY-P140YHMA-BS



CN2
 Connect to the outdoor multi controller board
 ①-②: 24-30V DC
 ③-④: 24-30V DC

CN1
 Connect to the outdoor noise filter circuit board
 ①-③ : 220-240V AC

PM1001-PD-001-2ABCD
 YAMASE Electric

XX XXXXXX

BH00C882H

SW:setting
 0...OFF
 1...ON

9-10. OUTDOOR UNIT FUNCTIONS

| No. | SW1 setting | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes | | |
|-----|-------------|--|---|--|---|---|----------------------------------|--|---------------------------------|---|-----------------|---|--|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | | |
| | | Relay output display | Compressor operation | 52C | 21S4 | SV1 | (SV2) | | | | Lighting always | ON: light on OFF: light off | |
| 0 | 00000000 | Check display | 0000~9999 (Alternating display of addresses and error code) | | | | | | | | | | |
| 1 | 10000000 | Indoor unit check status | No. 1 unit check | No. 2 unit check | No. 3 unit check | No. 4 unit check | No. 5 unit check | No. 6 unit check | No. 7 unit check | No. 8 unit check | | Check: light on Normal: light off | |
| 2 | 01000000 | Protection input | High-pressure abnormality | Shutdown (discharge temperature) abnormality | Discharge temperature abnormality | TH4 abnormality | TH3 abnormality | Outdoor fan rotational frequency abnormality | TH7 abnormality | TH8 abnormality | | Display input microprocessor protection (abnormality) | |
| 3 | 11000000 | Protection input | Heatsink overheating | Over current interception | Voltage abnormality | Insufficient refrigerant amount abnormality | Current sensor abnormality | Low-pressure abnormality | 63HS abnormality | start over current interception abnormality | | | |
| 4 | 00100000 | Protection input | Abnormality in the number of indoor units | Address double | Indoor unit capacity error | Over capacity | Indoor unit address error | Outdoor unit address error | Current sensor open/short | serial communication abnormality | | | |
| 5 | 10100000 | Abnormality delay display 1 | High-pressure abnormality delay | Shutdown (discharge temperature) abnormality delay | Discharge temperature abnormality delay | TH4 abnormality delay | TH3 abnormality delay | Outdoor fan rotational frequency abnormality delay | TH7 abnormality delay | start over current interception abnormality delay | | Display all abnormalities remaining in abnormality | |
| 6 | 01100000 | Abnormality delay display 2 | Heatsink overheating delay | Over current interception delay | Voltage abnormality delay | Insufficient refrigerant amount abnormality delay | Current sensor abnormality delay | Low-pressure abnormality delay | 63HS abnormality delay | start over current interception abnormality delay | | delay | |
| 7 | 11100000 | Abnormality delay display 3 | Abnormality in the number of indoor units | Address double | Indoor unit capacity error | Frozen protection delay | Power module abnormality delay | TH6 abnormality delay | Current sensor open/short delay | communication(POWER BOARD) abnormality delay | | | |
| 8 | 00010000 | Abnormality delay history 1 | High-pressure abnormality delay | Shutdown (discharge temperature) abnormality delay | Discharge temperature abnormality delay | TH4 abnormality delay | TH3 abnormality delay | Outdoor fan rotational frequency abnormality delay | TH7 abnormality delay | start over current interception abnormality delay | | Display all abnormalities remaining in abnormality delay history | |
| 9 | 10010000 | Abnormality delay history 2 | Heatsink overheating delay | Over current interception delay | Voltage abnormality delay | Insufficient refrigerant amount abnormality delay | Current sensor abnormality delay | Low-pressure abnormality delay | 63HS abnormality delay | start over current interception abnormality delay | | | |
| 10 | 01010000 | Abnormality delay history 3 | Abnormality in the number of indoor units | Address double | Indoor unit capacity error | Frozen protection delay | Power module abnormality delay | TH6 abnormality delay | Current sensor open/short delay | communication(POWER BOARD) abnormality delay | | | |
| 11 | 11010000 | Abnormality code history 1 (the latest) | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | Abnormality code history 1 | | •Display abnormalities up to present (including abnormality terminals) | |
| 12 | 00110000 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | Abnormality code history 2 | | •History record in 1 is the latest; records become older in sequence; history record in 10 is the oldest. | |
| 13 | 10110000 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | Abnormality code history 3 | | | |
| 14 | 01110000 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | Abnormality code history 4 | | | |
| 15 | 11110000 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | Abnormality code history 5 | | | |
| 16 | 00001000 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | Abnormality code history 6 | | | |
| 17 | 10001000 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | Abnormality code history 7 | | | |
| 18 | 01001000 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | Abnormality code history 8 | | | |
| 19 | 11001000 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | Abnormality code history 9 | | | |
| 20 | 00010100 | Abnormality code history 10 (the oldest) | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | Abnormality code history 10 | | | |
| 21 | 10101000 | Cumulative time | 0~9999(unit::1-hour) | | | | | | | | | | |
| 22 | 01010100 | Cumulative time | 0~9999(unit::10-hour) | | | | | | | | | | |
| 23 | 11101000 | Outdoor unit operation display | Excitation Current | Restart after 3 minutes | Compressor operation | Abnormality(detection) | | | | | | Display of cumulative compressor operating time | |
| 24 | 00011000 | Indoor unit operation mode | No. 1 unit mode | No. 2 unit mode | No. 3 unit mode | No. 4 unit mode | No. 5 unit mode | No. 6 unit mode | No. 7 unit mode | No. 8 unit mode | | Cooling : light on Heating: light flashing Stop fan: light off | |
| 25 | 10011000 | Indoor unit operation display | No. 1 unit operation | No. 2 unit operation | No. 3 unit operation | No. 4 unit operation | No. 5 unit operation | No. 6 unit operation | No. 7 unit operation | No. 8 unit operation | | Thermo ON : light on Thermo OFF : light off | |
| 26 | 01011000 | Capacity code (No. 1 indoor unit) | 0~255 | | | | | | | | | | •Display of indoor unit capacity code |
| 27 | 11011000 | Capacity code (No. 2 indoor unit) | | | | | | | | | | | •The No. 1 unit will start from the address with the lowest number |
| 28 | 00011000 | Capacity code (No. 3 indoor unit) | | | | | | | | | | | |
| 29 | 10111000 | Capacity code (No. 4 indoor unit) | | | | | | | | | | | |
| 30 | 01111000 | Capacity code (No. 5 indoor unit) | | | | | | | | | | | |

| No. | SW1 setting | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes | |
|--|-------------|--|--|--|--|--------------------------------------|--|---|---------------------------|---|-------|--|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| 31 | 11111000 | IC1 operation mode | OFF | Fan | Cooling thermo ON | Cooling thermo OFF | Heating thermo ON | Heating thermo OFF | Heating thermo OFF | | | •Display of indoor unit operating mode |
| 32 | 00000100 | IC2 operation mode | | | | | | | | | | |
| 33 | 10000100 | IC3 operation mode | | | | | | | | | | |
| 34 | 01000100 | IC4 operation mode | | | | | | | | | | |
| 35 | 11000100 | IC5 operation mode | | | | | | | | | | |
| 36 | 00100100 | OC operation mode | ON/OFF | Heating/Cooling | Abnormal/Normal | DEFROST/NO | Refrigerant pull back/no | Excitation current/no | 3-min.delay/no | | | Light on/light off |
| 37 | 10100100 | External connection status | P97:Autochange over permission CN3N1-3 input | P96:Autochange over fixed mode CN3N1-2 input | P95:Undefined CN3S1-2 input | P94:Demand CN3D1-3 input | P93:Silent CN3D1-2 input | | | | | Input: light off No input: light on |
| 38 | 01100100 | Communication demand capacity | 0~255 | | | | | | | | | Display of communication demand capacity |
| 39 | 11100100 | Number of compressor ON/OFF | 0000~9999 (unit : 010) | | | | | | | | | |
| 40 | 00010100 | Compressor operating current | 0~999.9 (A) | | | | | | | | | |
| 41 | 10010100 | Input current of outdoor unit | 0~999.9 (A) | | | | | | | | | |
| 42 | 01010100 | Thermo ON operating time | 0000~9999 (unit : 010) | | | | | | | | | |
| 43 | 11010100 | Total capacity of thermo on | 0~255 | | | | | | | | | |
| 44 | 00110100 | Number of indoor units | 0~255 (Max. 8 unit) | | | | | | | | | |
| 45 | 10110100 | DC bus voltage | 0~999.9 (V) | | | | | | | | | |
| 46 | 01110100 | State of LEV control | Td over heat prevention | SHd decrease prevention | Min. S _j correction depends on Td | LEV opening correction depends on Pd | LEV opening correction depends on Td | Correction of high compression ratio prevention | | | | |
| 47 | 11110100 | State of compressor frequency control 1 | Discharge pressure control | Discharge temperature control | Max. Hz control | Discharge temp. (heating) Backup | Discharge pressure (heating) Backup | Max. Hz control | Freeze prevention control | | | |
| 48 | 00001100 | State of compressor frequency control 2 | Heatsink over heat prevention control | Secondary current control | Input current control | | Frequency restrain of receipt voltage change | | | | | |
| 49 | 10001100 | Protection input | | | | Frozen protection | TH6 abnormality | | | | | Power module abnormality |
| 50 | 01001100 | The second current value when micro computer of POWER BOARD abnormality is detected | 0~999.9[A/rms] | | | | | | | | | |
| 51 | 11001100 | The radiator panel temperature when microcomputer of POWER BOARD abnormality is detected | -99.9~999.9(Short/Open:-99.9 or 999.9) | | | | | | | | | |
| State of compressor frequency(Hz) control (Words) | | | Content | | | | | | | | | |
| Discharge pressure control | | | Hz control by pressure limitation | | | | | | | | | |
| Discharge temperature control | | | Hz control by discharge temperature limitation | | | | | | | | | |
| Max.Hz control | | | Max.Hz limitation when power supply on | | | | | | | | | |
| SV control | | | Hz control by bypass valve | | | | | | | | | |
| Abnormal rise of Pd control | | | Control that restrains abnormal rise of discharge pressure | | | | | | | | | |
| Heatsink over heat prevention control | | | Heatsink over heat prevention control | | | | | | | | | |
| Secondary current control | | | Secondary current control | | | | | | | | | |
| Input current control | | | Input current control | | | | | | | | | |
| Hz correction of receipt voltage decrease prevention | | | Max.Hz correction control due to voltage decrease | | | | | | | | | |
| Hz restrain of receipt voltage change | | | Max.Hz correction control due to receipt voltage change | | | | | | | | | |

| No. | SW1 setting 12345678 | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes |
|-----|-------------------------|---|---|---|---|---|---|---|---|---|---|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| 64 | 00000010 | Operational frequency | 0~FF(16 progressive) | | | | | | | | Display of actual operating frequency |
| 65 | 10000010 | Target frequency | 0~255 | | | | | | | | Display of target frequency |
| 66 | 01000010 | Outdoor fan control step number | 0~15 | | | | | | | | Display of number of outdoor fan control steps (target) |
| 69 | 10100010 | IC1 LEV Opening pulse | 0~2000 | | | | | | | | Display of opening pulse of indoor LEV |
| 70 | 01100010 | IC2 LEV Opening pulse | | | | | | | | | |
| 71 | 11100010 | IC3 LEV Opening pulse | | | | | | | | | |
| 72 | 00010010 | IC4 LEV Opening pulse | | | | | | | | | |
| 73 | 10010010 | IC5 LEV Opening pulse | | | | | | | | | |
| 74 | 01010010 | High-pressure sensor (Pd) kgf/cm ² | | | | | | | | | |
| 75 | 11010010 | TH4(Td) °C | -99.9 ~ 999.9 | | | | | | | | Display of outdoor subcool (SC) data and detection data from high-pressure sensor and each thermistor |
| 76 | 00110010 | TH6(ET) °C | | | | | | | | | |
| 77 | 10110010 | TH7(Outdoor-temp.) °C | | | | | | | | | |
| 78 | 01110010 | TH3(Outdoor pipe) °C | | | | | | | | | |
| 80 | 00001010 | TH8(Power module) °C | | | | | | | | | |
| 81 | 10001010 | IC1 TH23(Gas) °C | -99.9 ~ 999.9 | | | | | | | | |
| 82 | 01001010 | IC2 TH23(Gas) °C | (When the indoor unit is not connected, it is displayed as"0".) | | | | | | | | |
| 83 | 11001010 | IC3 TH23(Gas) °C | | | | | | | | | |
| 84 | 00101010 | IC4 TH23(Gas) °C | | | | | | | | | |
| 85 | 10101010 | IC5 TH23(Gas) °C | | | | | | | | | |
| 86 | 01101010 | IC1 TH22(Liquid) °C | | | | | | | | | |
| 87 | 11101010 | IC2 TH22(Liquid) °C | | | | | | | | | |
| 88 | 00011010 | IC3 TH22(Liquid) °C | | | | | | | | | |
| 89 | 10011010 | IC4 TH22 (Liquid) °C | | | | | | | | | |
| 90 | 01011010 | IC5 TH22 (Liquid) °C | | | | | | | | | |
| 91 | 11011010 | IC1 TH21(Intake) °C | | | | | | | | | |
| 92 | 00111010 | IC2 TH21 (Intake) °C | | | | | | | | | |
| 93 | 10111010 | IC3 TH21 (Intake) °C | | | | | | | | | |
| 94 | 01111010 | IC4 TH21 (Intake) °C | | | | | | | | | |
| 95 | 11111010 | IC5 TH21 (Intake) °C | | | | | | | | | |
| 96 | 00000110 | Outdoor SC (cooling) °C | -99.9 ~ 999.9 | | | | | | | | |

| No. | SW1 setting | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes | |
|-----|-------------|---|---------------------------------------|---|---|---|---|---|---|---|--|---|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| 97 | 10000110 | Target subcool step | -2~4 | | | | | | | | Display of target subcool step data | |
| 98 | 01000110 | IC1 SC/SH °C | -99.9 ~ 999.9 | | | | | | | | Display of indoor SC/SH data | |
| 99 | 11000110 | IC2 SC/SH °C | | | | | | | | | | |
| 100 | 00100110 | IC3 SC/SH °C | | | | | | | | | | |
| 101 | 10100110 | IC4 SC/SH °C | | | | | | | | | | |
| 102 | 01100110 | IC5 SC/SH °C | | | | | | | | | | |
| 103 | 11100110 | Discharge superheat (SHd) °C | -99.9~999.9 | | | | | | | | Display of discharge superheat data | |
| 105 | 10010110 | Target Pd display (heating) kgf/cm ² | Pdm(0.0~30.0) | | | | | | | | Display of all control target data | |
| 106 | 01010110 | Target ET display (cooling) °C | ETm(-2.0~23.0) | | | | | | | | | |
| 107 | 11010110 | Target outdoor SC (cooling) °C | SCm(0.0~20.0) | | | | | | | | | |
| 108 | 00110110 | Target indoor SC/SH (IC1) °C | SCm/SHm(0.0~20.0) | | | | | | | | | |
| 109 | 10110110 | Target indoor SC/SH (IC2) °C | | | | | | | | | | |
| 110 | 01110110 | Target indoor SC/SH (IC3) °C | | | | | | | | | | |
| 111 | 11110110 | Target indoor SC/SH (IC4) °C | | | | | | | | | | |
| 112 | 00001110 | Target indoor SC/SH (IC5) °C | | | | | | | | | | |
| 121 | 10011110 | TH4 (Td) °F | | | | | | | | | | Display of detection data from high-pressure sensor and each thermistor |
| 122 | 01011110 | TH3 (Outdoor pipe) °F | -99.9~999.9 [°F] | | | | | | | | | |
| 123 | 11011110 | TH6 (ET) °F | | | | | | | | | | |
| 124 | 00111110 | TH7 (Outdoor temp.) °F | | | | | | | | | | |
| 125 | 10111110 | High pressure sensor (Pd) PSIG | 0.0~711.0 [PSIG] | | | | | | | | | |
| 126 | 01111110 | TH8 (Power module) °F | -99.9~999.9 [°F] | | | | | | | | Display of actual frequency at time of abnormality delay | |
| 128 | 00000001 | Actual frequency of abnormality delay | 0~FF(16 progressive) | | | | | | | | | |
| 129 | 10000001 | Fan step number at time of abnormality delay | 0~15 | | | | | | | | | Display of fan step number at time of abnormality delay |
| 131 | 11000001 | IC1 LEV opening pulse abnormality delay | | | | | | | | | | Display of opening pulse of indoor LEV at time of abnormality delay |
| 132 | 00100001 | IC2 LEV opening pulse abnormality delay | 0~2000 | | | | | | | | | |
| 133 | 10100001 | IC3 LEV opening pulse abnormality delay | | | | | | | | | | |
| 134 | 01100001 | IC4 LEV opening pulse abnormality delay | | | | | | | | | | |
| 135 | 11100001 | IC5 LEV opening pulse abnormality delay | | | | | | | | | | |

| No. | SW1 setting | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes | |
|-----|-------------|--|---------------------------------------|---|---|---|---|---|---|---|-------|--|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | | |
| 136 | 00010001 | High-pressure sensor data at time of abnormality delay kgf/cm ² | | | | | | | | | | Display of data from high-pressure sensor, all thermistors, and SC/SH at time of abnormality delay |
| 137 | 10010001 | TH4 sensor data at time of abnormality delay °C | | | | | | | | | | |
| 138 | 01010001 | TH6 sensor data at time of abnormality delay °C | | | | | | | | | | |
| 139 | 11010001 | TH3 sensor data at time of abnormality delay °C | | | | | | | | | | |
| 140 | 00110001 | TH8 sensor data at time of abnormality delay °C | | | | | | | | | | |
| 141 | 10110001 | OC SC (cooling) at time of abnormality delay °C | | | | | | | | | | |
| 142 | 01110001 | IC1 SC/SH at time of abnormality delay °C | | | | | | | | | | |
| 143 | 11110001 | IC2 SC/SH at time of abnormality delay °C | | | | | | | | | | |
| 144 | 00001001 | IC3 SC/SH at time of abnormality delay °C | | | | | | | | | | |
| 145 | 10001001 | IC4 SC/SH at time of abnormality delay °C | | | | | | | | | | |
| 146 | 01001001 | IC5 SC/SH at time of abnormality delay °C | | | | | | | | | | |
| 147 | 11001001 | IC1 TH21 Intake °F | | | | | | | | | | |
| 148 | 00101001 | IC2 TH21 Intake °F | | | | | | | | | | |
| 149 | 10101001 | IC3 TH21 Intake °F | | | | | | | | | | |
| 150 | 01101001 | IC4 TH21 Intake °F | | | | | | | | | | |
| 151 | 11101001 | IC5 TH21 Intake °F | | | | | | | | | | |
| 152 | 00011001 | IC6 TH21 Intake °F | | | | | | | | | | |
| 153 | 10011001 | IC7 TH21 Intake °F | | | | | | | | | | |
| 154 | 01011001 | IC8 TH21 Intake °F | | | | | | | | | | |
| 155 | 11011001 | IC1 TH23 Gas °F | | | | | | | | | | |
| 156 | 00111001 | IC2 TH23 Gas °F | | | | | | | | | | |
| 157 | 10111001 | IC3 TH23 Gas °F | | | | | | | | | | |
| 158 | 01111001 | IC4 TH23 Gas °F | | | | | | | | | | |
| 159 | 11111001 | IC5 TH23 Gas °F | | | | | | | | | | |
| 160 | 00000101 | IC6 TH23 Gas °F | | | | | | | | | | |
| 161 | 10000101 | IC7 TH23 Gas °F | | | | | | | | | | |
| 162 | 01000101 | IC8 TH23 Gas °F | | | | | | | | | | |

| No. | SW1 setting 12345678 | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes |
|-----|-------------------------|--|---------------------------------------|---|---|---|---|---|---|---|--|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| 170 | 01010101 | ROM version monitor | | | | | | | | | Display of version data of ROM |
| 171 | 11010101 | ROM type | | | | | | | | | Display of ROM type |
| 172 | 00110101 | Check Sum code | | | | | | | | | Display of check sum code of ROM |
| 173 | 10110101 | IC1 TH22 Liquid °F | | | | | | | | | Display of detection data from each indoor liquid pipe thermistor |
| 174 | 01110101 | IC2 TH22 Liquid °F | | | | | | | | | |
| 175 | 11110101 | IC3 TH22 Liquid °F | | | | | | | | | |
| 176 | 00001101 | IC4 TH22 Liquid °F | | | | | | | | | |
| 177 | 10001101 | IC5 TH22 Liquid °F | | | | | | | | | |
| 178 | 01001101 | IC6 TH22 Liquid °F | | | | | | | | | |
| 179 | 11001101 | IC7 TH22 Liquid °F | | | | | | | | | |
| 180 | 00101101 | IC8 TH22 Liquid °F | | | | | | | | | |
| 189 | 10111101 | 4220 Error history | | | | | | | | | |
| 192 | 00000011 | Actual frequency at time of abnormality | | | | | | | | | Display of actual frequency at time of abnormality |
| 193 | 10000011 | Fan step number at time of abnormality | | | | | | | | | Display of fan step number at time of abnormality |
| 195 | 11000011 | IC1 LEV opening pulse at time of abnormality | | | | | | | | | Display of opening pulse of indoor LEV at time of abnormality |
| 196 | 00100011 | IC2 LEV opening pulse at time of abnormality | | | | | | | | | |
| 197 | 10100011 | IC3 LEV opening pulse at time of abnormality | | | | | | | | | |
| 198 | 01100011 | IC4 LEV opening pulse at time of abnormality | | | | | | | | | |
| 199 | 11100011 | IC5 LEV opening pulse at time of abnormality | | | | | | | | | |
| 200 | 00010011 | High-pressure sensor data at abnormality kgf/cm ² | | | | | | | | | Display of data from high-pressure sensor and all thermistors at time of abnormality |
| 201 | 10010011 | TH4 sensor data at time of abnormality °C | | | | | | | | | |
| 202 | 01010011 | TH6 sensor data at time of abnormality °C | | | | | | | | | Display of data from SC/SH and all thermistors at time of abnormality |
| 203 | 11010011 | TH3 sensor data at time of abnormality °C | | | | | | | | | |
| 204 | 00110011 | TH8 sensor data at time of abnormality °C | | | | | | | | | |
| 206 | 01110011 | IC1 SC/SH at time of abnormality °C | | | | | | | | | |
| 207 | 11110011 | IC2 SC/SH at time of abnormality °C | | | | | | | | | |
| 208 | 00001011 | IC3 SC/SH at time of abnormality °C | | | | | | | | | |
| 209 | 10001011 | IC4 SC/SH at time of abnormality °C | | | | | | | | | |
| 210 | 01001011 | IC5 SC/SH at time of abnormality °C | | | | | | | | | |

-99.9 ~ 999.9 [°F]
(When the indoor unit is not connected, it is displayed as "32".)

-99.9 ~ 999.9

| No. | SW1 setting 12345678 | Display mode | Display on the LED1, 2 (display data) | | | | | | | | Notes |
|-----|-------------------------|--|---|-----|-------------------|--------------------|-------------------|--------------------|---------------------------------------|---|--|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | |
| 211 | 11001011 | IC6 Capacity code | 0~255 | | | | | | | | Display of indoor unit capacity mode |
| 212 | 00101011 | IC7 Capacity code | | | | | | | | | |
| 213 | 10101011 | IC8 Capacity code | | | | | | | | | |
| 214 | 01101011 | IC6 operation mode | OFF | Fan | Cooling thermo ON | Cooling thermo OFF | Heating thermo ON | Heating thermo OFF | Display of indoor unit operating mode | | |
| 215 | 11101011 | IC7 operation mode | | | | | | | Display of indoor unit operating mode | | |
| 216 | 00011011 | IC8 operation mode | | | | | | | | | |
| 217 | 10011011 | IC6 LEV opening pulse | 0~2000 | | | | | | | | Display of opening pulse of indoor LEV |
| 218 | 01011011 | IC7 LEV opening pulse | | | | | | | | | |
| 219 | 11011011 | IC8 LEV opening pulse | | | | | | | | | |
| 220 | 00111011 | IC6 TH23(Gas) °C | -99.9 ~ 999.9 (When the indoor unit is not connected, it is displayed as "0".) | | | | | | | | Display of data from high-pressure sensor, all thermistors, and outdoor SC |
| 221 | 10111011 | IC7 TH23(Gas) °C | | | | | | | | | |
| 222 | 01111011 | IC8 TH23(Gas) °C | | | | | | | | | |
| 223 | 11111011 | IC6 TH22(Liquid) °C | | | | | | | | | |
| 224 | 00000111 | IC7 TH22(Liquid) °C | | | | | | | | | |
| 225 | 10000111 | IC8 TH22(Liquid) °C | | | | | | | | | |
| 226 | 01000111 | IC6 TH21(Intake) °C | | | | | | | | | |
| 227 | 11000111 | IC7 TH21(Intake) °C | | | | | | | | | |
| 228 | 00100111 | IC8 TH21(Intake) °C | | | | | | | | | |
| 229 | 10100111 | IC6 SC/SH °C | -99.9 ~ 999.9 | | | | | | | | Display of indoor SC/SH data |
| 230 | 01100111 | IC7 SC/SH °C | during heating:subcool (SC)/during cooling:superheat (SH) | | | | | | | | |
| 231 | 11100111 | IC8 SC/SH °C | SCm/SHm (0.0~14.0) | | | | | | | | Display of all control target data |
| 232 | 00010111 | IC6 target SC/SH °C | | | | | | | | | |
| 233 | 10010111 | IC7 target SC/SH °C | | | | | | | | | |
| 234 | 01010111 | IC8 target SC/SH °C | | | | | | | | | |
| 235 | 11010111 | IC6 LEV opening pulse at abnormality delay | 0~2000 | | | | | | | | Display of opening pulse of indoor LEV at time of abnormality |
| 236 | 00110111 | IC7 LEV opening pulse at abnormality delay | | | | | | | | | |
| 237 | 10110111 | IC8 LEV opening pulse at abnormality delay | | | | | | | | | |
| 238 | 01110111 | IC6 SC/SH at abnormality delay °C | -99.9 ~ 999.9 | | | | | | | | Display of SC/ SH data at time of abnormality |
| 239 | 11110111 | IC7 SC/SH at abnormality delay °C | | | | | | | | | |
| 240 | 00001111 | IC8 SC/SH at abnormality delay °C | | | | | | | | | |
| 241 | 10001111 | IC6 LEV opening pulse at time of abnormality | 0~2000 | | | | | | | | Display of opening pulse of indoor LEV at time of abnormality |
| 242 | 01001111 | IC7 LEV opening pulse at time of abnormality | | | | | | | | | |
| 243 | 11001111 | IC8 LEV opening pulse at time of abnormality | | | | | | | | | |
| 244 | 00101111 | IC6 SC/SH at abnormality °C | -99.9 ~ 999.9 | | | | | | | | Display of SC/ SH data at time of abnormality |
| 245 | 10101111 | IC7 SC/SH at abnormality °C | | | | | | | | | |
| 246 | 01101111 | IC8 SC/SH at abnormality °C | | | | | | | | | |

This chapter provides an introduction to electrical wiring for the CITY MULTI-S series, together with notes concerning power wiring, wiring for control (transmission wires and remote controller wires), and the frequency converter.

10-1. OVERVIEW OF POWER WIRING

- (1) Use a separate power supply for the outdoor unit and indoor unit.
- (2) Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
- (3) The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10 %.
- (4) Specific wiring requirements should adhere to the wiring regulations of the region.
- (5) Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
- (6) Install an earth longer than other cables.

⚠ Warning:


- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.

⚠ Caution:

- Some installation site may require attachment of an earth leakage breaker. If no earth leakage breaker is installed, it may cause an electric shock.
- Do not use anything other than breaker and fuse with correct capacity. Using fuse and wire or copper wire with too large capacity may cause a malfunction of unit or fire.

10-2. WIRE DIAMETER AND MAIN POWER SWITCH CAPACITY

10-2-1. Wiring diagram for main power supply



10-2-2. Power supply wire diameter and capacity

| Model | Power Supply | Minimum Wire Thickness (mm ²) | | | Breaker for Wiring*1 | Breaker for Current Leakage |
|--------------|--------------|---|--------|--------|----------------------|-----------------------------|
| | | Main Cable | Branch | Ground | | |
| Outdoor Unit | P100-140 | 3N~ AC380/400/415V, 50Hz | 1.5 | - | 1.5 | 16 A 30 mA 0.1 sec. or less |
| Indoor Unit | | ~N AC220/230/240V, 50Hz | 1.5 | 1.5 | 1.5 | 15 A 30 mA 0.1 sec. or less |

*1. A breaker with at least 3.5mm contact separation in each pole shall be provided. Use earth leakage breaker (NV).

10-3. DESIGN FOR CONTROL WIRING

Please note that the types and numbers of control wires needed by the CITY MULTI-S series will depend on the remote controllers and whether they are linked with the system.

10-3-1. Selection number of control wires

| | | |
|---------------------------------|---|---|
| | | M-NET remote controller |
| Use | | Remote controller used in system control operations. • Group operation involving different refrigerant systems. • Linked operation with upper control system. |
| Remote controller → indoor unit | | 2 wires (non-polar) |
| Transmission wires | Wires connecting → indoor units | |
| | Wires connecting → indoor units with outdoor unit | |
| | Wires connecting → outdoor units | |

10-3-2. Control signal wires

• Transmission wires

- Types of transmission cables : Shielding wire CVVS or CPEVS.
- Cable diameter : More than 1.25mm²
- Maximum wiring length : Within 200 m

10-3-3. M-NET Remote controller wiring

| | |
|------------------------------|---|
| Kind of remote control cable | Shielding wire MVVS |
| Cable diameter | 0.5 to 1.25mm ² |
| Remarks | When 10m is exceeded, use cable with the same specifications as 10-3-2. Control signal wires. |

10-3-4. MA Remote control cables


| | |
|------------------------------|-----------------------------|
| Kind of remote control cable | 2-core cable (unshielded) |
| Cable diameter | 0.3 to 1.25 mm ² |

10-4. SYSTEM SWITCH SETTING

In order to identify the destinations of signals to the outdoor units, indoor units, and remote controller of the MULTI-S series, each microprocessor must be assigned an identification number (address). The addresses of outdoor units, indoor units, and remote controller must be set using their settings switches. Please consult the installation manual that comes with each unit for detailed information on setting procedures.

10-5. EXAMPLE EXTERNAL WIRING DIAGRAM FOR A BASIC SYSTEM

10-5-1. Example using a M-NET remote controller



10-6. METHOD FOR OBTAINING ELECTRICAL CHARACTERISTICS WHEN A CAPACITY AGREEMENT IS TO BE SIGNED WITH AN ELECTRIC POWER COMPANY

The electrical characteristics of connected indoor unit system for air conditioning systems, including the MULTI-S series, will depend on the arrangement of the indoor and outdoor units.

First read the data on the selected indoor and outdoor units and then use the following formulas to calculate the electrical characteristics before applying for a capacity agreement with the local electric power company.

10-6-1. Obtaining the electrical characteristics of a CITY MULTI-S series system

(1) Procedure for obtaining total power consumption

| | Page numbers in this technical manual | Power consumption |
|---|--|-------------------|
| Total power consumption of each indoor unit | See the technical manual of each indoor unit | ① |
| *1 Power consumption of outdoor unit | Standard capacity table— Refer to 5-2. | ② |
| Total power consumption of system | See the technical manual of each indoor unit | ①+② <kW> |

*1 Please note that the power consumption of the outdoor unit will vary depending on the total capacity of the selected indoor units.

(2) Method of obtaining total current

| | Page numbers in this technical manual | Subtotal |
|--|--|----------|
| Total current through each indoor unit | See the technical manual of each indoor unit | ① |
| *2 Current through outdoor unit | Standard capacity table— Refer to 5-2. | ② |
| Total current through system | See the technical manual of each indoor unit | ①+② <A> |

*2 Please note that the current through the outdoor unit will vary depending on the total capacity of the selected indoor units.

(3) Method of obtaining system power factor

Use the following formula and the total power and current obtained in parts ① and ② on the above tables to calculate the system power factor.


$$\text{System power factor} = \frac{(\text{Total system power consumption})}{(\text{Total system current} \times \text{voltage})} \times 100\%$$

10-6-2. Applying to an electric power company for power and total current

Calculations should be performed separately for heating and cooling employing the same methods; use the largest resulting value in your application to the electric power company.

11-1. REFRIGERANT PIPING SYSTEM

Line-Branch Method
 Connection Examples
 (Connecting to 4 Indoor Units)



| | | |
|---------------------------------|---|---|
| Permissible Length | Total Piping Length | $A+B+C+a+b+c+d \leq 120m$ |
| | Farthest Piping Length (L) | $A+B+C+d \leq 80m$ |
| | Farthest Piping Length After First Branch (ℓ) | $B+C+d \leq 30m$ |
| Permissible High/Low Difference | High/Low Difference in Indoor/Outdoor Section (H) | 30 meters or less (If the outdoor unit is lower, 20 meters or less) |
| | High/Low Difference in Indoor/Indoor Section (h) | 12 meters or less |

■ **Selecting the Refrigerant Branch Kit**
 Use an optional branch piping kit (CMY-Y62-G-E).

■ **Select Each Section of Refrigerant Piping**

(1) Section From Outdoor Unit to First Branch (A)
 (2) Sections From Branch to Indoor Unit (a,b,c,d)
 (3) Section From Branch to Branch (B,C)

Each Section of Piping

Select the size from the table to the right.

| (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter) | (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter) | | | | | | | | | | | | | | | | | | | | | |
|--|---|----------------------|-------|---------------|-------------|-------|----------|--------|---|--------------|----------------------|--|-------------|-------------|-------|----------|-------|-----------|-------------|-------|----------|--------|
| <table border="1"> <thead> <tr> <th>Model</th> <th colspan="2">Piping Diameter (mm)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">PUMY-P100~140</td> <td>Liquid Line</td> <td>φ9.52</td> </tr> <tr> <td>Gas Line</td> <td>φ15.88</td> </tr> </tbody> </table> | Model | Piping Diameter (mm) | | PUMY-P100~140 | Liquid Line | φ9.52 | Gas Line | φ15.88 | <table border="1"> <thead> <tr> <th>Model number</th> <th colspan="2">Piping Diameter (mm)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">50 or lower</td> <td>Liquid Line</td> <td>φ6.35</td> </tr> <tr> <td>Gas Line</td> <td>φ12.7</td> </tr> <tr> <td rowspan="2">63 to 140</td> <td>Liquid Line</td> <td>φ9.52</td> </tr> <tr> <td>Gas Line</td> <td>φ15.88</td> </tr> </tbody> </table> | Model number | Piping Diameter (mm) | | 50 or lower | Liquid Line | φ6.35 | Gas Line | φ12.7 | 63 to 140 | Liquid Line | φ9.52 | Gas Line | φ15.88 |
| Model | Piping Diameter (mm) | | | | | | | | | | | | | | | | | | | | | |
| PUMY-P100~140 | Liquid Line | φ9.52 | | | | | | | | | | | | | | | | | | | | |
| | Gas Line | φ15.88 | | | | | | | | | | | | | | | | | | | | |
| Model number | Piping Diameter (mm) | | | | | | | | | | | | | | | | | | | | | |
| 50 or lower | Liquid Line | φ6.35 | | | | | | | | | | | | | | | | | | | | |
| | Gas Line | φ12.7 | | | | | | | | | | | | | | | | | | | | |
| 63 to 140 | Liquid Line | φ9.52 | | | | | | | | | | | | | | | | | | | | |
| | Gas Line | φ15.88 | | | | | | | | | | | | | | | | | | | | |
| (3) Refrigerant Piping Diameter In Section From Branch to Branch | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Liquid Line (mm)</th> <th>Gas Line (mm)</th> </tr> </thead> <tbody> <tr> <td>φ9.52</td> <td>φ15.88</td> </tr> </tbody> </table> | Liquid Line (mm) | Gas Line (mm) | φ9.52 | φ15.88 | | | | | | | | | | | | | | | | | | |
| Liquid Line (mm) | Gas Line (mm) | | | | | | | | | | | | | | | | | | | | | |
| φ9.52 | φ15.88 | | | | | | | | | | | | | | | | | | | | | |

■ **Additional refrigerant charge**

- Refrigerant of 3kg equivalent to 50m total extended piping length is already included when the outdoor unit is shipped. Thus, if the total extended piping length is 50m or less, there is no need to charge with additional refrigerant.
- If the total extended piping length exceeds 50m, calculate the required additional refrigerant charge using the procedure shown on the right.
- If the calculated additional refrigerant charge is a negative amount, do not charge with any refrigerant.

<Additional Charge>


| | | | | | | |
|------------------------------------|---|---|---|---|---|---|
| Additional refrigerant charge (kg) | = | Liquid pipe size Total length of φ9.52 × 0.06 (m) × 0.06 (kg/m) | + | Liquid pipe size Total length of φ6.35 × 0.024 (m) × 0.024 (kg/m) | - | Refrigerant amount for outdoor unit 3.0kg |
|------------------------------------|---|---|---|---|---|---|

<Example> Outdoor model : 125
 Indoor 1 : 63 A : φ9.52 10m a : φ9.52 15m
 2 : 40 B : φ9.52 10m b : φ6.35 10m
 3 : 25 C : φ9.52 10m c : φ6.35 10m
 4 : 20 d : φ6.35 20m

The total length of each liquid line is as follows;
 φ9.52 : A + B + C + a = 10 + 10 + 10 + 15 = 45m
 φ6.35 : b + c + d = 10 + 10 + 20 = 40m

<Calculation example>
 Additional refrigerant charge = 45 × 0.06 + 40 × 0.024 - 3.0 = 0.7kg (rounded up)

Header-Branch Method
Connection Examples
(Connecting to 4 Indoor Units)



| | | |
|---------------------------------|---|---|
| Permissible Length | Total Piping Length | $A+a+b+c+d \leq 120m$ |
| | Farthest Piping Length (L) | $A+d \leq 80m$ |
| | Farthest Piping Length After First Branch (ℓ) | d is 30 meters or less |
| Permissible High/Low Difference | High/Low Difference in Indoor/Outdoor Section (H) | 30 meters or less (If the outdoor unit is lower, 20 meters or less) |
| | High/Low Difference in Indoor/Indoor Section (h) | 12 meters or less |

Selecting the Refrigerant Branch Kit

Please select branching kit, which is sold separately, from the table below.
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

| | |
|----------------------------|----------------------------|
| Branch header (4 branches) | Branch header (8 branches) |
| CMY-Y64-G-E | CMY-Y68-G-E |

Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to First Branch (A)
 - (2) Sections From Branch to Indoor Unit (a,b,c,d)
- Each Section of Piping

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)
- (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

| Model | Piping Diameter (mm) | |
|---------------|----------------------|--------|
| PUMY-P100-140 | Liquid Line | φ9.52 |
| | Gas Line | φ15.88 |

| Model number | Piping Diameter (mm) | |
|--------------|----------------------|--------|
| 50 or lower | Liquid Line | φ6.35 |
| | Gas Line | φ12.7 |
| 63 to 140 | Liquid Line | φ9.52 |
| | Gas Line | φ15.88 |

Select the size from the table to the right.

Additional refrigerant charge

- Refrigerant of 3kg equivalent to 50m total extended piping length is already included when the outdoor unit is shipped. Thus, if the total extended piping length is 50m or less, there is no need to charge with additional refrigerant.
- If the total extended piping length exceeds 50m, calculate the required additional refrigerant charge using the procedure shown on the right.
- If the calculated additional refrigerant charge is a negative amount, do not charge with any refrigerant.

<Additional Charge>

| | | | | | | |
|-------------------------------|---|---|---|--|---|-------------------------------------|
| Additional refrigerant charge | = | Liquid pipe size Total length of φ9.52 × 0.06 | + | Liquid pipe size Total length of φ6.35 × 0.024 | - | Refrigerant amount for outdoor unit |
| (kg) | | (m) × 0.06 (kg/m) | | (m) × 0.024 (kg/m) | | 3.0kg |

<Example> Outdoor : 125
Indoor 1 : 63 A : φ9.52 30m a : φ9.52 15m
 2 : 40 b : φ6.35 10m
 3 : 25 c : φ6.35 10m
 4 : 20 d : φ6.35 20m


At the conditions below:

The total length of each liquid line is as follows;
φ9.52 : A + a = 30 + 15 = 45m
φ6.35 : b + c + d = 10 + 10 + 20 = 40m

<Calculation example>

Additional refrigerant charge = 45 × 0.06 + 40 × 0.024 - 3.0 = 0.7kg (rounded up)

Method of Combined Branching of Lines and Headers
 Connection Examples
 (Connecting to 5 Indoor Units)



| | | |
|---------------------------------|---|---|
| Permissible Length | Total Piping Length | A+B+C+a+b+c+d+e is 120 meters or less |
| | Farthest Piping Length (L) | A+B+b is 80 meters or less |
| | Farthest Piping Length After First Branch (ℓ) | B+b is 30 meters or less |
| Permissible High/Low Difference | High/Low Difference in Indoor/Outdoor Section (H) | 30 meters or less (If the outdoor unit is lower, 20 meters or less) |
| | High/Low Difference in Indoor/Indoor Section (h) | 12 meters or less |

Selecting the Refrigerant Branch Kit

Please select branching kit, which is sold separately, from the table below.
 (The kit comprises sets for use with liquid pipes and for use with gas pipes.)

| Branch Joint | Branch Header (4 branches) | Branch Header (8 branches) |
|--------------|----------------------------|----------------------------|
| CMY-Y62-G-E | CMY-Y64-G-E | CMY-Y68-G-E |

Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to First Branch (A)
 - (2) Sections From Branch to Indoor Unit (a,b,c,d,e)
 - (3) Section From Branch to Branch (B,C)
- Each Section of Piping
- Select the size from the table to the right.

| | | | |
|---|---------------|----------------------|--------|
| (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter) | Model | Piping Diameter (mm) | |
| | PUMY-P100~140 | Liquid Line | φ9.52 |
| | | Gas Line | φ15.88 |

| | | | |
|---|--------------|----------------------|-------|
| (2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter) | Model number | Piping Diameter (mm) | |
| | | Liquid Line | φ6.35 |
| | 50 or lower | Gas Line | φ12.7 |
| | | Liquid Line | φ9.52 |
| 63 to 140 | Gas Line | φ15.88 | |

(3) Refrigerant Piping Diameter In Section From Branch to Branch

| Liquid Line (mm) | Gas Line (mm) |
|------------------|---------------|
| φ9.52 | φ15.88 |

Additional refrigerant charge

- Refrigerant of 3kg equivalent to 50m total extended piping length is already included when the outdoor unit is shipped. Thus, if the total extended piping length is 50m or less, there is no need to charge with additional refrigerant.
- If the total extended piping length exceeds 50m, calculate the required additional refrigerant charge using the procedure shown on the right.
- If the calculated additional refrigerant charge is a negative amount, do not charge with any refrigerant.

<Additional Charge>

| | | | | | | |
|------------------------------------|---|---|---|---|---|--|
| Additional refrigerant charge (kg) | = | Liquid pipe size Total length of φ9.52 × 0.06 (m) × 0.06 (kg/m) | + | Liquid pipe size Total length of φ6.35 × 0.024 (m) × 0.024 (kg/m) | - | Refrigerant amount for outdoor unit 125: 3.0kg |
|------------------------------------|---|---|---|---|---|--|

<Example>

| | | | | |
|---------------|-----------|-----|-----------|-----|
| Indoor 1 : 50 | A : φ9.52 | 10m | a : φ9.52 | 5m |
| 2 : 40 | B : φ9.52 | 20m | b : φ6.35 | 10m |
| 3 : 32 | C : φ9.52 | 10m | c : φ6.35 | 5m |
| 4 : 20 | | | d : φ6.35 | 5m |
| 5 : 20 | | | e : φ6.35 | 5m |

At the conditions below:

The total length of each liquid line is as follows;
 φ9.52 : A + B + C + a = 10 + 20 + 10 + 5 = 45m
 φ6.35 : b + c + d + e = 10 + 5 + 5 + 5 = 25m

<Calculation example>
 Additional refrigerant charge = 45 × 0.06 + 25 × 0.024 - 3.0 = 0.3kg (rounded up)

11-2. PRECAUTIONS AGAINST REFRIGERANT LEAKAGE

11-2-1. Introduction


R410A refrigerant of this air conditioner is non-toxic and non-flammable but leaking of large amount from an indoor unit into the room where the unit is installed may be deleterious.

To prevent possible injury, the rooms should be large enough to keep the R410A concentration specified by KHK: (a high pressure gas safety association) installation guidelines S0010 as follows.

Maximum concentration
Maximum refrigerant concentration of R410A of a room is 0.3 kg/m³ accordance with the installation guidelines. To facilitate calculation, the maximum concentration is expressed in units of kg/m³ (kg of R410A per m³)

Maximum concentration of R410A: 0.3kg/m³


(KHK installation guidelines S0010)




(2) Calculate room volumes (m³) and find the room with the smallest volume

The part with represents the room with the smallest volume.

(a) Situation in which there are no partitions



(b) There are partitions, but there are openings that allow the effective mixing of air.



11-2-2. Confirming procedure of R410A concentration


Follow (1) to (3) to confirm the R410A concentration and take appropriate treatment, if necessary.

(1) Calculate total refrigerant amount by each refrigerant system.

Total refrigerant amount is precharged refrigerant at ex-factory plus additional charged amount at field installation.

Note:
When single refrigeration system consists of several independent refrigeration circuit, figure out the total refrigerant amount by each independent refrigerant circuit.

(c) If the smallest room has mechanical ventilation apparatus that is linked to a household gas detection and alarm device, the calculations should be performed for the second smallest room.



(3) Use the results of calculations (1) and (2) to calculate the refrigerant concentration:

$$\frac{\text{Total refrigerant in the refrigerating unit (kg)}}{\text{The smallest room in which an indoor unit has been installed (m}^3\text{)}} \leq \text{Maximum concentration(kg/m}^3\text{)}$$

Maximum concentration of R410A:0.3kg/m³

If the calculation results do not exceed the maximum concentration, perform the same calculations for the larger second and third room, etc., until it has been determined that nowhere the maximum concentration will be exceeded.

OUTDOOR UNIT : PUMY-P100YHM
 PUMY-P100YHM₁
 PUMY-P100YHMA(-BS)





PUMY-P125YHM
 PUMY-P125YHM₁
 PUMY-P125YHMA(-BS)

PUMY-P140YHM
 PUMY-P140YHM₁
 PUMY-P140YHMA(-BS)

| OPERATING PROCEDURE | PHOTOS & ILLUSTRATION |
|--|---|
| <p>1. Removing the service panel and top panel</p> <p>(1) Remove 3 service panel fixing screws (5 × 10) and slide the hook on the right downward to remove the service panel.</p> <p>(2) Remove screws (3 for front, 3 for rear/5 × 10) of the top panel and remove it.</p> | <p>Figure 1</p> |
| <p>2. Removing the fan motor (MF1, MF2)</p> <p>(1) Remove the service panel. (See figure 1.)</p> <p>(2) Remove the top panel. (See figure 1.)</p> <p>(3) Remove 5 fan grille fixing screws (5 × 10) to detach the fan grille. (See figure 1.)</p> <p>(4) Remove a nut (for right handed screw of M6) to detach the propeller. (See photo 1.)</p> <p>(5) Disconnect the connectors, CNF1 and CNF2 on Multi controller board in electrical parts box.</p> <p>(6) Remove 4 fan motor fixing screws (5 × 25) to detach the fan motor. (See photo 2.)</p> | <p>Photo 1</p> <p>Photo 2</p> |
| <p>3. Removing the electrical parts box</p> <p>(1) Remove the service panel. (See figure 1.)</p> <p>(2) Remove the top panel. (See figure 1.)</p> <p>(3) Disconnect the connecting wire from terminal block.</p> <p>(4) Remove all the following connectors from Multi controller board; fan motor, thermistor <Outdoor pipe>, thermistor <Discharge>, thermistor <Low pressure saturated temp>, thermistor <Outdoor>, high pressure switch, high pressure sensor, low pressure switch, solenoid valve coil <Four-way valve> and solenoid valve coil <Bypass valve>.</p> <p>Then remove a screw (4 × 8) from the valve bed to remove the lead wire.</p> <p>Pull out the disconnected wire from the electrical parts box.</p> <p><Diagram symbol in the connector housing></p> <ul style="list-style-type: none"> • Fan motor (CNF1, CNF2) • Thermistor <Outdoor pipe> (TH3) • Thermistor <Discharge> (TH4) • Thermistor <Low pressure saturated temp, Outdoor> (TH6/7) • High pressure switch (63H) • High pressure sensor (63HS) • Low pressure switch (63L) • Solenoid valve coil <Four-way valve> (21S4) • Solenoid valve coil <Bypass valve> (SV1) <p>(5) Remove the terminal cover and disconnect the compressor lead wire.</p> | <p>Photo 3</p> |

Continued to the next page.

From the previous page.


| OPERATING PROCEDURE | PHOTOS & ILLUSTRATION |
|--|--|
| <p>(6) Remove electrical parts box fixing screw (4 × 10) and detach the electrical parts box by pulling it upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.</p> | <p>Photo 4</p>  |
| <p>4. Removing the thermistor <Low pressure saturated temp.> (TH6)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See figure 1.) (2) Remove the top panel. (See figure 1.) (3) Disconnect the connectors, TH6 and TH7 (red), on the Multi controller board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (5) Pull out the thermistor <Low pressure saturated temp.> (TH6) from the sensor holder. <p>Note: In case of replacing thermistor <Low pressure saturated temp.> (TH6), replace it together with thermistor <Outdoor> (TH7) since they are combined together. Refer to No.5 below to remove thermistor <Outdoor>.</p> | <p>Photo 5</p>  |
| <p>5. Removing the thermistor <Outdoor> (TH7)</p> <ol style="list-style-type: none"> (1) Remove the service panel. (See figure 1.) (2) Remove the top panel. (See figure 1.) (3) Disconnect the connector TH7 (red) on the Multi controller board in the electrical parts box. (4) Loosen the wire clamps on top of the electrical parts box. (See photo 4.) (5) Pull out the thermistor <Outdoor> (TH7) from the sensor holder. <p>Note: In case of replacing thermistor <Outdoor> (TH7), replace it together with thermistor <Low pressure saturated temp.> (TH6), since they are combined together. Refer to No.4 above to remove thermistor <Low pressure saturated temp.>.</p> | <p>Photo 6</p> <p style="text-align: center;">PUMY-P100/125/140YHM(1)</p>  <p style="text-align: center;">PUMY-P100/125/140YHMA(-BS)</p>  |



OPERATING PROCEDURE

6. Removing the thermistor <Outdoor pipe> (TH3) and thermistor <Discharge> (TH4)

- (1) Remove the service panel. (See figure 1.)
- (2) Disconnect the connectors, TH3 (white) and TH4 (white), on the Multi controller board in the electrical parts box.
- (3) Loosen the clamp for the lead wire in the rear of the electrical parts box.
- (4) Pull out the thermistor <Outdoor pipe> (TH3) and thermistor <Discharge> (TH4) from the sensor holder.




7. Removing the 4-way valve coil (21S4)

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)

[Removing the 4-way valve coil]

- (3) Remove 4-way valve coil fixing screw (M5 × 6 for 100-140YHM, M4 × 6 for 100-140YHM₁/YHMA(-BS)).
- (4) Remove the 4-way valve coil by sliding the coil toward you.
- (5) Disconnect the connector 21S4 (green) on the Multi controller board in the electrical parts box.




8. Removing the 4-way valve

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16) and then remove the valve bed.
- (4) Remove 4 right side panel fixing screws (5 × 10) in the rear of the unit and then remove the right side panel.
- (5) Remove the 4-way valve coil. (See photo 8.)
- (6) Recover refrigerant.
- (7) Remove the welded part of 4-way valve.

Note 1: Recover refrigerant without spreading it in the air.

Note 2: The welded part can be removed easily by removing the right side panel.

Note 3: When installing the four-way valve, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.



OPERATING PROCEDURE

9. Removing bypass valve coil (SV1) and bypass valve

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove 3 right side panel fixing screws (5 × 10) in the rear of the unit and remove the right side panel.
- (4) Remove the bypass valve coil fixing screw (M4 × 6).
- (5) Remove the bypass valve coil by sliding the coil upward.
- (6) Disconnect the connector SV1 (white) on the Multi controller circuit board in the electrical parts box.
- (7) Recover refrigerant.
- (8) Remove the welded part of bypass valve.

Note 1: Recover refrigerant without spreading it in the air.

Note 2: The welded part can be removed easily by removing the right side panel.

10. Removing the high pressure switch (63H) and low pressure switch (63L)

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove the electrical parts box. (See photo 4.)
- (4) Remove 3 right side panel fixing screws (5 × 10) in the rear of the unit and remove the right side panel.
- (5) Pull out the lead wire of high pressure switch and low pressure switch.
- (6) Recover refrigerant.
- (7) Remove the welded part of high pressure switch and low pressure switch.

Note 1: Recover refrigerant without spreading it in the air.

Note 2: The welded part can be removed easily by removing the right side panel.

Note 3: When installing the high pressure switch and low pressure switch, cover them with a wet cloth to prevent them from heating (100°C or more), then braze the pipes so that the inside of pipes are not oxidized.

11. Removing the high pressure sensor (63HS)

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove the electrical parts box. (See photo 4.)
- (4) Remove 3 right side panel fixing screws (5 × 10) in the rear of the unit and remove the right side panel.
- (5) Pull out the lead wire of high pressure sensor.
- (6) Recover refrigerant.
- (7) Remove the welded part of high pressure sensor.

Note 1: Recover refrigerant without spreading it in the air.

Note 2: The welded part can be removed easily by removing the right side panel.

Note 3: When installing the high pressure sensor, cover it with a wet cloth to prevent it from heating (100°C or more), then braze the pipes so that the inside of pipes are not oxidized.

PHOTOS

Photo 9





Photo 10



OPERATING PROCEDURE

12. Removing the reactors (ACL1, ACL2, ACL3)

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove the 6 screws, screw ⑧ and ⑨ (5 × 10), that fix the front panel and remove the front panel. (See photo 3.)
- (4) Remove the 2 screws, screw ⑩ and ⑪ (both 4 × 10), that fix the separator, screw ⑩ from the valve bed and screw ⑪ from the bottom of the separator, and tilt the separator to the side of the fan motor slightly. (See photo 11.)
- (5) Disconnect the lead wires from the reactor and remove the 4 screws, screw ⑫, that fix the reactor to remove the reactor. (See photo 12 and 13.)

Note 1: The reactor is very heavy (4kg)! Be careful when handling it.

Note 2: The reactor box is also removable.

PHOTOS

Photo 11




Photo 12





Photo 13



OPERATING PROCEDURE


13. Removing the compressor (MC)

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove 2 front cover panel fixing screws (5 × 10) and remove the front cover panel. (See photo 3.)
- (4) Remove 2 back cover panel fixing screws (5 × 10) and remove the back cover panel.
- (5) Remove the electrical parts box. (See photo 3.)
- (6) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16) and then remove the valve bed.
- (7) Remove 3 right side panel fixing screws (5 × 10) in the rear of the unit and then remove the right side panel.
- (8) Remove 3 separator fixing screws (4 × 10) and remove the separator.
- (9) Recover refrigerant.
- (10) Remove the 3 points of the motor for compressor fixing nut using spanner or adjustable wrench.
- (11) Remove the welded pipe of motor for compressor inlet and outlet and then remove the compressor.

Note: Recover refrigerant without spreading it in the air.

PHOTOS

Photo 14



14. Removing the accumulator

- (1) Remove the service panel. (See figure 1.)
- (2) Remove the top panel. (See figure 1.)
- (3) Remove 2 front cover panel fixing screws (5 × 10) and remove the front cover panel. (See photo 3.)
- (4) Remove 2 back cover panel fixing screws (5 × 10) and remove the back cover panel.
- (5) Remove the electrical parts box. (See photo 3.)
- (6) Remove 3 valve bed fixing screws (4 × 10) and 4 ball valve and stop valve fixing screws (5 × 16) and then remove the valve bed.
- (7) Remove 3 right side panel fixing screws (5 × 10) in the rear of the unit and then remove the right side panel.
- (8) Recover refrigerant.
- (9) Remove 4 welded pipes of power receiver inlet and outlet.
- (10) Remove 2 receiver leg fixing screws (4 × 10). (See photo 16.)

Note: Recover refrigerant without spreading it in the air.

Photo 15





Photo 16




13

PARTS LIST (non-RoHS compliant)



13-1. STRUCTURAL PARTS

PUMY-P100YHM PUMY-P125YHM PUMY-P140YHM
 PUMY-P100YHM₁ PUMY-P125YHM₁ PUMY-P140YHM₁



| No. | Part No. | Part Name | Specification | Q'ty/set | | Remarks (Drawing No.) | Wiring Diagram Symbol | Recom- mended Q'ty |
|-----|-------------|---------------------|---------------|--------------------------|------------------|--------------------------|-----------------------------|--------------------------|
| | | | | PUMY-P100/125/140 YHM | YHM ₁ | | | |
| 1 | - | F.ST SCREW | (5×10) | 38 | 38 | (DG12F536H10) | | |
| 2 | R01 E02 662 | SIDE PANEL (L) | | 1 | | | | |
| | T7W E02 662 | SIDE PANEL (L) | | | 1 | | | |
| 3 | T7W E02 691 | FAN GRILLE | | 2 | 2 | | | |
| 4 | T7W E02 667 | FRONT PANEL | | 1 | 1 | | | |
| 5 | - | SEPARATOR | | 1 | 1 | (BK00C409G05) | | |
| 6 | R01 E14 686 | BASE ASSY | | 1 | 1 | | | |
| 7 | R01 E25 130 | MOTOR SUPPORT | | 1 | 1 | | | |
| 8 | - | VALVE BED ASSY | | 1 | 1 | (BK00C142G15) | | |
| 9 | R01 30L 655 | HANDLE | | 2 | 2 | | | |
| 10 | R01 E00 658 | COVER PANEL (FRONT) | | 1 | | | | |
| | R01 E13 658 | COVER PANEL (FRONT) | | | 1 | | | |
| 11 | R01 E01 658 | COVER PANEL (REAR) | | 1 | | | | |
| | R01 E11 658 | COVER PANEL (REAR) | | | 1 | | | |
| 12 | R01 E24 661 | SIDE PANEL (R) | | 1 | 1 | | | |
| 13 | T7W E04 668 | SERVICE PANEL | | 1 | 1 | | | |
| 14 | - | LABEL (MITSUBISHI) | | 1 | 1 | (DG79R130H01) | | |
| 15 | R01 E01 698 | REAR GUARD | | 1 | 1 | | | |
| 16 | R01 E08 641 | TOP PANEL | | 1 | 1 | | | |
| 17 | R01 E00 655 | HANDLE | | 1 | 1 | | | |

13-2. FUNCTIONAL PARTS
PUMY-P100YHM PUMY-P100YHM₁
PUMY-P125YHM PUMY-P125YHM₁
PUMY-P140YHM PUMY-P140YHM₁





Part numbers that are circled are not shown in the figure.

| No. | Part No. | | | Part Name | Specification | PUMY-P100/125/140 | | Remarks (Drawing No.) | Wiring Diagram Symbol | Recom- mended Q'ty |
|-----|----------|-----|-----|------------------------------------|---|-------------------|------------------|--------------------------|-----------------------------|--------------------------|
| | | | | | | YHM | YHM ₁ | | | |
| | | | | | | | | | | |
| 1 | R01 | E41 | 221 | FAN MOTOR | | 2 | | | MF1,2 | |
| | R01 | E44 | 221 | FAN MOTOR | | | 2 | | MF1,2 | |
| 2 | R01 | E01 | 115 | PROPELLER FAN | | 2 | 2 | | | |
| 3 | R01 | E02 | 097 | NUT | | 2 | 2 | | | |
| 4 | T7W | E07 | 259 | REACTOR | | 3 | 3 | | ACL1,2,3 | |
| 5 | R01 | E06 | 413 | CHARGE PLUG | | 2 | 2 | | | |
| 6 | T97 | 410 | 747 | COMPRESSOR | ANB33FDEMT Including RUBBER MOUNT | 1 | 1 | | MC | |
| 7 | R01 | E09 | 410 | STOP VALVE | 3/8 | 1 | 1 | | | |
| 8 | R01 | E09 | 411 | BALL VALVE | 5/8 | 1 | 1 | | | |
| 9 | R01 | E03 | 450 | STRAINER | | 1 | 1 | | | |
| 10 | R01 | E35 | 440 | ACCUMULATOR | | 1 | 1 | | | |
| 11 | R01 | E09 | 490 | OIL SEPARATOR | | 1 | 1 | | | |
| 12 | R01 | E22 | 425 | CAPILLARY TUBE | | 1 | 1 | φ2.5×φ0.8×1000 | | |
| 13 | T7W | E04 | 208 | H.P SENSOR | | 1 | 1 | | 63HS | |
| 14 | R01 | E09 | 428 | BYPASS VALVE | | 1 | 1 | | | |
| 15 | R01 | 25T | 209 | LOW PRESSURE SWITCH | | 1 | 1 | | 63L | |
| 16 | T7W | E08 | 242 | SOLENOID VALVE COIL <BYPASS VALVE> | | 1 | 1 | | SV1 | |
| 17 | T7W | A01 | 242 | SOLENOID COIL <FOUR-WAY VALVE> | | 1 | | | 21S4 | |
| | T7W | E28 | 242 | | | | 1 | | 21S4 | |
| 18 | R01 | E24 | 403 | FOUR-WAY VALVE | | 1 | | | | |
| | R01 | E26 | 403 | | | | | 1 | | |
| 19 | T7W | E43 | 202 | THERMISTOR | | 1 | 1 | | TH6,7 | |
| 20 | R01 | E04 | 208 | HIGH PRESSURE SWITCH | | 1 | 1 | | 63H | |
| 21 | T7W | E26 | 408 | HEAT EXCHANGER | | 1 | 1 | | | |
| 22 | T7W | E08 | 346 | NOISE FILTER CIRCUIT BOARD | | 1 | | | N.F. | |
| | T7W | E14 | 346 | | | | | 1 | | N.F. |
| 23 | T7W | E39 | 310 | CONVERTER CIRCUIT BOARD | | 1 | 1 | | CONV.B. | |
| 24 | T7W | E26 | 313 | POWER CIRCUIT BOARD | | 1 | 1 | | P.B. | |
| 25 | | — | | ELECTRICAL PARTS BOX | | 1 | 1 | (BK00C410G06) | | |
| 26 | R01 | E08 | 233 | RESISTOR | | 1 | 1 | | RS | |
| 27 | T7W | E03 | 254 | MAIN SMOOTHING CAPACITOR | | 2 | 2 | | CB1, CB2 | |
| 28 | T7W | E06 | 259 | REACTOR | | 1 | 1 | | ACL4 | |
| 29 | R01 | E01 | 311 | TRANSMISSION POWER BOARD | | 1 | 1 | | M-P.B. | |
| 30 | R01 | H52 | 310 | MULTI CONTROLLER CIRCUIT BOARD | | 1 | | | MULTI.B. | |
| | R01 | H76 | 310 | | | | | 1 | | MULTI.B. |
| 31 | T7W | E17 | 716 | TERMINAL BLOCK | 3P (M1, M2, S) | 2 | 2 | | TB3, TB7 | |
| 32 | T7W | E06 | 716 | TERMINAL BLOCK | 5P (L1,L2,L3,N,⊕) | 1 | 1 | | TB1 | |
| 33 | R01 | E02 | 239 | FUSE | 250V 6.3A | 2 | 2 | | F1,2 | |
| 34 | R01 | E66 | 202 | THERMISTOR (OUTDOOR PIPE) | | 1 | 1 | | TH3 | |
| 35 | T7W | E06 | 254 | CAPACITOR | | 1 | 1 | | CK | |
| 36 | R01 | 17T | 201 | THERMISTOR (DISCHARGE) | | 1 | | | TH4 | |
| | R01 | 44L | 201 | | | | | 1 | | TH4 |

14-1. FUNCTIONAL PARTS

| | | |
|---------------------------|---------------------------|---------------------------|
| PUMY-P100YHM ₁ | PUMY-P125YHM ₁ | PUMY-P140YHM ₁ |
| PUMY-P100YHMA | PUMY-P125YHMA | PUMY-P140YHMA |
| PUMY-P100YHMA-BS | PUMY-P125YHMA-BS | PUMY-P140YHMA-BS |



Part numbers that are circled are not shown in the figure.

| No. | ROHS | Part No. | Part Name | Specification | Q'ty/set | | | Remarks (Drawing No.) | Wiring Diagram Symbol | Recom- mended Q'ty |
|-----|------|-------------|-----------------------------------|-----------------------|-------------------|------|---------|----------------------------|-----------------------------|--------------------------|
| | | | | | PUMY-P100/125/140 | | | | | |
| | | | | | YHM ₁ | YHMA | YHMA-BS | | | |
| 1 | G | R01 E44 221 | FAN MOTOR | | 2 | | | | MF1, 2 | |
| | G | T7W E27 763 | FAN MOTOR | | | 2 | 2 | | MF1, 2 | |
| 2 | G | R01 E08 115 | PROPELLER FAN | | 2 | 2 | 2 | | | |
| 3 | G | R01 E09 097 | NUT | | 2 | 2 | 2 | | | |
| 4 | G | T7W E12 259 | REACTOR | | 3 | 3 | 3 | | ACL1,2,3 | |
| 5 | G | R01 E14 413 | CHARGE PLUG | | 2 | 2 | 2 | | | |
| 6 | G | T97 415 747 | COMPRESSOR | ANB33FDEMT | 1 | | | Including RUBBER MOUNTS | MC | |
| | G | T97 415 754 | COMPRESSOR | ANB33FDKMT | | 1 | 1 | | MC | |
| 7 | G | R01 E13 410 | STOP VALVE | 3/8 | 1 | 1 | 1 | | | |
| 8 | G | R01 E11 411 | BALL VALVE | 5/8 | 1 | 1 | 1 | | | |
| 9 | G | R01 E06 450 | STRAINER | | 1 | 1 | 1 | | | |
| 10 | G | R01 E44 440 | ACCUMULATOR | | 1 | 1 | 1 | | | |
| 11 | G | R01 E12 490 | OIL SEPARATOR | | 1 | 1 | 1 | | | |
| 12 | G | R01 E26 425 | CAPILLARY TUBE | | 1 | 1 | 1 | φ2.5×φ0.8×1000 | | |
| 13 | G | R01 E07 208 | H.P SENSOR | | 1 | 1 | 1 | | 63HS | |
| 14 | G | R01 E14 428 | BYPASS VALVE | | 1 | 1 | 1 | | | |
| 15 | G | R01 E00 209 | LOW PRESSURE SWITHCH | | 1 | 1 | 1 | | 63L | |
| 16 | G | T7W E32 242 | SOLENOID VALVE COIL(BYPASS VALVE) | | 1 | | | | SV1 | |
| | G | R01 E57 242 | SOLENOID VALVE COIL(BYPASS VALVE) | | | 1 | | | SV1 | |
| | G | T7W E51 242 | SOLENOID VALVE COIL(BYPASS VALVE) | | | | 1 | | SV1 | |
| 17 | G | T7W E28 242 | SOLENOID COIL(FOUR-WAY VALVE) | | 1 | | | | 21S4 | |
| | G | R01 E58 242 | SOLENOID COIL(FOUR-WAY VALVE) | | | 1 | 1 | | 21S4 | |
| 18 | G | R01 E26 403 | FOUR-WAY VALVE | | 1 | | | | | |
| | G | R01 E32 403 | FOUR-WAY VALVE | | | 1 | 1 | | | |
| 19 | G | R01 E94 202 | THERMISTOR | | 1 | 1 | 1 | | TH6, 7 | |
| 20 | G | R01 E06 208 | HIGH PRESSURE SWITCH | | 1 | 1 | 1 | | 63H | |
| 21 | G | T7W E39 408 | HEAT EXCHANGER | | 1 | 1 | 1 | | | |
| 22 | G | T7W E23 346 | NOISE FILTER CIRCUIT BOARD | | 1 | 1 | 1 | | N.F. | |
| 23 | G | T7W E54 310 | CONVERTER CIRCUIT BOARD | | 1 | | | | CONV.B. | |
| | G | T7W E63 310 | CONVERTER CIRCUIT BOARD | | | 1 | 1 | | CONV.B. | |
| 24 | G | T7W E32 313 | POWER CURCUIT BOARD | | 1 | | | | P.B. | |
| | G | T7W E42 313 | POWER CURCUIT BOAR | | | 1 | 1 | | P.B. | |
| 25 | G | — | ELECTRICAL PARTS BOX | | 1 | 1 | 1 | (BK00C410G08) | | |
| 26 | G | R01 E10 233 | RESISTOR | | 1 | 1 | 1 | | RS | |
| 27 | G | R01 E02 254 | MAIN SMOOTHING CAPACITOR | | 2 | | | | CB1,CB2 | |
| | G | T7W E21 255 | MAIN SMOOTHING CAPACITOR | | | 2 | 2 | | CB1,CB2 | |
| 28 | G | T7W E11 259 | REACTOR | | 1 | | | | ACL4 | |
| | G | R01 E31 259 | REACTOR | | | 1 | 1 | | ACL4 | |
| 29 | G | R01 E02 311 | TRANSMISSION POWER BOARD | | 1 | 1 | 1 | | M-P.B. | |
| 30 | G | R01 H76 310 | MULTI CONTROLLER CIRCUIT BOARD | | 1 | | | | MULTI.B. | |
| | G | R01 N56 310 | CONTROLLER CIRCUIT BOARD | | | 1 | 1 | | C.B. | |
| 31 | G | T7W E31 716 | TERMINAL BLOCK | 3P (M1, M2, S) | 2 | | | | TB3,TB7 | |
| | G | R01 E27 246 | TERMINAL BLOCK | 3P (M1, M2, S) | | 2 | 2 | | TB3,TB7 | |
| 32 | G | T7W E30 716 | TERMINAL BLOCK | 5P (L1, L2, L3, N, 0) | 1 | 1 | 1 | | TB1 | |
| 33 | G | R01 E06 239 | FUSE | 250V 6.3A | 2 | 2 | 2 | | F1, 2 | |
| 34 | G | R01 H00 202 | THERMISTOR (OUTDOOR PIPE) | | 1 | 1 | 1 | | TH3 | |
| 35 | G | T7W E10 254 | CAPACITOR | | 1 | 1 | 1 | | CK | |
| 36 | G | R01 E11 201 | THERMISTOR (DISCHARGE) | | 1 | 1 | 1 | | TH4 | |

14-2. STRUCTURAL PARTS

PUMY-P100YHM₁


PUMY-P125YHM₁

PUMY-P140YHM₁

PUMY-P100YHMA(-BS)

PUMY-P125YHMA(-BS)

PUMY-P140YHMA(-BS)



| No. | RoHS | Part No. | Part Name | Specification | Q'ty/set | | Remarks (Drawing No.) | Wiring Diagram Symbol | Recom- mended Q'ty |
|-----|------|-------------|---------------------|---------------|------------------------|---------|--------------------------|-----------------------------|--------------------------|
| | | | | | PUMY-P100/125/140 | | | | |
| | | | | | YMH ₁ /YHMA | YHMA-BS | | | |
| 1 | G | — | F.ST SCREW | (5x10) | 38 | 38 | (DG12F536H10) | | |
| 2 | G | T7W E03 662 | SIDE PANEL (L) | | 1 | | | | |
| | G | T7W E06 662 | SIDE PANEL (L) | | | 1 | | | |
| 3 | G | T7W E03 691 | FAN GRILLE | | 2 | 2 | | | |
| 4 | G | T7W E06 667 | FRONT PANEL | | 1 | 1 | | | |
| 5 | G | — | SEPARATOR | | 1 | | (BK00C409G12) | | |
| | G | — | SEPARATOR | | | 1 | (BK00C409G14) | | |
| 6 | G | R01 E31 686 | BASE ASSY | | 1 | | | | |
| | G | R01 E26 686 | BASE ASSY | | | 1 | | | |
| 7 | G | R01 E27 130 | MOTOR SUPPORT | | 1 | | | | |
| | G | R01 E19 130 | MOTOR SUPPORT | | | 1 | | | |
| 8 | G | — | VALVE BED ASSY | | 1 | | (BK00C142G27) | | |
| | G | — | VALVE BED ASSY | | | 1 | (BK00C142G29) | | |
| 9 | G | R01 E01 655 | HANDLE | | 2 | 2 | | | |
| 10 | G | R01 E13 658 | COVER PANEL (FRONT) | | 1 | | | | |
| | G | R01 E14 658 | COVER PANEL (FRONT) | | | 1 | | | |
| 11 | G | R01 E11 658 | COVER PANEL (REAR) | | 1 | | | | |
| | G | R01 E24 658 | COVER PANEL (REAR) | | | 1 | | | |
| 12 | G | R01 E32 661 | SIDE PANEL (R) | | 1 | | | | |
| | G | T7W E19 661 | SIDE PANEL (R) | | | 1 | | | |
| 13 | G | T7W E09 668 | SERVICE PANEL | | 1 | | | | |
| | G | T7W E13 668 | SERVICE PANEL | | | 1 | | | |
| 14 | G | — | LABEL (MITSUBISHI) | | 1 | 1 | (DG79R130H01) | | |
| 15 | G | R01 E07 698 | REAR GUARD | | 1 | 1 | | | |
| 16 | G | R01 E15 641 | TOP PANEL | | 1 | | | | |
| | G | R01 E28 641 | TOP PANEL | | | 1 | | | |
| 17 | G | R01 E02 655 | HANDLE | | 1 | 1 | | | |

DRAIN SOCKET

| | |
|----------|--------------|
| Part No. | PAC-SG61DS-E |
|----------|--------------|

AIR OUTLET GUIDE

| | |
|----------|--------------|
| Part No. | PAC-SG59SG-E |
|----------|--------------|

* Need 2 pieces.

AIR GUIDE

| | |
|----------|--------------|
| Part No. | PAC-SH63AG-E |
|----------|--------------|

* Need 2 pieces.

DRAIN PAN

| | |
|----------|--------------|
| Part No. | PAC-SG64DP-E |
|----------|--------------|

FILTER DRYER (For liquid line : $\phi 9.52$)

| | |
|----------|--------------|
| Part No. | PAC-SG82DR-E |
|----------|--------------|

* Only for R410A model (Don't use for R22 model.)

BRANCH PIPE (Joint)

| Part No. | NUMBER OF BRANCHING POINTS |
|-------------|----------------------------|
| CMY-Y62-G-E | 2 |
| CMY-Y64-G-E | 4 |
| CMY-Y68-G-E | 8 |

CITY MULTI™



HEAD OFFICE : TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO100-8310, JAPAN

©Copyright 2005 MITSUBISHI ELECTRIC ENGINEERING CO., LTD.
Distributed in Jun. 2008 No.OC355 REVISED EDITION-D PDF 7
Distributed in Dec. 2007 No.OC355 REVISED EDITION-C PDF 8
Distributed in Aug. 2006 No.OC355 REVISED EDITION-B PDF 8
Distributed in Feb. 2006 No.OC355 REVISED EDITION-A PDF 9
Distributed in Sep. 2005 No.OC355 PDF 9
Made in Japan

New publication, effective Jun. 2008
Specifications subject to change without notice